

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II

County ALEXANDER Instrument Location Alexander Co. 50
Instrument Serial No. 008813 91 COMMERCIAL PARK AVE
TAYLORSVILLE, NC 28681

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 4th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Handwritten Signature]
Signature of Certifying Official

659
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

ALEXANDER COUNTY ALEXANDER COUNTY SO
010

Serial Number: 008813
Test Date: 04/04/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: Ingle Larry W
Permit Number: 0035-2495
Effective:
01/09/2020-01/09/2022

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG902201
Exp Date: 01/22/2021

Test	g/210L	Time
DIAC	Pass	9:33am
AIR BLK	.00	9:33am
ACCY CHR	.00	9:34am
AIR BLK	.00	9:35am
SUB TEST	.00	9:36am
AIR BLK	.00	9:37am
SUB TEST	.00	9:38am
AIR BLK	.00	9:39am

Reported AC: 00 / 210L


Signature of Chemical Analyst

Court CVR


Analyst

This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007

Intox EC/IR-II: Preventive Maintenance

ALEXANDER COUNTY ALEXANDER COUNTY SO 010

Serial Number: 008813 Test Record Number: 1933
Test Date: 04/04/2020 Test Time: 9:42am EDT

System Check: Passed

Baseline Tests

Test	Status	Time
IR	Pass	9:42am
FLO	Pass	9:42am
EC	Pass	9:42am

Temperature Tests

Test	Status	Time
FCL	Pass	9:42am
SRC	Pass	9:42am
DET	Pass	9:42am
BAR	Pass	9:42am
BT	Pass	9:42am

Blank Tests

Test	Status	Time
AIR	Pass	9:43am


Printer Tests

Test	Status	Time
PRNT	Pass	9:43am

CRC Tests

Test	Status	Time
COMP	Pass	9:43am
CAL	Pass	9:43am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Ashe Instrument Location Ashe Co. Jail

Instrument Serial No. 008849 Jefferson, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

649
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

ASHE COUNTY ASHE COUNTY JAIL 040

Serial Number: 008849
Test Date: 04/13/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BURNETTE, ANTHONY J
Permit Number: 11304E
Effective:
06/01/2019-00/00/0000

Officer's Name: NONE,
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG933703
Exp Date: 12/03/2021

Test	g/210L	Time
DIAG	Pass	4:27pm
AIR BLK	.00	4:28pm
ACCY CHK	.07	4:28pm
AIR BLK	.00	4:30pm
SUB TEST	.00	4:30pm
AIR BLK	.00	4:31pm
SUB TEST	.00	4:33pm
AIR BLK	.00	4:34pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court GVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

ASHE COUNTY ASHE COUNTY JAIL 040

Serial Number: 008849 Test Record Number: 1338
Test Date: 04/13/2020 Test Time: 4:34pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	4:35pm
FLO	Pass	4:35pm
FC	Pass	4:35pm

Temperature Tests

Test	Status	Time
FC1	Pass	4:35pm
SRC	Pass	4:35pm
DET	Pass	4:35pm
BAR	Pass	4:35pm
BT	Pass	4:35pm

Blank Tests

Test	Status	Time
AIR	Pass	4:35pm


Printer Tests

Test	Status	Time
PRNT	Pass	4:36pm

CRC Tests

Test	Status	Time
COMP	Pass	4:36pm
CAL	Pass	4:36pm

Preventive Maintenance
Status: Pass



Analys t

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Avery Instrument Location Avery Co. Jail
Instrument Serial No. 208664 Newland, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 9 day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

649
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

AVERY COUNTY AVERY COUNTY JAIL 050

Serial Number: 008664
Test Date: 04/09/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BURNETTE, ANTHONY J

Permit Number: 11304E

Effective:

06/01/2019-06/01/2021

Officer's Name: NONE,

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG821801

Exp Date: 08/06/2020

Test	g/210L	Time
DIAG	Pass	11:11am
AIR BLK	.00	11:12am
ACCY CHK	.08	11:12am
AIR BLK	.00	11:13am
SUB TEST	.00	11:14am
AIR BLK	.00	11:15am
SUB TEST	.00	11:16am
AIR BLK	.00	11:17am

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

AVERY COUNTY AVERY COUNTY JAIL 050

Serial Number: 008664 Test Record Number: 1016
Test Date: 04/09/2020 Test Time: 11:20am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:20am
FLO	Pass	11:20am
FC	Pass	11:20am

Temperature Tests

Test	Status	Time
FC1	Pass	11:20am
SRC	Pass	11:20am
DET	Pass	11:20am
BAR	Pass	11:20am
BT	Pass	11:20am

Blank Tests

Test	Status	Time
AIR	Pass	11:21am

Printer Tests

Test	Status	Time
PRNT	Pass	11:21am

CRC Tests

Test	Status	Time
COMP	Pass	11:21am
CAL	Pass	11:21am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Avery Instrument Location Banner Elk PD
Instrument Serial No. 004724 Banner Elk, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

649
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

AVERY COUNTY BANNER ELK PD 050

Serial Number: 008724

Test Date: 04/13/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BURNETTE, ANTHONY J

Permit Number: 11034E

Effective:

06/01/2019-06/01/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG902201

Exp Date: 01/22/2021

Test	g/210L	Time
DIAG	Pass	11:50am
AIR BLK	.00	11:51am
ACCY CHK	.08	11:52am
AIR BLK	.00	11:52am
SUB TEST	.00	11:53am
AIR BLK	.00	11:54am
SUB TEST	.00	11:55am
AIR BLK	.00	11:56am

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

AVERY COUNTY BANNER ELK PD 050

Serial Number: 008724 Test Record Number: 616
Test Date: 04/13/2020 Test Time: 11:59am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:59am
FLO	Pass	11:59am
FC	Pass	11:59am

Temperature Tests

Test	Status	Time
FC1	Pass	12:00pm
SRC	Pass	12:00pm
DET	Pass	12:00pm
BAR	Pass	12:00pm
BT	Pass	12:00pm

Blank Tests

Test	Status	Time
AIR	Pass	12:00pm

Printer Tests

Test	Status	Time
PRNT	Pass	12:00pm

CRC Tests

Test	Status	Time
COMP	Pass	12:00pm
CAL	Pass	12:00pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Beaufort Instrument Location Beaufort Co Court house
Instrument Serial No. 008586 112 W. 2nd St, Washington, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 17th day of April, 2010, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Handwritten Signature]

Signature of Certifying Official

1043

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

BEAUFORT COUNTY COURTHOUSE 060

Serial Number: 008586
Test Date: 04/17/2020

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: GUARD, KELLY G

Permit Number: 12955E

Effective:

06/01/2019-06/01/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG821801

Exp Date: 08/06/2020


Test	g/210L	Time
DIAG	Pass	12:33pm
AIR BLK	.00	12:34pm
ACCY CHK	.08	12:34pm
AIR BLK	.00	12:36pm
SUB TEST	.00	12:36pm
AIR BLK	.00	12:37pm
SUB TEST	.00	12:39pm
AIR BLK	.00	12:40pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

BEAUFORT COUNTY COURTHOUSE 060

Serial Number: 008586 Test Record Number: 1585
Test Date: 04/17/2020 Test Time: 12:41pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:41pm
FLO	Pass	12:41pm
FC	Pass	12:41pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:41pm
SRC	Pass	12:41pm
DET	Pass	12:41pm
BAR	Pass	12:41pm
BT	Pass	12:41pm

Blank Tests

Test	Status	Time
AIR	Pass	12:42pm

Printer Tests

Test	Status	Time
PRNT	Pass	12:42pm

CRC Tests

Test	Status	Time
COMP	Pass	12:42pm
CAL	Pass	12:42pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Beaufort Instrument Location Beaufort Co. Courthouse

Instrument Serial No. 008909 112 W. 2nd St. Washington, NC.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 17th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Ken P
Signature of Certifying Official

643
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

BEAUFORT COUNTY COURTHOUSE 060

Serial Number: 008909
Test Date: 04/17/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: GUARD, KELLY G

Permit Number: 12955E

Effective:

06/01/2019-06/01/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG821801

Exp Date: 08/06/2020

Test	g/210L	Time
DIAG	Pass	12:08pm
AIR BLK	.00	12:09pm
ACCY CHK	.08	12:09pm
AIR BLK	.00	12:11pm
SUB TEST	.00	12:11pm
AIR BLK	.00	12:12pm
SUB TEST	.00	12:14pm
AIR BLK	.00	12:14pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

BEAUFORT COUNTY COURTHOUSE 060

Serial Number: 008909 Test Record Number: 3474
Test Date: 04/17/2020 Test Time: 12:16pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:16pm
FLO	Pass	12:16pm
FC	Pass	12:16pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:16pm
SRC	Pass	12:16pm
DET	Pass	12:16pm
BAR	Pass	12:16pm
BT	Pass	12:16pm

Blank Tests

Test	Status	Time
AIR	Pass	12:17pm

Printer Tests

Test	Status	Time
PRNT	Pass	12:17pm

CRC Tests

Test	Status	Time
COMP	Pass	12:17pm
CAL	Pass	12:17pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County BERTIE Instrument Location BERTIE CO. S.O.

Instrument Serial No. 008897 222 COUNTY FARM RD, WINDSOR N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 17th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Linda A. Kurl
Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

BERTIE COUNTY BERTIE CO SO 070

Serial Number: 008897
Test Date: 04/17/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: Keesler, Linda A
Permit Number: 0045-5468
Effective:
07/08/2019-07/08/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG911506
Exp Date: 04/25/2021


Test	g/210L	Time
DIAG	Pass	2:12pm
AIR BLK	.00	2:12pm
ACCY CHK	.08	2:13pm
AIR BLK	.00	2:14pm
SUB TEST	.00	2:15pm
AIR BLK	.00	2:16pm
SUB TEST	.00	2:17pm
AIR BLK	.00	2:18pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

BERTIE COUNTY BERTIE CO SO 070

Serial Number: 008897 Test Record Number: 1329
Test Date: 04/17/2020 Test Time: 2:19pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:19pm
FLO	Pass	2:19pm
FC	Pass	2:19pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:19pm
SRC	Pass	2:19pm
DET	Pass	2:19pm
BAR	Pass	2:19pm
BT	Pass	2:19pm

Blank Tests

Test	Status	Time
AIR	Pass	2:20pm


Printer Tests

Test	Status	Time
PRNT	Pass	2:20pm

CRC Tests

Test	Status	Time
COMP	Pass	2:20pm
CAL	Pass	2:20pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County BRUNSWICK Instrument Location BRUNSWICK Co
Instrument Serial No. 008585 DETENTION CENTER

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 17 day of APRIL, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. B...
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

BRUNSWICK COUNTY DETENTION CENTER 090

Serial Number: 008585

Test Date: 04/17/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R

Permit Number: 15671E

Effective:

06/01/2019-06/01/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG919902

Exp Date: 07/18/2021

Test	g/210L	Time
DIAG	Pass	3:13pm
AIR BLK	.00	3:15pm
ACCY CHK	.07	3:15pm
AIR BLK	.00	3:16pm
SUB TEST	.00	3:17pm
AIR BLK	.00	3:18pm
SUB TEST	.00	3:20pm
AIR BLK	.00	3:21pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

BRUNSWICK COUNTY DETENTION CENTER 090

Serial Number: 008585 Test Record Number: 4398
Test Date: 04/17/2020 Test Time: 3:22pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:23pm
FLO	Pass	3:23pm
FC	Pass	3:23pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:23pm
SRC	Pass	3:23pm
DET	Pass	3:23pm
BAR	Pass	3:23pm
BT	Pass	3:23pm

Blank Tests

Test	Status	Time
AIR	Pass	3:24pm

Printer Tests

Test	Status	Time
PRNT	Pass	3:24pm

CRC Tests

Test	Status	Time
COMP	Pass	3:24pm
CAL	Pass	3:24pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County BRUNSWICK Instrument Location BRUNSWICK Co
Instrument Serial No. 008607 DETENTION CENTER

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 17 day of APRIL, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan Ray Bowers
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

BRUNSWICK COUNTY DETENTION CENTER 090

Serial Number: 008602
Test Date: 04/17/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R
Permit Number: 15671E
Effective:
06/01/2019-06/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG919902
Exp Date: 07/18/2021

Test	g/210L	Time
DIAG	Pass	3:29pm
AIR BLK	.00	3:29pm
ACCY CHK	.07	3:30pm
AIR BLK	.00	3:31pm
SUB TEST	.00	3:31pm
AIR BLK	.00	3:32pm
SUB TEST	.00	3:34pm
AIR BLK	.00	3:35pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

BRUNSWICK COUNTY DETENTION CENTER 090

Serial Number: 008602 Test Record Number: 4563
Test Date: 04/17/2020 Test Time: 3:35pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:36pm
FLO	Pass	3:36pm
FC	Pass	3:36pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:36pm
SRC	Pass	3:36pm
DET	Pass	3:36pm
BAR	Pass	3:36pm
BT	Pass	3:36pm

Blank Tests

Test	Status	Time
AIR	Pass	3:37pm


Printer Tests

Test	Status	Time
PRNT	Pass	3:37pm

CRC Tests

Test	Status	Time
COMP	Pass	3:37pm
CAL	Pass	3:37pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County BRUNSWICK Instrument Location OAK ISLAND
Instrument Serial No. 008648 POLICE DEPT.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 17 day of APRIL, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. Barnes
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

BRUNSWICK COUNTY OAK ISLAND PD 090

Serial Number: 008648
Test Date: 04/17/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R

Permit Number: 15671E

Effective:

06/01/2019-06/01/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG911506


Exp Date: 04/25/2021

Test	g/210L	Time
DIAG	Pass	1:19pm
AIR BLK	.00	1:20pm
ACCY CHK	.07	1:20pm
AIR BLK	.00	1:21pm
SUB TEST	.00	1:22pm
AIR BLK	.00	1:23pm
SUB TEST	.00	1:24pm
AIR BLK	.00	1:25pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

BRUNSWICK COUNTY OAK ISLAND PD 090

Serial Number: 008648 Test Record Number: 1663
Test Date: 04/17/2020 Test Time: 1:26pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:26pm
FLO	Pass	1:26pm
FC	Pass	1:26pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:26pm
SRC	Pass	1:26pm
DET	Pass	1:26pm
BAR	Pass	1:26pm
BT	Pass	1:26pm

Blank Tests

Test	Status	Time
AIR	Pass	1:27pm

Printer Tests

Test	Status	Time
PRNT	Pass	1:27pm

CRC Tests

Test	Status	Time
COMP	Pass	1:27pm
CAL	Pass	1:27pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County BRUNSWICK Instrument Location SUNSET BEACH
Instrument Serial No. 008874 POLICE DEPT

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14 day of APRIL, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. B...
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

BRUNSWICK COUNTY SUNSET BEACH PD 090

Serial Number: 008874
Test Date: 04/14/2020

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R

Permit Number: 15671E

Effective:

06/01/2019-06/01/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG920301


Exp Date: 07/22/2021

Test	g/210L	Time
DIAG	Pass	1:35pm
AIR BLK	.00	1:36pm
ACCY CHK	.08	1:37pm
AIR BLK	.00	1:38pm
SUB TEST	.00	1:39pm
AIR BLK	.00	1:39pm
SUB TEST	.00	1:41pm
AIR BLK	.00	1:42pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

BRUNSWICK COUNTY SUNSET BEACH PD 090

Serial Number: 008874 Test Record Number: 707
Test Date: 04/14/2020 Test Time: 1:44pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:44pm
FLO	Pass	1:44pm
FC	Pass	1:44pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:44pm
SRC	Pass	1:44pm
DET	Pass	1:44pm
BAR	Pass	1:44pm
BT	Pass	1:44pm

Blank Tests

Test	Status	Time
AIR	Pass	1:45pm


Printer Tests

Test	Status	Time
PRNT	Pass	1:45pm

CRC Tests

Test	Status	Time
COMP	Pass	1:45pm
CAL	Pass	1:45pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Ramcombe Instrument Location Buncombe Co. Jail

Instrument Serial No. 008697 Asheville, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Paul R. Cuth
Signature of Certifying Official

635
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

BUNCOMBE COUNTY BUNCOMBE COUNTY JAIL
100

Serial Number: 008697
Test Date: 04/13/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: Cutler, Daniel R
Permit Number: 0084-3310
Effective:
07/12/2019-07/12/2021

Officer's Name: NONE,
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG933901
Exp Date: 12/05/2021

Test	g/210L	Time
DIAG	Pass	12:56pm
AIR BLK	.00	12:57pm
ACCY CHK	.08	12:57pm
AIR BLK	.00	12:58pm
SUB TEST	.00	12:59pm
AIR BLK	.00	1:00pm
SUB TEST	.00	1:01pm
AIR BLK	.00	1:02pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

BUNCOMBE COUNTY BUNCOMBE COUNTY JAIL 100

Serial Number: 008697 Test Record Number: 3784
Test Date: 04/13/2020 Test Time: 1:04pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:04pm
FLO	Pass	1:04pm
FC	Pass	1:04pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:04pm
SRC	Pass	1:04pm
DET	Pass	1:04pm
BAR	Pass	1:04pm
BT	Pass	1:04pm

Blank Tests

Test	Status	Time
AIR	Pass	1:05pm

Printer Tests

Test	Status	Time
PRNT	Pass	1:05pm

CRC Tests

Test	Status	Time
COMP	Pass	1:05pm
CAL	Pass	1:05pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Buncombe Instrument Location Buncombe Co. Jail

Instrument Serial No. C08748 Asheville, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



David R. Cuthbert
Signature of Certifying Official

635
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

BUNCOMBE COUNTY BUNCOMBE COUNTY JAIL
100

Serial Number: 008748
Test Date: 04/13/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: Cutler, Daniel R
Permit Number: 0084-3310
Effective:
07/12/2019-07/12/2021

Officer's Name: NONE,
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG933703
Exp Date: 12/03/2021

Test	g/210L	Time
DIAG	Pass	12:57pm
AIR BLK	.00	12:58pm
ACCY CHK	.07	12:58pm
AIR BLK	.00	12:59pm
SUB TEST	.00	1:00pm
AIR BLK	.00	1:01pm
SUB TEST	.00	1:02pm
AIR BLK	.00	1:03pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

BUNCOMBE COUNTY BUNCOMBE COUNTY JAIL 100

Serial Number: 008748 Test Record Number: 1188
Test Date: 04/13/2020 Test Time: 1:04pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:05pm
FLO	Pass	1:05pm
FC	Pass	1:05pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:05pm
SRC	Pass	1:05pm
DET	Pass	1:05pm
BAR	Pass	1:05pm
BT	Pass	1:05pm

Blank Tests

Test	Status	Time
AIR	Pass	1:06pm

Printer Tests

Test	Status	Time
PRNT	Pass	1:06pm

CRC Tests

Test	Status	Time
COMP	Pass	1:06pm
CAL	Pass	1:06pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Buncombe Instrument Location Buncombe Co Jail

Instrument Serial No. 008798 Asheville, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of April, 20 20, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Paul R. Cook

Signature of Certifying Official

635

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

BUNCOMBE COUNTY BUNCOMBE COUNTY JAIL
100

Serial Number: 008798
Test Date: 04/13/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: Cutler, Daniel R
Permit Number: 0084-3310
Effective:
07/12/2019-07/12/2021

Officer's Name: NONE,
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG933703
Exp Date: 12/03/2021

Test	g/210L	Time
DIAG	Pass	12:57pm
AIR BLK	.00	12:58pm
ACCY CHK	.08	12:59pm
AIR BLK	.00	1:00pm
SUB TEST	.00	1:01pm
AIR BLK	.00	1:01pm
SUB TEST	.00	1:03pm
AIR BLK	.00	1:04pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

BUNCOMBE COUNTY BUNCOMBE COUNTY JAIL 100

Serial Number: 008798 Test Record Number: 5373
Test Date: 04/13/2020 Test Time: 1:05pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:05pm
FLO	Pass	1:05pm
FC	Pass	1:05pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:05pm
SRC	Pass	1:05pm
DET	Pass	1:05pm
BAR	Pass	1:05pm
BT	Pass	1:05pm

Blank Tests

Test	Status	Time
AIR	Pass	1:06pm

Printer Tests

Test	Status	Time
PRNT	Pass	1:06pm

CRC Tests

Test	Status	Time
COMP	Pass	1:06pm
CAL	Pass	1:06pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County CABARRUS Instrument Location KANNAPOLIS P.D.

Instrument Serial No. 008589

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15th day of APRIL, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Handwritten Signature]

Signature of Certifying Official

659

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CABARRUS COUNTY KANNAPOLIS PD 120

Serial Number: 008589
Test Date: 04/15/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: Ingle, Larry W

Permit Number: 0035-2495

Effective:

01/09/2020-01/09/2022

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG007601

Exp Date: 03/16/2022

Test	g/210L	Time
DIAG	Pass	1:45pm
AIR BLK	.00	1:46pm
ACCY CHK	.08	1:47pm
AIR BLK	.00	1:48pm
SUB TEST	.00	1:48pm
AIR BLK	.00	1:50pm
SUB TEST	.00	1:51pm
AIR BLK	.00	1:52pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR

Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

CABARRUS COUNTY KANNAPOLIS PD 120

Serial Number: 008589 Test Record Number: 3097
Test Date: 04/15/2020 Test Time: 1:55pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:55pm
FLO	Pass	1:55pm
FC	Pass	1:55pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:55pm
SRC	Pass	1:55pm
DET	Pass	1:55pm
BAR	Pass	1:55pm
BT	Pass	1:55pm

Blank Tests

Test	Status	Time
AIR	Pass	1:56pm

Printer Tests

Test	Status	Time
PRNT	Pass	1:56pm

CRC Tests

Test	Status	Time
COMP	Pass	1:56pm
CAL	Pass	1:56pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County CABARRUS Instrument Location CABARRUS COUNTY 50

Instrument Serial No. 008625

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15th day of APRIL, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

656
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CABARRUS COUNTY CABARRUS COUNTY SO 120

Serial Number: 008625
Test Date: 04/15/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: Hays, Mark D
Permit Number: 0011-3099
Effective:
11/13/2019-11/13/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG902106
Exp Date: 01/21/2021


Test	g/210L	Time
DIAG	Pass	2:28pm
AIR BLK	.00	2:29pm
ACCY CHK	.08	2:30pm
AIR BLK	.00	2:31pm
SUB TEST	.00	2:32pm
AIR BLK	.00	2:33pm
SUB TEST	.00	2:34pm
AIR BLK	.00	2:35pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

CABARRUS COUNTY CABARRUS COUNTY SO 120

Serial Number: 008625 Test Record Number: 5494
Test Date: 04/15/2020 Test Time: 2:36pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:37pm
FLO	Pass	2:37pm
FC	Pass	2:37pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:37pm
SRC	Pass	2:37pm
DET	Pass	2:37pm
BAR	Pass	2:37pm
BT	Pass	2:37pm

Blank Tests

Test	Status	Time
AIR	Pass	2:38pm

Printer Tests

Test	Status	Time
PRNT	Pass	2:38pm

CRC Tests

Test	Status	Time
COMP	Pass	2:38pm
CAL	Pass	2:38pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Caldwell Instrument Location Caldwell Co. Jail

Instrument Serial No. 008719 Lenoir, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Chris Doy
Signature of Certifying Official

658
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CALDWELL COUNTY CALDWELL COUNTY JAIL
130

Serial Number: 008719
Test Date: 04/13/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: TOWERY, CHAD V
Permit Number: 26632E
Effective:
05/01/2019-05/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG007601
Exp Date: 03/16/2022

Test	g/210L	Time
DIAG	Pass	2:18pm
AIR BLK	.00	2:18pm
ACCY CHK	.07	2:19pm
AIR BLK	.00	2:21pm
SUB TEST	.00	2:21pm
AIR BLK	.00	2:22pm
SUB TEST	.00	2:24pm
AIR BLK	.00	2:25pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

CALDWELL COUNTY CALDWELL COUNTY JAIL 130

Serial Number: 008719 Test Record Number: 2635
Test Date: 04/13/2020 Test Time: 2:25pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:26pm
FLO	Pass	2:26pm
FC	Pass	2:26pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:26pm
SRC	Pass	2:26pm
DET	Pass	2:26pm
BAR	Pass	2:26pm
BT	Pass	2:26pm

Blank Tests

Test	Status	Time
AIR	Pass	2:27pm

Printer Tests

Test	Status	Time
PRNT	Pass	2:27pm

CRC Tests

Test	Status	Time
COMP	Pass	2:27pm
CAL	Pass	2:27pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Caldwell Instrument Location Caldwell Co. Jail

Instrument Serial No. 008719 Lenoir, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Chris Doyle
Signature of Certifying Official

658
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CALDWELL COUNTY CALDWELL COUNTY JAIL
130

Serial Number: 008719
Test Date: 04/13/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: TOWERY, CHAD V
Permit Number: 26632E
Effective:
05/01/2019-05/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG007601
Exp Date: 03/16/2022


Test	g/210L	Time
DIAG	Pass	2:18pm
AIR BLK	.00	2:18pm
ACCY CHK	.07	2:19pm
AIR BLK	.00	2:21pm
SUB TEST	.00	2:21pm
AIR BLK	.00	2:22pm
SUB TEST	.00	2:24pm
AIR BLK	.00	2:25pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

CALDWELL COUNTY CALDWELL COUNTY JAIL 130

Serial Number: 008719 Test Record Number: 2635
Test Date: 04/13/2020 Test Time: 2:25pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:26pm
FLO	Pass	2:26pm
FC	Pass	2:26pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:26pm
SRC	Pass	2:26pm
DET	Pass	2:26pm
BAR	Pass	2:26pm
BT	Pass	2:26pm

Blank Tests

Test	Status	Time
AIR	Pass	2:27pm

Printer Tests

Test	Status	Time
PRNT	Pass	2:27pm

CRC Tests

Test	Status	Time
COMP	Pass	2:27pm
CAL	Pass	2:27pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Caldwell Instrument Location Caldwell Co Jail

Instrument Serial No. 008903 Levine NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Ch. J. Joy
Signature of Certifying Official

658
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CALDWELL COUNTY CALDWELL COUNTY JAIL
130

Serial Number: 008803
Test Date: 04/13/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: TOWERY, CHAD V
Permit Number: 26632E
Effective:
05/01/2019-05/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG902201
Exp Date: 01/22/2021


Test	g/210L	Time
DIAG	Pass	11:40am
AIR BLK	.00	11:41am
ACCY CHK	.07	11:42am
AIR BLK	.00	11:43am
SUB TEST	.00	11:44am
AIR BLK	.00	11:45am
SUB TEST	.00	11:47am
AIR BLK	.00	11:48am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR.



Analyst

Intox EC/IR-II: Preventive Maintenance

CALDWELL COUNTY CALDWELL COUNTY JAIL 130

Serial Number: 008803 Test Record Number: 662
Test Date: 04/13/2020 Test Time: 11:49am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:49am
FLO	Pass	11:49am
FC	Pass	11:49am

Temperature Tests

Test	Status	Time
FC1	Pass	11:50am
SRC	Pass	11:50am
DET	Pass	11:50am
BAR	Pass	11:50am
BT	Pass	11:50am

Blank Tests

Test	Status	Time
AIR	Pass	11:50am


Printer Tests

Test	Status	Time
PRNT	Pass	11:50am

CRC Tests

Test	Status	Time
COMP	Pass	11:50am
CAL	Pass	11:50am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Caldwell Instrument Location Caldwell Co Jail

Instrument Serial No. 008903 Levine NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Ch. J. Joy

Signature of Certifying Official

658

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CALDWELL COUNTY CALDWELL COUNTY JAIL
130

Serial Number: 008803
Test Date: 04/13/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: TOWERY, CHAD V
Permit Number: 26632E
Effective:
05/01/2019-05/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG902201
Exp Date: 01/22/2021


Test	g/210L	Time
DIAG	Pass	11:40am
AIR BLK	.00	11:41am
ACCY CHK	.07	11:42am
AIR BLK	.00	11:43am
SUB TEST	.00	11:44am
AIR BLK	.00	11:45am
SUB TEST	.00	11:47am
AIR BLK	.00	11:48am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR.



Analyst

Intox EC/IR-II: Preventive Maintenance

CALDWELL COUNTY CALDWELL COUNTY JAIL 130

Serial Number: 008803 Test Record Number: 662
Test Date: 04/13/2020 Test Time: 11:49am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:49am
FLO	Pass	11:49am
FC	Pass	11:49am

Temperature Tests

Test	Status	Time
FC1	Pass	11:50am
SRC	Pass	11:50am
DET	Pass	11:50am
BAR	Pass	11:50am
BT	Pass	11:50am

Blank Tests

Test	Status	Time
AIR	Pass	11:50am


Printer Tests

Test	Status	Time
PRNT	Pass	11:50am

CRC Tests

Test	Status	Time
COMP	Pass	11:50am
CAL	Pass	11:50am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Camden Instrument Location Camden Co. S.O.

Instrument Serial No. 008940 117 N. Carolina Hwy 343, Camden, NC.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 9th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Key
Signature of Certifying Official

643
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CAMDEN COUNTY CAMDEN CO SO 140

Serial Number: 008940
Test Date: 04/09/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: GUARD, KELLY G
Permit Number: 12955E
Effective:
06/01/2019-06/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG911501
Exp Date: 04/25/2021

Test	g/210L	Time
DIAG	Pass	12:14pm
AIR BLK	.00	12:15pm
ACCY CHK	.08	12:16pm
AIR BLK	.00	12:17pm
SUB TEST	.00	12:17pm
AIR BLK	.00	12:18pm
SUB TEST	.00	12:20pm
AIR BLK	.00	12:21pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

CAMDEN COUNTY CAMDEN CO SO 140

Serial Number: 008940 Test Record Number: 1013
Test Date: 04/09/2020 Test Time: 12:22pm EDT

System Check: Passed

Baseline Tests

Test	Status	Time
IR	Pass	12:23pm
FLO	Pass	12:23pm
FC	Pass	12:23pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:23pm
SRC	Pass	12:23pm
DET	Pass	12:23pm
BAR	Pass	12:23pm
BT	Pass	12:23pm

Blank Tests

Test	Status	Time
AIR	Pass	12:23pm

Printer Tests

Test	Status	Time
PRNT	Pass	12:23pm

CRC Tests

Test	Status	Time
COMP	Pass	12:24pm
CAL	Pass	12:24pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Caswell Instrument Location Caswell Co. Detention Ctr.

Instrument Serial No. 608593 211 County Park Rd Yanceyville, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

662
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CASWELL COUNTY DETENTION CENTER 160

Serial Number: 008593
Test Date: 04/16/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: BARNES, STOKES
Permit Number: 11434E
Effective:
04/01/2019-04/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG919902
Exp Date: 07/18/2021

Test	g/210L	Time
DIAG	Pass	5:15pm
AIR BLK	.00	5:16pm
ACCY CHK	.08	5:17pm
AIR BLK	.00	5:18pm
SUB TEST	.00	5:18pm
AIR BLK	.00	5:19pm
SUB TEST	.00	5:20pm
AIR BLK	.00	5:21pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

CASWELL COUNTY DETENTION CENTER 160

Serial Number: 008593 Test Record Number: 1801
Test Date: 04/16/2020 Test Time: 5:22pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	5:22pm
FLO	Pass	5:22pm
FC	Pass	5:22pm

Temperature Tests

Test	Status	Time
FC1	Pass	5:22pm
SRC	Pass	5:22pm
DET	Pass	5:22pm
BAR	Pass	5:22pm
BT	Pass	5:22pm

Blank Tests

Test	Status	Time
AIR	Pass	5:23pm


Printer Tests

Test	Status	Time
PRNT	Pass	5:23pm

CRC Tests

Test	Status	Time
COMP	Pass	5:23pm
CAL	Pass	5:23pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Catawba Instrument Location Catawba County SO
Instrument Serial No. 008687 100 B Southwest Blvd, Newton

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 17th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Joseph E. Hecht
Signature of Certifying Official

650
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CATAWBA COUNTY CATAWBA COUNTY SO 170

Serial Number: 008687
Test Date: 04/17/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: Hutchinson, Joseph E

Permit Number: 0035-6075

Effective:

07/09/2019-07/09/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG933901

Exp Date: 12/05/2021

Test	g/210L	Time
DIAG	Pass	1:02pm
AIR BLK	.00	1:03pm
ACCY CHK	.07	1:04pm
AIR BLK	.00	1:05pm
SUB TEST	.00	1:06pm
AIR BLK	.00	1:06pm
SUB TEST	.00	1:08pm
AIR BLK	.00	1:09pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

CATAWBA COUNTY CATAWBA COUNTY SO 170

Serial Number: 008687 Test Record Number: 3071
Test Date: 04/17/2020 Test Time: 1:10pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:10pm
FLO	Pass	1:10pm
FC	Pass	1:10pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:10pm
SRC	Pass	1:10pm
DET	Pass	1:10pm
BAR	Pass	1:10pm
BT	Pass	1:10pm

Blank Tests

Test	Status	Time
AIR	Pass	1:11pm


Printer Tests

Test	Status	Time
PRNT	Pass	1:11pm

CRC Tests

Test	Status	Time
COMP	Pass	1:11pm
CAL	Pass	1:11pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Catawba Instrument Location Hickory PD
Instrument Serial No. 008841

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 8 day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

656
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CATAWBA COUNTY HICKORY PD 170

Serial Number: 008841
Test Date: 04/08/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: Hays, Mark D
Permit Number: 0011-3099
Effective:
11/13/2019-11/13/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG821801
Exp Date: 08/06/2020

Test	g/210L	Time
DIAG	Pass	9:29am
AIR BLK	.00	9:30am
ACCY CHK	.08	9:31am
AIR BLK	.00	9:32am
SUB TEST	.00	9:33am
AIR BLK	.00	9:34am
SUB TEST	.00	9:36am
AIR BLK	.00	9:37am

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR

Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

CATAWBA COUNTY HICKORY PD 170

Serial Number: 008841 Test Record Number: 2034
Test Date: 04/08/2020 Test Time: 9:38am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	9:38am
FLO	Pass	9:38am
FC	Pass	9:39am

Temperature Tests

Test	Status	Time
FC1	Pass	9:39am
SRC	Pass	9:39am
DET	Pass	9:39am
BAR	Pass	9:39am
BT	Pass	9:39am

Blank Tests

Test	Status	Time
AIR	Pass	9:39am


Printer Tests

Test	Status	Time
PRNT	Pass	9:39am

CRC Tests

Test	Status	Time
COMP	Pass	9:39am
CAL	Pass	9:39am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Chatham Co Instrument Location Chatham Co Detention Center

Instrument Serial No. 008591 Pittsboro, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

654
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CHATHAM COUNTY DETENTION CENTER 180

Serial Number: 008591
Test Date: 04/15/2020

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: Keesler, Grayham C

Permit Number: 0045-5487

Effective:

11/04/2019-11/04/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG934001

Exp Date: 12/06/2021


Test	g/210L	Time
DIAG	Pass	4:00pm
AIR BLK	.00	4:01pm
ACCY CHK	.08	4:02pm
AIR BLK	.00	4:03pm
SUB TEST	.00	4:03pm
AIR BLK	.00	4:04pm
SUB TEST	.00	4:06pm
AIR BLK	.00	4:07pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

CHATHAM COUNTY DETENTION CENTER 130

Serial Number: 008591 Test Record Number: 2327
Test Date: 04/15/2020 Test Time: 4:07pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	4:08pm
FLO	Pass	4:08pm
FC	Pass	4:08pm

Temperature Tests

Test	Status	Time
FC1	Pass	4:08pm
SRC	Pass	4:08pm
DET	Pass	4:08pm
BAR	Pass	4:08pm
BT	Pass	4:08pm

Blank Tests

Test	Status	Time
AIR	Pass	4:09pm

Printer Tests

Test	Status	Time
PRNT	Pass	4:09pm

CRC Tests

Test	Status	Time
COMP	Pass	4:09pm
CAL	Pass	4:09pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Chatham Co. Instrument Location Siler City Police Dept
Instrument Serial No. 007811 Siler City, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15th day of April, 20 20, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

654
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CHATHAM COUNTY SILER CITY PD 180

Serial Number: 008811
Test Date: 04/15/2020

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: Keesler, Grayham C

Permit Number: 0045-5487

Effective:

11/04/2019-11/04/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG911501

Exp Date: 04/25/2021

Test	g/210L	Time
DIAG	Pass	2:58pm
AIR BLK	.00	2:59pm
ACCY CHK	.08	2:59pm
AIR BLK	.00	3:00pm
SUB TEST	.00	3:01pm
AIR BLK	.00	3:02pm
SUB TEST	.00	3:03pm
AIR BLK	.00	3:04pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

CHATHAM COUNTY SILER CITY PD 180

Serial Number: 008811 Test Record Number: 1405
Test Date: 04/15/2020 Test Time: 3:05pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:06pm
FLO	Pass	3:06pm
FC	Pass	3:06pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:06pm
SRC	Pass	3:06pm
DET	Pass	3:06pm
BAR	Pass	3:06pm
BT	Pass	3:06pm

Blank Tests

Test	Status	Time
AIR	Pass	3:06pm

Printer Tests

Test	Status	Time
PRNT	Pass	3:07pm

CRC Tests

Test	Status	Time
COMP	Pass	3:07pm
CAL	Pass	3:07pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Chowan Instrument Location Chowan Co. Public Safety
Instrument Serial No. 008895 Center, 305 Freemason St., Forest Hill
N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 17th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



James Kaye
Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CHOWAN COUNTY PUBLIC SAFETY CENTER 200

Serial Number: 008895
Test Date: 04/17/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: Keesler, Linda A
Permit Number: 0045-5468
Effective:
07/08/2019-07/08/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG902201
Exp Date: 01/22/2021

Test	g/210L	Time
DIAG	Pass	12:58pm
AIR BLK	.00	12:59pm
ACCY CHK	.08	1:00pm
AIR BLK	.00	1:01pm
SUB TEST	.00	1:01pm
AIR BLK	.00	1:02pm
SUB TEST	.00	1:04pm
AIR BLK	.00	1:05pm

Reported AC: 00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

CHOWAN COUNTY PUBLIC SAFETY CENTER 200

Serial Number: 008895 Test Record Number: 956
Test Date: 04/17/2020 Test Time: 1:06pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:07pm
FLO	Pass	1:07pm
FC	Pass	1:07pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:07pm
SRC	Pass	1:07pm
DET	Pass	1:07pm
BAR	Pass	1:07pm
BT	Pass	1:07pm

Blank Tests

Test	Status	Time
AIR	Pass	1:08pm

Printer Tests

Test	Status	Time
PRNT	Pass	1:08pm

CRC Tests

Test	Status	Time
COMP	Pass	1:08pm
CAL	Pass	1:08pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Cleveland Instrument Location Cleveland County SO
Instrument Serial No. 008893 Annex

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 9 day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

656
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CLEVELAND COUNTY CLEVELAND SO-ANNEX
220

Serial Number: 008893
Test Date: 04/09/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: *Hays, Mark D*
Permit Number: 0011-3099
Effective:
11/13/2019-11/13/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: *Breath Test*

Lot Number: AG007601
Exp Date: 03/16/2022

Test	g/210L	Time
DIAG	Pass	11:47am
AIR BLK	.00	11:47am
ACCY CHK	.08	11:48am
AIR BLK	.00	11:49am
SUB TEST	.00	11:50am
AIR BLK	.00	11:51am
SUB TEST	.00	11:53am
AIR BLK	.00	11:54am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR

Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

CLEVELAND COUNTY CLEVELAND SO-ANNEX 220

Serial Number: 008893 Test Record Number: 1722
Test Date: 04/09/2020 Test Time: 11:55am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:55am
FLO	Pass	11:55am
FC	Pass	11:55am

Temperature Tests

Test	Status	Time
FC1	Pass	11:55am
SRC	Pass	11:55am
DET	Pass	11:55am
BAR	Pass	11:55am
BT	Pass	11:55am

Blank Tests

Test	Status	Time
AIR	Pass	11:56am


Printer Tests

Test	Status	Time
PRNT	Pass	11:56am

CRC Tests

Test	Status	Time
COMP	Pass	11:56am
CAL	Pass	11:56am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County COLUMBUS Instrument Location COLUMBUS COUNTY
Instrument Serial No. 008875 DETENTION CENTER

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14 day of APRIL, 20 20, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. Bowers

Signature of Certifying Official

648

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

COLUMBUS COUNTY DETENTION CENTER 230

Serial Number: 008875
Test Date: 04/14/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R

Permit Number: 15671E

Effective:

06/01/2019-06/01/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG934001

Exp Date: 12/06/2021

Test	g/210L	Time
DIAG	Pass	10:01am
AIR BLK	.00	10:02am
ACCY CHK	.08	10:02am
AIR BLK	.00	10:03am
SUB TEST	.00	10:04am
AIR BLK	.00	10:05am
SUB TEST	.00	10:07am
AIR BLK	.00	10:08am

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

COLUMBUS COUNTY DETENTION CENTER 230

Serial Number: 008875 Test Record Number: 2276
Test Date: 04/14/2020 Test Time: 10:08am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:08am
FLO	Pass	10:08am
FC	Pass	10:09am

Temperature Tests

Test	Status	Time
FC1	Pass	10:09am
SRC	Pass	10:09am
DET	Pass	10:09am
BAR	Pass	10:09am
BT	Pass	10:09am

Blank Tests

Test	Status	Time
AIR	Pass	10:09am


Printer Tests

Test	Status	Time
PRNT	Pass	10:09am

CRC Tests

Test	Status	Time
COMP	Pass	10:09am
CAL	Pass	10:09am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County COLUMBUS Instrument Location COLUMBUS COUNTY
Instrument Serial No. 008886 DETENTION CENTER

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14 day of APRIL, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alex R. Bann

Signature of Certifying Official

648

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

COLUMBUS COUNTY DETENTION CENTER 230

Serial Number: 008886

Test Date: 04/14/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R

Permit Number: 15671E

Effective:

06/01/2019-06/01/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG911501

Exp Date: 04/25/2021

Test	g/210L	Time
DIAG	Pass	9:49am
AIR BLK	.00	9:50am
ACCY CHK	.08	9:51am
AIR BLK	.00	9:52am
SUB TEST	.00	9:52am
AIR BLK	.00	9:53am
SUB TEST	.00	9:55am
AIR BLK	.00	9:56am

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

COLUMBUS COUNTY DETENTION CENTER 230

Serial Number: 008886 Test Record Number: 1520
Test Date: 04/14/2020 Test Time: 9:57am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	9:57am
FLO	Pass	9:57am
FC	Pass	9:57am

Temperature Tests

Test	Status	Time
FC1	Pass	9:57am
SRC	Pass	9:57am
DET	Pass	9:57am
BAR	Pass	9:57am
BT	Pass	9:57am

Blank Tests

Test	Status	Time
AIR	Pass	9:58am

Printer Tests

Test	Status	Time
PRNT	Pass	9:58am

CRC Tests

Test	Status	Time
COMP	Pass	9:58am
CAL	Pass	9:58am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Cumberland Co. Instrument Location Cumberland Co Detention Center
Instrument Serial No. 108614 Fayetteville, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

654
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CUMBERLAND COUNTY DETENTION CENTER 250

Serial Number: 008614
Test Date: 04/14/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: Keesler, Grayham C
Permit Number: 0045-5487
Effective:
11/04/2019-11/04/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG007601
Exp Date: 03/16/2022

Test	g/210L	Time
DIAG	Pass	10:55am
AIR BLK	.00	10:56am
ACCY CHK	.07	10:56am
AIR BLK	.00	10:57am
SUB TEST	.00	10:58am
AIR BLK	.00	10:59am
SUB TEST	.00	11:00am
AIR BLK	.00	11:01am

Reported AC: 00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

CUMBERLAND COUNTY DETENTION CENTER 250

Serial Number: 008614 Test Record Number: 4418
Test Date: 04/14/2020 Test Time: 11:04am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:04am
FLO	Pass	11:04am
FC	Pass	11:05am

Temperature Tests

Test	Status	Time
FC1	Pass	11:05am
SRC	Pass	11:05am
DET	Pass	11:05am
BAR	Pass	11:05am
BT	Pass	11:05am

Blank Tests

Test	Status	Time
AIR	Pass	11:05am


Printer Tests

Test	Status	Time
PRNT	Pass	11:05am

CRC Tests

Test	Status	Time
COMP	Pass	11:05am
CAL	Pass	11:05am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Cumberland County Instrument Location Cumberland Co. Detention Center

Instrument Serial No. 008632 Fayetteville, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Handwritten Signature]
Signature of Certifying Official

654
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CUMBERLAND COUNTY DETENTION CENTER 250

Serial Number: 008632
Test Date: 04/14/2020

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: Keesler, Grayham C

Permit Number: 0045-5487

Effective:

11/04/2019-11/04/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG934001

Exp Date: 12/06/2021

Test	g/210L	Time
DIAG	Pass	10:56am
AIR BLK	.00	10:57am
ACCY CHK	.08	10:57am
AIR BLK	.00	10:58am
SUB TEST	.00	10:59am
AIR BLK	.00	11:00am
SUB TEST	.00	11:02am
AIR BLK	.00	11:03am

Reported AG: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

CUMBERLAND COUNTY DETENTION CENTER 250

Serial Number: 008632 Test Record Number: 4305
Test Date: 04/14/2020 Test Time: 11:05am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:05am
FLO	Pass	11:05am
FC	Pass	11:05am

Temperature Tests

Test	Status	Time
FC1	Pass	11:05am
SRC	Pass	11:05am
DET	Pass	11:05am
BAR	Pass	11:05am
BT	Pass	11:05am

Blank Tests

Test	Status	Time
AIR	Pass	11:06am

Printer Tests

Test	Status	Time
PRNT	Pass	11:06am

CRC Tests

Test	Status	Time
COMP	Pass	11:06am
CAL	Pass	11:06am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Cumberland Co. Instrument Location Cumberland Co. Detention Center

Instrument Serial No. 008633 Fayetteville, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

654
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CUMBERLAND COUNTY DETENTION CENTER 250

Serial Number: 008633
Test Date: 04/14/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: Keesler, Grayham C
Permit Number: 0045-5487
Effective:
11/04/2019-11/04/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG007601
Exp Date: 03/16/2022

Test	g/210L	Time
DIAG	Pass	10:51am
AIR BLK	.00	10:51am
ACCY CHK	.08	10:52am
AIR BLK	.00	10:53am
SUB TEST	.00	10:54am
AIR BLK	.00	10:55am
SUB TEST	.00	10:57am
AIR BLK	.00	10:58am

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

CUMBERLAND COUNTY DETENTION CENTER 250

Serial Number: 008633 Test Record Number: 5521
Test Date: 04/14/2020 Test Time: 11:01am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:01am
FLO	Pass	11:01am
FC	Pass	11:01am

Temperature Tests

Test	Status	Time
FC1	Pass	11:01am
SRC	Pass	11:01am
DET	Pass	11:01am
BAR	Pass	11:01am
BT	Pass	11:01am

Blank Tests

Test	Status	Time
AIR	Pass	11:02am


Printer Tests

Test	Status	Time
PRNT	Pass	11:02am

CRC Tests

Test	Status	Time
COMP	Pass	11:02am
CAL	Pass	11:02am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Cumberland Co. Instrument Location Cumberland Co. Detention Center
Instrument Serial No. 008612 Fayetteville, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

654
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CUMBERLAND COUNTY DETENTION CENTER 250

Serial Number: 008672
Test Date: 04/14/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: Keesler, Grayham C
Permit Number: 0045-5487
Effective:
11/04/2019-11/04/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG007601
Exp Date: 03/16/2022

Test	g/210L	Time
DIAG	Pass	10:53am
AIR BLK	.00	10:54am
ACCY CHK	.07	10:55am
AIR BLK	.00	10:56am
SUB TEST	.00	10:57am
AIR BLK	.00	10:58am
SUB TEST	.00	10:59am
AIR BLK	.00	11:00am

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

CUMBERLAND COUNTY DETENTION CENTER 250

Serial Number: 008672 Test Record Number: 6955
Test Date: 04/14/2020 Test Time: 11:00am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:01am
FLO	Pass	11:01am
FC	Pass	11:01am

Temperature Tests

Test	Status	Time
FC1	Pass	11:01am
SRC	Pass	11:01am
DET	Pass	11:01am
BAR	Pass	11:01am
BT	Pass	11:01am

Blank Tests

Test	Status	Time
AIR	Pass	11:02am


Printer Tests

Test	Status	Time
PRNT	Pass	11:02am

CRC Tests

Test	Status	Time
COMP	Pass	11:02am
CAL	Pass	11:02am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Cumberland Co. Instrument Location FT BRAGG LEC
Instrument Serial No. 009108 P110

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

654
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CUMBERLAND COUNTY FT BRAGG LEC 250

Serial Number: 008908
Test Date: 04/14/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: Keesler, Grayham C
Permit Number: 0045-5487
Effective:
11/04/2019-11/04/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG934001
Exp Date: 12/06/2021


Test	g/210L	Time
DIAG	Pass	1:07pm
AIR BLK	.00	1:08pm
ACCY CHK	.08	1:08pm
AIR BLK	.00	1:10pm
SUB TEST	.00	1:10pm
AIR BLK	.00	1:11pm
SUB TEST	.00	1:13pm
AIR BLK	.00	1:13pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

CUMBERLAND COUNTY FT BRAGG LEC 250

Serial Number: 008908 Test Record Number: 1909
Test Date: 04/14/2020 Test Time: 1:14pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:15pm
FLO	Pass	1:15pm
FC	Pass	1:15pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:15pm
SRC	Pass	1:15pm
DET	Pass	1:15pm
BAR	Pass	1:15pm
BT	Pass	1:15pm

Blank Tests

Test	Status	Time
AIR	Pass	1:16pm


Printer Tests

Test	Status	Time
PRNT	Pass	1:16pm

CRC Tests

Test	Status	Time
COMP	Pass	1:16pm
CAL	Pass	1:16pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Currituck Instrument Location Currituck Co S.D. Corolla

Instrument Serial No. 008949 1123 Ocean Trail, Corolla, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

643
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CURRITUCK COUNTY SO-COROLLA 260

Serial Number: 008949
Test Date: 04/15/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: GUARD, KELLY G
Permit Number: 12955E
Effective:
06/01/2019-06/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG007601
Exp Date: 03/16/2022


Test	g/210L	Time
DIAG	Pass	8:54am
AIR BLK	.00	8:54am
ACCY CHK	.08	8:55am
AIR BLK	.00	8:56am
SUB TEST	.00	8:57am
AIR BLK	.00	8:58am
SUB TEST	.00	8:59am
AIR BLK	.00	9:00am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

CURRITUCK COUNTY SO-COROLLA 260

Serial Number: 008949 Test Record Number: 535
Test Date: 04/15/2020 Test Time: 9:01am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	9:01am
FLO	Pass	9:01am
FC	Pass	9:02am

Temperature Tests

Test	Status	Time
FC1	Pass	9:02am
SRC	Pass	9:02am
DET	Pass	9:02am
BAR	Pass	9:02am
BT	Pass	9:02am

Blank Tests

Test	Status	Time
AIR	Pass	9:02am

Printer Tests

Test	Status	Time
PRNT	Pass	9:02am

CRC Tests

Test	Status	Time
COMP	Pass	9:02am
CAL	Pass	9:02am

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County DARE Instrument Location DARE Co Detection Center

Instrument Serial No. 005783 1044 Driftwood Dr., Manteo, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 29th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



June A. Powell
Signature of Certifying Official

6417
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

DARE COUNTY DARE CO DETENTION CE 270

Serial Number: 008783
Test Date: 04/29/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: Keesler, Linda A

Permit Number: 0045-5468

Effective:

07/08/2019-07/08/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG919901

Exp Date: 07/18/2021

Test	g/210L	Time
DIAG	Pass	1:12pm
AIR BLK	.00	1:12pm
ACCY CHK	.07	1:13pm
AIR BLK	.00	1:14pm
SUB TEST	.00	1:15pm
AIR BLK	.00	1:15pm
SUB TEST	.00	1:17pm
AIR BLK	.00	1:18pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

DARE COUNTY DARE CO DETENTION CE 270

Serial Number: 008783 Test Record Number: 907
Test Date: 04/29/2020 Test Time: 1:19pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:19pm
FLO	Pass	1:19pm
FC	Pass	1:19pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:19pm
SRC	Pass	1:19pm
DET	Pass	1:19pm
BAR	Pass	1:19pm
BT	Pass	1:19pm

Blank Tests

Test	Status	Time
AIR	Pass	1:20pm


Printer Tests

Test	Status	Time
PRNT	Pass	1:20pm

CRC Tests

Test	Status	Time
COMP	Pass	1:20pm
CAL	Pass	1:20pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County DARE

Instrument Location DARE Co. Detection Center

Instrument Serial No. 008804

1044 Driftwood Dr., Manteo, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 29th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Timothy Keese
Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

DARE COUNTY DARE CO DETENTION CE 270

Serial Number: 008804
Test Date: 04/29/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: Keesler, Linda A

Permit Number: 0045-5468

Effective:

07/08/2019-07/08/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG902106

Exp Date: 01/21/2021

Test	g/210L	Time
DIAG	Pass	1:14pm
AIR BLK	.00	1:15pm
ACCY CHK	.07	1:15pm
AIR BLK	.00	1:16pm
SUB TEST	.00	1:17pm
AIR BLK	.00	1:18pm
SUB TEST	.00	1:19pm
AIR BLK	.00	1:20pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

DARE COUNTY DARE CO DETENTION CE 270

Serial Number: 008804 Test Record Number: 2348
Test Date: 04/29/2020 Test Time: 1:22pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:22pm
FLO	Pass	1:22pm
FC	Pass	1:22pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:23pm
SRC	Pass	1:23pm
DET	Pass	1:23pm
BAR	Pass	1:23pm
BT	Pass	1:23pm

Blank Tests

Test	Status	Time
AIR	Pass	1:23pm


Printer Tests

Test	Status	Time
PRNT	Pass	1:23pm

CRC Tests

Test	Status	Time
COMP	Pass	1:23pm
CAL	Pass	1:23pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Dare Instrument Location Dare Co. S.O. - Hatteras

Instrument Serial No. 008807 50346 N Highway 12, Frisno, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

643
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

DARE COUNTY DARE CO SO HATTERAS 270

Serial Number: 008807
Test Date: 04/14/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: GUARD, KELLY G
Permit Number: 12955E
Effective:
06/01/2019-06/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG821801
Exp Date: 08/06/2020

Test	g/210L	Time
DIAG	Pass	8:05am
AIR BLK	.00	8:06am
ACCY CHK	.07	8:07am
AIR BLK	.00	8:08am
SUB TEST	.00	8:09am
AIR BLK	.00	8:10am
SUB TEST	.00	8:11am
AIR BLK	.00	8:12am

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

DARE COUNTY DARE CO SO HATTERAS 270

Serial Number: 008807 Test Record Number: 1141
Test Date: 04/14/2020 Test Time: 8:14am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	8:14am
FLO	Pass	8:14am
FC	Pass	8:14am

Temperature Tests

Test	Status	Time
FC1	Pass	8:14am
SRC	Pass	8:14am
DET	Pass	8:14am
BAR	Pass	8:14am
BT	Pass	8:14am

Blank Tests

Test	Status	Time
AIR	Pass	8:15am

Printer Tests

Test	Status	Time
PRNT	Pass	8:15am

CRC Tests

Test	Status	Time
COMP	Pass	8:15am
CAL	Pass	8:15am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Davidson Instrument Location Davidson Co. Jail

Instrument Serial No. 005845 Lexington, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

699
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

DAVIDSON COUNTY DAVIDSON CO JAIL 280

Serial Number: 008845

Test Date: 04/16/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BURNETTE, ANTHONY J

Permit Number: 11304E

Effective:

06/01/2019-06/01/2021

Officer's Name: NONE,

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG933901

Exp Date: 12/05/2021

Test	g/210L	Time
DIAG	Pass	2:15pm
AIR BLK	.00	2:16pm
ACCY CHK	.08	2:17pm
AIR BLK	.00	2:18pm
SUB TEST	.00	2:19pm
AIR BLK	.00	2:20pm
SUB TEST	.00	2:21pm
AIR BLK	.00	2:22pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

DAVIDSON COUNTY DAVIDSON CO JAIL 280

Serial Number: 008845 Test Record Number: 3376
Test Date: 04/16/2020 Test Time: 2:23pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:23pm
FLO	Pass	2:23pm
FC	Pass	2:24pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:24pm
SRC	Pass	2:24pm
DET	Pass	2:24pm
BAR	Pass	2:24pm
BT	Pass	2:24pm

Blank Tests

Test	Status	Time
AIR	Pass	2:24pm

Printer Tests

Test	Status	Time
PRNT	Pass	2:24pm

CRC Tests

Test	Status	Time
COMP	Pass	2:24pm
CAL	Pass	2:24pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Davidson Instrument Location Thomasville

Instrument Serial No. 008872 Police Department

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

649
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

DAVIDSON COUNTY THOMASVILLE PD 280

Serial Number: 008872
Test Date: 04/16/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BURNETTE, ANTHONY J
Permit Number: 11304E
Effective:
06/01/2019-06/01/2021

Officer's Name: NONE,
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG919901
Exp Date: 07/18/2021

Test	g/210L	Time
DIAG	Pass	3:16pm
AIR BLK	.00	3:17pm
ACCY CHK	.08	3:17pm
AIR BLK	.00	3:18pm
SUB TEST	.00	3:19pm
AIR BLK	.00	3:20pm
SUB TEST	.00	3:21pm
AIR BLK	.00	3:22pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

DAVIDSON COUNTY THOMASVILLE PD 280

Serial Number: 008872 Test Record Number: 1475
Test Date: 04/16/2020 Test Time: 3:23pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:23pm
FLO	Pass	3:23pm
FC	Pass	3:23pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:24pm
SRC	Pass	3:24pm
DET	Pass	3:24pm
BAR	Pass	3:24pm
BT	Pass	3:24pm

Blank Tests

Test	Status	Time
AIR	Pass	3:24pm


Printer Tests

Test	Status	Time
PRNT	Pass	3:24pm

CRC Tests

Test	Status	Time
COMP	Pass	3:24pm
CAL	Pass	3:24pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Davidson Instrument Location Lexington

Instrument Serial No. 009883 Police Department

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature] Signature of Certifying Official 649 Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

DAVIDSON COUNTY LEXINGTON PD 280

Serial Number: 008883
Test Date: 04/16/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BURNETTE, ANTHONY J
Permit Number: 11304E
Effective:
06/01/2019-06/01/2021

Officer's Name: NONE,
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG821401
Exp Date: 08/02/2020

Test	g/210L	Time
DIAG	Pass	1:23pm
AIR BLK	.00	1:24pm
ACCY CHK	.08	1:25pm
AIR BLK	.00	1:26pm
SUB TEST	.00	1:27pm
AIR BLK	.00	1:28pm
SUB TEST	.00	1:29pm
AIR BLK	.00	1:30pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

DAVIDSON COUNTY LEXINGTON PD 280

Serial Number: 008883 Test Record Number: 2197
Test Date: 04/16/2020 Test Time: 1:31pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:31pm
FLO	Pass	1:31pm
FC	Pass	1:31pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:31pm
SRC	Pass	1:31pm
DET	Pass	1:31pm
BAR	Pass	1:31pm
BT	Pass	1:31pm

Blank Tests

Test	Status	Time
AIR	Pass	1:32pm


Printer Tests

Test	Status	Time
PRNT	Pass	1:32pm

CRC Tests

Test	Status	Time
COMP	Pass	1:32pm
CAL	Pass	1:32pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Davie Instrument Location Davie Co Jail

Instrument Serial No. 008905 Mocksville, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

699
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

DAVIE COUNTY DAVIE COUNTY JAIL 290

Serial Number: 008905
Test Date: 04/16/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BURNETTE, ANTHONY J
Permit Number: 11304E
Effective:
06/01/2019-06/01/2021

Officer's Name: NONE,
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG821801
Exp Date: 08/06/2020

Test	g/210L	Time
DIAG	Pass	11:55am
AIR BLK	.00	11:56am
ACCY CHK	.08	11:57am
AIR BLK	.00	11:58am
SUB TEST	.00	11:59am
AIR BLK	.00	12:00pm
SUB TEST	.00	12:02pm
AIR BLK	.00	12:03pm

Reported AC: .00 g/210L

~~Signature of Chemical Analyst~~

Court CWR



Analyst

Intox EC/IR-II: Preventive Maintenance

DAVIE COUNTY DAVIE COUNTY JAIL 290

Serial Number: 008905 Test Record Number: 2475
Test Date: 04/16/2020 Test Time: 12:04pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:04pm
FLO	Pass	12:04pm
FC	Pass	12:04pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:04pm
SRC	Pass	12:04pm
DET	Pass	12:04pm
BAR	Pass	12:04pm
BT	Pass	12:04pm

Blank Tests

Test	Status	Time
AIR	Pass	12:05pm

Printer Tests

Test	Status	Time
PRNT	Pass	12:05pm

CRC Tests

Test	Status	Time
COMP	Pass	12:05pm
CAL	Pass	12:05pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Durham Instrument Location Durham Co Jail

Instrument Serial No. 008859 219 S. Mangum St Durham, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

662
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

DURHAM COUNTY DURHAM COUNTY JAIL 310

Serial Number: 008859
Test Date: 04/14/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: BARNES, STOKES
Permit Number: 11434E
Effective:
04/01/2019-04/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG933703
Exp Date: 12/03/2021

Test	g/210L	Time
DIAG	Pass	12:44pm
AIR BLK	.00	12:45pm
ACCY CHK	.08	12:45pm
AIR BLK	.00	12:46pm
SUB TEST	.00	12:47pm
AIR BLK	.00	12:48pm
SUB TEST	.00	12:49pm
AIR BLK	.00	12:50pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

DURHAM COUNTY DURHAM COUNTY JAIL 310

Serial Number: 008859 Test Record Number: 2381
Test Date: 04/14/2020 Test Time: 12:51pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:51pm
FLO	Pass	12:51pm
FC	Pass	12:52pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:52pm
SRC	Pass	12:52pm
DET	Pass	12:52pm
BAR	Pass	12:52pm
BT	Pass	12:52pm

Blank Tests

Test	Status	Time
AIR	Pass	12:52pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:52pm

CRC Tests

Test	Status	Time
COMP	Pass	12:53pm
CAL	Pass	12:53pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Durham Instrument Location Durham Co Jail

Instrument Serial No. 008878 219 S. Mangum St Durham, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Stefanos Barnes
Signature of Certifying Official

662
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

DURHAM COUNTY DURHAM COUNTY JAIL 310

Serial Number: 008878
Test Date: 04/14/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BARNES, STOKES
Permit Number: 11434E
Effective:
04/01/2019-04/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG933703
Exp Date: 12/03/2021


Test	g/210L	Time
DIAG	Pass	12:43pm
AIR BLK	.00	12:43pm
ACCY CHK	.08	12:44pm
AIR BLK	.00	12:45pm
SUB TEST	.00	12:45pm
AIR BLK	.00	12:46pm
SUB TEST	.00	12:48pm
AIR BLK	.00	12:49pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

DURHAM COUNTY DURHAM COUNTY JAIL 310

Serial Number: 008878 Test Record Number: 4823
Test Date: 04/14/2020 Test Time: 12:51pm EDT

System Check *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:51pm
FLO	Pass	12:51pm
FC	Pass	12:51pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:51pm
SRC	Pass	12:51pm
DET	Pass	12:51pm
BAR	Pass	12:51pm
BT	Pass	12:51pm

Blank Tests

Test	Status	Time
AIR	Pass	12:52pm

Printer Tests

Test	Status	Time
PRNT	Pass	12:52pm

CRC Tests

Test	Status	Time
COMP	Pass	12:52pm
CAL	Pass	12:52pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Durham Instrument Location Durham Co Jail

Instrument Serial No. 008891 219 S. Mangum St Durham NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 11 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

642
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

DURHAM COUNTY DURHAM COUNTY JAIL 310

Serial Number: 008891
Test Date: 04/14/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENENCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: BARNES, STOKES
Permit Number: 11434E
Effective:
04/01/2019-04/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG933703
Exp Date: 12/03/2021

Test	g/210L	Time
DIAG	Pass	12:43pm
AIR BLK	.00	12:44pm
ACCY CHK	.08	12:45pm
AIR BLK	.00	12:46pm
SUB TEST	.00	12:46pm
AIR BLK	.00	12:47pm
SUB TEST	.00	12:48pm
AIR BLK	.00	12:49pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

DURHAM COUNTY DURHAM COUNTY JAIL 310

Serial Number: 008891 Test Record Number: 4197
Test Date: 04/14/2020 Test Time: 12:51pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:51pm
FLO	Pass	12:51pm
FC	Pass	12:51pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:51pm
SRC	Pass	12:51pm
DET	Pass	12:51pm
BAR	Pass	12:51pm
BT	Pass	12:51pm

Blank Tests

Test	Status	Time
AIR	Pass	12:52pm

Printer Tests

Test	Status	Time
PRNT	Pass	12:52pm

CRC Tests

Test	Status	Time
COMP	Pass	12:52pm
CAL	Pass	12:52pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Edgemont Instrument Location Edgemont Co Magistrate
Instrument Serial No. 008603 Office, 3005 Anacosta Rd., Tarboro

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

643
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

EDGECOMBE COUNTY EDGECOMBE CO MAGISTR
320

Serial Number: 008603
Test Date: 04/16/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: GUARD, KELLY G
Permit Number: 12955E
Effective:
06/01/2019-06/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG821801
Exp Date: 08/06/2020

Test	g/210L	Time
DIAG	Pass	11:58am
AIR BLK	.00	11:59am
ACCY CHK	.08	12:00pm
AIR BLK	.00	12:01pm
SUB TEST	.00	12:01pm
AIR BLK	.00	12:02pm
SUB TEST	.00	12:04pm
AIR BLK	.00	12:05pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

EDGECOMBE COUNTY EDGECOMBE CO MAGISTR 320

Serial Number: 008603 Test Record Number: 1821
Test Date: 04/16/2020 Test Time: 12:06pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:07pm
FLO	Pass	12:07pm
FC	Pass	12:07pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:07pm
SRC	Pass	12:07pm
DET	Pass	12:07pm
BAR	Pass	12:07pm
BT	Pass	12:07pm

Blank Tests

Test	Status	Time
AIR	Pass	12:07pm

Printer Tests

Test	Status	Time
PRNT	Pass	12:07pm

CRC Tests

Test	Status	Time
COMP	Pass	12:08pm
CAL	Pass	12:08pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Edgercombe Instrument Location Edgercombe Co. Magistrate's

Instrument Serial No. 008663 Office, 300 S. Hammonds Rd, Tarboro, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

643
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

EDGECOMBE COUNTY EDGECOMBE CO MAGISTR
320

Serial Number: 008663
Test Date: 04/16/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: GUARD, KELLY G
Permit Number: 12955E
Effective:
06/01/2019-06/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG902201
Exp Date: 01/22/2021

Test	g/210L	Time
DIAG	Pass	11:33am
AIR BLK	.00	11:34am
ACCY CHK	.08	11:34am
AIR BLK	.00	11:35am
SUB TEST	.00	11:36am
AIR BLK	.00	11:37am
SUB TEST	.00	11:38am
AIR BLK	.00	11:39am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

EDGECOMBE COUNTY EDGECOMBE CO MAGISTR 320

Serial Number: 008663 Test Record Number: 3283
Test Date: 04/16/2020 Test Time: 11:40am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:41am
FLO	Pass	11:41am
FC	Pass	11:41am

Temperature Tests

Test	Status	Time
FC1	Pass	11:41am
SRC	Pass	11:41am
DET	Pass	11:41am
BAR	Pass	11:41am
BT	Pass	11:41am

Blank Tests

Test	Status	Time
AIR	Pass	11:42am


Printer Tests

Test	Status	Time
PRNT	Pass	11:42am

CRC Tests

Test	Status	Time
COMP	Pass	11:42am
CAL	Pass	11:42am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Forsyth Instrument Location Kernersville PD

Instrument Serial No. 008650 Kernersville, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature] 649
Signature of Certifying Official Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

FORSYTH COUNTY KERNERSVILLE PD 330

Serial Number: 008650
Test Date: 04/15/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BURNETTE, ANTHONY J
Permit Number: 11304E
Effective:
06/01/2019-06/01/2021

Officer's Name: NONE,
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG933901
Exp Date: 12/05/2021

Test	g/210L	Time
DIAG	Pass	5:32pm
AIR BLK	.00	5:33pm
ACCY CHK	.08	5:33pm
AIR BLK	.00	5:35pm
SUB TEST	.00	5:35pm
AIR BLK	.00	5:36pm
SUB TEST	.00	5:38pm
AIR BLK	.00	5:38pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

FORSYTH COUNTY KERNERSVILLE PD 330

Serial Number: 008650 Test Record Number: 1611
Test Date: 04/15/2020 Test Time: 5:39pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	5:39pm
FLO	Pass	5:39pm
FC	Pass	5:39pm

Temperature Tests

Test	Status	Time
FC1	Pass	5:40pm
SRC	Pass	5:40pm
DET	Pass	5:40pm
BAR	Pass	5:40pm
BT	Pass	5:40pm

Blank Tests

Test	Status	Time
AIR	Pass	5:40pm


Printer Tests

Test	Status	Time
PRNT	Pass	5:40pm

CRC Tests

Test	Status	Time
COMP	Pass	5:40pm
CAL	Pass	5:40pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Gaston Instrument Location Gaston County
Instrument Serial No. 008684 Sheriff's Office

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 9 day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

656
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

GASTON COUNTY GASTON COUNTY SO 350

Serial Number: 008684
Test Date: 04/09/2020

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: Hays, Mark D

Permit Number: 0011-3099

Effective:

11/13/2019-11/13/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG933901

Exp Date: 12/05/2021

Test	g/210L	Time
DIAG	Pass	2:16pm
AIR BLK	.00	2:17pm
ACCY CHK	.08	2:17pm
AIR BLK	.00	2:18pm
SUB TEST	.00	2:19pm
AIR BLK	.00	2:20pm
SUB TEST	.00	2:22pm
AIR BLK	.00	2:23pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

GASTON COUNTY GASTON COUNTY SO 350

Serial Number: 008684 Test Record Number: 4698
Test Date: 04/09/2020 Test Time: 2:24pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:24pm
FLO	Pass	2:24pm
FC	Pass	2:24pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:25pm
SRC	Pass	2:25pm
DET	Pass	2:25pm
BAR	Pass	2:25pm
BT	Pass	2:25pm

Blank Tests

Test	Status	Time
AIR	Pass	2:25pm


Printer Tests

Test	Status	Time
PRNT	Pass	2:25pm

CRC Tests

Test	Status	Time
COMP	Pass	2:25pm
CAL	Pass	2:25pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Gaston Instrument Location Mt. Holly
Instrument Serial No. 008733 Police Department

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 9 day of April, 2020 the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

656

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

GASTON COUNTY MT. HOLLY PD 350

Serial Number: 008733
Test Date: 04/09/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: Hays, Mark D
Permit Number: 0011-3099
Effective:
11/13/2019-11/13/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG904301
Exp Date: 02/12/2021

Test	g/210L	Time
DIAG	Pass	3:43pm
AIR BLK	.00	3:44pm
ACCY CHK	.08	3:44pm
AIR BLK	.00	3:45pm
SUB TEST	.00	3:46pm
AIR BLK	.00	3:47pm
SUB TEST	.00	3:48pm
AIR BLK	.00	3:49pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

GASTON COUNTY MT. HOLLY PD 350

Serial Number: 008733 Test Record Number: 1229
Test Date: 04/09/2020 Test Time: 3:51pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:51pm
FLO	Pass	3:51pm
FC	Pass	3:52pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:52pm
SRC	Pass	3:52pm
DET	Pass	3:52pm
BAR	Pass	3:52pm
BT	Pass	3:52pm

Blank Tests

Test	Status	Time
AIR	Pass	3:52pm


Printer Tests

Test	Status	Time
PRNT	Pass	3:52pm

CRC Tests

Test	Status	Time
COMP	Pass	3:52pm
CAL	Pass	3:52pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County GATES Instrument Location GATES CO. S.O.

Instrument Serial No. 008884 202 COURT ST, GATESVILLE, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

1047
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

GATES COUNTY GATES CO SO 360

Serial Number: 008884

Test Date: 04/15/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: Keesler, Linda A

Permit Number: 0045-5468

Effective:

07/08/2019-07/08/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG007601

Exp Date: 03/16/2022

Test	g/210L	Time
DIAG	Pass	2:43pm
AIR BLK	.00	2:44pm
ACCY CHK	.08	2:44pm
AIR BLK	.00	2:46pm
SUB TEST	.00	2:46pm
AIR BLK	.00	2:47pm
SUB TEST	.00	2:49pm
AIR BLK	.00	2:49pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

GATES COUNTY GATES CO SO 360

Serial Number: 008884 Test Record Number: 947
Test Date: 04/15/2020 Test Time: 2:50pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:50pm
FLO	Pass	2:50pm
FC	Pass	2:50pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:50pm
SRC	Pass	2:50pm
DET	Pass	2:50pm
BAR	Pass	2:50pm
BT	Pass	2:50pm

Blank Tests

Test	Status	Time
AIR	Pass	2:51pm


Printer Tests

Test	Status	Time
PRNT	Pass	2:51pm

CRC Tests

Test	Status	Time
COMP	Pass	2:51pm
CAL	Pass	2:51pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Granville Instrument Location Creedmoor PD

Instrument Serial No. 008641 111 MASONIC ST CREEDMOOR, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

662
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

GRANVILLE COUNTY CREEDMOOR PD 380

Serial Number: 008641
Test Date: 04/16/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: BARNES, STOKES
Permit Number: 11434E
Effective:
04/01/2019-04/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG919902
Exp Date: 07/18/2021

Test	g/210L	Time
DIAG	Pass	9:57am
AIR BLK	.00	9:58am
ACCY CHK	.08	9:59am
AIR BLK	.00	9:59am
SUB TEST	.00	10:00am
AIR BLK	.00	10:01am
SUB TEST	.00	10:03am
AIR BLK	.00	10:03am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

GRANVILLE COUNTY CREEDMOOR PD 380

Serial Number: 008641 Test Record Number: 1285
Test Date: 04/16/2020 Test Time: 10:04am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:05am
FLO	Pass	10:05am
FC	Pass	10:05am

Temperature Tests

Test	Status	Time
FC1	Pass	10:05am
SRC	Pass	10:05am
DET	Pass	10:05am
BAR	Pass	10:05am
BT	Pass	10:05am

Blank Tests

Test	Status	Time
AIR	Pass	10:05am

Printer Tests

Test	Status	Time
PRNT	Pass	10:05am

CRC Tests

Test	Status	Time
COMP	Pass	10:06am
CAL	Pass	10:06am

Preventive Maintenance

Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Granville Instrument Location Oxford PD

Instrument Serial No. 008923 201 E. McClanahan St. Oxford NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

667
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

GRANVILLE COUNTY OXFORD PD 380

Serial Number: 008923
Test Date: 04/16/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: BARNES, STOKES
Permit Number: 11434E
Effective:
04/01/2019-04/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG902201
Exp Date: 01/22/2021

Test	g/210L	Time
DIAG	Pass	3:19pm
AIR BLK	.00	3:19pm
ACCY CHK	.07	3:20pm
AIR BLK	.00	3:21pm
SUB TEST	.00	3:22pm
AIR BLK	.00	3:23pm
SUB TEST	.00	3:24pm
AIR BLK	.00	3:25pm

Reported AC: 00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

GRANVILLE COUNTY OXFORD PD 380

Serial Number: 008923 Test Record Number: 2392
Test Date: 04/16/2020 Test Time: 3:27pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:27pm
FLO	Pass	3:27pm
FC	Pass	3:27pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:28pm
SRC	Pass	3:28pm
DET	Pass	3:28pm
BAR	Pass	3:28pm
BT	Pass	3:28pm

Blank Tests

Test	Status	Time
AIR	Pass	3:28pm

Printer Tests

Test	Status	Time
PRNT	Pass	3:28pm

CRC Tests

Test	Status	Time
COMP	Pass	3:28pm
CAL	Pass	3:28pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Greene Instrument Location Greene Co. SD

Instrument Serial No. 008670 301 W. Greene St, Snow Hill,
NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 23rd day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature] 647
Signature of Certifying Official Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

GREENE COUNTY GREENE CO SO 390

Serial Number: 008670
Test Date: 04/23/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: Keesler, Linda A
Permit Number: 0045-5468
Effective:
07/08/2019-07/08/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG919901
Exp Date: 07/18/2021

Test	g/210L	Time
DIAG	Pass	12:10pm
AIR BLK	.00	12:10pm
ACCY CHK	.08	12:11pm
AIR BLK	.00	12:12pm
SUB TEST	.00	12:13pm
AIR BLK	.00	12:13pm
SUB TEST	.00	12:15pm
AIR BLK	.00	12:16pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

GREENE COUNTY GREENE CO SO 390

Serial Number: 008670 Test Record Number: 1950
Test Date: 04/23/2020 Test Time: 12:16pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:17pm
FLO	Pass	12:17pm
FC	Pass	12:17pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:17pm
SRC	Pass	12:17pm
DET	Pass	12:17pm
BAR	Pass	12:17pm
BT	Pass	12:17pm

Blank Tests

Test	Status	Time
AIR	Pass	12:18pm

Printer Tests

Test	Status	Time
PRNT	Pass	12:18pm

CRC Tests

Test	Status	Time
COMP	Pass	12:18pm
CAL	Pass	12:18pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Greene Instrument Location Greene Co. S.D.
Instrument Serial No. 008918 301 W. Greene St, S.W. Hill, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Linda Keesh
Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

GREENE COUNTY GREENE CO SO 390

Serial Number: 008918
Test Date: 04/14/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: Keesler, Linda A
Permit Number: 0045-5468
Effective:
07/08/2019-07/08/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG919901
Exp Date: 07/18/2021

Test	g/210L	Time
DIAG	Pass	3:17pm
AIR BLK	.00	3:18pm
ACCY CHK	.08	3:18pm
AIR BLK	.00	3:19pm
SUB TEST	.00	3:20pm
AIR BLK	.00	3:20pm
SUB TEST	.00	3:22pm
AIR BLK	.00	3:23pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

GREENE COUNTY GREENE CO SO 390

Serial Number: 008918 Test Record Number: 744
Test Date: 04/14/2020 Test Time: 3:23pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:24pm
FLO	Pass	3:24pm
FC	Pass	3:24pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:24pm
SRC	Pass	3:24pm
DET	Pass	3:24pm
BAR	Pass	3:24pm
BT	Pass	3:24pm

Blank Tests

Test	Status	Time
AIR	Pass	3:24pm

Printer Tests

Test	Status	Time
PRNT	Pass	3:25pm

CRC Tests

Test	Status	Time
COMP	Pass	3:25pm
CAL	Pass	3:25pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Guilford Instrument Location High Point Jail

Instrument Serial No. 008655 High Point, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

649
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

GUILFORD COUNTY HIGH POINT JAIL 401

Serial Number: 008655
Test Date: 04/15/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: *BURNETTE, ANTHONY J*

Permit Number: 11304E

Effective:

06/01/2019-06/01/2021

Officer's Name: NONE,

Type of Agency: FTA

Agency: DHHS

Test Type: *Breath Test*

Lot Number: AG821401

Exp Date: 08/02/2020

Test	g/210L	Time
DIAG	Pass	4:31pm
AIR BLK	.00	4:32pm
ACCY CHK	.07	4:32pm
AIR BLK	.00	4:33pm
SUB TEST	.00	4:34pm
AIR BLK	.00	4:35pm
SUB TEST	.00	4:37pm
AIR BLK	.00	4:37pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

GUILFORD COUNTY HIGH POINT JAIL 401

Serial Number: 008655 Test Record Number: 3524
Test Date: 04/15/2020 Test Time: 4:38pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	4:39pm
FLO	Pass	4:39pm
FC	Pass	4:39pm

Temperature Tests

Test	Status	Time
FC1	Pass	4:39pm
SRC	Pass	4:39pm
DET	Pass	4:39pm
BAR	Pass	4:39pm
BT	Pass	4:39pm

Blank Tests

Test	Status	Time
AIR	Pass	4:39pm


Printer Tests

Test	Status	Time
PRNT	Pass	4:40pm

CRC Tests

Test	Status	Time
COMP	Pass	4:40pm
CAL	Pass	4:40pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Guilford Instrument Location VPC - (71-015672)

Instrument Serial No. 008604 Gilchrist, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15 day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

049
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

GUILFORD COUNTY UNC-G POLICE DEPT 400

Serial Number: 008604
Test Date: 04/15/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BURNETTE, ANTHONY J

Permit Number: 11304E

Effective:

06/01/2019-06/01/2021

Officer's Name: NONE,

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG933703

Exp Date: 12/03/2021

Test	g/210L	Time
DIAG	Pass	1:50pm
AIR BLK	.00	1:51pm
ACCY CHK	.08	1:51pm
AIR BLK	.00	1:53pm
SUB TEST	.00	1:53pm
AIR BLK	.00	1:54pm
SUB TEST	.00	1:56pm
AIR BLK	.00	1:57pm

Reported AC: .00 g/210L

~~Signature of Chemical Analyst~~

COURT CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

GUILFORD COUNTY UNC-G POLICE DEPT 400

Serial Number: 008604 Test Record Number: 1899
Test Date: 04/15/2020 Test Time: 1:58pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:58pm
FLO	Pass	1:58pm
FC	Pass	1:59pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:59pm
SRC	Pass	1:59pm
DET	Pass	1:59pm
BAR	Pass	1:59pm
BT	Pass	1:59pm

Blank Tests

Test	Status	Time
AIR	Pass	1:59pm

Printer Tests

Test	Status	Time
PRNT	Pass	1:59pm

CRC Tests

Test	Status	Time
COMP	Pass	2:00pm
CAL	Pass	2:00pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Guilford Instrument Location Greensboro

Instrument Serial No. 008725 Police Department

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 20 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

649
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

GUILFORD COUNTY GREENSBORO PD 400

Serial Number: 008725
Test Date: 04/20/2020

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BURNETTE, ANTHONY J

Permit Number: 11304E

Effective:

06/01/2019-06/01/2021

Officer's Name: NONE,

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG920301

Exp Date: 07/22/2021

Test	g/210L	Time
DIAG	Pass	3:17pm
AIR BLK	.00	3:18pm
ACCY CHK	.08	3:18pm
AIR BLK	.00	3:19pm
SUB TEST	.00	3:20pm
AIR BLK	.00	3:21pm
SUB TEST	.00	3:22pm
AIR BLK	.00	3:23pm

Reported AC: .00 g/210L

~~Signature of Chemical Analyst~~

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

GUILFORD COUNTY GREENSBORO PD 400

Serial Number: 008725 Test Record Number: 4563
Test Date: 04/20/2020 Test Time: 3:25pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:25pm
FLO	Pass	3:25pm
FC	Pass	3:25pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:25pm
SRC	Pass	3:25pm
DET	Pass	3:25pm
BAR	Pass	3:25pm
BT	Pass	3:25pm

Blank Tests

Test	Status	Time
AIR	Pass	3:26pm

Printer Tests

Test	Status	Time
PRNT	Pass	3:26pm

CRC Tests

Test	Status	Time
COMP	Pass	3:26pm
CAL	Pass	3:26pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Guilford Instrument Location High Point PD

Instrument Serial No. 008828 High Point, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15 day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

649
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

GUILFORD COUNTY HIGH POINT PD 401

Serial Number: 008828
Test Date: 04/15/2020

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BURNETTE, ANTHONY J

Permit Number: 11304E

Effective:
06/01/2019-06/01/2021

Officer's Name: NONE,

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG919901

Exp Date: 07/18/2021

Test	g/210L	Time
DIAG	Pass	3:40pm
AIR BLK	.00	3:41pm
ACCY CHK	.08	3:42pm
AIR BLK	.00	3:43pm
SUB TEST	.00	3:44pm
AIR BLK	.00	3:45pm
SUB TEST	.00	3:46pm
AIR BLK	.00	3:47pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

GUILFORD COUNTY HIGH POINT PD 401

Serial Number: 008828 Test Record Number: 3354
Test Date: 04/15/2020 Test Time: 3:48pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:48pm
FLO	Pass	3:48pm
FC	Pass	3:49pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:49pm
SRC	Pass	3:49pm
DET	Pass	3:49pm
BAR	Pass	3:49pm
BT	Pass	3:49pm

Blank Tests

Test	Status	Time
AIR	Pass	3:49pm

Printer Tests

Test	Status	Time
PRNT	Pass	3:49pm

CRC Tests

Test	Status	Time
COMP	Pass	3:49pm
CAL	Pass	3:49pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County HALIFAX Instrument Location Roanoke Rapids PD

Instrument Serial No. 008635 1040 Roanoke Ave Roanoke Rapids NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15 day of April, 20 20 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Stokes Barnes
Signature of Certifying Official

662
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

HALIFAX CO ROANOKE RAPIDS PD 410

Serial Number: 008635
Test Date: 04/15/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: BARNES, STOKES
Permit Number: 11434E
Effective:
04/01/2019-04/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG911501
Exp Date: 04/25/2021


Test	g/210L	Time
DIAG	Pass	3:35pm
AIR BLK	.00	3:35pm
ACCY CHK	.08	3:36pm
AIR BLK	.00	3:37pm
SUB TEST	.00	3:38pm
AIR BLK	.00	3:39pm
SUB TEST	.00	3:40pm
AIR BLK	.00	3:41pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

HALIFAX CO ROANOKE RAPIDS PD 410

Serial Number: 008635 Test Record Number: 1768
Test Date: 04/15/2020 Test Time: 3:42pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:43pm
FLO	Pass	3:43pm
FC	Pass	3:43pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:43pm
SRC	Pass	3:43pm
DET	Pass	3:43pm
BAR	Pass	3:43pm
BT	Pass	3:43pm

Blank Tests

Test	Status	Time
AIR	Pass	3:44pm


Printer Tests

Test	Status	Time
PRNT	Pass	3:44pm

CRC Tests

Test	Status	Time
COMP	Pass	3:44pm
CAL	Pass	3:44pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County HALIFAX Instrument Location Roanoke Rapids PD

Instrument Serial No. 008656 1040 Roanoke Ave Roanoke Rapids, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

662
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

HALIFAX CO. ROANOKE RAPIDS PD 410

Serial Number: 008656
Test Date: 04/15/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: BARNES, STOKES
Permit Number: 11434E
Effective:
04/01/2019-04/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG902201
Exp Date: 01/22/2021

Test	g/210L	Time
DIAG	Pass	3:36pm
AIR BLK	.00	3:37pm
ACCY CHK	.07	3:38pm
AIR BLK	.00	3:39pm
SUB TEST	.00	3:39pm
AIR BLK	.00	3:40pm
SUB TEST	.00	3:42pm
AIR BLK	.00	3:42pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

HALIFAX CO. ROANOKE RAPIDS PD 410

Serial Number: 008656 Test Record Number: 678
Test Date: 04/15/2020 Test Time: 3:43pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:43pm
FLO	Pass	3:43pm
FC	Pass	3:43pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:43pm
SRC	Pass	3:43pm
DET	Pass	3:43pm
BAR	Pass	3:43pm
BT	Pass	3:43pm

Blank Tests

Test	Status	Time
AIR	Pass	3:44pm

Printer Tests

Test	Status	Time
PRNT	Pass	3:44pm

CRC Tests

Test	Status	Time
COMP	Pass	3:44pm
CAL	Pass	3:44pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County HALIFAX Instrument Location HALIFAX Co. S.O.

Instrument Serial No. 008695 355 Fernell Ln HALIFAX, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

662
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

HALIFAX CO. HALIFAX CO SO 410

Serial Number: 008695
Test Date: 04/15/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: BARNES, STOKES
Permit Number: 11434E
Effective:
04/01/2019-04/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG911501
Exp Date: 04/25/2021

Test	g/210L	Time
DIAG	Pass	2:35pm
AIR BLK	.00	2:36pm
ACCY CHK	.08	2:37pm
AIR BLK	.00	2:38pm
SUB TEST	.00	2:38pm
AIR BLK	.00	2:39pm
SUB TEST	.00	2:41pm
AIR BLK	.00	2:42pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

HALIFAX CO. HALIFAX CO SO 410

Serial Number: 008695 Test Record Number: 2917
Test Date: 04/15/2020 Test Time: 2:45pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:46pm
FLO	Pass	2:46pm
FC	Pass	2:46pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:46pm
SRC	Pass	2:46pm
DET	Pass	2:46pm
BAR	Pass	2:46pm
BT	Pass	2:46pm

Blank Tests

Test	Status	Time
AIR	Pass	2:47pm


Printer Tests

Test	Status	Time
PRNT	Pass	2:47pm

CRC Tests

Test	Status	Time
COMP	Pass	2:47pm
CAL	Pass	2:47pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Henderson Instrument Location Henderson Co. Jail

Instrument Serial No. 008806 Henderson, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature] Signature of Certifying Official 635 Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

HENDERSON COUNTY DENTENTION 440

Serial Number: 008806
Test Date: 04/13/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: Cutler, Daniel R
Permit Number: 0084-3310
Effective:
07/12/2019-07/12/2021

Officer's Name: NONE,
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG920301
Exp Date: 07/22/2021

Test	g/210L	Time
DIAG	Pass	2:25pm
AIR BLK	.00	2:26pm
ACCY CHK	.07	2:27pm
AIR BLK	.00	2:28pm
SUB TEST	.00	2:29pm
AIR BLK	.00	2:30pm
SUB TEST	.00	2:31pm
AIR BLK	.00	2:32pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

HENDERSON COUNTY DENTENTION 440

Serial Number: 008806 Test Record Number: 2896
Test Date: 04/13/2020 Test Time: 2:33pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:33pm
FLO	Pass	2:33pm
FC	Pass	2:33pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:34pm
SRC	Pass	2:34pm
DET	Pass	2:34pm
BAR	Pass	2:34pm
BT	Pass	2:34pm

Blank Tests

Test	Status	Time
AIR	Pass	2:34pm

Printer Tests

Test	Status	Time
PRNT	Pass	2:34pm

CRC Tests

Test	Status	Time
COMP	Pass	2:34pm
CAL	Pass	2:34pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Henderson Instrument Location Henderson Co. Jail

Instrument Serial No. 108822 Hendersonville, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Paul R. Cuth
Signature of Certifying Official

635
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

HENDERSON COUNTY DETENTION 440

Serial Number: 008822
Test Date: 04/13/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: Cutler, Daniel R

Permit Number: 0084-3310

Effective:

07/12/2019-07/12/2021

Officer's Name: NONE,

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG007601

Exp Date: 03/16/2022

Test	g/210L	Time
DIAG	Pass	2:45pm
AIR BLK	.00	2:46pm
ACCY CHK	.08	2:46pm
AIR BLK	.00	2:48pm
SUB TEST	.00	2:49pm
AIR BLK	.00	2:49pm
SUB TEST	.00	2:51pm
AIR BLK	.00	2:52pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

HENDERSON COUNTY DETENTION 440

Serial Number: 008822 Test Record Number: 2589
Test Date: 04/13/2020 Test Time: 2:53pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:53pm
FLO	Pass	2:53pm
FC	Pass	2:53pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:53pm
SRC	Pass	2:53pm
DET	Pass	2:53pm
BAR	Pass	2:53pm
BT	Pass	2:53pm

Blank Tests

Test	Status	Time
AIR	Pass	2:54pm

Printer Tests

Test	Status	Time
PRNT	Pass	2:54pm

CRC Tests

Test	Status	Time
COMP	Pass	2:54pm
CAL	Pass	2:54pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County HEARTFORD Instrument Location Aboskie P.O.

Instrument Serial No. 008848 705 W. Main ST, Aboskie, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Joseph K. Kiser
Signature of Certifying Official

697
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

HERTFORD COUNTY AHOSKIE PD 450

Serial Number: 008848
Test Date: 04/15/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: Keesler, Linda A
Permit Number: 0045-5468
Effective:
07/08/2019-07/08/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG821401
Exp Date: 08/02/2020


Test	g/210L	Time
DIAG	Pass	11:33am
AIR BLK	.00	11:34am
ACCY CHK	.07	11:34am
AIR BLK	.00	11:35am
SUB TEST	.00	11:36am
AIR BLK	.00	11:37am
SUB TEST	.00	11:38am
AIR BLK	.00	11:39am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

HERTFORD COUNTY AHOSKIE PD 450

Serial Number: 008848 Test Record Number: 1473
Test Date: 04/15/2020 Test Time: 11:40am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:40am
FLO	Pass	11:40am
FC	Pass	11:40am

Temperature Tests

Test	Status	Time
FC1	Pass	11:40am
SRC	Pass	11:40am
DET	Pass	11:40am
BAR	Pass	11:40am
BT	Pass	11:40am

Blank Tests

Test	Status	Time
AIR	Pass	11:41am

Printer Tests

Test	Status	Time
PRNT	Pass	11:41am

CRC Tests

Test	Status	Time
COMP	Pass	11:41am
CAL	Pass	11:41am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Hyd Instrument Location Hd Co S.D. - Ocrake
Instrument Serial No. 008797 NC 12, Ocrake, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Ken Signature of Certifying Official 643 Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

HYDE COUNTY HYDE CO SO OCRACOKE 470

Serial Number: 008797
Test Date: 04/14/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: GUARD, KELLY G
Permit Number: 12955E
Effective:
06/01/2019-06/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG911501
Exp Date: 04/25/2021

Test	g/210L	Time
DIAG	Pass	11:07am
AIR BLK	.00	11:07am
ACCY CHK	.08	11:08am
AIR BLK	.00	11:09am
SUB TEST	.00	11:10am
AIR BLK	.00	11:11am
SUB TEST	.00	11:12am
AIR BLK	.00	11:13am

Reported AC: .00 g/210L



Signature of Chemical Analyst
Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

HYDE COUNTY HYDE CO SO OCRACoke 470

Serial Number: 008797 Test Record Number: 583
Test Date: 04/14/2020 Test Time: 11:14am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:15am
FLO	Pass	11:15am
FC	Pass	11:15am

Temperature Tests

Test	Status	Time
FC1	Pass	11:15am
SRC	Pass	11:15am
DET	Pass	11:15am
BAR	Pass	11:15am
BT	Pass	11:15am

Blank Tests

Test	Status	Time
AIR	Pass	11:16am

Printer Tests

Test	Status	Time
PRNT	Pass	11:16am

CRC Tests

Test	Status	Time
COMP	Pass	11:16am
CAL	Pass	11:16am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Hyde Instrument Location Hyde Co. SO.
Instrument Serial No. 008801 1233 Main St., Swan Quarter, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 17th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

643
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

HYDE COUNTY HYDE CO SO SWAN QUAR 470

Serial Number: 008801
Test Date: 04/17/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: GUARD, KELLY G

Permit Number: 12955E

Effective:

06/01/2019-06/01/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG933703

Exp Date: 12/03/2021

Test	g/210L	Time
DIAG	Pass	10:11am
AIR BLK	.00	10:11am
ACCY CHK	.07	10:12am
AIR BLK	.00	10:13am
SUB TEST	.00	10:13am
AIR BLK	.00	10:14am
SUB TEST	.00	10:16am
AIR BLK	.00	10:17am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

HYDE COUNTY HYDE CO SO SWAN QUAR 470

Serial Number: 008801 Test Record Number: 542
Test Date: 04/17/2020 Test Time: 10:18am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:18am
FLO	Pass	10:18am
FC	Pass	10:18am

Temperature Tests

Test	Status	Time
FC1	Pass	10:18am
SRC	Pass	10:18am
DET	Pass	10:18am
BAR	Pass	10:18am
BT	Pass	10:18am

Blank Tests

Test	Status	Time
AIR	Pass	10:19am

Printer Tests

Test	Status	Time
PRNT	Pass	10:19am

CRC Tests

Test	Status	Time
COMP	Pass	10:19am
CAL	Pass	10:19am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Iredell Instrument Location Statesville PD

Instrument Serial No. 008619

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16 day of April, 20 20 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Ma D. Hays
Signature of Certifying Official

656
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

IREDELL COUNTY STATESVILLE PD 480

Serial Number: 008619
Test Date: 04/16/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: Hays, Mark D
Permit Number: 0011-3099
Effective:
11/13/2019-11/13/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG007601
Exp Date: 03/16/2022

Test	g/210L	Time
DIAG	Pass	10:32am
AIR BLK	.00	10:33am
ACCY CHK	.08	10:34am
AIR BLK	.00	10:35am
SUB TEST	.00	10:35am
AIR BLK	.00	10:36am
SUB TEST	.00	10:38am
AIR BLK	.00	10:39am

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR

Analyst

Intox EC/IR-II: Preventive Maintenance

IREDELL COUNTY STATESVILLE PD 480

Serial Number: 008619 Test Record Number: 1699
Test Date: 04/16/2020 Test Time: 10:40am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:40am
FLO	Pass	10:40am
FC	Pass	10:40am

Temperature Tests

Test	Status	Time
FC1	Pass	10:41am
SRC	Pass	10:41am
DET	Pass	10:41am
BAR	Pass	10:41am
BT	Pass	10:41am

Blank Tests

Test	Status	Time
AIR	Pass	10:41am


Printer Tests

Test	Status	Time
PRNT	Pass	10:41am

CRC Tests

Test	Status	Time
COMP	Pass	10:41am
CAL	Pass	10:41am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Iredell Instrument Location Mooreville PD

Instrument Serial No. 008685 950 W. Iredell Ave, Mooreville

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Joseph E. [Signature]
Signature of Certifying Official

650
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

IREDELL COUNTY MOORESVILLE PD 480

Serial Number: 008685
Test Date: 04/16/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: Hutchinson, Joseph E
Permit Number: 0035-6075
Effective:
07/09/2019-07/09/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG919902
Exp Date: 07/18/2021


Test	g/210L	Time
DIAG	Pass	11:45am
AIR BLK	.00	11:46am
ACCY CHK	.07	11:46am
AIR BLK	.00	11:47am
SUB TEST	.00	11:48am
AIR BLK	.00	11:49am
SUB TEST	.00	11:50am
AIR BLK	.00	11:51am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

IREDELL COUNTY MOORESVILLE PD 480

Serial Number: 008685 Test Record Number: 3371
Test Date: 04/16/2020 Test Time: 11:52am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:52am
FLO	Pass	11:53am
FC	Pass	11:53am

Temperature Tests

Test	Status	Time
FC1	Pass	11:53am
SRC	Pass	11:53am
DET	Pass	11:53am
BAR	Pass	11:53am
BT	Pass	11:53am

Blank Tests

Test	Status	Time
AIR	Pass	11:53am


Printer Tests

Test	Status	Time
PRNT	Pass	11:53am

CRC Tests

Test	Status	Time
COMP	Pass	11:54am
CAL	Pass	11:54am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Johnston Co. Instrument Location Johnston Co Detention Center

Instrument Serial No. 008863 Smithfield, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 1st day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

654
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

JOHNSTON COUNTY DETENTION CENTER 500

Serial Number: 008863
Test Date: 04/07/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: Keesler, Grayham C
Permit Number: 0045-5487
Effective:
11/04/2019-11/04/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG934001
Exp Date: 12/06/2021

Test	g/210L	Time
DIAG	Pass	10:03am
AIR BLK	.00	10:03am
ACCY CHK	.08	10:04am
AIR BLK	.00	10:05am
SUB TEST	.00	10:06am
AIR BLK	.00	10:07am
SUB TEST	.00	10:08am
AIR BLK	.00	10:09am

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

JOHNSTON COUNTY DETENTION CENTER 500

Serial Number: 008863 Test Record Number: 761
Test Date: 04/07/2020 Test Time: 10:10am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:10am
FLO	Pass	10:10am
FC	Pass	10:10am

Temperature Tests

Test	Status	Time
FC1	Pass	10:11am
SRC	Pass	10:11am
DET	Pass	10:11am
BAR	Pass	10:11am
BT	Pass	10:11am

Blank Tests

Test	Status	Time
AIR	Pass	10:11am


Printer Tests

Test	Status	Time
PRNT	Pass	10:11am

CRC Tests

Test	Status	Time
COMP	Pass	10:11am
CAL	Pass	10:11am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Johnston Co. Instrument Location Selma Police Dept.

Instrument Serial No. 008575 Selma, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

654
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

JOHNSTON COUNTY SELMA PD 500

Serial Number: 008595
Test Date: 04/13/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: Keesler, Grayham C

Permit Number: 0045-5487

Effective:

11/04/2019-11/04/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG911501

Exp Date: 04/25/2021

Test	g/210L	Time
DIAG	Pass	2:07pm
AIR BLK	.00	2:08pm
ACCY CHK	.07	2:09pm
AIR BLK	.00	2:10pm
SUB TEST	.00	2:11pm
AIR BLK	.00	2:11pm
SUB TEST	.00	2:13pm
AIR BLK	.00	2:14pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

JOHNSTON COUNTY SELMA PD 500

Serial Number: 008595 Test Record Number: 1441
Test Date: 04/13/2020 Test Time: 2:17pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:17pm
FLO	Pass	2:17pm
FC	Pass	2:17pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:18pm
SRC	Pass	2:18pm
DET	Pass	2:18pm
BAR	Pass	2:18pm
BT	Pass	2:18pm

Blank Tests

Test	Status	Time
AIR	Pass	2:18pm

Printer Tests

Test	Status	Time
PRNT	Pass	2:18pm

CRC Tests

Test	Status	Time
COMP	Pass	2:18pm
CAL	Pass	2:18pm

Preventive Maintenance
Status: Pass



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Johnston Co. Instrument Location Clayton Police Dept.
Instrument Serial No. 00 8658 Clayton, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

654
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

JOHNSTON COUNTY CLAYTON PD 500

Serial Number: 008658
Test Date: 04/13/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: Keesler, Grayham C

Permit Number: 0045-5487

Effective:

11/04/2019-11/04/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG934001

Exp Date: 12/06/2021

Test	g/210L	Time
DIAG	Pass	1:08pm
AIR BLK	.00	1:09pm
ACCY CHK	.08	1:09pm
AIR BLK	.00	1:10pm
SUB TEST	.00	1:11pm
AIR BLK	.00	1:12pm
SUB TEST	.00	1:13pm
AIR BLK	.00	1:14pm

Reported AC? .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

JOHNSTON COUNTY CLAYTON PD 500

Serial Number: 008658 Test Record Number: 1605
Test Date: 04/13/2020 Test Time: 1:14pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:15pm
FLO	Pass	1:15pm
FC	Pass	1:15pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:15pm
SRC	Pass	1:15pm
DET	Pass	1:15pm
BAR	Pass	1:15pm
BT	Pass	1:15pm

Blank Tests

Test	Status	Time
AIR	Pass	1:15pm


Printer Tests

Test	Status	Time
PRNT	Pass	1:16pm

CRC Tests

Test	Status	Time
COMP	Pass	1:16pm
CAL	Pass	1:16pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Johnston Co Instrument Location Therese R. Detamore Center

Instrument Serial No. 008510 Smithfield, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

654
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

JOHNSTON COUNTY DETENTION CENTER 500

Serial Number: 008810
Test Date: 04/13/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: Keesler, Grayham C
Permit Number: 0045-5487
Effective:
11/04/2019-11/04/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG934001
Exp Date: 12/06/2021

Test	g/210L	Time
DIAG	Pass	2:58pm
AIR BLK	.00	2:59pm
ACCY CHK	.08	2:59pm
AIR BLK	.00	3:00pm
SUB TEST	.00	3:01pm
AIR BLK	.00	3:02pm
SUB TEST	.00	3:03pm
AIR BLK	.00	3:04pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

JOHNSTON COUNTY DETENTION CENTER 500

Serial Number: 008810 Test Record Number: 4048
Test Date: 04/13/2020 Test Time: 3:06pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:06pm
FLO	Pass	3:06pm
FC	Pass	3:06pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:06pm
SRC	Pass	3:06pm
DET	Pass	3:06pm
BAR	Pass	3:06pm
BT	Pass	3:06pm

Blank Tests

Test	Status	Time
AIR	Pass	3:07pm

Printer Tests

Test	Status	Time
PRNT	Pass	3:07pm

CRC Tests

Test	Status	Time
COMP	Pass	3:07pm
CAL	Pass	3:07pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Johnston Co. Instrument Location Johnston Co Detention Center
Instrument Serial No. 008846 Smithfield, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 27th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

654
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

JOHNSTON COUNTY DETENTION CENTER 500

Serial Number: 008846
Test Date: 04/29/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: Keesler, Grayham C
Permit Number: 0045-5487
Effective:
11/04/2019-11/04/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG934001
Exp Date: 12/06/2021

Test	g/210L	Time
DIAG	Pass	12:26pm
AIR BLK	.00	12:26pm
ACCY CHK	.07	12:27pm
AIR BLK	.00	12:28pm
SUB TEST	.00	12:29pm
AIR BLK	.00	12:30pm
SUB TEST	.00	12:31pm
AIR BLK	.00	12:32pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

JOHNSTON COUNTY DETENTION CENTER 500

Serial Number: 008846 Test Record Number: 5138
Test Date: 04/29/2020 Test Time: 12:33pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:33pm
FLO	Pass	12:33pm
FC	Pass	12:33pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:33pm
SRC	Pass	12:33pm
DET	Pass	12:33pm
BAR	Pass	12:33pm
BT	Pass	12:33pm

Blank Tests

Test	Status	Time
AIR	Pass	12:34pm

Printer Tests


Test	Status	Time
PRNT	Pass	12:34pm

CRC Tests

Test	Status	Time
COMP	Pass	12:34pm
CAL	Pass	12:34pm

Preventive Maintenance

Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Lee Co. Instrument Location Lee Co. Jail
Instrument Serial No. 008645 Sanford, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

654
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

LEE COUNTY DETENTION CENTER 520

Serial Number: 008645
Test Date: 04/14/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: Keesler, Grayham C
Permit Number: 0045-5487
Effective:
11/04/2019-11/04/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG911501
Exp Date: 04/25/2021

Test	g/210L	Time
DIAG	Pass	3:23pm
AIR BLK	.00	3:23pm
ACCY CHK	.08	3:24pm
AIR BLK	.00	3:25pm
SUB TEST	.00	3:26pm
AIR BLK	.00	3:26pm
SUB TEST	.00	3:28pm
AIR BLK	.00	3:29pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

LEE COUNTY DETENTION CENTER 520

Serial Number: 008645 Test Record Number: 2010
Test Date: 04/14/2020 Test Time: 3:30pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:30pm
FLO	Pass	3:30pm
FC	Pass	3:30pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:30pm
SRC	Pass	3:30pm
DET	Pass	3:30pm
BAR	Pass	3:30pm
BT	Pass	3:30pm

Blank Tests

Test	Status	Time
AIR	Pass	3:31pm


Printer Tests

Test	Status	Time
PRNT	Pass	3:31pm

CRC Tests

Test	Status	Time
COMP	Pass	3:31pm
CAL	Pass	3:31pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Lee Co. Instrument Location SANFORD Police Dept.

Instrument Serial No. 008967 SANFORD, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

639
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

LEE COUNTY SANFORD POLICE DEPT 520

Serial Number: 008867
Test Date: 04/14/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: Keesler, Grayham C
Permit Number: 0045-5487
Effective:
11/04/2019-11/04/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG934001
Exp Date: 12/06/2021


Test	g/210L	Time
DIAG	Pass	4:01pm
AIR BLK	.00	4:01pm
ACCY CHK	.08	4:02pm
AIR BLK	.00	4:03pm
SUB TEST	.00	4:04pm
AIR BLK	.00	4:04pm
SUB TEST	.00	4:06pm
AIR BLK	.00	4:07pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-III: Preventive Maintenance

LEE COUNTY SANFORD POLICE DEPT 520

Serial Number: 00826 Test Record Number: 1155
Test Date: 04/14/2000 Test Time: 4:08pm EDT

System Check: Passed

Baseline Tests

Test	Status	Time
IR	Pass	4:08pm
FLC	Pass	4:08pm
FC	Pass	4:08pm

Temperature Tests

Test	Status	Time
FC1	Pass	4:08pm
SRC	Pass	4:08pm
DET	Pass	4:08pm
BAR	Pass	4:08pm
BT	Pass	4:08pm

Blank Tests

Test	Status	Time
AIR	Pass	4:09pm

Printer Tests


Test	Status	Time
PRNT	Pass	4:09pm

CRC Tests

Test	Status	Time
COMP	Pass	4:09pm
CAL	Pass	4:09pm

Preventive Maintenance

Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County LENOIR Instrument Location LENOIR CO S.O.
Instrument Serial No. 008639 130 QUEEN ST., KINSTON, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



James Reed
Signature of Certifying Official
647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

LENOIR COUNTY LENOIR CO SO 530

Serial Number: 008639
Test Date: 04/14/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: Keesler, Linda A
Permit Number: 0045-5468
Effective:
07/08/2019-07/08/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG933703
Exp Date: 12/03/2021

Test	g/210L	Time
DIAG	Pass	12:40pm
AIR BLK	.00	12:41pm
ACCY CHK	.07	12:41pm
AIR BLK	.00	12:42pm
SUB TEST	.00	12:43pm
AIR BLK	.00	12:44pm
SUB TEST	.00	12:45pm
AIR BLK	.00	12:46pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

LENOIR COUNTY LENOIR CO SO 530

Serial Number: 008639 Test Record Number: 3414
Test Date: 04/14/2020 Test Time: 12:47pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:47pm
FLO	Pass	12:47pm
FC	Pass	12:47pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:47pm
SRC	Pass	12:47pm
DET	Pass	12:47pm
BAR	Pass	12:47pm
BT	Pass	12:47pm

Blank Tests

Test	Status	Time
AIR	Pass	12:48pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:48pm

CRC Tests

Test	Status	Time
COMP	Pass	12:48pm
CAL	Pass	12:48pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Madison Instrument Location Mar's Hill PD

Instrument Serial No. 008582 Mar's Hill, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14 day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Paul R. Galt
Signature of Certifying Official

635
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MADISON COUNTY MARS HILL PD 560

Serial Number: 008582
Test Date: 04/14/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: Cutler, Daniel R

Permit Number: 0084-3310

Effective:

07/12/2019-07/12/2021

Officer's Name: NONE,

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG911506

Exp Date: 04/25/2021

Test	g/210L	Time
DIAG	Pass	2:41pm
AIR BLK	.00	2:41pm
ACCY CHK	.07	2:42pm
AIR BLK	.00	2:43pm
SUB TEST	.00	2:44pm
AIR BLK	.00	2:45pm
SUB TEST	.00	2:46pm
AIR BLK	.00	2:47pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

MADISON COUNTY MARS HILL PD 560

Serial Number: 008582 Test Record Number: 1154
Test Date: 04/14/2020 Test Time: 2:48pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:48pm
FLO	Pass	2:48pm
FC	Pass	2:49pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:49pm
SRC	Pass	2:49pm
DET	Pass	2:49pm
BAR	Pass	2:49pm
BT	Pass	2:49pm

Blank Tests

Test	Status	Time
AIR	Pass	2:49pm

Printer Tests

Test	Status	Time
PRNT	Pass	2:49pm

CRC Tests

Test	Status	Time
COMP	Pass	2:49pm
CAL	Pass	2:49pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Madison Instrument Location Madison Co. Jail

Instrument Serial No. 008599 Marshall, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14 day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Paul R. Guth
Signature of Certifying Official

635
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MADISON COUNTY MADISON COUNTY JAIL 560

Serial Number: 008599
Test Date: 04/14/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: Cutler, Daniel R
Permit Number: 0084-3310
Effective:
07/12/2019-07/12/2021

Officer's Name: NONE,
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG919902
Exp Date: 07/18/2021

Test	g/210L	Time
DIAG	Pass	12:25pm
AIR BLK	.00	12:26pm
ACCY CHK	.08	12:26pm
AIR BLK	.00	12:27pm
SUB TEST	.00	12:28pm
AIR BLK	.00	12:29pm
SUB TEST	.00	12:30pm
AIR BLK	.00	12:31pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

MADISON COUNTY MADISON COUNTY JAIL 560

Serial Number: 008599 Test Record Number: 1095
Test Date: 04/14/2020 Test Time: 12:32pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:32pm
FLO	Pass	12:32pm
FC	Pass	12:32pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:33pm
SRC	Pass	12:33pm
DET	Pass	12:33pm
BAR	Pass	12:33pm
BT	Pass	12:33pm

Blank Tests

Test	Status	Time
AIR	Pass	12:33pm

Printer Tests

Test	Status	Time
PRNT	Pass	12:33pm

CRC Tests

Test	Status	Time
COMP	Pass	12:33pm
CAL	Pass	12:33pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County MARTIN Instrument Location MARTIN CO S.O.

Instrument Serial No. 008912 305 E MAIN ST, WILLIAMSTON, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 17th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Linda A. Keel
Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MARTIN COUNTY SHERIFF'S OFFICE 570

Serial Number: 008912
Test Date: 04/17/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: Keesler, Linda A
Permit Number: 0045-5468
Effective:
07/08/2019-07/08/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG007601
Exp Date: 03/16/2022


Test	g/210L	Time
DIAG	Pass	3:24pm
AIR BLK	.00	3:24pm
ACCY CHK	.07	3:25pm
AIR BLK	.00	3:26pm
SUB TEST	.00	3:27pm
AIR BLK	.00	3:28pm
SUB TEST	.00	3:29pm
AIR BLK	.00	3:30pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

MARTIN COUNTY SHERIFF'S OFFICE 570

Serial Number: 008912 Test Record Number: 1576
Test Date: 04/17/2020 Test Time: 3:31pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:31pm
FLO	Pass	3:31pm
FC	Pass	3:31pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:31pm
SRC	Pass	3:31pm
DET	Pass	3:31pm
BAR	Pass	3:31pm
BT	Pass	3:31pm

Blank Tests

Test	Status	Time
AIR	Pass	3:32pm


Printer Tests

Test	Status	Time
PRNT	Pass	3:32pm

CRC Tests

Test	Status	Time
COMP	Pass	3:32pm
CAL	Pass	3:32pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County McDowell Instrument Location McDowell Co. Jail

Instrument Serial No. 009888 Model WC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]

Signature of Certifying Official

658

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MCDOWELL COUNTY JAIL 580

Serial Number: 008888
Test Date: 04/14/2020

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: TOWERY, CHAD V

Permit Number: 26632E

Effective:

05/01/2019-05/01/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG831801

Exp Date: 11/14/2020

Test	g/210L	Time
DIAG	Pass	11:37am
AIR BLK	.00	11:38am
ACCY CHK	.07	11:39am
AIR BLK	.00	11:40am
SUB TEST	.00	11:40am
AIR BLK	.00	11:41am
SUB TEST	.00	11:43am
AIR BLK	.00	11:44am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

MCDOWELL COUNTY JAIL 580

Serial Number: 008888 Test Record Number: 1546
Test Date: 04/14/2020 Test Time: 11:44am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:45am
FLO	Pass	11:45am
FC	Pass	11:45am

Temperature Tests

Test	Status	Time
FC1	Pass	11:45am
SRC	Pass	11:45am
DET	Pass	11:45am
BAR	Pass	11:45am
BT	Pass	11:45am

Blank Tests

Test	Status	Time
AIR	Pass	11:45am


Printer Tests

Test	Status	Time
PRNT	Pass	11:46am

CRC Tests

Test	Status	Time
COMP	Pass	11:46am
CAL	Pass	11:46am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County McDowell Instrument Location McDowell Co. Jail

Instrument Serial No. 009888 Model WC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]

Signature of Certifying Official

658

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MCDOWELL COUNTY JAIL 580

Serial Number: 008888

Test Date: 04/14/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: TOWERY, CHAD V

Permit Number: 26632E

Effective:

05/01/2019-05/01/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG831801

Exp Date: 11/14/2020

Test	g/210L	Time
DIAG	Pass	11:37am
AIR BLK	.00	11:38am
ACCY CHK	.07	11:39am
AIR BLK	.00	11:40am
SUB TEST	.00	11:40am
AIR BLK	.00	11:41am
SUB TEST	.00	11:43am
AIR BLK	.00	11:44am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

MCDOWELL COUNTY JAIL 580

Serial Number: 008888 Test Record Number: 1546
Test Date: 04/14/2020 Test Time: 11:44am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:45am
FLO	Pass	11:45am
FC	Pass	11:45am

Temperature Tests

Test	Status	Time
FC1	Pass	11:45am
SRC	Pass	11:45am
DET	Pass	11:45am
BAR	Pass	11:45am
BT	Pass	11:45am

Blank Tests

Test	Status	Time
AIR	Pass	11:45am


Printer Tests

Test	Status	Time
PRNT	Pass	11:46am

CRC Tests

Test	Status	Time
COMP	Pass	11:46am
CAL	Pass	11:46am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County McDowell Instrument Location McDowell Co Jail

Instrument Serial No. 008892 Marion WC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14 day of April, 2021 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Chris Dow

Signature of Certifying Official

658

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MCDOWELL COUNTY JAIL 580

Serial Number: 008892
Test Date: 04/14/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: TOWERY, CHAD V

Permit Number: 26632E

Effective:

05/01/2019-05/01/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG821401

Exp Date: 08/02/2020


Test	g/210L	Time
DIAG	Pass	11:25am
AIR BLK	.00	11:26am
ACCY CHK	.07	11:27am
AIR BLK	.00	11:28am
SUB TEST	.00	11:29am
AIR BLK	.00	11:30am
SUB TEST	.00	11:31am
AIR BLK	.00	11:32am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

MCDOWELL COUNTY JAIL 580

Serial Number: 008892 Test Record Number: 843
Test Date: 04/14/2020 Test Time: 11:33am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:33am
FLO	Pass	11:33am
FC	Pass	11:33am

Temperature Tests

Test	Status	Time
FC1	Pass	11:33am
SRC	Pass	11:33am
DET	Pass	11:33am
BAR	Pass	11:33am
BT	Pass	11:33am

Blank Tests

Test	Status	Time
AIR	Pass	11:34am

Printer Tests

Test	Status	Time
PRNT	Pass	11:34am

CRC Tests

Test	Status	Time
COMP	Pass	11:34am
CAL	Pass	11:34am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County McDowell Instrument Location McDowell Co Jail

Instrument Serial No. 008892 Marion WC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14 day of April, 2021 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Chris Dow

Signature of Certifying Official

658

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MCDOWELL COUNTY JAIL 580

Serial Number: 008892
Test Date: 04/14/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: TOWERY, CHAD V

Permit Number: 26632E

Effective:

05/01/2019-05/01/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG821401

Exp Date: 08/02/2020


Test	g/210L	Time
DIAG	Pass	11:25am
AIR BLK	.00	11:26am
ACCY CHK	.07	11:27am
AIR BLK	.00	11:28am
SUB TEST	.00	11:29am
AIR BLK	.00	11:30am
SUB TEST	.00	11:31am
AIR BLK	.00	11:32am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

MCDOWELL COUNTY JAIL 580

Serial Number: 008892 Test Record Number: 843
Test Date: 04/14/2020 Test Time: 11:33am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:33am
FLO	Pass	11:33am
FC	Pass	11:33am

Temperature Tests

Test	Status	Time
FC1	Pass	11:33am
SRC	Pass	11:33am
DET	Pass	11:33am
BAR	Pass	11:33am
BT	Pass	11:33am

Blank Tests

Test	Status	Time
AIR	Pass	11:34am

Printer Tests

Test	Status	Time
PRNT	Pass	11:34am

CRC Tests

Test	Status	Time
COMP	Pass	11:34am
CAL	Pass	11:34am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II

County Mecklenburg Instrument Location Mecklenburg County
Instrument Serial No. 008690 Sheriff's Office

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Mark D. Hays
Signature of Certifying Official

656
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MECKLENBURG COUNTY SHERIFFS OFFICE 590

Serial Number: 008690
Test Date: 04/13/2020

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: Hays, Mark D

Permit Number: 0011-3099

Effective:

11/13/2019-11/13/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG934303

Exp Date: 12/09/2021

Test	g/210L	Time
DIAG	Pass	1:11pm
AIR BLK	.00	1:12pm
ACCY CHK	.08	1:13pm
AIR BLK	.00	1:14pm
SUB TEST	.00	1:16pm
AIR BLK	.00	1:17pm
SUB TEST	.00	1:19pm
AIR BLK	.00	1:20pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR

Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

MECKLENBURG COUNTY SHERIFFS OFFICE 590

Serial Number: 008690 Test Record Number: 6519
Test Date: 04/13/2020 Test Time: 1:22pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:22pm
FLO	Pass	1:22pm
FC	Pass	1:22pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:22pm
SRC	Pass	1:22pm
DET	Pass	1:22pm
BAR	Pass	1:22pm
BT	Pass	1:22pm

Blank Tests

Test	Status	Time
AIR	Pass	1:23pm


Printer Tests

Test	Status	Time
PRNT	Pass	1:23pm

CRC Tests

Test	Status	Time
COMP	Pass	1:23pm
CAL	Pass	1:23pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Mecklenburg Instrument Location CMRD-LEC
Instrument Serial No. 008691

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

656
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MECKLENBURG COUNTY CMPD LEC 590

Serial Number: 008691
Test Date: 04/13/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: Hays, Mark D
Permit Number: 0011-3099
Effective:
11/13/2019-11/13/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG007601
Exp Date: 03/16/2022

Test	g/210L	Time
DIAG	Pass	1:55pm
AIR BLK	.00	1:55pm
ACCY CHK	.08	1:56pm
AIR BLK	.00	1:57pm
SUB TEST	.00	1:59pm
AIR BLK	.00	2:00pm
SUB TEST	.00	2:02pm
AIR BLK	.00	2:03pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

MECKLENBURG COUNTY CMPD LEC 590

Serial Number: 008691 Test Record Number: 8089
Test Date: 04/13/2020 Test Time: 2:04pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:04pm
FLO	Pass	2:04pm
FC	Pass	2:04pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:05pm
SRC	Pass	2:05pm
DET	Pass	2:05pm
BAR	Pass	2:05pm
BT	Pass	2:05pm

Blank Tests

Test	Status	Time
AIR	Pass	2:05pm


Printer Tests

Test	Status	Time
PRNT	Pass	2:05pm

CRC Tests

Test	Status	Time
COMP	Pass	2:05pm
CAL	Pass	2:05pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Mecklenburg Instrument Location Cornelius PD
Instrument Serial No. 008692

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

656
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MECKLENBURG COUNTY CORNELIUS PD 590

Serial Number: 008692
Test Date: 04/13/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: Hays, Mark D
Permit Number: 0011-3099
Effective:
11/13/2019-11/13/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG007601
Exp Date: 03/16/2022

Test	g/210L	Time
DIAG	Pass	3:21pm
AIR BLK	.00	3:22pm
ACCY CHK	.08	3:23pm
AIR BLK	.00	3:24pm
SUB TEST	.00	3:24pm
AIR BLK	.00	3:25pm
SUB TEST	.00	3:27pm
AIR BLK	.00	3:28pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

MECKLENBURG COUNTY CORNELIUS PD 590

Serial Number: 008692 Test Record Number: 2992
Test Date: 04/13/2020 Test Time: 3:29pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:29pm
FLO	Pass	3:29pm
FC	Pass	3:29pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:29pm
SRC	Pass	3:29pm
DET	Pass	3:29pm
BAR	Pass	3:29pm
BT	Pass	3:29pm

Blank Tests

Test	Status	Time
AIR	Pass	3:30pm

Printer Tests

Test	Status	Time
PRNT	Pass	3:30pm

CRC Tests

Test	Status	Time
COMP	Pass	3:30pm
CAL	Pass	3:30pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Mecklenburg Instrument Location Matthews PD
Instrument Serial No 008699

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

656
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MECKLENBURG COUNTY MATTHEWS PD 590

Serial Number: 008699
Test Date: 04/13/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: Hays, Mark D
Permit Number: 0011-3099
Effective:
11/13/2019-11/13/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG902106
Exp Date: 01/21/2021

Test	g/210L	Time
DIAG	Pass	12:15pm
AIR BLK	.00	12:16pm
ACCY CHK	.08	12:17pm
AIR BLK	.00	12:18pm
SUB TEST	.00	12:19pm
AIR BLK	.00	12:20pm
SUB TEST	.00	12:22pm
AIR BLK	.00	12:23pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

MECKLENBURG COUNTY MATTHEWS PD 590

Serial Number: 008699 Test Record Number: 2840
Test Date: 04/13/2020 Test Time: 12:24pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:25pm
FLO	Pass	12:25pm
FC	Pass	12:25pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:25pm
SRC	Pass	12:25pm
DET	Pass	12:25pm
BAR	Pass	12:25pm
BT	Pass	12:25pm

Blank Tests

Test	Status	Time
AIR	Pass	12:25pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:26pm

CRC Tests

Test	Status	Time
COMP	Pass	12:26pm
CAL	Pass	12:26pm

Preventive Maintenance
Status: *Pass*



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Mecklenburg Instrument Location Pineville PD

Instrument Serial No. 008703

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

656
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MECKLENBURG COUNTY PINEVILLE PD 590

Serial Number: 008703
Test Date: 04/13/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: Hays, Mark D
Permit Number: 0011-3099
Effective:
11/13/2019-11/13/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG904301
Exp Date: 02/21/2021

Test	g/210L	Time
DIAG	Pass	11:19am
AIR BLK	.00	11:20am
ACCY CHK	.08	11:21am
AIR BLK	.00	11:22am
SUB TEST	.00	11:23am
AIR BLK	.00	11:24am
SUB TEST	.00	11:26am
AIR BLK	.00	11:27am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

MECKLENBURG COUNTY PINEVILLE PD 590

Serial Number: 008703 Test Record Number: 5847
Test Date: 04/13/2020 Test Time: 11:28am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:28am
FLO	Pass	11:28am
FC	Pass	11:28am

Temperature Tests

Test	Status	Time
FC1	Pass	11:29am
SRC	Pass	11:29am
DET	Pass	11:29am
BAR	Pass	11:29am
BT	Pass	11:29am

Blank Tests

Test	Status	Time
AIR	Pass	11:29am

Printer Tests

Test	Status	Time
PRNT	Pass	11:29am

CRC Tests

Test	Status	Time
COMP	Pass	11:29am
CAL	Pass	11:29am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Mitchell Instrument Location Spice Pine P.D.
Instrument Serial No. C208726 Spice Pine, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15 day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



David R. Luther
Signature of Certifying Official

635
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MITCHELL COUNTY SPRUCE PINE PD 600

Serial Number: 008725
Test Date: 04/15/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: Cutler, Dandel R
Permit Number: 0084-3310
Effective:
07/12/2019-07/12/2021

Officer's Name: NONE,
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG920301
Exp Date: 07/22/2021

Test	g/210L	Time
DIAG	Pass	12:52pm
AIR BLK	.00	12:53pm
ACCY CHK	.08	12:54pm
AIR BLK	.00	12:55pm
SUB TEST	.00	12:55pm
AIR BLK	.00	12:56pm
SUB TEST	.00	12:58pm
AIR BLK	.00	12:59pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

MITCHELL COUNTY SPRUCE PINE PD 600

Serial Number: 008726 Test Record Number: 1037
Test Date: 04/15/2020 Test Time: 1:00pm EDT

System Check: Passed

Baseline Tests

Test	Status	Time
IR	Pass	1:00pm
FLO	Pass	1:00pm
FC	Pass	1:00pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:01pm
SRC	Pass	1:01pm
DET	Pass	1:01pm
BAP	Pass	1:01pm
BT	Pass	1:01pm

Blank Tests

Test	Status	Time
AIR	Pass	1:01pm

Printer Tests

Test	Status	Time
PRNT	Pass	1:01pm

CRC Tests

Test	Status	Time
COMP	Pass	1:01pm
CAL	Pass	1:01pm

Preventive Maintenance
Status: Pass



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Wake Co. Instrument Location Pinehurst Police Dept.

Instrument Serial No. 007110 Pinehurst, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Handwritten Signature]
Signature of Certifying Official

654
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MOORE COUNTY PINEHURST PD 620

Serial Number: 008710

Test Date: 04/16/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: Keesler, Grayham C

Permit Number: 0045-5487

Effective:

11/04/2019-11/04/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG911501

Exp Date: 04/25/2021

Test	g/210L	Time
DIAG	Pass	3:05pm
AIR BLK	.00	3:06pm
ACCY CHK	.07	3:07pm
AIR BLK	.00	3:07pm
SUB TEST	.00	3:08pm
AIR BLK	.00	3:09pm
SUB TEST	.00	3:10pm
AIR BLK	.00	3:11pm

Reported AC: 00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

MOORE COUNTY PINEHURST PD 620

Serial Number: 008710 Test Record Number: 1663
Test Date: 04/16/2020 Test Time: 3:12pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:12pm
FLO	Pass	3:12pm
FC	Pass	3:12pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:12pm
SRC	Pass	3:12pm
DET	Pass	3:12pm
BAR	Pass	3:12pm
BT	Pass	3:12pm

Blank Tests

Test	Status	Time
AIR	Pass	3:13pm


Printer Tests

Test	Status	Time
PRNT	Pass	3:13pm

CRC Tests

Test	Status	Time
COMP	Pass	3:13pm
CAL	Pass	3:13pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County NASH Instrument Location NASHVILLE PD

Instrument Serial No. 008630 5015 PRANCE ST. Nashville, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15 day of April, 2022 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

642
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

NASH COUNTY NASHVILLE PD 630

Serial Number: 008630
Test Date: 04/15/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: BARNES, STOKES
Permit Number: 11434E
Effective:
04/01/2019-04/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG007601
Exp Date: 03/16/2022

Test	g/210L	Time
DIAG	Pass	12:12pm
AIR BLK	.00	12:13pm
ACCY CHK	.08	12:13pm
AIR BLK	.00	12:14pm
SUB TEST	.00	12:15pm
AIR BLK	.00	12:16pm
SUB TEST	.00	12:17pm
AIR BLK	.00	12:18pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

NASH COUNTY NASHVILLE PD 630

Serial Number: 008630 Test Record Number: 4751
Test Date: 04/15/2020 Test Time: 12:19pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:19pm
FLO	Pass	12:19pm
FC	Pass	12:19pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:19pm
SRC	Pass	12:19pm
DET	Pass	12:19pm
BAR	Pass	12:19pm
BT	Pass	12:19pm

Blank Tests

Test	Status	Time
AIR	Pass	12:20pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:20pm

CRC Tests

Test	Status	Time
COMP	Pass	12:20pm
CAL	Pass	12:20pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County NASH Instrument Location ROCKY MOUNT PD
Instrument Serial No. 008740 #1 Government Pl. Rocky Mount, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Stokes Buenos
Signature of Certifying Official

662
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

NASH COUNTY ROCKY MOUNT PD 630

Serial Number: 008740
Test Date: 04/15/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: BARNES, STOKES
Permit Number: 11434E
Effective:
04/01/2019-04/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG919902
Exp Date: 07/18/2021

Test	g/210L	Time
DIAG	Pass	10:56am
AIR BLK	.00	10:56am
ACCY CHK	.07	10:57am
AIR BLK	.00	10:58am
SUB TEST	.00	10:59am
AIR BLK	.00	11:00am
SUB TEST	.00	11:01am
AIR BLK	.00	11:02am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

NASH COUNTY ROCKY MOUNT PD 630

Serial Number: 008740 Test Record Number: 742
Test Date: 04/15/2020 Test Time: 11:02am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:03am
FLO	Pass	11:03am
FC	Pass	11:03am

Temperature Tests

Test	Status	Time
FC1	Pass	11:03am
SRC	Pass	11:03am
DET	Pass	11:03am
BAR	Pass	11:03am
BT	Pass	11:03am

Blank Tests

Test	Status	Time
AIR	Pass	11:03am

Printer Tests

Test	Status	Time
PRNT	Pass	11:03am

CRC Tests

Test	Status	Time
COMP	Pass	11:04am
CAL	Pass	11:04am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County NASH Instrument Location ROCKY MOUNT PD

Instrument Serial No. 008741 #1 Government PL Rocky Mount, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

662
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

NASH COUNTY ROCKY MOUNT PD 630

Serial Number: 008741
Test Date: 04/15/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: BARNES, STOKES
Permit Number: 11434E
Effective:
04/01/2019-04/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG919902
Exp Date: 07/18/2021

Test	g/210L	Time
DIAG	Pass	10:57am
AIR BLK	.00	10:58am
ACCY CHK	.07	10:58am
AIR BLK	.00	10:59am
SUB TEST	.00	11:00am
AIR BLK	.00	11:01am
SUB TEST	.00	11:02am
AIR BLK	.00	11:03am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

NASH COUNTY ROCKY MOUNT PD 630

Serial Number: 008741 Test Record Number: 2554
Test Date: 04/15/2020 Test Time: 11:03am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:04am
FLO	Pass	11:04am
FC	Pass	11:04am

Temperature Tests

Test	Status	Time
FC1	Pass	11:04am
SRC	Pass	11:04am
DET	Pass	11:04am
BAR	Pass	11:04am
BT	Pass	11:04am

Blank Tests

Test	Status	Time
AIR	Pass	11:05am

Printer Tests

Test	Status	Time
PRNT	Pass	11:05am

CRC Tests

Test	Status	Time
COMP	Pass	11:05am
CAL	Pass	11:05am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County NEW HANOVER Instrument Location NEW HANOVER Co
Instrument Serial No. 008617 DETENTION CENTER

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 17 day of APRIL, 20 20 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. B...
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

NEW HANOVER COUNTY DETENTION CENTER
640

Serial Number: 008617
Test Date: 04/17/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R
Permit Number: 15671E
Effective:
06/01/2019-06/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG934001
Exp Date: 12/06/2021

Test	g/210L	Time
DIAG	Pass	9:40am
AIR BLK	.00	9:40am
ACCY CHK	.08	9:41am
AIR BLK	.00	9:42am
SUB TEST	.00	9:42am
AIR BLK	.00	9:43am
SUB TEST	.00	9:45am
AIR BLK	.00	9:46am

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

NEW HANOVER COUNTY DETENTION CENTER 640

Serial Number: 008617 Test Record Number: 3200
Test Date: 04/17/2020 Test Time: 9:47am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	9:47am
FLO	Pass	9:47am
FC	Pass	9:48am

Temperature Tests

Test	Status	Time
FC1	Pass	9:48am
SRC	Pass	9:48am
DET	Pass	9:48am
BAR	Pass	9:48am
BT	Pass	9:48am

Blank Tests

Test	Status	Time
AIR	Pass	9:48am

Printer Tests

Test	Status	Time
PRNT	Pass	9:48am

CRC Tests

Test	Status	Time
COMP	Pass	9:48am
CAL	Pass	9:48am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County NEW HANOVER Instrument Location NEW HANOVER CO

Instrument Serial No. 008676 DETENTION CENTER

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 17 day of APRIL, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. Bona
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

NEW HANOVER COUNTY DETENTION CENTER
640

Serial Number: 008626
Test Date: 04/17/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R
Permit Number: 15671E
Effective:
06/01/2019-06/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG934001
Exp Date: 12/06/2021

Test	g/210L	Time
DIAG	Pass	9:34am
AIR BLK	.00	9:35am
ACCY CHK	.08	9:35am
AIR BLK	.00	9:36am
SUB TEST	.00	9:37am
AIR BLK	.00	9:38am
SUB TEST	.00	9:39am
AIR BLK	.00	9:40am

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

NEW HANOVER COUNTY DETENTION CENTER 640

Serial Number: 008626 Test Record Number: 7734
Test Date: 04/17/2020 Test Time: 9:41am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	9:41am
FLO	Pass	9:41am
FC	Pass	9:42am

Temperature Tests

Test	Status	Time
FC1	Pass	9:42am
SRC	Pass	9:42am
DET	Pass	9:42am
BAR	Pass	9:42am
BT	Pass	9:42am

Blank Tests

Test	Status	Time
AIR	Pass	9:42am

Printer Tests

Test	Status	Time
PRNT	Pass	9:42am

CRC Tests

Test	Status	Time
COMP	Pass	9:43am
CAL	Pass	9:43am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County NEW HAMNOVER Instrument Location WILMINGTON

Instrument Serial No. 008629 POLICE DEPT

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16 day of APRIL, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. Basso
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

NEW HANOVER COUNTY WILMINGTON PD 640

Serial Number: 008628
Test Date: 04/16/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R
Permit Number: 15671E
Effective:
06/01/2019-06/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG934001
Exp Date: 12/06/2021

Test	g/210L	Time
DIAG	Pass	3:45pm
AIR BLK	.00	3:46pm
ACCY CHK	.08	3:46pm
AIR BLK	.00	3:47pm
SUB TEST	.00	3:48pm
AIR BLK	.00	3:49pm
SUB TEST	.00	3:50pm
AIR BLK	.00	3:51pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

NEW HANOVER COUNTY WILMINGTON PD 640

Serial Number: 008628 Test Record Number: 5265

Test Date: 04/16/2020 Test Time: 3:53pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:53pm
FLO	Pass	3:53pm
FC	Pass	3:53pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:53pm
SRC	Pass	3:53pm
DET	Pass	3:53pm
BAR	Pass	3:53pm
BT	Pass	3:53pm

Blank Tests

Test	Status	Time
AIR	Pass	3:54pm

Printer Tests


Test	Status	Time
PRNT	Pass	3:54pm

CRC Tests

Test	Status	Time
COMP	Pass	3:54pm
CAL	Pass	3:54pm

Preventive Maintenance

Status: Pass



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County NEW HANOVER Instrument Location WRIGHTSVILLE BEACH
Instrument Serial No. 0086667 POLICE DEPT.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16 day of APRIL, 20 20 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. B...
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

NEW HANOVER COUNTY WRIGHTSVILLE BCH PD
640

Serial Number: 008667
Test Date: 04/16/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R

Permit Number: 15671E

Effective:

06/01/2019-06/01/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG934001


Exp Date: 12/06/2021

Test	g/210L	Time
DIAG	Pass	1:28pm
AIR BLK	.00	1:29pm
ACCY CHK	.08	1:30pm
AIR BLK	.00	1:31pm
SUB TEST	.00	1:31pm
AIR BLK	.00	1:32pm
SUB TEST	.00	1:34pm
AIR BLK	.00	1:34pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

NEW HANOVER COUNTY WRIGHTSVILLE BCH PD 640

Serial Number: 008667 Test Record Number: 1980
Test Date: 04/16/2020 Test Time: 1:38pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:38pm
FLO	Pass	1:38pm
FC	Pass	1:38pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:38pm
SRC	Pass	1:38pm
DET	Pass	1:38pm
BAR	Pass	1:38pm
BT	Pass	1:38pm

Blank Tests

Test	Status	Time
AIR	Pass	1:39pm

Printer Tests

Test	Status	Time
PRNT	Pass	1:39pm

CRC Tests

Test	Status	Time
COMP	Pass	1:39pm
CAL	Pass	1:39pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Northampton Instrument Location Northampton Co. S.D.

Instrument Serial No. 008607 105 W. Jefferson St Jackson NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Handwritten Signature]

Signature of Certifying Official

642

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

NORTHAMPTON COUNTY SHERIFFS DEPARTMENT
650

Serial Number: 008607
Test Date: 04/15/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: BARNES, STOKES
Permit Number: 11434E
Effective:
04/01/2019-04/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG919902
Exp Date: 07/18/2021

Test	g/210L	Time
DIAG	Pass	1:39pm
AIR BLK	.00	1:40pm
ACCY CHK	.07	1:41pm
AIR BLK	.00	1:42pm
SUB TEST	.00	1:42pm
AIR BLK	.00	1:43pm
SUB TEST	.00	1:45pm
AIR BLK	.00	1:46pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

NORTHAMPTON COUNTY SHERIFFS DEPARTMENT 650

Serial Number: 008607 Test Record Number: 1035
Test Date: 04/15/2020 Test Time: 1:46pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:46pm
FLO	Pass	1:46pm
FC	Pass	1:47pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:47pm
SRC	Pass	1:47pm
DET	Pass	1:47pm
BAR	Pass	1:47pm
BT	Pass	1:47pm

Blank Tests

Test	Status	Time
AIR	Pass	1:47pm


Printer Tests

Test	Status	Time
PRNT	Pass	1:47pm

CRC Tests

Test	Status	Time
COMP	Pass	1:47pm
CAL	Pass	1:47pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Northampton Instrument Location Northampton Co. 50

Instrument Serial No. 008688 105 W. Jefferson St Jackson, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Stokes Brown
Signature of Certifying Official

662
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

NORTHAMPTON COUNTY SHERIFFS DEPARTMENT
650

Serial Number: 008688
Test Date: 04/15/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BARNES, STOKES
Permit Number: 11434E
Effective:
04/01/2019-04/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG919902
Exp Date: 07/18/2021

Test	g/210L	Time
DIAG	Pass	1:40pm
AIR BLK	.00	1:41pm
ACCY CHK	.07	1:41pm
AIR BLK	.00	1:42pm
SUB TEST	.00	1:43pm
AIR BLK	.00	1:44pm
SUB TEST	.00	1:45pm
AIR BLK	.00	1:46pm

Reported AC: 00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

NORTHAMPTON COUNTY SHERIFFS DEPARTMENT 650

Serial Number: 008688 Test Record Number: 856
Test Date: 04/15/2020 Test Time: 1:47pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:47pm
FLO	Pass	1:47pm
FC	Pass	1:47pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:48pm
SRC	Pass	1:48pm
DET	Pass	1:48pm
BAR	Pass	1:48pm
BT	Pass	1:48pm

Blank Tests

Test	Status	Time
AIR	Pass	1:48pm

Printer Tests

Test	Status	Time
PRNT	Pass	1:48pm

CRC Tests

Test	Status	Time
COMP	Pass	1:48pm
CAL	Pass	1:48pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County ONslow Instrument Location MCA5 NEW RIVER
Instrument Serial No. 008901 PMO

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 9 day of APRIL, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. B...
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

ONSLOW COUNTY MCAS NEW RIVER 660

Serial Number: 008901
Test Date: 04/09/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R
Permit Number: 15671E
Effective:
06/01/2019-06/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG934001
Exp Date: 12/06/2021

Test	g/210L	Time
DIAG	Pass	1:18pm
AIR BLK	.00	1:18pm
ACCY CHK	.08	1:19pm
AIR BLK	.00	1:20pm
SUB TEST	.00	1:21pm
AIR BLK	.00	1:22pm
SUB TEST	.00	1:23pm
AIR BLK	.00	1:24pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

ONslow COUNTY MCAS NEW RIVER 660

Serial Number: 008901 Test Record Number: 1237
Test Date: 04/09/2020 Test Time: 1:25pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:25pm
FLO	Pass	1:25pm
FC	Pass	1:25pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:26pm
SRC	Pass	1:26pm
DET	Pass	1:26pm
BAR	Pass	1:26pm
BT	Pass	1:26pm

Blank Tests

Test	Status	Time
AIR	Pass	1:26pm


Printer Tests

Test	Status	Time
PRNT	Pass	1:26pm

CRC Tests

Test	Status	Time
COMP	Pass	1:26pm
CAL	Pass	1:26pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County ONSLAW Instrument Location CAMP LEJEUNE

Instrument Serial No. 008920 PMO

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of APRIL, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. Bowers
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

ONslow COUNTY CAMP LEJEUNE PMO 660

Serial Number: 008920

Test Date: 04/13/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R

Permit Number: 15671E

Effective:

06/01/2019-06/01/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG919901


Exp Date: 07/18/2021

Test	g/210L	Time
DIAG	Pass	1:40pm
AIR BLK	.00	1:40pm
ACCY CHK	.08	1:41pm
AIR BLK	.00	1:42pm
SUB TEST	.00	1:43pm
AIR BLK	.00	1:43pm
SUB TEST	.00	1:45pm
AIR BLK	.00	1:46pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

ONSLOW COUNTY CAMP LEJEUNE PMO 660

Serial Number: 008920 Test Record Number: 1791

Test Date: 04/13/2020 Test Time: 1:47pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:47pm
FLO	Pass	1:47pm
FC	Pass	1:47pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:47pm
SRC	Pass	1:47pm
DET	Pass	1:47pm
BAR	Pass	1:47pm
BT	Pass	1:47pm

Blank Tests

Test	Status	Time
AIR	Pass	1:48pm


Printer Tests

Test	Status	Time
PRNT	Pass	1:48pm

CRC Tests

Test	Status	Time
COMP	Pass	1:48pm
CAL	Pass	1:48pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County ONslow Instrument Location ONslow COUNTY
Instrument Serial No. 008931 DETENTION CENTER

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 09 day of APRIL, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. Bunn
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

ONSLOW COUNTY DETENTION CENTER 660

Serial Number: 008931
Test Date: 04/09/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R
Permit Number: 15671E
Effective:
06/01/2019-06/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG934001
Exp Date: 12/06/2021

Test	g/210L	Time
DIAG	Pass	3:42pm
AIR BLK	.00	3:43pm
ACCY CHK	.07	3:43pm
AIR BLK	.00	3:44pm
SUB TEST	.00	3:45pm
AIR BLK	.00	3:46pm
SUB TEST	.00	3:47pm
AIR BLK	.00	3:48pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

ONslow COUNTY DETENTION CENTER 660

Serial Number: 008931 Test Record Number: 3288
Test Date: 04/09/2020 Test Time: 3:49pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:49pm
FLO	Pass	3:49pm
FC	Pass	3:50pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:50pm
SRC	Pass	3:50pm
DET	Pass	3:50pm
BAR	Pass	3:50pm
BT	Pass	3:50pm

Blank Tests

Test	Status	Time
AIR	Pass	3:50pm


Printer Tests

Test	Status	Time
PRNT	Pass	3:50pm

CRC Tests

Test	Status	Time
COMP	Pass	3:51pm
CAL	Pass	3:51pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County ONSGLOW Instrument Location ONSGLOW COUNTY
Instrument Serial No. 008932 DETENTION CENTER

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 09 day of APRIL, 20 20, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. B...
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

ONslow COUNTY DETENTION CENTER 660

Serial Number: 008932
Test Date: 04/09/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R
Permit Number: 15671E
Effective:
06/01/2019-06/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG934001
Exp Date: 12/06/2021

Test	g/210L	Time
DIAG	Pass	3:44pm
AIR BLK	.00	3:45pm
ACCY CHK	.08	3:46pm
AIR BLK	.00	3:47pm
SUB TEST	.00	3:47pm
AIR BLK	.00	3:48pm
SUB TEST	.00	3:50pm
AIR BLK	.00	3:51pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

ONslow COUNTY DETENTION CENTER 660

Serial Number: 008932 Test Record Number: 5510
Test Date: 04/09/2020 Test Time: 3:51pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:52pm
FLO	Pass	3:52pm
FC	Pass	3:52pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:52pm
SRC	Pass	3:52pm
DET	Pass	3:52pm
BAR	Pass	3:52pm
BT	Pass	3:52pm

Blank Tests

Test	Status	Time
AIR	Pass	3:52pm


Printer Tests

Test	Status	Time
PRNT	Pass	3:52pm

CRC Tests

Test	Status	Time
COMP	Pass	3:53pm
CAL	Pass	3:53pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County PRANCE Instrument Location Hillsborough PD

Instrument Serial No. 008799 127 N. Churton St Hillsborough, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

662
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

ORANGE COUNTY HILLSBOROUGH PD 670

Serial Number: 008799
Test Date: 04/13/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BARNES, STOKES
Permit Number: 11434E
Effective:
04/01/2019-04/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG920301
Exp Date: 07/22/2021

Test	g/210L	Time
DIAG	Pass	3:33pm
AIR BLK	.00	3:34pm
ACCY CHK	.08	3:35pm
AIR BLK	.00	3:36pm
SUB TEST	.00	3:36pm
AIR BLK	.00	3:37pm
SUB TEST	.00	3:39pm
AIR BLK	.00	3:40pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

ORANGE COUNTY HILLSBOROUGH PD 670

Serial Number: 008799 Test Record Number: 3190
Test Date: 04/13/2020 Test Time: 3:40pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:41pm
FLO	Pass	3:41pm
FC	Pass	3:41pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:41pm
SRC	Pass	3:41pm
DET	Pass	3:41pm
BAR	Pass	3:41pm
BT	Pass	3:41pm

Blank Tests

Test	Status	Time
AIR	Pass	3:42pm

Printer Tests

Test	Status	Time
PRNT	Pass	3:42pm

CRC Tests

Test	Status	Time
COMP	Pass	3:42pm
CAL	Pass	3:42pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County ORANGE

Instrument Location Chapel Hill PD

Instrument Serial No. 005456

828 Martin Luther King Blvd
Chapel Hill NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14 day of April, 20 20 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Stokes Barnes

Signature of Certifying Official

662

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

ORANGE COUNTY CHAPEL HILL PD 670

Serial Number: 008856
Test Date: 04/14/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: BARNES, STOKES
Permit Number: 11434E
Effective:
04/01/2019-04/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG933703
Exp Date: 12/03/2021

Test	g/210L	Time
DIAG	Pass	11:10am
AIR BLK	.00	11:11am
ACCY CHK	.08	11:12am
AIR BLK	.00	11:13am
SUB TEST	.00	11:13am
AIR BLK	.00	11:14am
SUB TEST	.00	11:16am
AIR BLK	.00	11:17am

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

ORANGE COUNTY CHAPEL HILL PD 670

Serial Number: 008856 Test Record Number: 2615
Test Date: 04/14/2020 Test Time: 11:18am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:18am
FLO	Pass	11:18am
FC	Pass	11:19am

Temperature Tests

Test	Status	Time
FC1	Pass	11:19am
SRC	Pass	11:19am
DET	Pass	11:19am
BAR	Pass	11:19am
BT	Pass	11:19am

Blank Tests

Test	Status	Time
AIR	Pass	11:19am

Printer Tests

Test	Status	Time
PRNT	Pass	11:19am

CRC Tests

Test	Status	Time
COMP	Pass	11:19am
CAL	Pass	11:19am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Pasquotank Instrument Location Pasquotank Co Public

Instrument Serial No. 008950 Safety Bldg., 200 E. Colonial St.,
Elizabeth City N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 9th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

**PASQUOTANK COUNTY PUBLIC SAFETY BLDG
690**

Serial Number: 008950
Test Date: 04/09/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: Keesler, Linda A
Permit Number: 0045-5468
Effective:
07/08/2019-07/08/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG920301
Exp Date: 07/22/2021


Test	g/210L	Time
DIAG	Pass	12:28pm
AIR BLK	.00	12:28pm
ACCY CHK	.08	12:29pm
AIR BLK	.00	12:30pm
SUB TEST	.00	12:30pm
AIR BLK	.00	12:31pm
SUB TEST	.00	12:33pm
AIR BLK	.00	12:33pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

PASQUOTANK COUNTY PUBLIC SAFETY BLDG 690

Serial Number: 008950 Test Record Number: 1765
Test Date: 04/09/2020 Test Time: 12:34pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:34pm
FLO	Pass	12:34pm
FC	Pass	12:34pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:34pm
SRC	Pass	12:34pm
DET	Pass	12:34pm
BAR	Pass	12:34pm
BT	Pass	12:34pm

Blank Tests

Test	Status	Time
AIR	Pass	12:35pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:35pm

CRC Tests

Test	Status	Time
COMP	Pass	12:35pm
CAL	Pass	12:35pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County PENDER Instrument Location PENDER COUNTY
Instrument Serial No. 008935 DETENTION CENTER

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15 day of APRIL, 20 20, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. Benson
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

PENDER COUNTY DETENTION CENTER 700

Serial Number: 008935

Test Date: 04/15/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R

Permit Number: 15671E

Effective:

06/01/2019-06/01/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG934001


Exp Date: 12/06/2021

Test	g/210L	Time
DIAG	Pass	11:14am
AIR BLK	.00	11:15am
ACCY CHK	.07	11:15am
AIR BLK	.00	11:16am
SUB TEST	.00	11:17am
AIR BLK	.00	11:18am
SUB TEST	.00	11:20am
AIR BLK	.00	11:21am

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

PENDER COUNTY DETENTION CENTER 700

Serial Number: 008935 Test Record Number: 2624
Test Date: 04/15/2020 Test Time: 11:24am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:24am
FLO	Pass	11:24am
FC	Pass	11:24am

Temperature Tests

Test	Status	Time
FC1	Pass	11:24am
SRC	Pass	11:24am
DET	Pass	11:24am
BAR	Pass	11:24am
BT	Pass	11:24am

Blank Tests

Test	Status	Time
AIR	Pass	11:25am

Printer Tests

Test	Status	Time
PRNT	Pass	11:25am

CRC Tests

Test	Status	Time
COMP	Pass	11:25am
CAL	Pass	11:25am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County PENDER Instrument Location PENDER COUNTY
Instrument Serial No. 008946 DETENTION CENTER

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15 day of APRIL, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. Bane
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

PENDER COUNTY DETENTION CENTER 700

Serial Number: 008946
Test Date: 04/15/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R
Permit Number: 15671E
Effective:
06/01/2019-06/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG934001
Exp Date: 12/06/2021

Test	g/210L	Time
DIAG	Pass	11:37am
AIR BLK	.00	11:38am
ACCY CHK	.08	11:39am
AIR BLK	.00	11:40am
SUB TEST	.00	11:41am
AIR BLK	.00	11:42am
SUB TEST	.00	11:44am
AIR BLK	.00	11:44am

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

PENDER COUNTY DETENTION CENTER 700

Serial Number: 008946 Test Record Number: 1084
Test Date: 04/15/2020 Test Time: 11:46am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:46am
FLO	Pass	11:46am
FC	Pass	11:46am

Temperature Tests

Test	Status	Time
FC1	Pass	11:46am
SRC	Pass	11:46am
DET	Pass	11:46am
BAR	Pass	11:46am
BT	Pass	11:46am

Blank Tests

Test	Status	Time
AIR	Pass	11:47am


Printer Tests

Test	Status	Time
PRNT	Pass	11:47am

CRC Tests

Test	Status	Time
COMP	Pass	11:47am
CAL	Pass	11:47am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County PENDER Instrument Location PENDER COUNTY
Instrument Serial No. 008948 GOVERNMENT ANNEX

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16 day of APRIL, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. B.
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

PENDER COUNTY GOVERNMENT ANNEX 700

Serial Number: 008948
Test Date: 04/16/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R
Permit Number: 15671E
Effective:
06/01/2019-06/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG934001
Exp Date: 12/06/2021

Test	g/210L	Time
DIAG	Pass	12:04pm
AIR BLK	.00	12:05pm
ACCY CHK	.08	12:05pm
AIR BLK	.00	12:06pm
SUB TEST	.00	12:06pm
AIR BLK	.00	12:07pm
SUB TEST	.00	12:09pm
AIR BLK	.00	12:10pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

PENDER COUNTY GOVERNMENT ANNEX 700

Serial Number: 008948 Test Record Number: 992
Test Date: 04/16/2020 Test Time: 12:10pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:11pm
FLO	Pass	12:11pm
FC	Pass	12:11pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:11pm
SRC	Pass	12:11pm
DET	Pass	12:11pm
BAR	Pass	12:11pm
BT	Pass	12:11pm

Blank Tests

Test	Status	Time
AIR	Pass	12:11pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:12pm

CRC Tests

Test	Status	Time
COMP	Pass	12:12pm
CAL	Pass	12:12pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Perguimans Instrument Location Perguimans Co. S.O.
Instrument Serial No. 008921 110 N. Church St., Hartford, NC.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 9th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]

Signature of Certifying Official

643

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

PERQUIMANS COUNTY PERQUIMANS CO SO 710

Serial Number: 008921
Test Date: 04/09/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: GUARD, KELLY G
Permit Number: 12955E
Effective:
06/01/2019-06/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG919901
Exp Date: 07/18/2021


Test	g/210L	Time
DIAG	Pass	1:48pm
AIR BLK	.00	1:49pm
ACCY CHK	.08	1:50pm
AIR BLK	.00	1:51pm
SUB TEST	.00	1:51pm
AIR BLK	.00	1:52pm
SUB TEST	.00	1:54pm
AIR BLK	.00	1:55pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

PERQUIMANS COUNTY PERQUIMANS CO SO 710

Serial Number: 008921 Test Record Number: 929
Test Date: 04/09/2020 Test Time: 1:56pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:56pm
FLO	Pass	1:56pm
FC	Pass	1:56pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:56pm
SRC	Pass	1:56pm
DET	Pass	1:56pm
BAR	Pass	1:56pm
BT	Pass	1:56pm

Blank Tests

Test	Status	Time
AIR	Pass	1:57pm

Printer Tests

Test	Status	Time
PRNT	Pass	1:57pm

CRC Tests

Test	Status	Time
COMP	Pass	1:57pm
CAL	Pass	1:57pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Person Instrument Location Person Co LEC
Instrument Serial No. 008693 120 Court St Roxboro, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

642
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

PERSON COUNTY PERSON CO. LEC 720

Serial Number: 008693
Test Date: 04/16/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BARNES, STOKES
Permit Number: 11434E
Effective:
04/01/2019-04/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG821801
Exp Date: 08/06/2020

Test	g/210L	Time
DIAG	Pass	4:22pm
AIR BLK	.00	4:23pm
ACCY CHK	.07	4:23pm
AIR BLK	.00	4:24pm
SUB TEST	.00	4:25pm
AIR BLK	.00	4:26pm
SUB TEST	.00	4:27pm
AIR BLK	.00	4:28pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

PERSON COUNTY PERSON CO. LEC 720

Serial Number: 008693 Test Record Number: 1680
Test Date: 04/16/2020 Test Time: 4:28pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	4:29pm
FLO	Pass	4:29pm
FC	Pass	4:29pm

Temperature Tests

Test	Status	Time
FC1	Pass	4:29pm
SRC	Pass	4:29pm
DET	Pass	4:29pm
BAR	Pass	4:29pm
BT	Pass	4:29pm

Blank Tests

Test	Status	Time
AIR	Pass	4:30pm


Printer Tests

Test	Status	Time
PRNT	Pass	4:30pm

CRC Tests

Test	Status	Time
COMP	Pass	4:30pm
CAL	Pass	4:30pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Person Instrument Location Person Co LEC

Instrument Serial No. 008880 120 Court St. Roxboro, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

662
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

PERSON COUNTY PERSON CO. LEC 720

Serial Number: 008880
Test Date: 04/16/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: BARNES, STOKES
Permit Number: 11434E
Effective:
04/01/2019-04/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG821801
Exp Date: 08/06/2020

Test	g/210L	Time
DIAG	Pass	4:22pm
AIR BLK	.00	4:23pm
ACCY CHK	.08	4:24pm
AIR BLK	.00	4:25pm
SUB TEST	.00	4:25pm
AIR BLK	.00	4:26pm
SUB TEST	.00	4:27pm
AIR BLK	.00	4:28pm

Reported AC: 00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

PERSON COUNTY PERSON CO. LEC 720

Serial Number: 008880 Test Record Number: 1587
Test Date: 04/16/2020 Test Time: 4:29pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	4:29pm
FLO	Pass	4:29pm
FC	Pass	4:29pm

Temperature Tests

Test	Status	Time
FC1	Pass	4:29pm
SRC	Pass	4:29pm
DET	Pass	4:29pm
BAR	Pass	4:29pm
BT	Pass	4:29pm

Blank Tests

Test	Status	Time
AIR	Pass	4:30pm

Printer Tests

Test	Status	Time
PRNT	Pass	4:30pm

CRC Tests

Test	Status	Time
COMP	Pass	4:30pm
CAL	Pass	4:30pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Pitt Instrument Location Pitt Co. Detention Center

Instrument Serial No. 008646 124 New Hope Rd., Greenville, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

1043
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

PITT COUNTY PITT CO DETENTION 730

Serial Number: 008646
Test Date: 04/13/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: GUARD, KELLY G
Permit Number: 12955E
Effective:
06/01/2019-06/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG902201
Exp Date: 01/22/2021

Test	g/210L	Time
DIAG	Pass	2:36pm
AIR BLK	.00	2:36pm
ACCY CHK	.08	2:37pm
AIR BLK	.00	2:38pm
SUB TEST	.00	2:39pm
AIR BLK	.00	2:40pm
SUB TEST	.00	2:42pm
AIR BLK	.00	2:42pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

PITT COUNTY PITT CO DETENTION 730

Serial Number: 008646 Test Record Number: 3999
Test Date: 04/13/2020 Test Time: 2:44pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:44pm
FLO	Pass	2:44pm
FC	Pass	2:44pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:44pm
SRC	Pass	2:44pm
DET	Pass	2:44pm
BAR	Pass	2:44pm
BT	Pass	2:44pm

Blank Tests

Test	Status	Time
AIR	Pass	2:45pm

Printer Tests

Test	Status	Time
PRNT	Pass	2:45pm

CRC Tests

Test	Status	Time
COMP	Pass	2:45pm
CAL	Pass	2:45pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Pitt Instrument Location Pitt Detention Center
Instrument Serial No. 008662 124 New Hope Rd, Greenville, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature] Signature of Certifying Official 643 Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

PITT COUNTY PITT CO DETENTION 730

Serial Number: 008662
Test Date: 04/13/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: GUARD, KELLY G
Permit Number: 12955E
Effective:
06/01/2019-06/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG902201
Exp Date: 01/22/2021


Test	g/210L	Time
DIAG	Pass	3:06pm
AIR BLK	.00	3:07pm
ACCY CHK	.08	3:07pm
AIR BLK	.00	3:08pm
SUB TEST	.00	3:09pm
AIR BLK	.00	3:10pm
SUB TEST	.00	3:11pm
AIR BLK	.00	3:12pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

PITT COUNTY PITT CO DETENTION 730

Serial Number: 008662 Test Record Number: 1153
Test Date: 04/13/2020 Test Time: 3:13pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:14pm
FLO	Pass	3:14pm
FC	Pass	3:14pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:14pm
SRC	Pass	3:14pm
DET	Pass	3:14pm
BAR	Pass	3:14pm
BT	Pass	3:14pm

Blank Tests

Test	Status	Time
AIR	Pass	3:15pm


Printer Tests

Test	Status	Time
PRNT	Pass	3:15pm

CRC Tests

Test	Status	Time
COMP	Pass	3:15pm
CAL	Pass	3:15pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Pitt Instrument Location Ayden P.D.
Instrument Serial No. 17D 86666 4144 West Ave., Ayden, NC.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature] Signature of Certifying Official 643 Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

FITT AYDEN PD 730

Serial Number: 008666
Test Date: 04/16/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: GUARD, KELLY G

Permit Number: 12955E

Effective:

06/01/2019-06/01/2021

Officer's Name: NONE, NCNE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG007601

Exp Date: 03/16/2022

Test	g/210L	Time
DIAG	Pass	3:07pm
AIR BLK	.00	3:07pm
ACCY CHK	.08	3:08pm
AIR BLK	.00	3:09pm
SUB TEST	.00	3:10pm
AIR BLK	.00	3:11pm
SUB TEST	.00	3:12pm
AIR BLK	.00	3:13pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

PITT AYDEN PD 730

Serial Number: 008666 Test Record Number: 1170
Test Date: 04/16/2020 Test Time: 3:14pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:14pm
FLO	Pass	3:14pm
FC	Pass	3:15pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:15pm
SRC	Pass	3:15pm
DET	Pass	3:15pm
BAR	Pass	3:15pm
BT	Pass	3:15pm

Blank Tests

Test	Status	Time
AIR	Pass	3:15pm

Printer Tests

Test	Status	Time
PRNT	Pass	3:15pm

CRC Tests

Test	Status	Time
COMP	Pass	3:16pm
CAL	Pass	3:16pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Polk Instrument Location Polk County LEC
Instrument Serial No. 008832

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 2 day of April, 20 20 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

656
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

POLK COUNTY POLK COUNTY LEC 740

Serial Number: C08832
Test Date: 04/02/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: Hays, Mark D
Permit Number: 0011-3099
Effective:
11/13/2019-11/13/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG007601
Exp Date: 03/16/2022

Test	g/210L	Time
DIAG	Pass	12:53pm
AIR BLK	.00	12:54pm
ACCY CHK	.07	12:55pm
AIR BLK	.00	12:56pm
SUB TEST	.00	12:57pm
AIR BLK	.00	12:58pm
SUB TEST	.00	12:59pm
AIR BLK	.00	1:00pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

POLK COUNTY POLK COUNTY LEC 740

Serial Number: 008832 Test Record Number: 1564
Test Date: 04/02/2020 Test Time: 1:02pm EDT

System Check: Passed

Baseline Tests

Test	Status	Time
IR	Pass	1:03pm
FLO	Pass	1:03pm
FC	Pass	1:03pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:03pm
SRC	Pass	1:03pm
DET	Pass	1:03pm
BAR	Pass	1:03pm
BT	Pass	1:03pm

Blank Tests

Test	Status	Time
AIR	Pass	1:04pm

Printer Tests

Test	Status	Time
PRNT	Pass	1:04pm

CRC Tests

Test	Status	Time
COMP	Pass	1:04pm
CAL	Pass	1:04pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Polk Instrument Location Polk County LEC
Instrument Serial No. 008881

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14 day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

656
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

POLK COUNTY POLK COUNTY LEC 740

Serial Number: 008881
Test Date: 04/14/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: Hays, Mark D
Permit Number: 0011-3099
Effective:
11/13/2019-11/13/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG821401
Exp Date: 08/02/2020

Test	g/210L	Time
DIAG	Pass	12:11pm
AIR BLK	.00	12:12pm
ACCY CHK	.08	12:13pm
AIR BLK	.00	12:14pm
SUB TEST	.00	12:14pm
AIR BLK	.00	12:15pm
SUB TEST	.00	12:17pm
AIR BLK	.00	12:18pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

POLK COUNTY POLK COUNTY LEC 740

Serial Number: 008881 Test Record Number: 885
Test Date: 04/14/2020 Test Time: 12:23pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:23pm
FLO	Pass	12:23pm
FC	Pass	12:23pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:23pm
SRC	Pass	12:23pm
DET	Pass	12:23pm
BAR	Pass	12:23pm
BT	Pass	12:23pm

Blank Tests

Test	Status	Time
AIR	Pass	12:24pm

Printer Tests

Test	Status	Time
PRNT	Pass	12:24pm

CRC Tests

Test	Status	Time
COMP	Pass	12:24pm
CAL	Pass	12:24pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Randolph Co. Instrument Location Archdale Police Dept.
Instrument Serial No. 008191 Archdale, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

654
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

RANDOLPH COUNTY ARCHDALE PD 750

Serial Number: 008791
Test Date: 04/15/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: Keesler, Grayham C
Permit Number: 0045-5487
Effective:
11/04/2019-11/04/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG933703
Exp Date: 12/03/2021


Test	g/210L	Time
DIAG	Pass	12:49pm
AIR BLK	.00	12:50pm
ACCY CHK	.08	12:51pm
AIR BLK	.00	12:52pm
SUB TEST	.00	12:52pm
AIR BLK	.00	12:53pm
SUB TEST	.00	12:55pm
AIR BLK	.00	12:56pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

RANDOLPH COUNTY ARCHDALE PD 750

Serial Number: 008791 Test Record Number: 1381
Test Date: 04/15/2020 Test Time: 12:56pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:57pm
FLO	Pass	12:57pm
FC	Pass	12:57pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:57pm
SRC	Pass	12:57pm
DET	Pass	12:57pm
BAR	Pass	12:57pm
BT	Pass	12:57pm

Blank Tests

Test	Status	Time
AIR	Pass	12:58pm

Printer Tests

Test	Status	Time
PRNT	Pass	12:58pm

CRC Tests

Test	Status	Time
COMP	Pass	12:58pm
CAL	Pass	12:58pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Richmond Co. Instrument Location Richmond Co. W/State office

Instrument Serial No. 108101 Rockingham, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

654
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

RICHMOND COUNTY MAGISTRATE'S OFFICE
760

Serial Number: 008701
Test Date: 04/16/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: Keesler, Grayham C
Permit Number: 0045-5487
Effective:
11/04/2019-11/04/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG934001
Exp Date: 12/06/2021


Test	g/210L	Time
DIAG	Pass	1:26pm
AIR BLK	.00	1:26pm
ACCY CHK	.08	1:27pm
AIR BLK	.00	1:28pm
SUB TEST	.00	1:29pm
AIR BLK	.00	1:29pm
SUB TEST	.00	1:31pm
AIR BLK	.00	1:32pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

RICHMOND COUNTY MAGISTRATE'S OFFICE 760

Serial Number: 008701 Test Record Number: 1209
Test Date: 04/16/2020 Test Time: 1:33pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:33pm
FLO	Pass	1:33pm
FC	Pass	1:33pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:34pm
SRC	Pass	1:34pm
DET	Pass	1:34pm
BAR	Pass	1:34pm
BT	Pass	1:34pm

Blank Tests

Test	Status	Time
AIR	Pass	1:34pm


Printer Tests

Test	Status	Time
PRNT	Pass	1:34pm

CRC Tests

Test	Status	Time
COMP	Pass	1:34pm
CAL	Pass	1:34pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Richmond Co. Instrument Location Richmond Co. Magistrate Office
Instrument Serial No. 078840 Rockingham, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

654
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

RICHMOND COUNTY MAGISTRATE'S OFFICE
760

Serial Number: 008840
Test Date: 04/16/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: Keesler, Grayham C
Permit Number: 0045-5487
Effective:
11/04/2019-11/04/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG934001
Exp Date: 12/06/2021

Test	g/210L	Time
DIAG	Pass	1:24pm
AIR BLK	.00	1:25pm
ACCY CHK	.07	1:26pm
AIR BLK	.00	1:27pm
SUB TEST	.00	1:27pm
AIR BLK	.00	1:28pm
SUB TEST	.00	1:30pm
AIR BLK	.00	1:31pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

RICHMOND COUNTY MAGISTRATE'S OFFICE 760

Serial Number: 008840 Test Record Number: 2425
Test Date: 04/16/2020 Test Time: 1:32pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:33pm
FLO	Pass	1:33pm
FC	Pass	1:33pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:33pm
SRC	Pass	1:33pm
DET	Pass	1:33pm
BAR	Pass	1:33pm
BT	Pass	1:33pm

Blank Tests

Test	Status	Time
AIR	Pass	1:33pm


Printer Tests

Test	Status	Time
PRNT	Pass	1:33pm

CRC Tests

Test	Status	Time
COMP	Pass	1:34pm
CAL	Pass	1:34pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Robeson Co. Instrument Location ST Pauls Police Dept.

Instrument Serial No. 0088H ST Pauls, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 17 day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

654
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

ROBESON COUNTY ST PAULS PD 770

Serial Number: 008814
Test Date: 04/17/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: Keesler, Grayham C
Permit Number: 0045-5487
Effective:
11/04/2019-11/04/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG911506
Exp Date: 04/25/2021


Test	g/210L	Time
DIAG	Pass	10:32am
AIR BLK	.00	10:33am
ACCY CHK	.08	10:34am
AIR BLK	.00	10:35am
SUB TEST	.00	10:36am
AIR BLK	.00	10:37am
SUB TEST	.00	10:39am
AIR BLK	.00	10:39am

Reported AC: 00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

ROBESON COUNTY ST PAULS PD 770

Serial Number: 008814 Test Record Number: 691
Test Date: 04/17/2020 Test Time: 10:40am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:40am
FLO	Pass	10:40am
FC	Pass	10:40am

Temperature Tests

Test	Status	Time
FC1	Pass	10:41am
SRC	Pass	10:41am
DET	Pass	10:41am
BAR	Pass	10:41am
BT	Pass	10:41am

Blank Tests

Test	Status	Time
AIR	Pass	10:41am


Printer Tests

Test	Status	Time
PRNT	Pass	10:41am

CRC Tests

Test	Status	Time
COMP	Pass	10:41am
CAL	Pass	10:41am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Robeson Co. Instrument Location Pembroke Police Dept

Instrument Serial No. 008731 Pembroke, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 17th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Handwritten Signature]
Signature of Certifying Official

654
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

ROBESON COUNTY PEMBROKE POLICE DEPT
770

Serial Number: 008837
Test Date: 04/17/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: Keesler, Grayham C
Permit Number: 0045-5487
Effective:
11/04/2019-11/04/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG911506
Exp Date: 04/25/2021

Test	g/210L	Time
DIAG	Pass	12:25pm
AIR BLK	.00	12:26pm
ACCY CHK	.08	12:26pm
AIR BLK	.00	12:27pm
SUB TEST	.00	12:28pm
AIR BLK	.00	12:29pm
SUB TEST	.00	12:30pm
AIR BLK	.00	12:31pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

ROBESON COUNTY PEMBROKE POLICE DEPT 770

Serial Number: 008837 Test Record Number: 1070
Test Date: 04/17/2020 Test Time: 12:32pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:32pm
FLO	Pass	12:32pm
FC	Pass	12:32pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:33pm
SRC	Pass	12:33pm
DET	Pass	12:33pm
BAR	Pass	12:33pm
BT	Pass	12:33pm

Blank Tests

Test	Status	Time
AIR	Pass	12:33pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:33pm

CRC Tests

Test	Status	Time
COMP	Pass	12:33pm
CAL	Pass	12:33pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Robeson Co. Instrument Location Red Springs Police Dept.
Instrument Serial No. 007851 Red Springs

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 11th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

654
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

ROBESON COUNTY RED SPRINGS PD 770

Serial Number: 008857
Test Date: 04/17/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: Keesler, Grayham C
Permit Number: 0045-5487
Effective:
11/04/2019-11/04/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG902201
Exp Date: 01/22/2021

Test	g/210L	Time
DIAG	Pass	11:30am
AIR BLK	.00	11:31am
ACCY CHK	.08	11:31am
AIR BLK	.00	11:33am
SUB TEST	.00	11:34am
AIR BLK	.00	11:35am
SUB TEST	.00	11:36am
AIR BLK	.00	11:37am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

ROBESON COUNTY RED SPRINGS PD 770

Serial Number: 008857 Test Record Number: 583
Test Date: 04/17/2020 Test Time: 11:38am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:38am
FLO	Pass	11:38am
FC	Pass	11:38am

Temperature Tests

Test	Status	Time
FC1	Pass	11:38am
SRC	Pass	11:38am
DET	Pass	11:38am
BAR	Pass	11:38am
BT	Pass	11:38am

Blank Tests

Test	Status	Time
AIR	Pass	11:39am


Printer Tests

Test	Status	Time
PRNT	Pass	11:39am

CRC Tests

Test	Status	Time
COMP	Pass	11:39am
CAL	Pass	11:39am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Rowan Instrument Location Salisbury P.D.

Instrument Serial No. 008835

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Handwritten Signature]
Signature of Certifying Official

659
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

ROWAN COUNTY SALISBURY PD 790

Serial Number: 008835
Test Date: 04/15/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: Ingle, Larry W

Permit Number: 0035-2495

Effective:

01/09/2020-01/09/2022

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG933703

Exp Date: 12/03/2021

Test	g/210L	Time
DIAG	Pass	10:05am
AIR BLK	.00	10:06am
ACCY CHK	.08	10:06am
AIR BLK	.00	10:07am
SUB TEST	.00	10:09am
AIR BLK	.00	10:10am
SUB TEST	.00	10:12am
AIR BLK	.00	10:13am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

ROWAN COUNTY SALISBURY PD 790

Serial Number: 008835 Test Record Number: 2531
Test Date: 04/15/2020 Test Time: 10:16am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:17am
FLO	Pass	10:17am
FC	Pass	10:17am

Temperature Tests

Test	Status	Time
FC1	Pass	10:17am
SRC	Pass	10:17am
DET	Pass	10:17am
BAR	Pass	10:17am
BT	Pass	10:17am

Blank Tests

Test	Status	Time
AIR	Pass	10:18am

Printer Tests

Test	Status	Time
PRNT	Pass	10:18am

CRC Tests

Test	Status	Time
COMP	Pass	10:18am
CAL	Pass	10:18am

Preventive Maintenance

Status: Pass



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Rowan Instrument Location China Grove P.D.
Instrument Serial No. 008862 China Grove, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Handwritten Signature]

Signature of Certifying Official

659

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

ROWAN COUNTY CHINA GROVE PD 790

Serial Number: 008862
Test Date: 04/15/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: Ingle, Larry W
Permit Number: 0035-2495
Effective:
01/09/2020-01/09/2022

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG821401
Exp Date: 08/02/2020

Test	g/210L	Time
DIAG	Pass	11:21am
AIR BLK	.00	11:22am
ACCY CHK	.08	11:22am
AIR BLK	.00	11:24am
SUB TEST	.00	11:24am
AIR BLK	.00	11:25am
SUB TEST	.00	11:26am
AIR BLK	.00	11:28am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

ROWAN COUNTY CHINA GROVE PD 790

Serial Number: 008862 Test Record Number: 895
Test Date: 04/15/2020 Test Time: 11:29am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:30am
FLO	Pass	11:30am
FC	Pass	11:30am

Temperature Tests

Test	Status	Time
FC1	Pass	11:30am
SRC	Pass	11:30am
DET	Pass	11:30am
BAR	Pass	11:30am
BT	Pass	11:30am

Blank Tests

Test	Status	Time
AIR	Pass	11:30am

Printer Tests

Test	Status	Time
PRNT	Pass	11:30am

CRC Tests

Test	Status	Time
COMP	Pass	11:31am
CAL	Pass	11:31am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County ROWAN Instrument Location SAUSBURY P.D.

Instrument Serial No. 008868

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15th day of APRIL, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

659
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

ROWAN COUNTY SALISBURY PD 790

Serial Number: 008868
Test Date: 04/15/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: Ingle, Larry W
Permit Number: 0035-2495
Effective:
01/09/2020-01/09/2022

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG933703
Exp Date: 12/03/2021

Test	g/210L	Time
DIAG	Pass	10:00am
AIR BLK	.00	10:01am
ACCY CHK	.08	10:02am
AIR BLK	.00	10:03am
SUB TEST	.00	10:03am
AIR BLK	.00	10:04am
SUB TEST	.00	10:06am
AIR BLK	.00	10:07am

Reported AC: 00 g/210L

Signature of Chemical Analyst

Court CVR

Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

ROWAN COUNTY SALISBURY PD 790

Serial Number: 008868 Test Record Number: 3111
Test Date: 04/15/2020 Test Time: 10:09am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:10am
FLO	Pass	10:10am
FC	Pass	10:10am

Temperature Tests

Test	Status	Time
FC1	Pass	10:10am
SRC	Pass	10:10am
DET	Pass	10:10am
BAR	Pass	10:10am
BT	Pass	10:10am

Blank Tests

Test	Status	Time
AIR	Pass	10:11am


Printer Tests

Test	Status	Time
PRNT	Pass	10:11am

CRC Tests

Test	Status	Time
COMP	Pass	10:11am
CAL	Pass	10:11am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County SAMPSON Instrument Location SAMPSON COUNTY
Instrument Serial No. 008825 DETENTION CENTER

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15 day of APRIL, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alex R. Bunn
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

SAMPSON COUNTY DETENTION CENTER 810

Serial Number: 008825
Test Date: 04/15/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R
Permit Number: 15671E
Effective:
06/01/2019-06/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG920301
Exp Date: 07/22/2021

Test	g/210L	Time
DIAG	Pass	8:44am
AIR BLK	.00	8:44am
ACCY CHK	.07	8:45am
AIR BLK	.00	8:47am
SUB TEST	.00	8:47am
AIR BLK	.00	8:48am
SUB TEST	.00	8:50am
AIR BLK	.00	8:51am

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

SAMPSON COUNTY DETENTION CENTER 810

Serial Number: 008825 Test Record Number: 2904
Test Date: 04/15/2020 Test Time: 8:52am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	8:52am
FLO	Pass	8:52am
FC	Pass	8:52am

Temperature Tests

Test	Status	Time
FC1	Pass	8:53am
SRC	Pass	8:53am
DET	Pass	8:53am
BAR	Pass	8:53am
BT	Pass	8:53am

Blank Tests

Test	Status	Time
AIR	Pass	8:53am

Printer Tests

Test	Status	Time
PRNT	Pass	8:53am

CRC Tests

Test	Status	Time
COMP	Pass	8:53am
CAL	Pass	8:53am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County SAMPSON Instrument Location SAMPSON COUNTY
Instrument Serial No. 008877 DETENTION CENTER

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15 day of APRIL, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. B...
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

SAMPSON COUNTY DETENTION CENTER 810

Serial Number: 008877
Test Date: 04/15/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R
Permit Number: 15671E
Effective:
06/01/2019-06/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG920301
Exp Date: 07/22/2021

Test	g/210L	Time
DIAG	Pass	8:43am
AIR BLK	.00	8:43am
ACCY CHK	.08	8:44am
AIR BLK	.00	8:45am
SUB TEST	.00	8:46am
AIR BLK	.00	8:47am
SUB TEST	.00	8:48am
AIR BLK	.00	8:49am

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

SAMPSON COUNTY DETENTION CENTER 810

Serial Number: 008877 Test Record Number: 3181
Test Date: 04/15/2020 Test Time: 8:49am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	8:50am
FLO	Pass	8:50am
FC	Pass	8:50am

Temperature Tests

Test	Status	Time
FC1	Pass	8:50am
SRC	Pass	8:50am
DET	Pass	8:50am
BAR	Pass	8:50am
BT	Pass	8:50am

Blank Tests

Test	Status	Time
AIR	Pass	8:51am

Printer Tests

Test	Status	Time
PRNT	Pass	8:51am

CRC Tests

Test	Status	Time
COMP	Pass	8:51am
CAL	Pass	8:51am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Scotland Co Instrument Location Laurinburg Police Dept
Instrument Serial No. 008834 Laurinburg NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

654
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

SCOTLAND COUNTY LAURINBURG PD 820

Serial Number: 008834
Test Date: 04/16/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: *Keesler, Grayham C*
Permit Number: 0045-5487
Effective:
11/04/2019-11/04/2021

Officer's Name: *NONE, NONE*
Type of Agency: *FTA*
Agency: *DHHS*
Test Type: *Breath Test*

Lot Number: AG934001
Exp Date: 12/06/2021


Test	g/210L	Time
DIAG	Pass	10:55am
AIR BLK	.00	10:55am
ACCY CHK	.08	10:56am
AIR BLK	.00	10:57am
SUB TEST	.00	10:58am
AIR BLK	.00	10:59am
SUB TEST	.00	11:00am
AIR BLK	.00	11:01am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

SCOTLAND COUNTY LAURINBURG PD 820

Serial Number: 008834 Test Record Number: 943
Test Date: 04/16/2020 Test Time: 11:02am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:02am
FLO	Pass	11:02am
FC	Pass	11:02am

Temperature Tests

Test	Status	Time
FC1	Pass	11:02am
SRC	Pass	11:02am
DET	Pass	11:02am
BAR	Pass	11:02am
BT	Pass	11:02am

Blank Tests

Test	Status	Time
AIR	Pass	11:03am

Printer Tests

Test	Status	Time
PRNT	Pass	11:03am

CRC Tests

Test	Status	Time
COMP	Pass	11:03am
CAL	Pass	11:03am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Scotland Co. Instrument Location Scotland Co. Sheriff Office

Instrument Serial No. 008861 Laurinburg, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

654
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

SCOTLAND COUNTY SHERIFF'S OFFICE 820

Serial Number: 008861
Test Date: 04/16/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: Keesler, Grayham C

Permit Number: 0045-5487

Effective:

11/04/2019-11/04/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG911506

Exp Date: 04/25/2021


Test	g/210L	Time
DIAG	Pass	11:35am
AIR BLK	.00	11:36am
ACCY CHK	.08	11:37am
AIR BLK	.00	11:38am
SUB TEST	.00	11:39am
AIR BLK	.00	11:40am
SUB TEST	.00	11:41am
AIR BLK	.00	11:42am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

SCOTLAND COUNTY SHERIFF'S OFFICE 820

Serial Number: 008861 Test Record Number: 1623
Test Date: 04/16/2020 Test Time: 11:43am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:43am
FLO	Pass	11:43am
FC	Pass	11:44am

Temperature Tests

Test	Status	Time
FC1	Pass	11:44am
SRC	Pass	11:44am
DET	Pass	11:44am
BAR	Pass	11:44am
BT	Pass	11:44am

Blank Tests

Test	Status	Time
AIR	Pass	11:44am


Printer Tests

Test	Status	Time
PRNT	Pass	11:44am

CRC Tests

Test	Status	Time
COMP	Pass	11:44am
CAL	Pass	11:44am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Stanly Instrument Location Locust PD
Instrument Serial No. _____ 186 Ray Kennedy Dr, Locust

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

650
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

STANLY LOCUST PD 830

Serial Number: 008706
Test Date: 04/15/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: Hutchinson, Joseph E

Permit Number: 0035-6075

Effective:

07/09/2019-07/09/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG933901

Exp Date: 12/05/2021

Test	g/210L	Time
DIAG	Pass	1:37pm
AIR BLK	.00	1:37pm
ACCY CHK	.08	1:38pm
AIR BLK	.00	1:39pm
SUB TEST	.00	1:41pm
AIR BLK	.00	1:42pm
SUB TEST	.00	1:43pm
AIR BLK	.00	1:44pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

STANLY LOCUST PD 830

Serial Number: 008706 Test Record Number: 3552
Test Date: 04/15/2020 Test Time: 1:48pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:49pm
FLO	Pass	1:49pm
FC	Pass	1:49pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:49pm
SRC	Pass	1:49pm
DET	Pass	1:49pm
BAR	Pass	1:49pm
BT	Pass	1:49pm

Blank Tests

Test	Status	Time
AIR	Pass	1:49pm

Printer Tests

Test	Status	Time
PRNT	Pass	1:49pm

CRC Tests

Test	Status	Time
COMP	Pass	1:50pm
CAL	Pass	1:50pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Stanly Instrument Location Stanly County SO
Instrument Serial No. 008824 126 S 3rd St, Albemarle

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15 day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

650
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

STANLY COUNTY STANLY COUNTY SO 830

Serial Number: 008824
Test Date: 04/15/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: Hutchinson, Joseph E
Permit Number: 0035-6075
Effective:
07/09/2019-07/09/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG007601
Exp Date: 03/16/2022

Test	g/210L	Time
DIAG	Pass	12:27pm
AIR BLK	.00	12:28pm
ACCY CHK	.08	12:29pm
AIR BLK	.00	12:31pm
SUB TEST	.00	12:32pm
AIR BLK	.00	12:33pm
SUB TEST	.00	12:34pm
AIR BLK	.00	12:35pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

STANLY COUNTY STANLY COUNTY SO 830

Serial Number: 008824 Test Record Number: 1568
Test Date: 04/15/2020 Test Time: 12:36pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:36pm
FLO	Pass	12:37pm
FC	Pass	12:37pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:37pm
SRC	Pass	12:37pm
DET	Pass	12:37pm
BAR	Pass	12:37pm
BT	Pass	12:37pm

Blank Tests

Test	Status	Time
AIR	Pass	12:37pm

Printer Tests

Test	Status	Time
PRNT	Pass	12:37pm

CRC Tests

Test	Status	Time
COMP	Pass	12:38pm
CAL	Pass	12:38pm

Preventive Maintenance
Status: Pass



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Stanly Instrument Location Stanly County SO
Instrument Serial No. 008842 126 S. 3rd St, Albemarle

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15 day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



J. E. [Signature]
Signature of Certifying Official

654
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

STANLY COUNTY STANLY COUNTY SO 830

Serial Number: 008842
Test Date: 04/15/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: Hutchinson, Joseph E
Permit Number: 0035-6075
Effective:
07/09/2019-07/09/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG919901
Exp Date: 07/18/2021

Test	g/210L	Time
DIAG	Pass	12:29pm
AIR BLK	.00	12:30pm
ACCY CHK	.08	12:30pm
AIR BLK	.00	12:31pm
SUB TEST	.00	12:32pm
AIR BLK	.00	12:33pm
SUB TEST	.00	12:35pm
AIR BLK	.00	12:35pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

STANLY COUNTY STANLY COUNTY SO 830

Serial Number: 008842 Test Record Number: 2284
Test Date: 04/15/2020 Test Time: 12:36pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:37pm
FLO	Pass	12:37pm
FC	Pass	12:37pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:37pm
SRC	Pass	12:37pm
DET	Pass	12:37pm
BAR	Pass	12:37pm
BT	Pass	12:37pm

Blank Tests

Test	Status	Time
AIR	Pass	12:38pm

Printer Tests

Test	Status	Time
PRNT	Pass	12:38pm

CRC Tests

Test	Status	Time
COMP	Pass	12:38pm
CAL	Pass	12:38pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Tyrrell Instrument Location Tyrrell Co. S.O.
Instrument Serial No. 008902 417 Main St, Columbus, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

643
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

TYRRELL COUNTY SHERIFF'S OFFICE 880

Serial Number: 008902
Test Date: 04/15/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: GUARD, KELLY G
Permit Number: 12955E
Effective:
06/01/2019-06/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG919901
Exp Date: 07/18/2021

Test	g/210L	Time
DIAG	Pass	11:28am
AIR BLK	.00	11:29am
ACCY CHK	.08	11:29am
AIR BLK	.00	11:30am
SUB TEST	.00	11:31am
AIR BLK	.00	11:32am
SUB TEST	.00	11:34am
AIR BLK	.00	11:34am

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

TYRRELL COUNTY SHERIFF'S OFFICE 880

Serial Number: 008902 Test Record Number: 890
Test Date: 04/15/2020 Test Time: 11:35am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:36am
FLO	Pass	11:36am
FC	Pass	11:36am

Temperature Tests

Test	Status	Time
FC1	Pass	11:36am
SRC	Pass	11:36am
DET	Pass	11:36am
BAR	Pass	11:36am
BT	Pass	11:36am

Blank Tests

Test	Status	Time
AIR	Pass	11:37am

Printer Tests

Test	Status	Time
PRNT	Pass	11:37am

CRC Tests

Test	Status	Time
COMP	Pass	11:37am
CAL	Pass	11:37am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Union Instrument Location Union County SO
Instrument Serial No. 008866

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 2 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

656
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

UNION COUNTY UNION COUNTY SO 890

Serial Number: 008866

Test Date: 04/02/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: Hays, Mark D

Permit Number: 0011-3099

Effective:

11/13/2019-11/13/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG904301

Exp Date: 02/12/2021

Test	g/210L	Time
DIAG	Pass	9:46am
AIR BLK	.00	9:47am
ACCY CHK	.07	9:48am
AIR BLK	.00	9:49am
SUB TEST	.00	9:50am
AIR BLK	.00	9:51am
SUB TEST	.00	9:52am
AIR BLK	.00	9:53am

Reported AC: .00 g/210L



 Signature of Chemical Analyst

Court CVR



 Analyst

Intox EC/IR-II: Preventive Maintenance

UNION COUNTY UNION COUNTY SO 890

Serial Number: 008866 Test Record Number: 3549
Test Date: 04/02/2020 Test Time: 9:54am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	9:55am
FLO	Pass	9:55am
FC	Pass	9:55am

Temperature Tests

Test	Status	Time
FC1	Pass	9:55am
SRC	Pass	9:55am
DET	Pass	9:55am
BAR	Pass	9:55am
BT	Pass	9:55am

Blank Tests

Test	Status	Time
AIR	Pass	9:56am


Printer Tests

Test	Status	Time
PRNT	Pass	9:56am

CRC Tests

Test	Status	Time
COMP	Pass	9:56am
CAL	Pass	9:56am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Union Instrument Location Union County SO

Instrument Serial No. 008876

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 2 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

656
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

UNION COUNTY UNION COUNTY SO 890

Serial Number: 008876
Test Date: 04/02/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: Hays, Mark D
Permit Number: 0011-3099
Effective:
11/13/2019-11/13/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG902201
Exp Date: 01/22/2021

Test	g/210L	Time
DIAG	Pass	9:36am
AIR BLK	.00	9:37am
ACCY CHK	.07	9:38am
AIR BLK	.00	9:39am
SUB TEST	.00	9:40am
AIR BLK	.00	9:41am
SUB TEST	.00	9:42am
AIR BLK	.00	9:43am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

UNION COUNTY UNION COUNTY SO 890

Serial Number: 008876 Test Record Number: 5628
Test Date: 04/02/2020 Test Time: 9:45am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	9:45am
FLO	Pass	9:45am
FC	Pass	9:45am

Temperature Tests

Test	Status	Time
FC1	Pass	9:45am
SRC	Pass	9:45am
DET	Pass	9:45am
BAR	Pass	9:45am
BT	Pass	9:45am

Blank Tests

Test	Status	Time
AIR	Pass	9:46am


Printer Tests

Test	Status	Time
PRNT	Pass	9:46am

CRC Tests

Test	Status	Time
COMP	Pass	9:46am
CAL	Pass	9:46am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County VANCE Instrument Location Vance Co S.O.

Instrument Serial No. 008870 156 Church St Henderson, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16 day of April, 20 20 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alex Bowers
Signature of Certifying Official

602
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

VANCE COUNTY SHERIFF'S DEPARTMENT 900

Serial Number: 008870
Test Date: 04/16/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: BARNES, STOKES
Permit Number: 11434E
Effective:
04/01/2019-04/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG911501
Exp Date: 04/25/2021

Test	g/210L	Time
DIAG	Pass	2:32pm
AIR BLK	.00	2:33pm
ACCY CHK	.08	2:34pm
AIR BLK	.00	2:35pm
SUB TEST	.00	2:36pm
AIR BLK	.00	2:37pm
SUB TEST	.00	2:38pm
AIR BLK	.00	2:39pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

VANCE COUNTY SHERIFF'S DEPARTMENT 900

Serial Number: 008870 Test Record Number: 2995
Test Date: 04/16/2020 Test Time: 2:41pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:42pm
FLO	Pass	2:42pm
FC	Pass	2:42pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:42pm
SRC	Pass	2:42pm
DET	Pass	2:42pm
BAR	Pass	2:42pm
BT	Pass	2:42pm

Blank Tests

Test	Status	Time
AIR	Pass	2:42pm


Printer Tests

Test	Status	Time
PRNT	Pass	2:43pm

CRC Tests

Test	Status	Time
COMP	Pass	2:43pm
CAL	Pass	2:43pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Vance Instrument Location Vance Co. S.D.

Instrument Serial No. 008937 156 Church ST Henderson, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

662
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

VANCE COUNTY SHERIFF'S DEPARTMENT 900

Serial Number: 008937
Test Date: 04/16/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: BARNES, STOKES
Permit Number: 11434E
Effective:
04/01/2019-04/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG934303
Exp Date: 12/09/2021

Test	g/210L	Time
DIAG	Pass	2:30pm
AIR BLK	.00	2:30pm
ACCY CHK	.08	2:31pm
AIR BLK	.00	2:32pm
SUB TEST	.00	2:33pm
AIR BLK	.00	2:34pm
SUB TEST	.00	2:35pm
AIR BLK	.00	2:36pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

VANCE COUNTY SHERIFF'S DEPARTMENT 900

Serial Number: 008937 Test Record Number: 2862
Test Date: 04/16/2020 Test Time: 2:36pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:37pm
FLO	Pass	2:37pm
FC	Pass	2:37pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:37pm
SRC	Pass	2:37pm
DET	Pass	2:37pm
BAR	Pass	2:37pm
BT	Pass	2:37pm

Blank Tests

Test	Status	Time
AIR	Pass	2:37pm

Printer Tests

Test	Status	Time
PRNT	Pass	2:37pm

CRC Tests

Test	Status	Time
COMP	Pass	2:38pm
CAL	Pass	2:38pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Wake Instrument Location CARY PD

Instrument Serial No. 008587 120 Wilkinson Ave Cary, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

662
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAKE COUNTY CARY PD 910

Serial Number: 008587

Test Date: 04/14/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, STOKES

Permit Number: 11434E

Effective:

04/01/2019-04/01/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG911501

Exp Date: 04/25/2021

Test	g/210L	Time
DIAG	Pass	3:41pm
AIR BLK	.00	3:42pm
ACCY CHK	.07	3:42pm
AIR BLK	.00	3:43pm
SUB TEST	.00	3:44pm
AIR BLK	.00	3:45pm
SUB TEST	.00	3:47pm
AIR BLK	.00	3:48pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY CARY PD 910

Serial Number: 008587 Test Record Number: 4265
Test Date: 04/14/2020 Test Time: 3:48pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:49pm
FLO	Pass	3:49pm
FC	Pass	3:49pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:49pm
SRC	Pass	3:49pm
DET	Pass	3:49pm
BAR	Pass	3:49pm
BT	Pass	3:49pm

Blank Tests

Test	Status	Time
AIR	Pass	3:50pm

Printer Tests

Test	Status	Time
PRNT	Pass	3:50pm

CRC Tests

Test	Status	Time
COMP	Pass	3:50pm
CAL	Pass	3:50pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Wake Instrument Location Apex PD STATION 41
Instrument Serial No. 008621 1615 E Williams St Apex NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

662
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAKE COUNTY APEX PD

Serial Number: 008621
Test Date: 04/14/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: BARNES, STOKES
Permit Number: 11434E
Effective:
04/01/2019-04/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG919902
Exp Date: 07/18/2021

Test	g/210L	Time
DIAG	Pass	2:58pm
AIR BLK	.00	2:59pm
ACCY CHK	.07	3:00pm
AIR BLK	.00	3:01pm
SUB TEST	.00	3:01pm
AIR BLK	.00	3:02pm
SUB TEST	.00	3:04pm
AIR BLK	.00	3:05pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY APEX PD

Serial Number: 008621 Test Record Number: 2787
Test Date: 04/14/2020 Test Time: 3:05pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:05pm
FLO	Pass	3:05pm
FC	Pass	3:06pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:06pm
SRC	Pass	3:06pm
DET	Pass	3:06pm
BAR	Pass	3:06pm
BT	Pass	3:06pm

Blank Tests

Test	Status	Time
AIR	Pass	3:06pm

Printer Tests

Test	Status	Time
PRNT	Pass	3:06pm

CRC Tests

Test	Status	Time
COMP	Pass	3:06pm
CAL	Pass	3:06pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Wake Instrument Location Wake Co Detention Center

Instrument Serial No. 008577 3301 Hammond Rd, Raleigh, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 9 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



A Stokes Barnes

Signature of Certifying Official

662

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAKE COUNTY DETENTION CENTER 910

Serial Number: 008577
Test Date: 04/09/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: BARNES, STOKES
Permit Number: 11434E
Effective:
04/01/2019-04/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG007601
Exp Date: 03/16/2022

Test	g/210L	Time
DIAG	Pass	10:36am
AIR BLK	.00	10:37am
ACCY CHK	.07	10:38am
AIR BLK	.00	10:39am
SUB TEST	.00	10:39am
AIR BLK	.00	10:40am
SUB TEST	.00	10:42am
AIR BLK	.00	10:43am

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY DETENTION CENTER 910

Serial Number: 008577 Test Record Number: 4931
Test Date: 04/09/2020 Test Time: 10:44am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:44am
FLO	Pass	10:44am
FC	Pass	10:44am

Temperature Tests

Test	Status	Time
FC1	Pass	10:44am
SRC	Pass	10:44am
DET	Pass	10:44am
BAR	Pass	10:44am
BT	Pass	10:44am

Blank Tests

Test	Status	Time
AIR	Pass	10:45am

Printer Tests

Test	Status	Time
PRNT	Pass	10:45am

CRC Tests

Test	Status	Time
COMP	Pass	10:45am
CAL	Pass	10:45am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Wake Instrument Location Wake Co Detention Center

Instrument Serial No. 008612 3301 Hammond Rd Raleigh, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 9 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Handwritten Signature]

Signature of Certifying Official

662

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAKE COUNTY DETENTION CENTER 910

Serial Number: 008612
Test Date: 04/09/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BARNES, STOKES
Permit Number: 11434E
Effective:
04/01/2019-04/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG007601
Exp Date: 03/16/2022

Test	g/210L	Time
DIAG	Pass	10:37am
AIR BLK	.00	10:38am
ACCY CHK	.08	10:38am
AIR BLK	.00	10:40am
SUB TEST	.00	10:40am
AIR BLK	.00	10:41am
SUB TEST	.00	10:43am
AIR BLK	.00	10:43am

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY DETENTION CENTER 910

Serial Number: 008612 Test Record Number: 461
Test Date: 04/09/2020 Test Time: 10:44am EDT

System Check: Passed

Baseline Tests

Test	Status	Time
IR	Pass	10:45am
FLO	Pass	10:45am
FC	Pass	10:45am

Temperature Tests

Test	Status	Time
FC1	Pass	10:45am
SRC	Pass	10:45am
DET	Pass	10:45am
BAR	Pass	10:45am
BT	Pass	10:45am

Blank Tests

Test	Status	Time
AIR	Pass	10:45am

Printer Tests

Test	Status	Time
PRNT	Pass	10:45am

CRC Tests

Test	Status	Time
COMP	Pass	10:46am
CAL	Pass	10:46am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Wake Instrument Location Wake Co Detention Center

Instrument Serial No. 008760 3301 Hammond Pk Raleigh, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 9 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

662
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAKE COUNTY DETENTION CENTER 910

Serial Number: 008760
Test Date: 04/09/2020

Citation Number: M000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BARNES, STOKES
Permit Number: 11434E
Effective:
04/01/2019-04/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG007601
Exp Date: 03/16/2022

Test	g/210L	Time
DIAG	Pass	10:35am
AIR BLK	.00	10:35am
ACCY CHK	.08	10:36am
AIR BLK	.00	10:37am
SUB TEST	.00	10:38am
AIR BLK	.00	10:39am
SUB TEST	.00	10:40am
AIR BLK	.00	10:41am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY DETENTION CENTER 910

Serial Number: 008760 Test Record Number: 3773
Test Date: 04/09/2020 Test Time: 10:43am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:44am
FLO	Pass	10:44am
FC	Pass	10:44am

Temperature Tests

Test	Status	Time
FC1	Pass	10:44am
SRC	Pass	10:44am
DET	Pass	10:44am
BAR	Pass	10:44am
BT	Pass	10:44am

Blank Tests

Test	Status	Time
AIR	Pass	10:44am

Printer Tests

Test	Status	Time
PRNT	Pass	10:44am

CRC Tests

Test	Status	Time
COMP	Pass	10:45am
CAL	Pass	10:45am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Wake Instrument Location Wake Co Detention Center

Instrument Serial No. 008778 3301 HAMMOND RD RALEIGH, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 9 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alexis Barnes

Signature of Certifying Official

642

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAKE COUNTY DETENTION CENTER 910

Serial Number: 008778

Test Date: 04/09/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, STOKES

Permit Number: 11434E

Effective:

04/01/2019-04/01/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG007601


Exp Date: 03/16/2022

Test	g/210L	Time
DIAG	Pass	10:35am
AIR BLK	.00	10:36am
ACCY CHK	.08	10:37am
AIR BLK	.00	10:38am
SUB TEST	.00	10:39am
AIR BLK	.00	10:40am
SUB TEST	.00	10:41am
AIR BLK	.00	10:42am

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY DETENTION CENTER 910

Serial Number: 008778 Test Record Number: 4913
Test Date: 04/09/2020 Test Time: 10:43am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:44am
FLO	Pass	10:44am
FC	Pass	10:44am

Temperature Tests

Test	Status	Time
FC1	Pass	10:44am
SRC	Pass	10:44am
DET	Pass	10:44am
BAR	Pass	10:44am
BT	Pass	10:44am

Blank Tests

Test	Status	Time
AIR	Pass	10:45am

Printer Tests

Test	Status	Time
PRNT	Pass	10:45am

CRC Tests

Test	Status	Time
COMP	Pass	10:45am
CAL	Pass	10:45am

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County WARREN Instrument Location WARREN CO LEC

Instrument Serial No. 008793 128 RASTERS LN WARRANTON, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16 day of April, 2020 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

662
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WARREN COUNTY WARREN COUNTY JAIL 920

Serial Number: 008793
Test Date: 04/16/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: BARNES, STOKES
Permit Number: 11434E
Effective:
04/01/2019-04/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG919902
Exp Date: 07/18/2021

Test	g/210L	Time
DIAG	Pass	1:38pm
AIR BLK	.00	1:39pm
ACCY CHK	.07	1:40pm
AIR BLK	.00	1:41pm
SUB TEST	.00	1:41pm
AIR BLK	.00	1:42pm
SUB TEST	.00	1:44pm
AIR BLK	.00	1:45pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

WARREN COUNTY WARREN COUNTY JAIL 920

Serial Number: 008793 Test Record Number: 1577
Test Date: 04/16/2020 Test Time: 1:45pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:45pm
FLO	Pass	1:45pm
FC	Pass	1:45pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:45pm
SRC	Pass	1:45pm
DET	Pass	1:45pm
BAR	Pass	1:45pm
BT	Pass	1:45pm

Blank Tests

Test	Status	Time
AIR	Pass	1:46pm

Printer Tests

Test	Status	Time
PRNT	Pass	1:46pm

CRC Tests

Test	Status	Time
COMP	Pass	1:46pm
CAL	Pass	1:46pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Washington Instrument Location Washington Co. S.O.
Instrument Serial No. 008829 120 Adams St., Plymouth, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 29th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

643
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WASHINGTON COUNTY SHERIFF'S OFFICE 930

Serial Number: 008829
Test Date: 04/29/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: GUARD, KELLY G
Permit Number: 12955E
Effective:
06/01/2019-06/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG902201
Exp Date: 01/22/2021

Test	g/210L	Time
DIAG	Pass	10:51am
AIR BLK	.00	10:52am
ACCY CHK	.07	10:53am
AIR BLK	.00	10:54am
SUB TEST	.00	10:55am
AIR BLK	.00	10:55am
SUB TEST	.00	10:57am
AIR BLK	.00	10:58am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

WASHINGTON COUNTY SHERIFF'S OFFICE 930

Serial Number: 008829 Test Record Number: 969
Test Date: 04/29/2020 Test Time: 10:59am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:59am
FLO	Pass	10:59am
FC	Pass	10:59am

Temperature Tests

Test	Status	Time
FC1	Pass	11:00am
SRC	Pass	11:00am
DET	Pass	11:00am
BAR	Pass	11:00am
BT	Pass	11:00am

Blank Tests

Test	Status	Time
AIR	Pass	11:00am

Printer Tests

Test	Status	Time
PRNT	Pass	11:00am

CRC Tests

Test	Status	Time
COMP	Pass	11:00am
CAL	Pass	11:00am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Washington Instrument Location Washington Co. S.O.
Instrument Serial No. 008851 Adams St, Plymouth, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Kue Signature of Certifying Official 643 Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WASHINGTON COUNTY SHERIFF'S OFFICE 930

Serial Number: 008851
Test Date: 04/15/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: GUARD, KELLY G
Permit Number: 12955E
Effective:
06/01/2019-06/01/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG902201
Exp Date: 01/22/2021

Test	g/210L	Time
DIAG	Pass	1:28pm
AIR BLK	.00	1:28pm
ACCY CHK	.08	1:29pm
AIR BLK	.00	1:30pm
SUB TEST	.00	1:31pm
AIR BLK	.00	1:32pm
SUB TEST	.00	1:34pm
AIR BLK	.00	1:35pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

WASHINGTON COUNTY SHERIFF'S OFFICE 930

Serial Number: 008851 Test Record Number: 683
Test Date: 04/15/2020 Test Time: 1:36pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:37pm
FLO	Pass	1:37pm
FC	Pass	1:37pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:37pm
SRC	Pass	1:37pm
DET	Pass	1:37pm
BAR	Pass	1:37pm
BT	Pass	1:37pm

Blank Tests

Test	Status	Time
AIR	Pass	1:37pm

Printer Tests

Test	Status	Time
PRNT	Pass	1:37pm

CRC Tests

Test	Status	Time
COMP	Pass	1:38pm
CAL	Pass	1:38pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Watauga Instrument Location Watauga Co Jail
Instrument Serial No. 008715 Boonville, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 9 day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

149
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WATAUGA COUNTY WATAUGA JAIL 940

Serial Number: 008715
Test Date: 04/09/2020

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BURNETTE, ANTHONY J

Permit Number: 11304E

Effective:
06/01/2019-06/01/2021

Officer's Name: NONE,

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG911506

Exp Date: 04/25/2021

Test	g/210L	Time
DIAG	Pass	1:18pm
AIR BLK	.00	1:19pm
ACCY CHK	.08	1:20pm
AIR BLK	.00	1:21pm
SUB TEST	.00	1:22pm
AIR BLK	.00	1:23pm
SUB TEST	.00	1:24pm
AIR BLK	.00	1:25pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

WATAUGA COUNTY WATAUGA JAIL 940

Serial Number: 008715 Test Record Number: 2387
Test Date: 04/09/2020 Test Time: 1:26pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:27pm
FLO	Pass	1:27pm
FC	Pass	1:27pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:27pm
SRC	Pass	1:27pm
DET	Pass	1:27pm
BAR	Pass	1:27pm
BT	Pass	1:27pm

Blank Tests

Test	Status	Time
AIR	Pass	1:28pm

Printer Tests

Test	Status	Time
PRNT	Pass	1:28pm

CRC Tests

Test	Status	Time
COMP	Pass	1:28pm
CAL	Pass	1:28pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Watauga Instrument Location Boone PD
Instrument Serial No. 0048716 Boone, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 9 day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

649
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WATAUGA COUNTY BOONE P D 940

Serial Number: 008716
Test Date: 04/09/2020

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BURNETTE, ANTHONY J

Permit Number: 11304E

Effective:

06/01/2019-06/01/2021

Officer's Name: NONE,

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG920301


Exp Date: 07/22/2021

Test	g/210L	Time
DIAG	Pass	2:14pm
AIR BLK	.00	2:15pm
ACCY CHK	.08	2:15pm
AIR BLK	.00	2:16pm
SUB TEST	.00	2:17pm
AIR BLK	.00	2:18pm
SUB TEST	.00	2:19pm
AIR BLK	.00	2:20pm

Reported AC: .00 g/210L

~~Signature of Chemical Analyst~~

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

WATAUGA COUNTY BOONE P D 940

Serial Number: 008716 Test Record Number: 2550
Test Date: 04/09/2020 Test Time: 2:21pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:21pm
FLO	Pass	2:21pm
FC	Pass	2:21pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:22pm
SRC	Pass	2:22pm
DET	Pass	2:22pm
BAR	Pass	2:22pm
BT	Pass	2:22pm

Blank Tests

Test	Status	Time
AIR	Pass	2:22pm

Printer Tests

Test	Status	Time
PRNT	Pass	2:22pm

CRC Tests

Test	Status	Time
COMP	Pass	2:22pm
CAL	Pass	2:22pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Wayne Instrument Location Wayne CO Detention STA
Instrument Serial No. 008249 207E Chestnut St Goldsboro, N.C

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13th day of April, 20 20, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAYNE COUNTY WAYNE CO DETENTION 950

Serial Number: 008649
Test Date: 04/13/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: Keesler, Linda A

Permit Number: 0045-5468

Effective:

07/08/2019-07/08/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG902106

Exp Date: 01/21/2021

Test	g/210L	Time
DIAG	Pass	2:28pm
AIR BLK	.00	2:29pm
ACCY CHK	.08	2:30pm
AIR BLK	.00	2:31pm
SUB TEST	.00	2:31pm
AIR BLK	.00	2:32pm
SUB TEST	.00	2:34pm
AIR BLK	.00	2:35pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007

Intox EC/IR-II: Preventive Maintenance

WAYNE COUNTY WAYNE CO DETENTION 950

Serial Number: 008649 Test Record Number: 4190
Test Date: 04/13/2020 Test Time: 2:40pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:41pm
FLO	Pass	2:41pm
FC	Pass	2:41pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:41pm
SRC	Pass	2:41pm
DET	Pass	2:41pm
BAR	Pass	2:41pm
BT	Pass	2:41pm

Blank Tests

Test	Status	Time
AIR	Pass	2:42pm

Printer Tests

Test	Status	Time
PRNT	Pass	2:42pm

CRC Tests

Test	Status	Time
COMP	Pass	2:42pm
CAL	Pass	2:42pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Wayne Instrument Location Wayne Co. Detention CTR
Instrument Serial No. 008671 207 E CHESTNUT ST, GOLDSBORO, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13th day of April, 20 20, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAYNE COUNTY WAYNE CO DETENTION 950

Serial Number: 008671
Test Date: 04/13/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: Keesler, Linda A

Permit Number: 0045-5468

Effective:

07/08/2019-07/08/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG933703

Exp Date: 12/03/2021

Test	g/210L	Time
DIAG	Pass	2:31pm
AIR BLK	.00	2:32pm
ACCY CHK	.07	2:33pm
AIR BLK	.00	2:34pm
SUB TEST	.00	2:34pm
AIR BLK	.00	2:35pm
SUB TEST	.00	2:38pm
AIR BLK	.00	2:38pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

WAYNE COUNTY WAYNE CO DETENTION 950

Serial Number: 008671 Test Record Number: 5022
Test Date: 04/13/2020 Test Time: 2:40pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:41pm
FLO	Pass	2:41pm
FC	Pass	2:41pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:41pm
SRC	Pass	2:41pm
DET	Pass	2:41pm
BAR	Pass	2:41pm
BT	Pass	2:41pm

Blank Tests

Test	Status	Time
AIR	Pass	2:41pm

Printer Tests

Test	Status	Time
PRNT	Pass	2:41pm

CRC Tests

Test	Status	Time
COMP	Pass	2:42pm
CAL	Pass	2:42pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Wayne

Instrument Location Seymour Johnson A.F.B.

Instrument Serial No. 008786

1010 VERMONT GARRISON RD, GOLDSBORO, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Handwritten Signature]
Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAYNE COUNTY SEYMOUR JOHNSON AFB 950

Serial Number: 008786
Test Date: 04/13/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: Keesler, Linda A
Permit Number: 11646E
Effective:
07/08/2019-07/08/2021

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG007601
Exp Date: 03/16/2022

Test	g/210L	Time
DIAG	Pass	4:52pm
AIR BLK	.00	4:53pm
ACCY CHK	.08	4:53pm
AIR BLK	.00	4:55pm
SUB TEST	.00	4:55pm
AIR BLK	.00	4:56pm
SUB TEST	.00	4:57pm
AIR BLK	.00	4:58pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

WAYNE COUNTY SEYMOUR JOHNSON AFB 950

Serial Number: 008786 Test Record Number: 347
Test Date: 04/13/2020 Test Time: 4:59pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	4:59pm
FLO	Pass	4:59pm
FC	Pass	4:59pm

Temperature Tests

Test	Status	Time
FC1	Pass	4:59pm
SRC	Pass	4:59pm
DET	Pass	4:59pm
BAR	Pass	4:59pm
BT	Pass	4:59pm

Blank Tests

Test	Status	Time
AIR	Pass	5:00pm

Printer Tests

Test	Status	Time
PRNT	Pass	5:00pm

CRC Tests

Test	Status	Time
COMP	Pass	5:00pm
CAL	Pass	5:00pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Wayne Instrument Location Wayne Co Detention CTR

Instrument Serial No. 008879 207 E Chestnut St, Goldsboro, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13th day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Tim A. Keesel
Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAYNE COUNTY WAYNE CO DETENTION 950

Serial Number: 008879
Test Date: 04/13/2020

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: Keesler, Linda A

Permit Number: 0045-5468

Effective:

07/08/2019-07/08/2021

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG902201

Exp Date: 01/22/2021


Test	g/210L	Time
DIAG	Pass	2:26pm
AIR BLK	.00	2:27pm
ACCY CHK	.08	2:27pm
AIR BLK	.00	2:28pm
SUB TEST	.00	2:29pm
AIR BLK	.00	2:30pm
SUB TEST	.00	2:32pm
AIR BLK	.00	2:33pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

WAYNE COUNTY WAYNE CO DETENTION 950

Serial Number: 008879 Test Record Number: 1283
Test Date: 04/13/2020 Test Time: 2:35pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:35pm
FLO	Pass	2:35pm
FC	Pass	2:35pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:35pm
SRC	Pass	2:35pm
DET	Pass	2:35pm
BAR	Pass	2:35pm
BT	Pass	2:35pm

Blank Tests

Test	Status	Time
AIR	Pass	2:36pm


Printer Tests

Test	Status	Time
PRNT	Pass	2:36pm

CRC Tests

Test	Status	Time
COMP	Pass	2:36pm
CAL	Pass	2:36pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Wilkes Instrument Location Wilkes Co Detention

Instrument Serial No. 004843 Wilkesboro, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

649
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WILKES COUNTY WILKES CO DETENTION 960

Serial Number: 008843
Test Date: 04/13/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BURNETTE, ANTHONY J
Permit Number: 11304E
Effective:
06/01/2019-06/01/2021

Officer's Name: NONE,
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG933901
Exp Date: 12/05/2021

Test	g/210L	Time
DIAG	Pass	3:11pm
AIR BLK	.00	3:12pm
ACCY CHK	.08	3:12pm
AIR BLK	.00	3:14pm
SUB TEST	.00	3:14pm
AIR BLK	.00	3:15pm
SUB TEST	.00	3:17pm
AIR BLK	.00	3:18pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

WILKES COUNTY WILKES CO DETENTION 960

Serial Number: 008843 Test Record Number: 2463
Test Date: 04/13/2020 Test Time: 3:18pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:19pm
FLO	Pass	3:19pm
FC	Pass	3:19pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:19pm
SRC	Pass	3:19pm
DET	Pass	3:19pm
BAR	Pass	3:19pm
BT	Pass	3:19pm

Blank Tests

Test	Status	Time
AIR	Pass	3:20pm


Printer Tests

Test	Status	Time
PRNT	Pass	3:20pm

CRC Tests

Test	Status	Time
COMP	Pass	3:20pm
CAL	Pass	3:20pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Wilkes Instrument Location Wilkes Co. Denton

Instrument Serial No. 008865 Wilkesboro NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of April, 2020, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

049
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WILKES COUNTY WILKES CO DETENTION 960

Serial Number: 008865

Test Date: 04/13/2020

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BURNETTE, ANTHONY J

Permit Number: 11304E

Effective:

06/01/2019-06/01/2021

Officer's Name: NONE,

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG933901


Exp Date: 12/05/2021

Test	g/210L	Time
DIAG	Pass	3:11pm
AIR BLK	.00	3:12pm
ACCY CHK	.08	3:13pm
AIR BLK	.00	3:14pm
SUB TEST	.00	3:15pm
AIR BLK	.00	3:16pm
SUB TEST	.00	3:17pm
AIR BLK	.00	3:18pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

WILKES COUNTY WILKES CO DETENTION 960

Serial Number: 008865 Test Record Number: 744
Test Date: 04/13/2020 Test Time: 3:19pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:20pm
FLO	Pass	3:20pm
FC	Pass	3:20pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:20pm
SRC	Pass	3:20pm
DET	Pass	3:20pm
BAR	Pass	3:20pm
BT	Pass	3:20pm

Blank Tests

Test	Status	Time
AIR	Pass	3:21pm


Printer Tests

Test	Status	Time
PRNT	Pass	3:21pm

CRC Tests

Test	Status	Time
COMP	Pass	3:21pm
CAL	Pass	3:21pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Yancey Instrument Location Yancey Co. Jail
Instrument Serial No. 008633 Burnsville, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15 day of April, 20 20, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Carol R. Guth
Signature of Certifying Official

635
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

YANCEY COUNTY YANCEY COUNTY JAIL 990

Serial Number: 008653
Test Date: 04/15/2020

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: Cutler, Daniel R
Permit Number: 0084-3310
Effective:
07/12/2019-07/12/2021

Officer's Name: NONE,
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG902201
Exp Date: 01/22/2021

Test	g/210L	Time
DIAG	Pass	12:00pm
AIR BLK	.00	12:01pm
ACCY CHK	.08	12:02pm
AIR BLK	.00	12:03pm
SUB TEST	.00	12:03pm
AIR BLK	.00	12:05pm
SUB TEST	.00	12:06pm
AIR BLK	.00	12:07pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

YANCEY COUNTY YANCEY COUNTY JAIL 990

Serial Number: 008653 Test Record Number: 1448
Test Date: 04/15/2020 Test Time: 12:08pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:08pm
FLO	Pass	12:09pm
FC	Pass	12:09pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:09pm
SRC	Pass	12:09pm
DET	Pass	12:09pm
BAR	Pass	12:09pm
BT	Pass	12:09pm

Blank Tests

Test	Status	Time
AIR	Pass	12:09pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:09pm

CRC Tests

Test	Status	Time
COMP	Pass	12:10pm
CAL	Pass	12:10pm

Preventive Maintenance
Status: *Pass*



Analyst