

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County ALAMANCE

Instrument Location Burlington PD


Instrument Serial No. 008907

267 W. Front St Burlington, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 23 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]

Signature of Certifying Official

442

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

ALAMANCE COUNTY BURLINGTON PD 000

Serial Number: 008907

Test Date: 08/23/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, STOKES

Permit Number: 11434E

Effective:

05/01/2017-05/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG814901

Exp Date: 05/29/2020

Test	g/210L	Time
DIAG	Pass	10:11am
AIR BLK	.00	10:12am
ACCY CHK	.08	10:13am
AIR BLK	.00	10:14am
SUB TEST	.00	10:15am
AIR BLK	.00	10:15am
SUB TEST	.00	10:17am
AIR BLK	.00	10:18am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

ALAMANCE COUNTY BURLINGTON PD 000

Serial Number: 008907 Test Record Number: 895
Test Date: 08/23/2018 Test Time: 10:18am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:19am
FLO	Pass	10:19am
FC	Pass	10:19am

Temperature Tests

Test	Status	Time
FC1	Pass	10:19am
SRC	Pass	10:19am
DET	Pass	10:19am
BAR	Pass	10:19am
BT	Pass	10:19am

Blank Tests

Test	Status	Time
AIR	Pass	10:20am


Printer Tests

Test	Status	Time
PRNT	Pass	10:20am

CRC Tests

Test	Status	Time
COMP	Pass	10:20am
CAL	Pass	10:20am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County ALAMANCE

Instrument Location Burlington PD

Instrument Serial No. 008812


267 W. Front St

Burlington, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 29 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

462
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

ALAMANCE COUNTY BURLINGTON PD 000

Serial Number: 008812

Test Date: 08/29/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, STOKES

Permit Number: 11434E

Effective:

05/01/2017-05/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG814901

Exp Date: 05/29/2020

Test	g/210L	Time
DIAG	Pass	9:47am
AIR BLK	.00	9:48am
ACCY CHK	.08	9:49am
AIR BLK	.00	9:49am
SUB TEST	.00	9:50am
AIR BLK	.00	9:51am
SUB TEST	.00	9:52am
AIR BLK	.00	9:53am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

ALAMANCE COUNTY BURLINGTON PD 000

Serial Number: 008812 Test Record Number: 3248
Test Date: 08/29/2018 Test Time: 9:54am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	9:54am
FLO	Pass	9:54am
FC	Pass	9:54am

Temperature Tests

Test	Status	Time
FC1	Pass	9:54am
SRC	Pass	9:54am
DET	Pass	9:54am
BAR	Pass	9:54am
BT	Pass	9:54am

Blank Tests

Test	Status	Time
AIR	Pass	9:55am


Printer Tests

Test	Status	Time
PRNT	Pass	9:55am

CRC Tests

Test	Status	Time
COMP	Pass	9:55am
CAL	Pass	9:55am

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II


County Avery Instrument Location Banner EIK PO

Instrument Serial No. 008724 Banner EIK, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 3 day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

649
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Preventive Maintenance

AVERY COUNTY BANNER ELK PD 050

Serial Number: 008724 Test Record Number: 561
Test Date: 08/03/2018 Test Time: 5:31pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	5:32pm
FLO	Pass	5:32pm
FC	Pass	5:32pm

Temperature Tests

Test	Status	Time
FC1	Pass	5:32pm
SRC	Pass	5:32pm
DET	Pass	5:32pm
BAR	Pass	5:32pm
BT	Pass	5:32pm

Blank Tests

Test	Status	Time
AIR	Pass	5:32pm

Printer Tests

Test	Status	Time
PRNT	Pass	5:32pm

CRC Tests

Test	Status	Time
COMP	Pass	5:33pm
CAL	Pass	5:33pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II

County BEAUFORT Instrument Location Belhaven P.O.
Instrument Serial No. 008928 Belhaven, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 29th day of AUGUST, 20 18 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Timothy R. K... ..

Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

BEAUFORT COUNTY BELHAVEN PD 060

Serial Number: 008928

Test Date: 08/29/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: KEESLER, LINDA A

Permit Number: 11646E

Effective:

08/01/2017-08/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG721401

Exp Date: 08/02/2019


Test	g/210L	Time
DIAG	Pass	12:24pm
AIR BLK	.00	12:25pm
ACCY CHK	.08	12:25pm
AIR BLK	.00	12:26pm
SUB TEST	.00	12:27pm
AIR BLK	.00	12:28pm
SUB TEST	.00	12:30pm
AIR BLK	.00	12:31pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007

Intox EC/IR-II: Preventive Maintenance

BEAUFORT COUNTY BELHAVEN. PD 060

Serial Number: 008928 Test Record Number: 351
Test Date: 08/29/2018 Test Time: 12:32pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:32pm
FLO	Pass	12:32pm
FC	Pass	12:32pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:32pm
SRC	Pass	12:32pm
DET	Pass	12:32pm
BAR	Pass	12:32pm
BT	Pass	12:32pm

Blank Tests

Test	Status	Time
AIR	Pass	12:33pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:33pm

CRC Tests

Test	Status	Time
COMP	Pass	12:33pm
CAL	Pass	12:33pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Buncombe Instrument Location Buncombe Co Jail
Instrument Serial No. 008748 Asheville, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 31 day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

649
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

BUNCOMBE COUNTY BUNCOMBE COUNTY JAIL
100

Serial Number: 008748
Test Date: 08/31/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BURNETTE, ANTHONY J

Permit Number: 11304E

Effective:

05/01/2017-05/01/2019

Officer's Name: NONE,

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG807101

Exp Date: 03/12/2020

Test	g/210L	Time
DIAG	Pass	4:53pm
AIR BLK	.00	4:54pm
ACCY CHK	.08	4:54pm
AIR BLK	.00	4:55pm
SUB TEST	.00	4:56pm
AIR BLK	.00	4:57pm
SUB TEST	.00	4:58pm
AIR BLK	.00	4:59pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

BUNCOMBE COUNTY BUNCOMBE COUNTY JAIL 100

Serial Number: 008748 Test Record Number: 1105

Test Date: 08/31/2018 Test Time: 5:01pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	5:01pm
FLO	Pass	5:01pm
FC	Pass	5:01pm

Temperature Tests

Test	Status	Time
FC1	Pass	5:01pm
SRC	Pass	5:01pm
DET	Pass	5:01pm
BAR	Pass	5:01pm
BT	Pass	5:01pm

Blank Tests

Test	Status	Time
AIR	Pass	5:02pm

Printer Tests

Test	Status	Time
PRNT	Pass	5:02pm

CRC Tests

Test	Status	Time
COMP	Pass	5:02pm
CAL	Pass	5:02pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Buncombe Instrument Location Bpt Mobile Unit 2

Instrument Serial No. 008973

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 28 day of August, 20 18, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Chris Jones

Signature of Certifying Official

658

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

BUNCOMBE BAT MOBILE UNIT 02 100

Serial Number: 008973

Test Date: 08/28/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: TOWERY, CHAD V

Permit Number: 26632E

Effective:

06/01/2017-06/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG807101

Exp Date: 03/12/2020

Test	g/210L	Time
DIAG	Pass	8:52pm
AIR BLK	.00	8:53pm
ACCY CHK	.07	8:53pm
AIR BLK	.00	8:54pm
SUB TEST	.00	8:55pm
AIR BLK	.00	8:56pm
SUB TEST	.00	8:57pm
AIR BLK	.00	8:58pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

BUNCOMBE BAT MOBILE UNIT 02 100

Serial Number: 008973 Test Record Number: 544
Test Date: 08/28/2018 Test Time: 8:59pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	8:59pm
FLO	Pass	8:59pm
FC	Pass	8:59pm

Temperature Tests

Test	Status	Time
FC1	Pass	8:59pm
SRC	Pass	8:59pm
DET	Pass	8:59pm
BAR	Pass	8:59pm
BT	Pass	8:59pm

Blank Tests

Test	Status	Time
AIR	Pass	9:00pm


Printer Tests

Test	Status	Time
PRNT	Pass	9:00pm

CRC Tests

Test	Status	Time
COMP	Pass	9:00pm
CAL	Pass	9:00pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Caldwell Instrument Location Caldwell Co. Jail

Instrument Serial No. 008803 Lenoir, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 27 day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

649
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CALDWELL COUNTY CALDWELL COUNTY JAIL

130

Serial Number: 008803

Test Date: 08/27/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BURNETTE, ANTHONY J

Permit Number: 11304E

Effective:

05/01/2017-05/01/2019

Officer's Name: NONE,

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG722408

Exp Date: 08/12/2019

Test	g/210L	Time
DIAG	Pass	4:40pm
AIR BLK	.00	4:41pm
ACCY CHK	.07	4:42pm
AIR BLK	.00	4:43pm
SUB TEST	.00	4:44pm
AIR BLK	.00	4:45pm
SUB TEST	.00	4:46pm
AIR BLK	.00	4:47pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

CALDWELL COUNTY CALDWELL COUNTY JAIL 130

Serial Number: 008803 Test Record Number: 507
Test Date: 08/27/2018 Test Time: 4:48pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	4:48pm
FLO	Pass	4:48pm
FC	Pass	4:48pm

Temperature Tests

Test	Status	Time
FC1	Pass	4:48pm
SRC	Pass	4:48pm
DET	Pass	4:48pm
BAR	Pass	4:48pm
BT	Pass	4:48pm

Blank Tests

Test	Status	Time
AIR	Pass	4:49pm

Printer Tests

Test	Status	Time
PRNT	Pass	4:49pm

CRC Tests

Test	Status	Time
COMP	Pass	4:49pm
CAL	Pass	4:49pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II


County Caldwell Instrument Location Caldwell Co. Jail

Instrument Serial No. 008719 Lenoir, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 27 day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

649
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CALDWELL COUNTY CALDWELL COUNTY JAIL

130

Serial Number: 008719

Test Date: 08/27/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BURNETTE, ANTHONY J

Permit Number: 11304E

Effective:

05/01/2017-05/01/2019

Officer's Name: NONE,

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG814901

Exp Date: 05/29/2020

Test	g/210L	Time
DIAG	Pass	4:41pm
AIR BLK	.00	4:42pm
ACCY CHK	.07	4:43pm
AIR BLK	.00	4:44pm
SUB TEST	.00	4:45pm
AIR BLK	.00	4:46pm
SUB TEST	.00	4:47pm
AIR BLK	.00	4:48pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

This form is used when performing Preventive Maintenance procedures

Forensic Tests for Alcohol Branch

Department of Health and Human Services

Rev. 12/2007

Intox EC/IR-II: Preventive Maintenance

CALDWELL COUNTY CALDWELL COUNTY JAIL 130

Serial Number: 008719 Test Record Number: 2405
Test Date: 08/27/2018 Test Time: 4:49pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	4:50pm
FLO	Pass	4:50pm
FC	Pass	4:50pm

Temperature Tests

Test	Status	Time
FC1	Pass	4:50pm
SRC	Pass	4:50pm
DET	Pass	4:50pm
BAR	Pass	4:50pm
BT	Pass	4:50pm

Blank Tests

Test	Status	Time
AIR	Pass	4:50pm


Printer Tests

Test	Status	Time
PRNT	Pass	4:50pm

CRC Tests

Test	Status	Time
COMP	Pass	4:51pm
CAL	Pass	4:51pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County CASWELL


Instrument Location CASWELL CO DETENTION CENTER

Instrument Serial No. 000593 211 COUNTY PARK RD YANCEYVILLE NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 20 day of AUGUST, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Bruce D. Smith
Signature of Certifying Official

637
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CASWELL COUNTY DETENTION CENTER 160

Serial Number: 008593
Test Date: 08/20/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: SMITH, BRIAN D
Permit Number: 08937E
Effective:
08/01/2017-08/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG734101
Exp Date: 12/07/2019

Test	g/210L	Time
DIAG	Pass	3:41pm
AIR BLK	.00	3:41pm
ACCY CHK	.07	3:42pm
AIR BLK	.00	3:43pm
SUB TEST	.00	3:43pm
AIR BLK	.00	3:44pm
SUB TEST	.00	3:46pm
AIR BLK	.00	3:46pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

CASWELL COUNTY DETENTION CENTER 160

Serial Number: 008593 Test Record Number: 1603
Test Date: 08/20/2018 Test Time: 3:47pm EDT

System Check: Passed

Baseline Tests

Test	Status	Time
IR	Pass	3:47pm
FLO	Pass	3:47pm
FC	Pass	3:47pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:48pm
SRC	Pass	3:48pm
DET	Pass	3:48pm
BAR	Pass	3:48pm
BT	Pass	3:48pm

Blank Tests

Test	Status	Time
AIR	Pass	3:48pm

Printer Tests

Test	Status	Time
PRNT	Pass	3:49pm

CRC Tests

Test	Status	Time
COMP	Pass	3:49pm
CAL	Pass	3:49pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Catawba Instrument Location Hickory PD
Instrument Serial No. 008841 347 2nd Ave SW, Hickory

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 2nd day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Joseph E. Hatcher
Signature of Certifying Official

650
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CATAWBA COUNTY HICKORY PD 170

Serial Number: 008841
Test Date: 08/02/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: HUTCHINSON, JOSEPH E

Permit Number: 19951E

Effective:

08/01/2017-08/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG702302

Exp Date: 01/23/2019


Test	g/210L	Time
DIAG	Pass	3:12pm
AIR BLK	.00	3:13pm
ACCY CHK	.08	3:14pm
AIR BLK	.00	3:15pm
SUB TEST	.00	3:16pm
AIR BLK	.00	3:16pm
SUB TEST	.00	3:18pm
AIR BLK	.00	3:19pm

Reported AC: ~~.00~~ g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

CATAWBA COUNTY HICKORY PD 170

Serial Number: 008841 Test Record Number: 1826
Test Date: 08/02/2018 Test Time: 3:20pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:20pm
FLO	Pass	3:20pm
FC	Pass	3:20pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:21pm
SRC	Pass	3:21pm
DET	Pass	3:21pm
BAR	Pass	3:21pm
BT	Pass	3:21pm

Blank Tests

Test	Status	Time
AIR	Pass	3:21pm


Printer Tests

Test	Status	Time
PRNT	Pass	3:21pm

CRC Tests

Test	Status	Time
COMP	Pass	3:21pm
CAL	Pass	3:21pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County CHATHAM Instrument Location CHATHAM COUNTY
Instrument Serial No. 008591 DETENTION CENTER
PITTSBORO, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 28 day of AUGUST, 20 18, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. B...
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CHATHAM COUNTY DETENTION CENTER 180

Serial Number: 008591
Test Date: 08/28/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R
Permit Number: 15671E
Effective:
07/01/2017-07/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG807102
Exp Date: 03/12/2020

Test	g/210L	Time
DIAG	Pass	3:51pm
AIR BLK	.00	3:52pm
ACCY CHK	.08	3:53pm
AIR BLK	.00	3:53pm
SUB TEST	.00	3:54pm
AIR BLK	.00	3:55pm
SUB TEST	.00	3:57pm
AIR BLK	.00	3:57pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

CHATHAM COUNTY DETENTION CENTER 180

Serial Number: 008591 Test Record Number: 2047
Test Date: 08/28/2018 Test Time: 3:59pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	4:00pm
FLO	Pass	4:00pm
FC	Pass	4:00pm

Temperature Tests

Test	Status	Time
FC1	Pass	4:00pm
SRC	Pass	4:00pm
DET	Pass	4:00pm
BAR	Pass	4:00pm
BT	Pass	4:00pm

Blank Tests

Test	Status	Time
AIR	Pass	4:00pm


Printer Tests

Test	Status	Time
PRNT	Pass	4:00pm

CRC Tests

Test	Status	Time
COMP	Pass	4:00pm
CAL	Pass	4:00pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II


County Cherokee Instrument Location Cherokee Co. Jail

Instrument Serial No. 008622 Murphy, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 28 day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Paul R. Lutter
Signature of Certifying Official

635
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CHEROKEE COUNTY CHEROKEE COUNTY JAIL
190

Serial Number: 008622
Test Date: 08/28/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: CUTLER, DANIEL R

Permit Number: 08457E

Effective:

09/01/2017-09/01/2019

Officer's Name: NONE,

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG734102


Exp Date: 12/07/2019

Test	g/210L	Time
DIAG	Pass	12:50pm
AIR BLK	.00	12:51pm
ACCY CHK	.08	12:52pm
AIR BLK	.00	12:53pm
SUB TEST	.00	12:53pm
AIR BLK	.00	12:54pm
SUB TEST	.00	12:56pm
AIR BLK	.00	12:57pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

CHEROKEE COUNTY CHEROKEE COUNTY JAIL 190

Serial Number: 008622 Test Record Number: 1044
Test Date: 08/28/2018 Test Time: 12:58pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:58pm
FLO	Pass	12:58pm
FC	Pass	12:58pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:58pm
SRC	Pass	12:58pm
DET	Pass	12:58pm
BAR	Pass	12:58pm
BT	Pass	12:58pm

Blank Tests

Test	Status	Time
AIR	Pass	12:59pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:59pm

CRC Tests

Test	Status	Time
COMP	Pass	1:00pm
CAL	Pass	1:00pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Cherokee Instrument Location Cherokee Co. Jail

Instrument Serial No. 008711 Murphy, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 28 day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



David R. Anthony
Signature of Certifying Official

635
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CHEROKEE COUNTY CHEROKEE COUNTY JAIL
190

Serial Number: 008711
Test Date: 08/28/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: *CUTLER, DANIEL R*

Permit Number: 08457E

Effective:

09/01/2017-09/01/2019

Officer's Name: NONE,

Type of Agency: FTA

Agency: DHHS

Test Type: *Breath Test*

Lot Number: AG716202


Exp Date: 06/11/2019

Test	g/210L	Time
DIAG	Pass	12:49pm
AIR BLK	.00	12:50pm
ACCY CHK	.07	12:51pm
AIR BLK	.00	12:52pm
SUB TEST	.00	12:52pm
AIR BLK	.00	12:53pm
SUB TEST	.00	12:55pm
AIR BLK	.00	12:56pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

CHEROKEE COUNTY CHEROKEE COUNTY JAIL 190

Serial Number: 008711 Test Record Number: 951
Test Date: 08/28/2018 Test Time: 12:57pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:57pm
FLO	Pass	12:57pm
FC	Pass	12:57pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:57pm
SRC	Pass	12:57pm
DET	Pass	12:57pm
BAR	Pass	12:57pm
BT	Pass	12:57pm

Blank Tests

Test	Status	Time
AIR	Pass	12:58pm

Printer Tests

Test	Status	Time
PRNT	Pass	12:58pm

CRC Tests

Test	Status	Time
COMP	Pass	12:58pm
CAL	Pass	12:58pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Clay Instrument Location Clay Co. Jail
Instrument Serial No. 008608 Hayesville, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 6 day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Paul R. Cuthbert
Signature of Certifying Official

635
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CLAY COUNTY CLAY COUNTY JAIL 210

Serial Number: 008608
Test Date: 08/06/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: CUTLER, DANIEL R
Permit Number: 08457
Effective:
09/01/2017-09/01/2019

Officer's Name: NONE,
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG716202
Exp Date: 06/11/2019

Test	g/210L	Time
DIAG	Pass	11:18am
AIR BLK	.00	11:19am
ACCY CHK	.07	11:20am
AIR BLK	.00	11:21am
SUB TEST	.00	11:21am
AIR BLK	.00	11:22am
SUB TEST	.00	11:24am
AIR BLK	.00	11:25am

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

CLAY COUNTY CLAY COUNTY JAIL 210

Serial Number: 008608 Test Record Number: 1198
Test Date: 08/06/2018 Test Time: 11:27am EDT

System Check: Passed

Baseline Tests

Test	Status	Time
IR	Pass	11:27am
FLO	Pass	11:27am
FC	Pass	11:27am

Temperature Tests

Test	Status	Time
FC1	Pass	11:27am
SRC	Pass	11:27am
DET	Pass	11:27am
BAR	Pass	11:27am
BT	Pass	11:27am

Blank Tests

Test	Status	Time
AIR	Pass	11:28am


Printer Tests

Test	Status	Time
PRNT	Pass	11:28am

CRC Tests

Test	Status	Time
COMP	Pass	11:28am
CAL	Pass	11:28am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Cleveland Instrument Location BAT Mobile Unit 2

Instrument Serial No. 008973

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 23 day of AUGUST, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Chad Jones
Signature of Certifying Official

659
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CLEVELAND BAT MOBILE UNIT 02 220

Serial Number: 008973
Test Date: 08/23/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: TOWERY, CHAD V

Permit Number: 26632E

Effective:

06/01/2017-06/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG807101

Exp Date: 03/12/2020

Test	g/210L	Time
DIAG	Pass	6:54pm
AIR BLK	.00	6:55pm
ACCY CHK	.08	6:55pm
AIR BLK	.00	6:56pm
SUB TEST	.00	6:57pm
AIR BLK	.00	6:57pm
SUB TEST	.00	6:59pm
AIR BLK	.00	7:00pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

CLEVELAND BAT MOBILE UNIT 02 220

Serial Number: 008973 Test Record Number: 534
Test Date: 08/23/2018 Test Time: 7:01pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	7:01pm
FLO	Pass	7:01pm
FC	Pass	7:01pm

Temperature Tests

Test	Status	Time
FC1	Pass	7:02pm
SRC	Pass	7:02pm
DET	Pass	7:02pm
BAR	Pass	7:02pm
BT	Pass	7:02pm

Blank Tests

Test	Status	Time
AIR	Pass	7:02pm


Printer Tests

Test	Status	Time
PRNT	Pass	7:02pm

CRC Tests

Test	Status	Time
COMP	Pass	7:02pm
CAL	Pass	7:02pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II


County CRAVEN Instrument Location DAT MODEL UNIT 6

Instrument Serial No. 008779 HAVELOCK

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2.degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 18 day of AUGUST, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]

Signature of Certifying Official

663

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CRAVEN COUNTY BAT MOBILE UNIT 6 240

Serial Number: 008779
Test Date: 08/18/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: VARNELL, BRYON L

Permit Number: 16896E

Effective:

09/26/2017-01/26/2026

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG716201

Exp Date: 06/11/2019

Test	g/210L	Time
DIAG	Pass	11:04pm
AIR BLK	.00	11:05pm
ACCY CHK	.07	11:06pm
AIR BLK	.00	11:07pm
SUB TEST	.00	11:07pm
AIR BLK	.00	11:08pm
SUB TEST	.00	11:10pm
AIR BLK	.00	11:11pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

CRAVEN COUNTY BAT MOBILE UNIT 6 240

Serial Number: 008779 Test Record Number: 3503
Test Date: 08/18/2018 Test Time: 11:13pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:13pm
FLO	Pass	11:13pm
FC	Pass	11:14pm

Temperature Tests

Test	Status	Time
FC1	Pass	11:14pm
SRC	Pass	11:14pm
DET	Pass	11:14pm
BAR	Pass	11:14pm
BT	Pass	11:14pm

Blank Tests

Test	Status	Time
AIR	Pass	11:14pm

Printer Tests

Test	Status	Time
PRNT	Pass	11:14pm

CRC Tests

Test	Status	Time
COMP	Pass	11:14pm
CAL	Pass	11:15pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II


County CRAVEN Instrument Location DAT MONDIE UNIT 6

Instrument Serial No. 0075V4 HAVETOCK

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 18 day of AUGUST, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

663
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CRAVEN COUNTY BAT MOBILE UNIT 6 240

Serial Number: 008584

Test Date: 08/18/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: VARNELL, BRYON L

Permit Number: 16896E

Effective:

09/26/2017-01/26/2026

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG807101

Exp Date: 03/12/2020

Test	g/210L	Time
DIAG	Pass	11:14pm
AIR BLK	.00	11:15pm
ACCY CHK	.07	11:16pm
AIR BLK	.00	11:17pm
SUB TEST	.00	11:17pm
AIR BLK	.00	11:18pm
SUB TEST	.00	11:19pm
AIR BLK	.00	11:20pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

CRAVEN COUNTY BAT MOBILE UNIT 6 240
Serial Number: 008584 Test Record Number: 2224
Test Date: 08/18/2018 Test Time: 11:24pm EDT
System Check: Passed

Baseline Tests

Test	Status	Time
IR	Pass	11:24pm
FLO	Pass	11:24pm
FC	Pass	11:24pm

Temperature Tests

Test	Status	Time
FC1	Pass	11:24pm
SRC	Pass	11:24pm
DET	Pass	11:24pm
BAR	Pass	11:24pm
BT	Pass	11:24pm

Blank Tests

Test	Status	Time
AIR	Pass	11:25pm

Printer Tests

Test	Status	Time
PRNT	Pass	11:25pm

CRC Tests

Test	Status	Time
COMP	Pass	11:25pm
CAL	Pass	11:25pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II


County CARROL Instrument Location RAF MOBILE UNIT 6

Instrument Serial No. 008779

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 10 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

663
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CURRITUCK COUNTY BAT MOBILE UNIT 6 260

Serial Number: 008779
Test Date: 08/10/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: VARNELL, BRYON L
Permit Number: 16896E
Effective:
09/26/2017-01/26/2026

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG716201
Exp Date: 06/11/2019

Test	g/210L	Time
DIAG	Pass	8:20pm
AIR BLK	.00	8:21pm
ACCY CHK	.07	8:21pm
AIR BLK	.00	8:22pm
SUB TEST	.00	8:23pm
AIR BLK	.00	8:24pm
SUB TEST	.00	8:25pm
AIR BLK	.00	8:26pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

CURRITUCK COUNTY BAT MOBILE UNIT 6 260

Serial Number: 008779 Test Record Number: 3500

Test Date: 08/10/2018 Test Time: 8:29pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	8:30pm
FLO	Pass	8:30pm
FC	Pass	8:30pm

Temperature Tests

Test	Status	Time
FC1	Pass	8:30pm
SRC	Pass	8:30pm
DET	Pass	8:30pm
BAR	Pass	8:30pm
BT	Pass	8:30pm

Blank Tests

Test	Status	Time
AIR	Pass	8:30pm

Printer Tests

Test	Status	Time
PRNT	Pass	8:30pm

CRC Tests

Test	Status	Time
COMP	Pass	8:31pm
CAL	Pass	8:31pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County CURLANDUCK Instrument Location AAI MADRID UNITS 6

Instrument Serial No. 009574

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 10 day of AUGUST, 2014, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

483
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CURRITUCK COUNTY BAT MOBILE UNIT 6 260

Serial Number: 008584

Test Date: 08/10/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: VARNELL, BRYON L

Permit Number: 16896E

Effective:

09/26/2017-01/26/2026

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG807101

Exp Date: 03/12/2020

Test	g/210L	Time
DIAG	Pass	8:24pm
AIR BLK	.00	8:25pm
ACCY CHK	.07	8:25pm
AIR BLK	.00	8:26pm
SUB TEST	.00	8:26pm
AIR BLK	.00	8:27pm
SUB TEST	.00	8:29pm
AIR BLK	.00	8:30pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

CURRITUCK COUNTY BAT MOBILE UNIT 6 260
Serial Number: 008584 Test Record Number: 2221
Test Date: 08/10/2018 Test Time: 8:31pm EDT
System Check: Passed

Baseline Tests

Test	Status	Time
IR	Pass	8:31pm
FLO	Pass	8:31pm
FC	Pass	8:31pm

Temperature Tests

Test	Status	Time
FC1	Pass	8:32pm
SRC	Pass	8:32pm
DET	Pass	8:32pm
BAR	Pass	8:32pm
BT	Pass	8:32pm

Blank Tests

Test	Status	Time
AIR	Pass	8:32pm


Printer Tests

Test	Status	Time
PRNT	Pass	8:32pm

CRC Tests

Test	Status	Time
COMP	Pass	8:32pm
CAL	Pass	8:32pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II


County CUNNINGHAM Instrument Location SAT MODE UNIT 6

Instrument Serial No. 008637 CLANDY

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 10 day of AUGUST, 20 14, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

663
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CURRITUCK COUNTY BAT MOBILE UNIT 6 260

Serial Number: 008637
Test Date: 08/10/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: VARNELL, BRYON L

Permit Number: 16896E

Effective:

09/26/2017-01/26/2026

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG716201

Exp Date: 06/11/2019

Test	g/210L	Time
DIAG	Pass	8:19pm
AIR BLK	.00	8:20pm
ACCY CHK	.07	8:20pm
AIR BLK	.00	8:21pm
SUB TEST	.00	8:22pm
AIR BLK	.00	8:23pm
SUB TEST	.00	8:24pm
AIR BLK	.00	8:25pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007

Intox EC/IR-II: Preventive Maintenance

CURRITUCK COUNTY BAT MOBILE UNIT 6 260

Serial Number: 008637 Test Record Number: 2934
Test Date: 08/10/2018 Test Time: 8:28pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	8:28pm
FLO	Pass	8:28pm
FC	Pass	8:28pm

Temperature Tests

Test	Status	Time
FC1	Pass	8:29pm
SRC	Pass	8:29pm
DET	Pass	8:29pm
BAR	Pass	8:29pm
BT	Pass	8:29pm

Blank Tests

Test	Status	Time
AIR	Pass	8:29pm


Printer Tests

Test	Status	Time
PRNT	Pass	8:29pm

CRC Tests

Test	Status	Time
COMP	Pass	8:29pm
CAL	Pass	8:29pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Currituck Instrument Location Currituck Co. S.O.
Instrument Serial No. 008947 407-A Maple Rd., Maple, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 30th day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

643
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CURRITUCK COUNTY CURRITUCK SO-MAPLE
260

Serial Number: 008947
Test Date: 08/30/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: GUARD, KELLY G
Permit Number: 12955E
Effective:
06/01/2017-06/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG702302
Exp Date: 01/23/2019

Test	g/210L	Time
DIAG	Pass	10:32am
AIR BLK	.00	10:32am
ACCY CHK	.07	10:33am
AIR BLK	.00	10:34am
SUB TEST	.00	10:34am
AIR BLK	.00	10:35am
SUB TEST	.00	10:37am
AIR BLK	.00	10:38am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

CURRITUCK COUNTY CURRITUCK SO-MAPLE 260

Serial Number: 008947 Test Record Number: 2249
Test Date: 08/30/2018 Test Time: 10:39am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:39am
FLO	Pass	10:39am
FC	Pass	10:40am

Temperature Tests

Test	Status	Time
FC1	Pass	10:40am
SRC	Pass	10:40am
DET	Pass	10:40am
BAR	Pass	10:40am
BT	Pass	10:40am

Blank Tests

Test	Status	Time
AIR	Pass	10:40am

Printer Tests

Test	Status	Time
PRNT	Pass	10:40am

CRC Tests

Test	Status	Time
COMP	Pass	10:41am
CAL	Pass	10:41am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County DARE Instrument Location DARE Co. Detection Ctr.
Instrument Serial No. 008851 1044 Driftwood Pt., Manteo, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 31st day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

DARE COUNTY DARE CO DETENTION CE 270

Serial Number: 008851
Test Date: 08/03/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: KEESLER, LINDA A
Permit Number: 11646
Effective:
08/01/2017-08/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG716201
Exp Date: 06/11/2019

Test	g/210L	Time
DIAG	Pass	2:40pm
AIR BLK	.00	2:41pm
ACCY CHK	.07	2:42pm
AIR BLK	.00	2:43pm
SUB TEST	.00	2:43pm
AIR BLK	.00	2:44pm
SUB TEST	.00	2:46pm
AIR BLK	.00	2:47pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

DARE COUNTY DARE CO DETENTION CE 270

Serial Number: 008851 Test Record Number: 611
Test Date: 08/03/2018 Test Time: 2:49pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:49pm
FLO	Pass	2:49pm
FC	Pass	2:50pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:50pm
SRC	Pass	2:50pm
DET	Pass	2:50pm
BAR	Pass	2:50pm
BT	Pass	2:50pm

Blank Tests

Test	Status	Time
AIR	Pass	2:50pm


Printer Tests

Test	Status	Time
PRNT	Pass	2:50pm

CRC Tests

Test	Status	Time
COMP	Pass	2:50pm
CAL	Pass	2:50pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County DARE Instrument Location DARE Co. Retention Ctr.
Instrument Serial No. 008783 1044 Driftwood Dr., Manteo, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 31st day of AUGUST, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

DARE COUNTY DARE CO DETENTION CE 270

Serial Number: 008783
Test Date: 08/03/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: KEESLER, LINDA A

Permit Number: 11646

Effective:

08/01/2017-08/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG734101

Exp Date: 12/07/2019

Test	g/210L	Time
DIAG	Pass	2:39pm
AIR BLK	.00	2:40pm
ACCY CHK	.07	2:40pm
AIR BLK	.00	2:41pm
SUB TEST	.00	2:41pm
AIR BLK	.00	2:42pm
SUB TEST	.00	2:44pm
AIR BLK	.00	2:45pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

DARE COUNTY DARE CO DETENTION CE 270

Serial Number: 008783 Test Record Number: 764
Test Date: 08/03/2018 Test Time: 2:45pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:46pm
FLO	Pass	2:46pm
FC	Pass	2:46pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:46pm
SRC	Pass	2:46pm
DET	Pass	2:46pm
BAR	Pass	2:46pm
BT	Pass	2:46pm

Blank Tests

Test	Status	Time
AIR	Pass	2:46pm

Printer Tests

Test	Status	Time
PRNT	Pass	2:46pm

CRC Tests

Test	Status	Time
COMP	Pass	2:47pm
CAL	Pass	2:47pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II

County DARE Instrument Location DARE Co. Detention Ctr.
Instrument Serial No. 008884 1044 Driftwood Dr., Manteo, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 17th day of August, 20 18 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Linda A. Keel
Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

DARE COUNTY DARE CO DETENTION CE 270

Serial Number: 008804

Test Date: 08/17/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: KEESLER, LINDA A

Permit Number: 11646

Effective:

08/01/2017-08/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG716201

Exp Date: 06/11/2019

Test	g/210L	Time
DIAG	Pass	11:00am
AIR BLK	.00	11:02am
ACCY CHK	.07	11:02am
AIR BLK	.00	11:03am
SUB TEST	.00	11:04am
AIR BLK	.00	11:04am
SUB TEST	.00	11:06am
AIR BLK	.00	11:07am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

DARE COUNTY DARE CO DETENTION CE 270

Serial Number: 008804 Test Record Number: 2105
Test Date: 08/17/2018 Test Time: 11:08am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:08am
FLO	Pass	11:08am
FC	Pass	11:08am

Temperature Tests

Test	Status	Time
FC1	Pass	11:08am
SRC	Pass	11:08am
DET	Pass	11:08am
BAR	Pass	11:08am
BT	Pass	11:08am

Blank Tests

Test	Status	Time
AIR	Pass	11:09am

Printer Tests

Test	Status	Time
PRNT	Pass	11:09am

CRC Tests

Test	Status	Time
COMP	Pass	11:09am
CAL	Pass	11:09am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Davie Instrument Location Davie County Jail
Instrument Serial No. 008905 Mocksville, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 9 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature] Signature of Certifying Official 657 Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

DAVIE COUNTY DAVIE COUNTY JAIL 290

Serial Number: 008905
Test Date: 08/09/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name:
BENFIELD II, KENNETH R
Permit Number: 22067E
Effective:
06/01/2018-06/01/2020

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG702401
Exp Date: 01/24/2019


Test	g/210L	Time
DIAG	Pass	11:10am
AIR BLK	.00	11:11am
ACCY CHK	.08	11:12am
AIR BLK	.00	11:13am
SUB TEST	.00	11:13am
AIR BLK	.00	11:14am
SUB TEST	.00	11:16am
AIR BLK	.00	11:17am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

DAVIE COUNTY DAVIE COUNTY JAIL 290

Serial Number: 008905 Test Record Number: 2240
Test Date: 08/09/2018 Test Time: 11:17am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:18am
FLO	Pass	11:18am
FC	Pass	11:18am

Temperature Tests

Test	Status	Time
FC1	Pass	11:18am
SRC	Pass	11:18am
DET	Pass	11:18am
BAR	Pass	11:18am
BT	Pass	11:18am

Blank Tests

Test	Status	Time
AIR	Pass	11:19am


Printer Tests

Test	Status	Time
PRNT	Pass	11:19am

CRC Tests

Test	Status	Time
COMP	Pass	11:19am
CAL	Pass	11:19am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County DURHAM

Instrument Location Durham Co JAIL


Instrument Serial No. 008859

219 S. Mangum St Durham NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 10 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

642
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

DURHAM COUNTY DURHAM COUNTY JAIL 310

Serial Number: 008859
Test Date: 08/10/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BARNES, STOKES
Permit Number: 11434E
Effective:
05/01/2017-05/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG710701
Exp Date: 04/17/2019

Test	g/210L	Time
DIAG	Pass	9:56am
AIR BLK	.00	9:57am
ACCY CHK	.08	9:58am
AIR BLK	.00	9:59am
SUB TEST	.00	9:59am
AIR BLK	.00	10:00am
SUB TEST	.00	10:01am
AIR BLK	.00	10:02am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

DURHAM COUNTY DURHAM COUNTY JAIL 310

Serial Number: 008859 Test Record Number: 2201
Test Date: 08/10/2018 Test Time: 10:04am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:04am
FLO	Pass	10:04am
FC	Pass	10:04am

Temperature Tests

Test	Status	Time
FC1	Pass	10:04am
SRC	Pass	10:04am
DET	Pass	10:04am
BAR	Pass	10:04am
BT	Pass	10:04am

Blank Tests

Test	Status	Time
AIR	Pass	10:05am


Printer Tests

Test	Status	Time
PRNT	Pass	10:05am

CRC Tests

Test	Status	Time
COMP	Pass	10:05am
CAL	Pass	10:05am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II


County Durham Instrument Location Bat Mobile Unit 8

Instrument Serial No 008775 Durham P.D.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 12 day of August, 20 18 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Donna B. Skinn
Signature of Certifying Official

6421
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

DURHAM COUNTY BAT MOBILE UNIT 8 310

Serial Number: 008775
Test Date: 08/11/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Female
Driver's License State: XX
Driver's License Number: NONE]

Analyst's Name: SKINNER, TONYA B
Permit Number: 13651E
Effective:
08/01/2017-08/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG734101
Exp Date: 12/07/2019

Test	g/210L	Time
DIAG	Pass	11:48pm
AIR BLK	.00	11:49pm
ACCY CHK	.07	11:49pm
AIR BLK	.00	11:50pm
SUB TEST	.00	11:51pm
AIR BLK	.00	11:51pm
SUB TEST	.00	11:53pm
AIR BLK	.00	11:54pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

DURHAM COUNTY BAT MOBILE UNIT 8 310

Serial Number: 008775 Test Record Number: 1779
Test Date: 08/11/2018 Test Time: 11:54pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:55pm
FLO	Pass	11:55pm
FC	Pass	11:55pm

Temperature Tests

Test	Status	Time
FC1	Pass	11:55pm
SRC	Pass	11:55pm
DET	Pass	11:55pm
BAR	Pass	11:55pm
BT	Pass	11:55pm

Blank Tests

Test	Status	Time
AIR	Pass	11:56pm


Printer Tests

Test	Status	Time
PRNT	Pass	11:56pm

CRC Tests

Test	Status	Time
COMP	Pass	11:56pm
CAL	Pass	11:56pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Durham Instrument Location Bat Mobile Unit-A
Instrument Serial No. 008601 Durham PD

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 11 day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Danya B Skinner 444
Signature of Certifying Official Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

DURHAM COUNTY BATMOBILE UNIT 8 310

Serial Number: 008601
Test Date: 08/11/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENACE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Female
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: SKINNER, TONYA B
Permit Number: 13651E
Effective:
08/01/2017-08/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG702401
Exp Date: 01/24/2019

Test	g/210L	Time
DIAG	Pass	11:11pm
AIR BLK	.00	11:11pm
ACCY CHK	.08	11:12pm
AIR BLK	.00	11:13pm
SUB TEST	.00	11:14pm
AIR BLK	.00	11:15pm
SUB TEST	.00	11:17pm
AIR BLK	.00	11:18pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

DURHAM COUNTY BATMOBILE UNIT 8 310

Serial Number: 008601 Test Record Number: 1287
Test Date: 08/11/2018 Test Time: 11:19pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:20pm
FLO	Pass	11:20pm
FC	Pass	11:20pm

Temperature Tests

Test	Status	Time
FC1	Pass	11:20pm
SRC	Pass	11:20pm
DET	Pass	11:20pm
BAR	Pass	11:20pm
BT	Pass	11:20pm

Blank Tests

Test	Status	Time
AIR	Pass	11:21pm

Printer Tests

Test	Status	Time
PRNT	Pass	11:21pm

CRC Tests

Test	Status	Time
COMP	Pass	11:21pm
CAL	Pass	11:21pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Durham Instrument Location Bat Mobile Unit

Instrument Serial No 008736 Durham PD

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 11 day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Donya B Skinner
Signature of Certifying Official

644
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

DURHAM COUNTY BAT MOBILE UNIT 8 310

Serial Number: 008736
Test Date: 08/11/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Female

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: SKINNER, TONYA B

Permit Number: 13651E

Effective:

08/01/2017-08/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG716201

Exp Date: 06/11/2019

Test	g/210L	Time
DIAG	Pass	10:59pm
AIR BLK	.00	11:00pm
ACCY CHK	.08	11:01pm
AIR BLK	.00	11:02pm
SUB TEST	.00	11:02pm
AIR BLK	.00	11:03pm
SUB TEST	.00	11:05pm
AIR BLK	.00	11:06pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Subject Test

DURHAM COUNTY BAT MOBILE UNIT 8 310

Serial Number: 008736
Test Date: 08/11/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Female
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: SKINNER, TONYA B
Permit Number: 13651E
Effective:
08/01/2017-08/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG716201
Exp Date: 06/11/2019

Test	g/210L	Time
DIAG	Pass	10:59pm
AIR BLK	.00	11:00pm
ACCY CHK	.08	11:01pm
AIR BLK	.00	11:02pm
SUB TEST	.00	11:02pm
AIR BLK	.00	11:03pm
SUB TEST	.00	11:05pm
AIR BLK	.00	11:06pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II

County Durham Instrument Location Pat Mobile Unit 8
Instrument Serial No. 008816 Durham PD

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 11 day of August, 20 18 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Donna B Skenni 640
Signature of Certifying Official Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

DURHAM COUNTY BAT MOBILE UNIT 8 310

Serial Number: 008816
Test Date: 08/11/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Female

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: SKINNER, TONYA B

Permit Number: 13651E

Effective:

08/01/2017-08/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG805801


Exp Date: 02/27/2020

Test	g/210L	Time
DIAG	Pass	11:52pm
AIR BLK	.00	11:53pm
ACCY CHK	.07	11:53pm
AIR BLK	.00	11:54pm
SUB TEST	.00	11:55pm
AIR BLK	.00	11:56pm
SUB TEST	.00	11:57pm
AIR BLK	.00	11:58pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

DURHAM COUNTY BAT MOBILE UNIT 8 310

Serial Number: 008816 Test Record Number: 7431
Test Date: 08/11/2018 Test Time: 11:59pm EDT

System Check: Passed

Baseline Tests

Test	Status	Time
IR	Pass	11:59pm
FLO	Pass	11:59pm
FC	Pass	11:59pm

Temperature Tests

Test	Status	Time
FC1	Pass	11:59pm
SRC	Pass	11:59pm
DET	Pass	11:59pm
BAR	Pass	11:59pm
BT	Pass	11:59pm

Blank Tests

Test	Status	Time
AIR	Pass	12:00am


Printer Tests

Test	Status	Time
PRNT	Pass	12:00am

CRC Tests

Test	Status	Time
COMP	Pass	12:00am
CAL	Pass	12:00am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II

County Durham Instrument Location Durham Co Jail
Instrument Serial No. 008891 219 S. Mangum St Durham, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 22 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

642
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

DURHAM COUNTY DURHAM COUNTY JAIL 310

Serial Number: 008891
Test Date: 08/22/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BARNES, STOKES
Permit Number: 11434E
Effective:
05/01/2017-05/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG734101
Exp Date: 12/07/2019

Test	g/210L	Time
DIAG	Pass	9:43am
AIR BLK	.00	9:43am
ACCY CHK	.08	9:44am
AIR BLK	.00	9:45am
SUB TEST	.00	9:45am
AIR BLK	.00	9:46am
SUB TEST	.00	9:47am
AIR BLK	.00	9:48am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

DURHAM COUNTY DURHAM COUNTY JAIL 310

Serial Number: 008891 Test Record Number: 3884
Test Date: 08/22/2018 Test Time: 9:50am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	9:50am
FLO	Pass	9:50am
FC	Pass	9:50am

Temperature Tests

Test	Status	Time
FC1	Pass	9:50am
SRC	Pass	9:50am
DET	Pass	9:50am
BAR	Pass	9:50am
BT	Pass	9:50am

Blank Tests

Test	Status	Time
AIR	Pass	9:51am

Printer Tests

Test	Status	Time
PRNT	Pass	9:51am

CRC Tests

Test	Status	Time
COMP	Pass	9:51am
CAL	Pass	9:51am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Durham Instrument Location Durham Co Jail
Instrument Serial No. 008878 219 S. Mangum St Durham, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 22 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

662
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

DURHAM COUNTY DURHAM COUNTY JAIL 310

Serial Number: 008878
Test Date: 08/22/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, STOKES

Permit Number: 11434E

Effective:

05/01/2017-05/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG807102

Exp Date: 03/12/2020

Test	g/210L	Time
DIAG	Pass	9:41am
AIR BLK	.00	9:42am
ACCY CHK	.08	9:43am
AIR BLK	.00	9:44am
SUB TEST	.00	9:44am
AIR BLK	.00	9:45am
SUB TEST	.00	9:47am
AIR BLK	.00	9:48am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

DURHAM COUNTY DURHAM COUNTY JAIL 310

Serial Number: 008878 Test Record Number: 4255
Test Date: 08/22/2018 Test Time: 9:50am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	9:50am
FLO	Pass	9:50am
FC	Pass	9:50am

Temperature Tests

Test	Status	Time
FC1	Pass	9:50am
SRC	Pass	9:50am
DET	Pass	9:50am
BAR	Pass	9:50am
BT	Pass	9:50am

Blank Tests

Test	Status	Time
AIR	Pass	9:51am


Printer Tests

Test	Status	Time
PRNT	Pass	9:51am

CRC Tests

Test	Status	Time
COMP	Pass	9:51am
CAL	Pass	9:51am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Edgecombe Instrument Location Edgecombe Co. Magistrates office

Instrument Serial No. 008847 300 S. ANACONDA RD., TARRIOT, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 21ST day of AUGUST, 20 18 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

697
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

EDGECOMBE COUNTY EDGECOMBE CO MAGISTR
320

Serial Number: 008847
Test Date: 08/21/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: KEESLER, LINDA A
Permit Number: 11646
Effective:
08/01/2017-08/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG702402
Exp Date: 01/24/2019


Test	g/210L	Time
DIAG	Pass	12:13pm
AIR BLK	.00	12:14pm
ACCY CHK	.08	12:15pm
AIR BLK	.00	12:16pm
SUB TEST	.00	12:17pm
AIR BLK	.00	12:18pm
SUB TEST	.00	12:19pm
AIR BLK	.00	12:20pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007

Intox EC/IR-II: Preventive Maintenance

EDGECOMBE COUNTY EDGECOMBE CO MAGISTR 320

Serial Number: 008847 Test Record Number: 650
Test Date: 08/21/2018 Test Time: 12:22pm EDT

System Check: Passed

Baseline Tests

Test	Status	Time
IR	Pass	12:22pm
FLO	Pass	12:22pm
FC	Pass	12:22pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:22pm
SRC	Pass	12:22pm
DET	Pass	12:22pm
BAR	Pass	12:22pm
BT	Pass	12:22pm

Blank Tests

Test	Status	Time
AIR	Pass	12:23pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:23pm

CRC Tests

Test	Status	Time
COMP	Pass	12:23pm
CAL	Pass	12:23pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Edgecombe Instrument Location Edgecombe Co. Magistrate office

Instrument Serial No. 008851 3005 AVACONNA RD., TARBORO, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 21st day of AUGUST, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

EDGECOMBE COUNTY EDGECOMBE CO MAGISTR.
320

Serial Number: 008851
Test Date: 08/21/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: KEESLER, LINDA A
Permit Number: 11646
Effective:
08/01/2017-08/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG721401
Exp Date: 08/02/2019


Test	g/210L	Time
DIAG	Pass	12:19pm
AIR BLK	.00	12:20pm
ACCY CHK	.08	12:20pm
AIR BLK	.00	12:21pm
SUB TEST	.00	12:22pm
AIR BLK	.00	12:23pm
SUB TEST	.00	12:25pm
AIR BLK	.00	12:25pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

EDGECOMBE COUNTY EDGECOMBE CO MAGISTR 320

Serial Number: 008851 Test Record Number: 614
Test Date: 08/21/2018 Test Time: 12:27pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:27pm
FLO	Pass	12:27pm
FC	Pass	12:27pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:27pm
SRC	Pass	12:27pm
DET	Pass	12:27pm
BAR	Pass	12:27pm
BT	Pass	12:27pm

Blank Tests

Test	Status	Time
AIR	Pass	12:28pm

Printer Tests

Test	Status	Time
PRNT	Pass	12:28pm

CRC Tests

Test	Status	Time
COMP	Pass	12:28pm
CAL	Pass	12:28pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Edgecombe Instrument Location Edgecombe Co. Magistrate's

Instrument Serial No. 008603 Office, 300 S. Anawanda Rd., Tarboro, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 29th day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

643
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

EDGECOMBE COUNTY EDGECOMBE CO MAGISTR
320

Serial Number: 008603
Test Date: 08/29/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: GUARD, KELLY G
Permit Number: 12955E
Effective:
06/01/2017-06/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG702402
Exp Date: 01/24/2019


Test	g/210L	Time
DIAG	Pass	9:42am
AIR BLK	.00	9:43am
ACCY CHK	.08	9:44am
AIR BLK	.00	9:45am
SUB TEST	.00	9:45am
AIR BLK	.00	9:46am
SUB TEST	.00	9:48am
AIR BLK	.00	9:48am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

EDGECOMBE COUNTY EDGECOMBE CO MAGISTR 320

Serial Number: 008603 Test Record Number: 1713
Test Date: 08/29/2018 Test Time: 9:50am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	9:50am
FLO	Pass	9:50am
FC	Pass	9:50am

Temperature Tests

Test	Status	Time
FC1	Pass	9:51am
SRC	Pass	9:51am
DET	Pass	9:51am
BAR	Pass	9:51am
BT	Pass	9:51am

Blank Tests

Test	Status	Time
AIR	Pass	9:51am


Printer Tests

Test	Status	Time
PRNT	Pass	9:51am

CRC Tests

Test	Status	Time
COMP	Pass	9:51am
CAL	Pass	9:51am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Edgecombe Instrument Location Edgecombe Co. Magistrate's

Instrument Serial No. 008663 Office, 300 S. Anacosta Rd., Tarboro, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 29th day of August, 20 18 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

643
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

EDGECOMBE COUNTY EDGECOMBE CO MAGISTR
320

Serial Number: 008663
Test Date: 08/29/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: GUARD, KELLY G

Permit Number: 12955E

Effective:

06/01/2017-06/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG721401

Exp Date: 08/02/2019


Test	g/210L	Time
DIAG	Pass	9:32am
AIR BLK	.00	9:33am
ACCY CHK	.08	9:33am
AIR BLK	.00	9:34am
SUB TEST	.00	9:35am
AIR BLK	.00	9:35am
SUB TEST	.00	9:37am
AIR BLK	.00	9:38am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

EDGECOMBE COUNTY EDGECOMBE CO MAGISTR 320

Serial Number: 008663 Test Record Number: 2943
Test Date: 08/29/2018 Test Time: 9:40am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	9:41am
FLO	Pass	9:41am
FC	Pass	9:41am

Temperature Tests

Test	Status	Time
FC1	Pass	9:41am
SRC	Pass	9:41am
DET	Pass	9:41am
BAR	Pass	9:41am
BT	Pass	9:41am

Blank Tests

Test	Status	Time
AIR	Pass	9:42am

Printer Tests

Test	Status	Time
PRNT	Pass	9:42am

CRC Tests

Test	Status	Time
COMP	Pass	9:42am
CAL	Pass	9:42am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County FORSYTH Instrument Location FORSYTH COUNTY DETENTION
Instrument Serial No. 008925 WINSTON-SALEM, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

657
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

FORSYTH COUNTY FORSYTH CO DETENTION
330

Serial Number: 008925
Test Date: 08/13/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name:
BENFIELD II, KENNETH R
Permit Number: 22067E
Effective:
06/01/2018-06/01/2020

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG805801
Exp Date: 02/27/2020

Test	g/210L	Time
DIAG	Pass	9:35am
AIR BLK	.00	9:36am
ACCY CHK	.08	9:36am
AIR BLK	.00	9:37am
SUB TEST	.00	9:38am
AIR BLK	.00	9:39am
SUB TEST	.00	9:41am
AIR BLK	.00	9:42am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

FORSYTH COUNTY FORSYTH CO DETENTION 330

Serial Number: 008925 Test Record Number: 2324
Test Date: 08/13/2018 Test Time: 9:42am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	9:43am
FLO	Pass	9:43am
FC	Pass	9:43am

Temperature Tests

Test	Status	Time
FC1	Pass	9:43am
SRC	Pass	9:43am
DET	Pass	9:43am
BAR	Pass	9:43am
BT	Pass	9:43am

Blank Tests

Test	Status	Time
AIR	Pass	9:44am


Printer Tests

Test	Status	Time
PRNT	Pass	9:44am

CRC Tests

Test	Status	Time
COMP	Pass	9:44am
CAL	Pass	9:44am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County FORSYTH

Instrument Location FORSYTH COUNTY DETENTION

Instrument Serial No. 008583

WINSTON-SALEM, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

657
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

FORSYTH COUNTY FORSYTH CO DETENTION
330

Serial Number: 008583
Test Date: 08/13/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name:
BENFIELD II, KENNETH R
Permit Number: 22067E
Effective:
06/01/2018-06/01/2020

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG805801
Exp Date: 02/27/2020

Test	g/210L	Time
DIAG	Pass	9:26am
AIR BLK	.00	9:26am
ACCY CHK	.08	9:27am
AIR BLK	.00	9:28am
SUB TEST	.00	9:29am
AIR BLK	.00	9:30am
SUB TEST	.00	9:31am
AIR BLK	.00	9:32am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

FORSYTH COUNTY FORSYTH CO DETENTION 330

Serial Number: 008583 Test Record Number: 7316
Test Date: 08/13/2018 Test Time: 9:33am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	9:33am
FLO	Pass	9:33am
FC	Pass	9:33am

Temperature Tests

Test	Status	Time
FC1	Pass	9:34am
SRC	Pass	9:34am
DET	Pass	9:34am
BAR	Pass	9:34am
BT	Pass	9:34am

Blank Tests

Test	Status	Time
AIR	Pass	9:34am


Printer Tests

Test	Status	Time
PRNT	Pass	9:34am

CRC Tests

Test	Status	Time
COMP	Pass	9:34am
CAL	Pass	9:34am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Forsyth Instrument Location Forsyth County Detention
Instrument Serial No. 008659 Winston-Salem, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

657
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

FORSYTH COUNTY FORSYTH CO DETENTION
330

Serial Number: 008659
Test Date: 08/13/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name:
BENFIELD II, KENNETH R
Permit Number: 22067E
Effective:
06/01/2018-06/01/2020

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG805801
Exp Date: 02/27/2020

Test	g/210L	Time
DIAG	Pass	9:23am
AIR BLK	.00	9:23am
ACCY CHK	.08	9:24am
AIR BLK	.00	9:25am
SUB TEST	.00	9:26am
AIR BLK	.00	9:27am
SUB TEST	.00	9:29am
AIR BLK	.00	9:30am

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

FORSYTH COUNTY FORSYTH CO DETENTION 330

Serial Number: 008659 Test Record Number: 4897
Test Date: 08/13/2018 Test Time: 9:31am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	9:31am
FLO	Pass	9:31am
FC	Pass	9:31am

Temperature Tests

Test	Status	Time
FC1	Pass	9:31am
SRC	Pass	9:31am
DET	Pass	9:31am
BAR	Pass	9:31am
BT	Pass	9:31am

Blank Tests

Test	Status	Time
AIR	Pass	9:32am


Printer Tests

Test	Status	Time
PRNT	Pass	9:32am

CRC Tests

Test	Status	Time
COMP	Pass	9:32am
CAL	Pass	9:32am

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County FORSYTH Instrument Location KERNERSVILLE POLICE

Instrument Serial No. 008650 Department

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 8 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

657
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

FORSYTH COUNTY KERNERSVILLE PD 330

Serial Number: 008650
Test Date: 08/08/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name:
BENFIELD II, KENNETH R
Permit Number: 22067E
Effective:
06/01/2018-06/01/2020

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG805801
Exp Date: 02/27/2020


Test	g/210L	Time
DIAG	Pass	10:04am
AIR BLK	.00	10:04am
ACCY CHK	.07	10:05am
AIR BLK	.00	10:06am
SUB TEST	.00	10:06am
AIR BLK	.00	10:07am
SUB TEST	.00	10:10am
AIR BLK	.00	10:11am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

FORSYTH COUNTY KERNERSVILLE PD 330

Serial Number: 008650 Test Record Number: 1455
Test Date: 08/08/2018 Test Time: 10:12am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:12am
FLO	Pass	10:12am
FC	Pass	10:12am

Temperature Tests

Test	Status	Time
FC1	Pass	10:12am
SRC	Pass	10:12am
DET	Pass	10:12am
BAR	Pass	10:12am
BT	Pass	10:12am

Blank Tests

Test	Status	Time
AIR	Pass	10:13am


Printer Tests

Test	Status	Time
PRNT	Pass	10:13am

CRC Tests

Test	Status	Time
COMP	Pass	10:13am
CAL	Pass	10:13am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Franklin Instrument Location Bot Mobile Unit 8
Instrument Serial No. 008736 Franklin CO 50

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 24th day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Jonya B Skinner
Signature of Certifying Official

644
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

FRANKLIN COUNTY BAT MOBILE UNIT 8 340

Serial Number: 008736
Test Date: 08/24/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Female

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: SKINNER, TONYA B

Permit Number: 13651E

Effective:

08/01/2017-08/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG716201


Exp Date: 06/11/2019

Test	g/210L	Time
DIAG	Pass	10:26pm
AIR BLK	.00	10:27pm
ACCY CHK	.08	10:27pm
AIR BLK	.00	10:28pm
SUB TEST	.00	10:29pm
AIR BLK	.00	10:30pm
SUB TEST	.00	10:31pm
AIR BLK	.00	10:32pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

FRANKLIN COUNTY BAT MOBILE UNIT 8 340

Serial Number: 008736 Test Record Number: 914
Test Date: 08/24/2018 Test Time: 10:38pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:38pm
FLO	Pass	10:38pm
FC	Pass	10:38pm

Temperature Tests

Test	Status	Time
FC1	Pass	10:39pm
SRC	Pass	10:39pm
DET	Pass	10:39pm
BAR	Pass	10:39pm
BT	Pass	10:39pm

Blank Tests

Test	Status	Time
AIR	Pass	10:39pm


Printer Tests

Test	Status	Time
PRNT	Pass	10:39pm

CRC Tests

Test	Status	Time
COMP	Pass	10:39pm
CAL	Pass	10:39pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II

County Franklin


Instrument Location Bat Mobile Unit 8

Instrument Serial No. 008615 Franklin CO SO

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 24 day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Danya B Skinner 644
Signature of Certifying Official Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

FRANKLIN COUNTY BAT MOBILE UNIT 8 340

Serial Number: 008615
Test Date: 08/24/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Female

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: SKINNER, TONYA B

Permit Number: 13651E

Effective:

08/01/2017-08/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG716201

Exp Date: 06/11/2019

Test	g/210L	Time
DIAG	Pass	10:19pm
AIR BLK	.00	10:20pm
ACCY CHK	.07	10:20pm
AIR BLK	.00	10:21pm
SUB TEST	.00	10:22pm
AIR BLK	.00	10:22pm
SUB TEST	.00	10:24pm
AIR BLK	.00	10:25pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

FRANKLIN COUNTY BAT MOBILE UNIT 8 340

Serial Number: 008615 Test Record Number: 5551
Test Date: 08/24/2018 Test Time: 10:37pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:37pm
FLO	Pass	10:37pm
FC	Pass	10:37pm

Temperature Tests

Test	Status	Time
FC1	Pass	10:38pm
SRC	Pass	10:38pm
DET	Pass	10:38pm
BAR	Pass	10:38pm
BT	Pass	10:38pm

Blank Tests

Test	Status	Time
AIR	Pass	10:38pm

Printer Tests

Test	Status	Time
PRNT	Pass	10:38pm

CRC Tests

Test	Status	Time
COMP	Pass	10:38pm
CAL	Pass	10:38pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II

County Franklin

Instrument Location Bat mobile Unit 8

Instrument Serial No. 008601

Franklin CO SO

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 24 day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Danya B Skinner

Signature of Certifying Official

644

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

FRANKLIN COUNTY BATMOBILE UNIT 8 340

Serial Number: 008601
Test Date: 08/24/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Female
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: SKINNER, TONYA B
Permit Number: 13651E
Effective:
08/01/2017-08/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG702401
Exp Date: 01/24/2019

Test	g/210L	Time
DIAG	Pass	10:15pm
AIR BLK	.00	10:16pm
ACCY CHK	.08	10:17pm
AIR BLK	.00	10:17pm
SUB TEST	.00	10:18pm
AIR BLK	.00	10:19pm
SUB TEST	.00	10:21pm
AIR BLK	.00	10:21pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

FRANKLIN COUNTY BATMOBILE UNIT 8 340

Serial Number: 008601 Test Record Number: 1294
Test Date: 08/24/2018 Test Time: 10:24pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:24pm
FLO	Pass	10:24pm
FC	Pass	10:24pm

Temperature Tests

Test	Status	Time
FC1	Pass	10:25pm
SRC	Pass	10:25pm
DET	Pass	10:25pm
BAR	Pass	10:25pm
BT	Pass	10:25pm

Blank Tests

Test	Status	Time
AIR	Pass	10:25pm


Printer Tests

Test	Status	Time
PRNT	Pass	10:25pm

CRC Tests

Test	Status	Time
COMP	Pass	10:25pm
CAL	Pass	10:25pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II


County Franklin Instrument Location Bat Mobile Unit 8

Instrument Serial No. 008929 Franklin CO 50

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 24 day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Dennis B. Skinner
Signature of Certifying Official

644
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

FRANKLIN COUNTY BAT MOBILE UNIT 8 340

Serial Number: 008929
Test Date: 08/24/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Female

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: SKINNER, TONYA B

Permit Number: 13651E

Effective:

08/01/2017-08/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG814901

Exp Date: 05/29/2020

Test	g/210L	Time
DIAG	Pass	10:08pm
AIR BLK	.00	10:09pm
ACCY CHK	.08	10:10pm
AIR BLK	.00	10:11pm
SUB TEST	.00	10:12pm
AIR BLK	.00	10:13pm
SUB TEST	.00	10:14pm
AIR BLK	.00	10:15pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

FRANKLIN COUNTY BAT MOBILE UNIT 8 340

Serial Number: 008929 Test Record Number: 1005
Test Date: 08/24/2018 Test Time: 10:21pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:22pm
FLO	Pass	10:22pm
FC	Pass	10:22pm

Temperature Tests

Test	Status	Time
FC1	Pass	10:22pm
SRC	Pass	10:22pm
DET	Pass	10:22pm
BAR	Pass	10:22pm
BT	Pass	10:22pm

Blank Tests

Test	Status	Time
AIR	Pass	10:23pm

Printer Tests

Test	Status	Time
PRNT	Pass	10:23pm

CRC Tests

Test	Status	Time
COMP	Pass	10:23pm
CAL	Pass	10:23pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II

County Franklin Instrument Location BAT mobile unit 8
Instrument Serial No. 008775 Franklin CO 50

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 24th day of August, 20 18 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Danya B Skinner
Signature of Certifying Official

644
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

FRANKLIN COUNTY BAT MOBILE UNIT 8 340

Serial Number: 008775
Test Date: 08/24/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Female
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: SKINNER, TONYA B
Permit Number: 13651E
Effective:
08/01/2017-08/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG734101
Exp Date: 12/07/2019

Test	g/210L	Time
DIAG	Pass	10:47pm
AIR BLK	.00	10:48pm
ACCY CHK	.08	10:48pm
AIR BLK	.00	10:49pm
SUB TEST	.00	10:50pm
AIR BLK	.00	10:51pm
SUB TEST	.00	10:53pm
AIR BLK	.00	10:54pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

FRANKLIN COUNTY BAT MOBILE UNIT 8 340

Serial Number: 008775 Test Record Number: 1787
Test Date: 08/24/2018 Test Time: 10:56pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:56pm
FLO	Pass	10:56pm
FC	Pass	10:56pm

Temperature Tests

Test	Status	Time
FC1	Pass	10:57pm
SRC	Pass	10:57pm
DET	Pass	10:57pm
BAR	Pass	10:57pm
BT	Pass	10:57pm

Blank Tests

Test	Status	Time
AIR	Pass	10:57pm


Printer Tests

Test	Status	Time
PRNT	Pass	10:57pm

CRC Tests

Test	Status	Time
COMP	Pass	10:57pm
CAL	Pass	10:57pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Gaston Instrument Location BBT Mobile Unit 2

Instrument Serial No. 008970

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 10 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Chris Jony
Signature of Certifying Official

658

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

GASTON BAT MOBILE UNIT 02 350

Serial Number: 008970

Test Date: 08/10/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: TOWERY, CHAD V

Permit Number: 26632E

Effective:

06/01/2017-06/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG807101

Exp Date: 03/12/2020


Test	g/210L	Time
DIAG	Pass	10:59pm
AIR BLK	.00	11:00pm
ACCY CHK	.07	11:00pm
AIR BLK	.00	11:01pm
SUB TEST	.00	11:01pm
AIR BLK	.00	11:02pm
SUB TEST	.00	11:04pm
AIR BLK	.00	11:05pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

GASTON BAT MOBILE UNIT 02 350

Serial Number: 008970 Test Record Number: 495
Test Date: 08/10/2018 Test Time: 11:07pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:07pm
FLO	Pass	11:07pm
FC	Pass	11:07pm

Temperature Tests

Test	Status	Time
FC1	Pass	11:07pm
SRC	Pass	11:07pm
DET	Pass	11:07pm
BAR	Pass	11:07pm
BT	Pass	11:07pm

Blank Tests

Test	Status	Time
AIR	Pass	11:08pm


Printer Tests

Test	Status	Time
PRNT	Pass	11:08pm

CRC Tests

Test	Status	Time
COMP	Pass	11:08pm
CAL	Pass	11:08pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Gates Instrument Location Gates Co. S.O.

Instrument Serial No. 008884 202 Court St., Statesville, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 22nd day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

643
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

GATES COUNTY GATES CO SO 360

Serial Number: 008884

Test Date: 08/22/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: GUARD, KELLY G

Permit Number: 12955E

Effective:

06/01/2017-06/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG710701

Exp Date: 04/17/2019


Test	g/210L	Time
DIAG	Pass	10:40am
AIR BLK	.00	10:41am
ACCY CHK	.07	10:42am
AIR BLK	.00	10:43am
SUB TEST	.00	10:44am
AIR BLK	.00	10:44am
SUB TEST	.00	10:46am
AIR BLK	.00	10:47am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

GATES COUNTY GATES CO SO 360

Serial Number: 008884 Test Record Number: 858
Test Date: 08/22/2018 Test Time: 10:49am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:50am
FLO	Pass	10:50am
FC	Pass	10:50am

Temperature Tests

Test	Status	Time
FC1	Pass	10:50am
SRC	Pass	10:50am
DET	Pass	10:50am
BAR	Pass	10:50am
BT	Pass	10:50am

Blank Tests

Test	Status	Time
AIR	Pass	10:50am

Printer Tests

Test	Status	Time
PRNT	Pass	10:50am

CRC Tests

Test	Status	Time
COMP	Pass	10:51am
CAL	Pass	10:51am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County GRANVILLE Instrument Location OXFORD PD

Instrument Serial No. 008923 204 E. McCLAWAHAN ST. OXFORD, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14 day of AUGUST, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Rae D. Smith
Signature of Certifying Official

637
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Preventive Maintenance

GRANVILLE COUNTY OXFORD PD 380

Serial Number: 008923 Test Record Number: 1848
Test Date: 08/14/2018 Test Time: 2:04pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:04pm
FLO	Pass	2:04pm
FC	Pass	2:04pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:04pm
SRC	Pass	2:04pm
DET	Pass	2:04pm
BAR	Pass	2:04pm
BT	Pass	2:04pm

Blank Tests

Test	Status	Time
AIR	Pass	2:05pm


Printer Tests

Test	Status	Time
PRNT	Pass	2:05pm

CRC Tests

Test	Status	Time
COMP	Pass	2:05pm
CAL	Pass	2:05pm

Preventive Maintenance
Status: Pass



Analyst

Intox EC/IR-II: Subject Test

GRANVILLE COUNTY OXFORD PD 380

Serial Number: 008923

Test Date: 08/14/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: SMITH, BRIAN D

Permit Number: 08937E

Effective:

08/01/2017-08/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG807102

Exp Date: 03/12/2020


Test	g/210L	Time
DIAG	Pass	1:55pm
AIR BLK	.00	1:55pm
ACCY CHK	.07	1:56pm
AIR BLK	.00	1:57pm
SUB TEST	.00	1:57pm
AIR BLK	.00	1:58pm
SUB TEST	.00	2:00pm
AIR BLK	.00	2:01pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Greene Instrument Location Greene Co. S.D.

Instrument Serial No. 008670 301 W. Greene St., Snow Hill, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 2nd day of AUGUST, 20 18 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

GREENE COUNTY GREENE CO SO 390

Serial Number: 008670
Test Date: 08/02/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: KEESLER, LINDA A
Permit Number: 11646
Effective:
08/01/2017-08/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG807102
Exp Date: 03/12/2020

Test	g/210L	Time
DIAG	Pass	2:59pm
AIR BLK	.00	3:01pm
ACCY CHK	.08	3:01pm
AIR BLK	.00	3:02pm
SUB TEST	.00	3:03pm
AIR BLK	.00	3:04pm
SUB TEST	.00	3:05pm
AIR BLK	.00	3:06pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

GREENE COUNTY GREENE CO SO 390

Serial Number: 008670 Test Record Number: 1776
Test Date: 08/02/2018 Test Time: 3:07pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:07pm
FLO	Pass	3:07pm
FC	Pass	3:07pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:07pm
SRC	Pass	3:07pm
DET	Pass	3:07pm
BAR	Pass	3:07pm
BT	Pass	3:07pm

Blank Tests

Test	Status	Time
AIR	Pass	3:08pm


Printer Tests

Test	Status	Time
PRNT	Pass	3:08pm

CRC Tests

Test	Status	Time
COMP	Pass	3:08pm
CAL	Pass	3:08pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Guilford Instrument Location High Point
Instrument Serial No. 008896 Police Department

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 3 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



L. Kevin Dean
Signature of Certifying Official

642
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

GUILFORD COUNTY HIGH POINT PD 401

Serial Number: 008896
Test Date: 08/03/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: DEAN, L K
Permit Number: 11598E
Effective:
04/01/2017-04/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG807101
Exp Date: 03/12/2020

Test	g/210L	Time
DIAG	Pass	10:49am
AIR BLK	.00	10:50am
ACCY CHK	.08	10:50am
AIR BLK	.00	10:51am
SUB TEST	.00	10:52am
AIR BLK	.00	10:53am
SUB TEST	.00	10:56am
AIR BLK	.00	10:56am

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

GUILFORD COUNTY HIGH POINT PD 401

Serial Number: 008896 Test Record Number: 1235
Test Date: 08/03/2018 Test Time: 10:57am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:57am
FLO	Pass	10:57am
FC	Pass	10:58am

Temperature Tests

Test	Status	Time
FC1	Pass	10:58am
SRC	Pass	10:58am
DET	Pass	10:58am
BAR	Pass	10:58am
BT	Pass	10:58am

Blank Tests

Test	Status	Time
AIR	Pass	10:58am


Printer Tests

Test	Status	Time
PRNT	Pass	10:58am

CRC Tests

Test	Status	Time
COMP	Pass	10:59am
CAL	Pass	10:59am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Guilford


Instrument Location Greensboro Jail

Instrument Serial No. 008718

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 9 day of AUGUST, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



L. Keir Deane
Signature of Certifying Official

642
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

GUILFORD COUNTY GREENSBORO JAIL 400

Serial Number: 008718
Test Date: 08/09/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: DEAN, L K

Permit Number: 11598E

Effective:

04/01/2017-04/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG734102


Exp Date: 12/07/2019

Test	g/210L	Time
DIAG	Pass	11:09am
AIR BLK	.00	11:10am
ACCY CHK	.08	11:10am
AIR BLK	.00	11:11am
SUB TEST	.00	11:12am
AIR BLK	.00	11:13am
SUB TEST	.00	11:14am
AIR BLK	.00	11:15am

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

GUILFORD COUNTY GREENSBORO JAIL 400

Serial Number: 008718 Test Record Number: 1813
Test Date: 08/09/2018 Test Time: 11:18am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:18am
FLO	Pass	11:18am
FC	Pass	11:18am

Temperature Tests

Test	Status	Time
FC1	Pass	11:18am
SRC	Pass	11:18am
DET	Pass	11:18am
BAR	Pass	11:18am
BT	Pass	11:18am

Blank Tests

Test	Status	Time
AIR	Pass	11:19am

Printer Tests

Test	Status	Time
PRNT	Pass	11:19am

CRC Tests

Test	Status	Time
COMP	Pass	11:19am
CAL	Pass	11:19am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Harnett Instrument Location BAT Mobile Unit 1
Instrument Serial No. 008600 Angier PO

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 10 day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

660
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

HARNETT COUNTY BAT MOBILE UNIT 1 420

Serial Number: 008600
Test Date: 08/10/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: SMITH, JASON R

Permit Number: 19145E

Effective:

03/01/2018-03/01/2020

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG716201

Exp Date: 06/11/2019

Test	g/210L	Time
DIAG	Pass	10:33pm
AIR BLK	.00	10:34pm
ACCY CHK	.07	10:34pm
AIR BLK	.00	10:35pm
SUB TEST	.00	10:36pm
AIR BLK	.00	10:37pm
SUB TEST	.00	10:38pm
AIR BLK	.00	10:39pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007

Intox EC/IR-II: Preventive Maintenance

HARNETT COUNTY BAT MOBILE UNIT 1 420

Serial Number: 008600 Test Record Number: 1819
Test Date: 08/10/2018 Test Time: 10:40pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:41pm
FLO	Pass	10:41pm
FC	Pass	10:41pm

Temperature Tests

Test	Status	Time
FC1	Pass	10:41pm
SRC	Pass	10:41pm
DET	Pass	10:41pm
BAR	Pass	10:41pm
BT	Pass	10:41pm

Blank Tests

Test	Status	Time
AIR	Pass	10:41pm


Printer Tests

Test	Status	Time
PRNT	Pass	10:41pm

CRC Tests

Test	Status	Time
COMP	Pass	10:42pm
CAL	Pass	10:42pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County HARNETT

Instrument Location DUNN POLICE DEPT


Instrument Serial No. 008644

DUNN, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15 day of AUGUST, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan Rg Barnes

Signature of Certifying Official

648

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

HARNETT COUNTY DUNN PD 420

Serial Number: 008644
Test Date: 08/15/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R

Permit Number: 15671E

Effective:

07/01/2017-07/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG807102

Exp Date: 03/12/2020

Test	g/210L	Time
DIAG	Pass	10:06am
AIR BLK	.00	10:07am
ACCY CHK	.07	10:07am
AIR BLK	.00	10:08am
SUB TEST	.00	10:09am
AIR BLK	.00	10:10am
SUB TEST	.00	10:12am
AIR BLK	.00	10:13am

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

HARNETT COUNTY DUNN PD 420

Serial Number: 008644 Test Record Number: 1322
Test Date: 08/15/2018 Test Time: 10:13am EDT

System Check: Passed

Baseline Tests

Test	Status	Time
IR	Pass	10:13am
FLO	Pass	10:13am
FC	Pass	10:13am

Temperature Tests

Test	Status	Time
FC1	Pass	10:14am
SRC	Pass	10:14am
DET	Pass	10:14am
BAR	Pass	10:14am
BT	Pass	10:14am

Blank Tests

Test	Status	Time
AIR	Pass	10:14am


Printer Tests

Test	Status	Time
PRNT	Pass	10:14am

CRC Tests

Test	Status	Time
COMP	Pass	10:15am
CAL	Pass	10:15am

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County HARNETT Instrument Location HARNETT COUNTY

Instrument Serial No. 008730 DETENTION CENTER
KILLINGTON, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15 day of AUGUST, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. B...
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

HARNETT COUNTY DETENTION CENTER 420

Serial Number: 008730
Test Date: 08/15/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R

Permit Number: 15671E

Effective:

07/01/2017-07/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG721401


Exp Date: 08/02/2019

Test	g/210L	Time
DIAG	Pass	11:47am
AIR BLK	.00	11:48am
ACCY CHK	.07	11:48am
AIR BLK	.00	11:49am
SUB TEST	.00	11:49am
AIR BLK	.00	11:50am
SUB TEST	.00	11:52am
AIR BLK	.00	11:53am

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

HARNETT COUNTY DETENTION CENTER 420

Serial Number: 008730 Test Record Number: 3011
Test Date: 08/15/2018 Test Time: 11:53am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:54am
FLO	Pass	11:54am
FC	Pass	11:54am

Temperature Tests

Test	Status	Time
FC1	Pass	11:54am
SRC	Pass	11:54am
DET	Pass	11:54am
BAR	Pass	11:54am
BT	Pass	11:54am

Blank Tests

Test	Status	Time
AIR	Pass	11:55am


Printer Tests

Test	Status	Time
PRNT	Pass	11:55am

CRC Tests

Test	Status	Time
COMP	Pass	11:55am
CAL	Pass	11:55am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County HARNETT Instrument Location HARNETT COUNTY
Instrument Serial No. 008729 DETENTION CENTER
LILLINGTON, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15 day of AUGUST, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. Basso
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

HARNETT COUNTY DETENTION CENTER 420

Serial Number: 008729
Test Date: 08/15/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R

Permit Number: 15671E

Effective:

07/01/2017-07/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG702302


Exp Date: 01/23/2019

Test	g/210L	Time
DIAG	Pass	12:07pm
AIR BLK	.00	12:07pm
ACCY CHK	.08	12:08pm
AIR BLK	.00	12:09pm
SUB TEST	.00	12:10pm
AIR BLK	.00	12:11pm
SUB TEST	.00	12:12pm
AIR BLK	.00	12:13pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

HARNETT COUNTY DETENTION CENTER 420

Serial Number: 008729 Test Record Number: 2256
Test Date: 08/15/2018 Test Time: 12:14pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:14pm
FLO	Pass	12:14pm
FC	Pass	12:14pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:14pm
SRC	Pass	12:14pm
DET	Pass	12:14pm
BAR	Pass	12:14pm
BT	Pass	12:14pm

Blank Tests

Test	Status	Time
AIR	Pass	12:15pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:15pm

CRC Tests

Test	Status	Time
COMP	Pass	12:15pm
CAL	Pass	12:15pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Hertford Instrument Location Murfreesboro P.D.

Instrument Serial No. 008906 115 E. Broad St., Murfreesboro, NC.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 22nd day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

643
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

HERTFORD COUNTY MURFREESBORO PD 450

Serial Number: 008906
Test Date: 08/22/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: GUARD, KELLY G

Permit Number: 12955E

Effective:

06/01/2017-06/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG702401

Exp Date: 01/24/2019

Test	g/210L	Time
DIAG	Pass	11:45am
AIR BLK	.00	11:46am
ACCY CHK	.08	11:46am
AIR BLK	.00	11:47am
SUB TEST	.00	11:48am
AIR BLK	.00	11:49am
SUB TEST	.00	11:51am
AIR BLK	.00	11:51am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

HERTFORD COUNTY MURFREESBORO PD 450

Serial Number: 008906 Test Record Number: 673
Test Date: 08/22/2018 Test Time: 11:58am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:59am
FLO	Pass	11:59am
FC	Pass	11:59am

Temperature Tests

Test	Status	Time
FC1	Pass	11:59am
SRC	Pass	11:59am
DET	Pass	11:59am
BAR	Pass	11:59am
BT	Pass	11:59am

Blank Tests

Test	Status	Time
AIR	Pass	12:00pm

Printer Tests

Test	Status	Time
PRNT	Pass	12:00pm

CRC Tests

Test	Status	Time
COMP	Pass	12:00pm
CAL	Pass	12:00pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II

County HEATFOOT Instrument Location DAI MODEL UNST C
Instrument Serial No. 008550 MURFREESBORO

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 25 day of AUGUST, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



A handwritten signature in black ink, appearing to be "J. J. [unclear]".

Signature of Certifying Official

663

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

HERTFORD COUNTY BAT MOBILE UNIT 6 450

Serial Number: 008580
Test Date: 08/25/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: VARNELL, BRYON L
Permit Number: 16896E
Effective:
09/26/2017-01/26/2026

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG710701
Exp Date: 04/17/2019

Test	g/210L	Time
DIAG	Pass	10:17pm
AIR BLK	.00	10:18pm
ACCY CHK	.07	10:18pm
AIR BLK	.00	10:19pm
SUB TEST	.00	10:19pm
AIR BLK	.00	10:20pm
SUB TEST	.00	10:22pm
AIR BLK	.00	10:23pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

HERTFORD COUNTY BAT MOBILE UNIT 6 450

Serial Number: 008580 Test Record Number: 2452
Test Date: 08/25/2018 Test Time: 10:24pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:24pm
FLO	Pass	10:24pm
FC	Pass	10:24pm

Temperature Tests

Test	Status	Time
FC1	Pass	10:24pm
SRC	Pass	10:24pm
DET	Pass	10:24pm
BAR	Pass	10:24pm
BT	Pass	10:24pm

Blank Tests

Test	Status	Time
AIR	Pass	10:25pm


Printer Tests

Test	Status	Time
PRNT	Pass	10:25pm

CRC Tests

Test	Status	Time
COMP	Pass	10:25pm
CAL	Pass	10:25pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Jackson Instrument Location Jackson Co. Jail

Instrument Serial No. 008722 Sylva, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 27 day of August, 20 18 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



David K. Carter
Signature of Certifying Official

635
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

JACKSON COUNTY JACKSON COUNTY JAIL 490

Serial Number: 008722
Test Date: 08/27/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: CUTLER, DANIEL R

Permit Number: 08457E

Effective:

09/01/2017-09/01/2019

Officer's Name: NONE,

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG734102


Exp Date: 12/07/2019

Test	g/210L	Time
DIAG	Pass	2:06pm
AIR BLK	.00	2:07pm
ACCY CHK	.07	2:08pm
AIR BLK	.00	2:09pm
SUB TEST	.00	2:10pm
AIR BLK	.00	2:11pm
SUB TEST	.00	2:12pm
AIR BLK	.00	2:13pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

JACKSON COUNTY JACKSON COUNTY JAIL 490

Serial Number: 008722 Test Record Number: 1030
Test Date: 08/27/2018 Test Time: 2:14pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:14pm
FLO	Pass	2:14pm
FC	Pass	2:14pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:14pm
SRC	Pass	2:14pm
DET	Pass	2:14pm
BAR	Pass	2:14pm
BT	Pass	2:14pm

Blank Tests

Test	Status	Time
AIR	Pass	2:15pm


Printer Tests

Test	Status	Time
PRNT	Pass	2:15pm

CRC Tests

Test	Status	Time
COMP	Pass	2:15pm
CAL	Pass	2:15pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Jackson Instrument Location Jackson Co. Jail

Instrument Serial No. 008708 Sylva, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 27 day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]

Signature of Certifying Official

635

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

JACKSON COUNTY JACKSON COUNTY JAIL 490

Serial Number: 008708
Test Date: 08/27/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: CUTLER, DANIEL R

Permit Number: 08457E

Effective:

09/01/2017-09/01/2019

Officer's Name: NONE,

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG722408

Exp Date: 08/12/2019

Test	g/210L	Time
DIAG	Pass	2:05pm
AIR BLK	.00	2:06pm
ACCY CHK	.08	2:07pm
AIR BLK	.00	2:07pm
SUB TEST	.00	2:08pm
AIR BLK	.00	2:09pm
SUB TEST	.00	2:10pm
AIR BLK	.00	2:11pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

JACKSON COUNTY JACKSON COUNTY JAIL 490

Serial Number: 008708 Test Record Number: 1381
Test Date: 08/27/2018 Test Time: 2:13pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:13pm
FLO	Pass	2:13pm
FC	Pass	2:13pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:13pm
SRC	Pass	2:13pm
DET	Pass	2:13pm
BAR	Pass	2:13pm
BT	Pass	2:13pm

Blank Tests

Test	Status	Time
AIR	Pass	2:14pm

Printer Tests

Test	Status	Time
PRNT	Pass	2:14pm

CRC Tests

Test	Status	Time
COMP	Pass	2:14pm
CAL	Pass	2:14pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II


County Jackson Instrument Location BAT Model Unit 2

Instrument Serial No. 008570

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 25 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Chris Jones
Signature of Certifying Official

658
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

JACKSON BAT MOBILE UNIT 02 490

Serial Number: 008973
Test Date: 08/25/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: TOWERY, CHAD V
Permit Number: 26632E
Effective:
06/01/2017-06/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG807101
Exp Date: 03/12/2020


Test	g/210L	Time
DIAG	Pass	7:18pm
AIR BLK	.00	7:19pm
ACCY CHK	.08	7:19pm
AIR BLK	.00	7:20pm
SUB TEST	.00	7:21pm
AIR BLK	.00	7:22pm
SUB TEST	.00	7:23pm
AIR BLK	.00	7:24pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

JACKSON BAT MOBILE UNIT 02 490

Serial Number: 008973 Test Record Number: 540
Test Date: 08/25/2018 Test Time: 7:25pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	7:25pm
FLO	Pass	7:25pm
FC	Pass	7:26pm

Temperature Tests

Test	Status	Time
FC1	Pass	7:26pm
SRC	Pass	7:26pm
DET	Pass	7:26pm
BAR	Pass	7:26pm
BT	Pass	7:26pm

Blank Tests

Test	Status	Time
AIR	Pass	7:26pm


Printer Tests

Test	Status	Time
PRNT	Pass	7:26pm

CRC Tests

Test	Status	Time
COMP	Pass	7:26pm
CAL	Pass	7:26pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County JOHNSTON

Instrument Location CLAYTON POLICE DEPT.

Instrument Serial No. 008658

CLAYTON, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 1 day of AUGUST, 20 18, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. Burns
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

JOHNSTON COUNTY CLAYTON PD 500

Serial Number: 008658
Test Date: 08/01/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R

Permit Number: 15671E

Effective:

07/01/2017-07/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG702401


Exp Date: 01/24/2019

Test	g/210L	Time
DIAG	Pass	11:08am
AIR BLK	.00	11:09am
ACCY CHK	.08	11:09am
AIR BLK	.00	11:10am
SUB TEST	.00	11:11am
AIR BLK	.00	11:11am
SUB TEST	.00	11:13am
AIR BLK	.00	11:14am

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

JOHNSTON COUNTY CLAYTON PD 500

Serial Number: 008658 Test Record Number: 1406
Test Date: 08/01/2018 Test Time: 11:15am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:16am
FLO	Pass	11:16am
FC	Pass	11:16am

Temperature Tests

Test	Status	Time
FC1	Pass	11:16am
SRC	Pass	11:16am
DET	Pass	11:16am
BAR	Pass	11:16am
BT	Pass	11:16am

Blank Tests

Test	Status	Time
AIR	Pass	11:17am


Printer Tests

Test	Status	Time
PRNT	Pass	11:17am

CRC Tests

Test	Status	Time
COMP	Pass	11:17am
CAL	Pass	11:17am

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County JOHNSTON Instrument Location BENSON POLICE DEPT.
Instrument Serial No. 008885 BENSON, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 1 day of AUGUST, 20 18, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. Benson
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

JOHNSTON COUNTY BENSON PD 500

Serial Number: 008885
Test Date: 08/01/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R
Permit Number: 15671E
Effective:
07/01/2017-07/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG807102
Exp Date: 03/12/2020

Test	g/210L	Time
DIAG	Pass	1:28pm
AIR BLK	.00	1:28pm
ACCY CHK	.07	1:29pm
AIR BLK	.00	1:30pm
SUB TEST	.00	1:31pm
AIR BLK	.00	1:32pm
SUB TEST	.00	1:33pm
AIR BLK	.00	1:34pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

JOHNSTON COUNTY BENSON PD 500

Serial Number: 008885 Test Record Number: 526
Test Date: 08/01/2018 Test Time: 1:35pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:35pm
FLO	Pass	1:35pm
FC	Pass	1:35pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:35pm
SRC	Pass	1:35pm
DET	Pass	1:35pm
BAR	Pass	1:35pm
BT	Pass	1:35pm

Blank Tests

Test	Status	Time
AIR	Pass	1:36pm


Printer Tests

Test	Status	Time
PRNT	Pass	1:36pm

CRC Tests

Test	Status	Time
COMP	Pass	1:36pm
CAL	Pass	1:36pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II

County JOHNSTON

Instrument Location SELMA POLICE DEPT.


Instrument Serial No. 008595

SELMA, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 6 day of AUGUST, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. B...
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

JOHNSTON COUNTY SELMA PD 500

Serial Number: 008595
Test Date: 08/06/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R

Permit Number: 15671E

Effective:

07/01/2017-07/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG805802

Exp Date: 02/27/2020

Test	g/210L	Time
DIAG	Pass	2:40pm
AIR BLK	.00	2:40pm
ACCY CHK	.07	2:41pm
AIR BLK	.00	2:42pm
SUB TEST	.00	2:43pm
AIR BLK	.00	2:43pm
SUB TEST	.00	2:45pm
AIR BLK	.00	2:46pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

JOHNSTON COUNTY SELMA PD 500

Serial Number: 008595 Test Record Number: 1257
Test Date: 08/06/2018 Test Time: 2:47pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:47pm
FLO	Pass	2:47pm
FC	Pass	2:48pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:48pm
SRC	Pass	2:48pm
DET	Pass	2:48pm
BAR	Pass	2:48pm
BT	Pass	2:48pm

Blank Tests

Test	Status	Time
AIR	Pass	2:48pm


Printer Tests

Test	Status	Time
PRNT	Pass	2:48pm

CRC Tests

Test	Status	Time
COMP	Pass	2:49pm
CAL	Pass	2:49pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County JOHNSTON Instrument Location JOHNSTON CO JAIL
Instrument Serial No. 008846 SMITHFIELD, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14 day of AUGUST, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. Bann
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

JOHNSTON COUNTY JOHNSTON CO JAIL 500

Serial Number: 008846

Test Date: 08/14/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R

Permit Number: 15671E

Effective:

07/01/2017-07/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG716201


Exp Date: 06/11/2019

Test	g/210L	Time
DIAG	Pass	10:06am
AIR BLK	.00	10:07am
ACCY CHK	.07	10:08am
AIR BLK	.00	10:09am
SUB TEST	.00	10:09am
AIR BLK	.00	10:10am
SUB TEST	.00	10:12am
AIR BLK	.00	10:13am

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

JOHNSTON COUNTY JOHNSTON CO JAIL 500

Serial Number: 008846 Test Record Number: 4332
Test Date: 08/14/2018 Test Time: 10:13am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:14am
FLO	Pass	10:14am
FC	Pass	10:14am

Temperature Tests

Test	Status	Time
FC1	Pass	10:14am
SRC	Pass	10:14am
DET	Pass	10:14am
BAR	Pass	10:14am
BT	Pass	10:14am

Blank Tests

Test	Status	Time
AIR	Pass	10:14am


Printer Tests

Test	Status	Time
PRNT	Pass	10:14am

CRC Tests

Test	Status	Time
COMP	Pass	10:15am
CAL	Pass	10:15am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County JOHNSTON Instrument Location JOHNSTON CO JAIL

Instrument Serial No. 008787 SMITHFIELD, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14 day of AUGUST, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. Bous

Signature of Certifying Official

648

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

JOHNSTON COUNTY JOHNSTON CO JAIL 500

Serial Number: 008787
Test Date: 08/14/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R

Permit Number: 15671E

Effective:

07/01/2017-07/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG805802

Exp Date: 02/27/2020

Test	g/210L	Time
DIAG	Pass	11:35am
AIR BLK	.00	11:36am
ACCY CHK	.08	11:36am
AIR BLK	.00	11:37am
SUB TEST	.00	11:38am
AIR BLK	.00	11:39am
SUB TEST	.00	11:40am
AIR BLK	.00	11:41am

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

JOHNSTON COUNTY JOHNSTON CO JAIL 500

Serial Number: 008787 Test Record Number: 786
Test Date: 08/14/2018 Test Time: 11:42am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:43am
FLO	Pass	11:43am
FC	Pass	11:43am

Temperature Tests

Test	Status	Time
FC1	Pass	11:43am
SRC	Pass	11:43am
DET	Pass	11:43am
BAR	Pass	11:43am
BT	Pass	11:43am

Blank Tests

Test	Status	Time
AIR	Pass	11:43am


Printer Tests

Test	Status	Time
PRNT	Pass	11:43am

CRC Tests

Test	Status	Time
COMP	Pass	11:44am
CAL	Pass	11:44am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County JONES Instrument Location NAT MODEL UNIT 6

Instrument Serial No. 008510 DOVER

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 17 day of AUGUST, 2014, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]

Signature of Certifying Official

443

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

JONES COUNTY BAT MOBILE UNIT 6 510

Serial Number: 008580
Test Date: 08/17/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: VARNELL, BRYON L
Permit Number: 16896E
Effective:
09/26/2017-01/26/2026

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG710701
Exp Date: 04/17/2019

Test	g/210L	Time
DIAG	Pass	11:15pm
AIR BLK	.00	11:16pm
ACCY CHK	.07	11:16pm
AIR BLK	.00	11:17pm
SUB TEST	.00	11:18pm
AIR BLK	.00	11:19pm
SUB TEST	.00	11:20pm
AIR BLK	.00	11:21pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007

Intox EC/IR-II: Preventive Maintenance

JONES COUNTY BAT MOBILE UNIT 6 510

Serial Number: 008580 Test Record Number: 2445
Test Date: 08/17/2018 Test Time: 11:23pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:24pm
FLO	Pass	11:24pm
FC	Pass	11:24pm

Temperature Tests

Test	Status	Time
FC1	Pass	11:24pm
SRC	Pass	11:24pm
DET	Pass	11:24pm
BAR	Pass	11:24pm
BT	Pass	11:24pm

Blank Tests

Test	Status	Time
AIR	Pass	11:24pm

Printer Tests

Test	Status	Time
PRNT	Pass	11:25pm

CRC Tests

Test	Status	Time
COMP	Pass	11:25pm
CAL	Pass	11:25pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II


County JONES Instrument Location RAF MOOREHEAD 6

Instrument Serial No. 008776

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 17 day of AUGUST, 2014, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]

Signature of Certifying Official

663

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

JONES COUNTY BAT MOBILE UNIT 6 510

Serial Number: 008776
Test Date: 08/17/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: VARNELL, BRYON L

Permit Number: 16896E

Effective:

09/26/2017-01/26/2026

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG710701

Exp Date: 04/17/2019

Test	g/210L	Time
DIAG	Pass	11:14pm
AIR BLK	.00	11:15pm
ACCY CHK	.07	11:15pm
AIR BLK	.00	11:16pm
SUB TEST	.00	11:17pm
AIR BLK	.00	11:18pm
SUB TEST	.00	11:19pm
AIR BLK	.00	11:20pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

JONES COUNTY BAT MOBILE UNIT 6 510

Serial Number: 008776 Test Record Number: 3460
Test Date: 08/17/2018 Test Time: 11:23pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:23pm
FLO	Pass	11:23pm
FC	Pass	11:23pm

Temperature Tests

Test	Status	Time
FC1	Pass	11:23pm
SRC	Pass	11:23pm
DET	Pass	11:23pm
BAR	Pass	11:23pm
BT	Pass	11:23pm

Blank Tests

Test	Status	Time
AIR	Pass	11:24pm

Printer Tests

Test	Status	Time
PRNT	Pass	11:24pm

CRC Tests

Test	Status	Time
COMP	Pass	11:24pm
CAL	Pass	11:24pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County LEE Instrument Location LEE COUNTY JAIL
Instrument Serial No. 008645 SANFORD, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 20 day of AUGUST, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. B...
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

LEE COUNTY LEE CO JAIL 520

Serial Number: 008645

Test Date: 08/20/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R

Permit Number: 15671E

Effective:

07/01/2017-07/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG716201

Exp Date: 06/11/2019

Test	g/210L	Time
DIAG	Pass	10:15am
AIR BLK	.00	10:16am
ACCY CHK	.07	10:17am
AIR BLK	.00	10:18am
SUB TEST	.00	10:18am
AIR BLK	.00	10:19am
SUB TEST	.00	10:21am
AIR BLK	.00	10:22am

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

LEE COUNTY LEE CO JAIL 520

Serial Number: 008645 Test Record Number: 1870
Test Date: 08/20/2018 Test Time: 10:22am EDT

System Check: Passed

Baseline Tests

Test	Status	Time
IR	Pass	10:23am
FLO	Pass	10:23am
FC	Pass	10:23am

Temperature Tests

Test	Status	Time
FC1	Pass	10:23am
SRC	Pass	10:23am
DET	Pass	10:23am
BAR	Pass	10:23am
BT	Pass	10:23am

Blank Tests

Test	Status	Time
AIR	Pass	10:23am


Printer Tests

Test	Status	Time
PRNT	Pass	10:24am

CRC Tests

Test	Status	Time
COMP	Pass	10:24am
CAL	Pass	10:24am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Macon

Instrument Location Macon Co. Magistrate

Instrument Serial No. 008795

Highlands, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 22 day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



David R. Catlin
Signature of Certifying Official

635
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MACON COUNTY MACON CO MAGISTRATE 550

Serial Number: 008795
Test Date: 08/22/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: CUTLER, DANIEL R
Permit Number: 08457E
Effective:
09/01/2017-09/01/2019

Officer's Name: NONE,
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG716201
Exp Date: 06/11/2019

Test	g/210L	Time
DIAG	Pass	2:24pm
AIR BLK	.00	2:25pm
ACCY CHK	.07	2:26pm
AIR BLK	.00	2:27pm
SUB TEST	.00	2:27pm
AIR BLK	.00	2:28pm
SUB TEST	.00	2:29pm
AIR BLK	.00	2:30pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

MACON COUNTY MACON CO MAGISTRATE 550

Serial Number: 008795 Test Record Number: 453
Test Date: 08/22/2018 Test Time: 2:32pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:32pm
FLO	Pass	2:32pm
FC	Pass	2:32pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:32pm
SRC	Pass	2:32pm
DET	Pass	2:32pm
BAR	Pass	2:32pm
BT	Pass	2:32pm

Blank Tests

Test	Status	Time
AIR	Pass	2:33pm

Printer Tests

Test	Status	Time
PRNT	Pass	2:33pm

CRC Tests

Test	Status	Time
COMP	Pass	2:33pm
CAL	Pass	2:33pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Madison Instrument Location Mars Hill PD

Instrument Serial No. 008582 Mars Hill, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 28 day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

649
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MADISON COUNTY MARS HILL PD 560

Serial Number: 008582
Test Date: 08/28/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BURNETTE, ANTHONY J

Permit Number: 11304E

Effective:

05/01/2017-05/01/2019

Officer's Name: NONE,

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG721401

Exp Date: 08/02/2019

Test	g/210L	Time
DIAG	Pass	3:25pm
AIR BLK	.00	3:26pm
ACCY CHK	.08	3:26pm
AIR BLK	.00	3:27pm
SUB TEST	.00	3:28pm
AIR BLK	.00	3:29pm
SUB TEST	.00	3:30pm
AIR BLK	.00	3:31pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

MADISON COUNTY MARS HILL PD 560

Serial Number: 008582 Test Record Number: 1127
Test Date: 08/28/2018 Test Time: 3:33pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:33pm
FLO	Pass	3:33pm
FC	Pass	3:33pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:33pm
SRC	Pass	3:33pm
DET	Pass	3:33pm
BAR	Pass	3:33pm
BT	Pass	3:33pm

Blank Tests

Test	Status	Time
AIR	Pass	3:34pm

Printer Tests

Test	Status	Time
PRNT	Pass	3:34pm

CRC Tests

Test	Status	Time
COMP	Pass	3:34pm
CAL	Pass	3:34pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Madison Instrument Location Madison Co. Jail

Instrument Serial No. 008599 Marshall, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 28 day of August, 20 18 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

649
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MADISON COUNTY MADISON COUNTY JAIL 560

Serial Number: 008599
Test Date: 08/28/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BURNETTE, ANTHONY J

Permit Number: 11304E

Effective:

05/01/2017-05/01/2019

Officer's Name: NONE,

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG702401

Exp Date: 01/24/2019

Test	g/210L	Time
DIAG	Pass	2:46pm
AIR BLK	.00	2:47pm
ACCY CHK	.08	2:47pm
AIR BLK	.00	2:48pm
SUB TEST	.00	2:49pm
AIR BLK	.00	2:50pm
SUB TEST	.00	2:51pm
AIR BLK	.00	2:52pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007

Intox EC/IR-II: Preventive Maintenance

MADISON COUNTY MADISON COUNTY JAIL 560

Serial Number: 008599 Test Record Number: 962
Test Date: 08/28/2018 Test Time: 2:53pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:53pm
FLO	Pass	2:53pm
FC	Pass	2:53pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:53pm
SRC	Pass	2:53pm
DET	Pass	2:53pm
BAR	Pass	2:53pm
BT	Pass	2:53pm

Blank Tests

Test	Status	Time
AIR	Pass	2:54pm

Printer Tests

Test	Status	Time
PRNT	Pass	2:54pm

CRC Tests

Test	Status	Time
COMP	Pass	2:54pm
CAL	Pass	2:54pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County McDowell Instrument Location McDowell Co. Jail

Instrument Serial No. 008892 Marion, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 2 day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

649
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MCDOWELL COUNTY JAIL 580

Serial Number: 008892
Test Date: 08/02/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BURNETTE, ANTHONY J

Permit Number: 11304E

Effective:

05/01/2017-05/01/2019

Officer's Name: NONE,

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG702401

Exp Date: 01/24/2019

Test	g/210L	Time
DIAG	Pass	3:57pm
AIR BLK	.00	3:58pm
ACCY CHK	.07	3:59pm
AIR BLK	.00	4:00pm
SUB TEST	.00	4:00pm
AIR BLK	.00	4:01pm
SUB TEST	.00	4:03pm
AIR BLK	.00	4:03pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

MCDOWELL COUNTY JAIL 580

Serial Number: 008892 Test Record Number: 618
Test Date: 08/02/2018 Test Time: 4:05pm EDT

System Check: Passed

Baseline Tests

Test	Status	Time
IR	Pass	4:05pm
FLO	Pass	4:05pm
FC	Pass	4:05pm

Temperature Tests

Test	Status	Time
FC1	Pass	4:05pm
SRC	Pass	4:05pm
DET	Pass	4:05pm
BAR	Pass	4:05pm
BT	Pass	4:05pm

Blank Tests

Test	Status	Time
AIR	Pass	4:06pm


Printer Tests

Test	Status	Time
PRNT	Pass	4:06pm

CRC Tests

Test	Status	Time
COMP	Pass	4:06pm
CAL	Pass	4:06pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County McDowell Instrument Location McDowell Co Jail
Instrument Serial No. 008888 Marion, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 2 day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

649
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MCDOWELL COUNTY JAIL 580

Serial Number: 008888

Test Date: 08/02/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BURNETTE, ANTHONY J

Permit Number: 11304E

Effective:

05/01/2017-05/01/2019

Officer's Name: NONE,

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG805801

Exp Date: 02/27/2020

Test	g/210L	Time
DIAG	Pass	3:58pm
AIR BLK	.00	3:59pm
ACCY CHK	.07	4:00pm
AIR BLK	.00	4:01pm
SUB TEST	.00	4:01pm
AIR BLK	.00	4:02pm
SUB TEST	.00	4:04pm
AIR BLK	.00	4:04pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007

Intox EC/IR-II: Preventive Maintenance .

MCDOWELL COUNTY JAIL 580

Serial Number: 008888 Test Record Number: 1508
Test Date: 08/02/2018 Test Time: 4:05pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	4:06pm
FLO	Pass	4:06pm
FC	Pass	4:06pm

Temperature Tests

Test	Status	Time
FC1	Pass	4:06pm
SRC	Pass	4:06pm
DET	Pass	4:06pm
BAR	Pass	4:06pm
BT	Pass	4:06pm

Blank Tests

Test	Status	Time
AIR	Pass	4:07pm

Printer Tests

Test	Status	Time
PRNT	Pass	4:07pm

CRC Tests

Test	Status	Time
COMP	Pass	4:07pm
CAL	Pass	4:07pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II

County MECKLENBURG Instrument Location BAT MOBILE #2
Instrument Serial No. 008970 CORNELIUS P.D.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 17th day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

659
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MECKLENBURG BAT MOBILE UNIT 02 590

Serial Number: 008970
Test Date: 08/17/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: INGLE, LARRY W
Permit Number: 07281E
Effective:
02/01/2018-02/01/2020

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG807101
Exp Date: 03/12/2020

Test	g/210L	Time
DIAG	Pass	10:24pm
AIR BLK	.00	10:25pm
ACCY CHK	.07	10:26pm
AIR BLK	.00	10:27pm
SUB TEST	.00	10:27pm
AIR BLK	.00	10:28pm
SUB TEST	.00	10:30pm
AIR BLK	.00	10:30pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

MECKLENBURG BAT MOBILE UNIT 02 590

Serial Number: 008970 Test Record Number: 498
Test Date: 08/17/2018 Test Time: 10:32pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:32pm
FLO	Pass	10:32pm
FC	Pass	10:32pm

Temperature Tests

Test	Status	Time
FC1	Pass	10:32pm
SRC	Pass	10:32pm
DET	Pass	10:32pm
BAR	Pass	10:32pm
BT	Pass	10:32pm

Blank Tests

Test	Status	Time
AIR	Pass	10:33pm

Printer Tests

Test	Status	Time
PRNT	Pass	10:33pm

CRC Tests

Test	Status	Time
COMP	Pass	10:33pm
CAL	Pass	10:33pm

Preventive Maintenance
Status: Pass



Analyst

This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II

County Mecklenburg Instrument Location BAR Mobile #3
Instrument Serial No. 008972 CMPO

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 22nd day of April ¹⁵ August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

659
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MECKLENBURG BAT MOBILE UNIT 3 590

Serial Number: 008972
Test Date: 08/22/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: INGLE, LARRY W

Permit Number: 07281E

Effective:

02/01/2018-02/01/2020

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG807101

Exp Date: 03/12/2020

Test	g/210L	Time
DIAG	Pass	9:52pm
AIR BLK	.00	9:53pm
ACCY CHK	.07	9:53pm
AIR BLK	.00	9:54pm
SUB TEST	.00	9:55pm
AIR BLK	.00	9:56pm
SUB TEST	.00	9:57pm
AIR BLK	.00	9:58pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR

Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

MECKLENBURG BAT MOBILE UNIT 3 590

Serial Number: 008972 Test Record Number: 302
Test Date: 08/22/2018 Test Time: 10:00pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:00pm
FLO	Pass	10:00pm
FC	Pass	10:00pm

Temperature Tests

Test	Status	Time
FC1	Pass	10:01pm
SRC	Pass	10:01pm
DET	Pass	10:01pm
BAR	Pass	10:01pm
BT	Pass	10:01pm

Blank Tests

Test	Status	Time
AIR	Pass	10:01pm

Printer Tests

Test	Status	Time
PRNT	Pass	10:01pm

CRC Tests

Test	Status	Time
COMP	Pass	10:01pm
CAL	Pass	10:01pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Mecklenburg Instrument Location BAV MOBILE #3
Instrument Serial No. 008968 CMPO

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 22nd day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Handwritten Signature]
Signature of Certifying Official

659
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MECKLENBURG BAT MOBILE UNIT 3 590

Serial Number: 008968
Test Date: 08/22/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: INGLE, LARRY W

Permit Number: 07281E

Effective:

02/01/2018-02/01/2020

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG814902

Exp Date: 05/29/2020

Test	g/210L	Time
DIAG	Pass	8:17pm
AIR BLK	.00	8:18pm
ACCY CHK	.07	8:19pm
AIR BLK	.00	8:19pm
SUB TEST	.00	8:20pm
AIR BLK	.00	8:21pm
SUB TEST	.00	8:22pm
AIR BLK	.00	8:23pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR

Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

MECKLENBURG BAT MOBILE UNIT 3 590

Serial Number: 008968 Test Record Number: 252
Test Date: 08/22/2018 Test Time: 8:25pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	8:25pm
FLO	Pass	8:25pm
FC	Pass	8:25pm

Temperature Tests

Test	Status	Time
FC1	Pass	8:25pm
SRC	Pass	8:25pm
DET	Pass	8:25pm
BAR	Pass	8:25pm
BT	Pass	8:25pm

Blank Tests

Test	Status	Time
AIR	Pass	8:26pm

Printer Tests

Test	Status	Time
PRNT	Pass	8:26pm

CRC Tests

Test	Status	Time
COMP	Pass	8:26pm
CAL	Pass	8:26pm

Preventive Maintenance
Status: *Pass*



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II

County MECKLENBURG Instrument Location BAT MOBILE #3
Instrument Serial No. 008971 CMPO

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 24th day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

659
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MECKLENBURG BAT MOBILE 3 590

Serial Number: 008971

Test Date: 08/24/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: INGLE, LARRY W

Permit Number: 07281E

Effective:

02/01/2018-02/01/2020

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG702302

Exp Date: 01/23/2019

Test	g/210L	Time
DIAG	Pass	9:40pm
AIR BLK	.00	9:41pm
ACCY CHK	.07	9:42pm
AIR BLK	.00	9:43pm
SUB TEST	.00	9:43pm
AIR BLK	.00	9:44pm
SUB TEST	.00	9:46pm
AIR BLK	.00	9:46pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR

Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

MECKLENBURG BAT MOBILE 3 590

Serial Number: 008971 Test Record Number: 224
Test Date: 08/24/2018 Test Time: 9:47pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	9:48pm
FLO	Pass	9:48pm
FC	Pass	9:48pm

Temperature Tests

Test	Status	Time
FC1	Pass	9:48pm
SRC	Pass	9:48pm
DET	Pass	9:48pm
BAR	Pass	9:48pm
BT	Pass	9:48pm

Blank Tests

Test	Status	Time
AIR	Pass	9:49pm

Printer Tests

Test	Status	Time
PRNT	Pass	9:49pm

CRC Tests

Test	Status	Time
COMP	Pass	9:49pm
CAL	Pass	9:49pm

Preventive Maintenance
Status: Pass



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II

County MECKLENBURG Instrument Location BAT MOBILE # 3
Instrument Serial No. 008968 CMPD

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 24th day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

659
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MECKLENBURG BAT MOBILE UNIT 3 590

Serial Number: 008968
Test Date: 08/24/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: INGLE, LARRY W
Permit Number: 07281E
Effective:
02/01/2018-02/01/2020

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG814902
Exp Date: 05/29/2020

Test	g/210L	Time
DIAG	Pass	9:54pm
AIR BLK	.00	9:55pm
ACCY CHK	.07	9:55pm
AIR BLK	.00	9:56pm
SUB TEST	.00	9:57pm
AIR BLK	.00	9:57pm
SUB TEST	.00	9:59pm
AIR BLK	.00	10:00pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

MECKLENBURG BAT MOBILE UNIT 3 590

Serial Number: 008968 Test Record Number: 256
Test Date: 08/24/2018 Test Time: 10:01pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:02pm
FLO	Pass	10:02pm
FC	Pass	10:02pm

Temperature Tests

Test	Status	Time
FC1	Pass	10:02pm
SRC	Pass	10:02pm
DET	Pass	10:02pm
BAR	Pass	10:02pm
BT	Pass	10:02pm

Blank Tests

Test	Status	Time
AIR	Pass	10:03pm

Printer Tests

Test	Status	Time
PRNT	Pass	10:03pm

CRC Tests

Test	Status	Time
COMP	Pass	10:03pm
CAL	Pass	10:03pm

Preventive Maintenance
Status: Pass



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Montgomery Co. Instrument Location Montgomery Co. Jail
Instrument Serial No. 008128 Troy NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 6th day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

654
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MONTGOMERY COUNTY MONTGOMERY CO JAIL
610

Serial Number: 008728
Test Date: 08/06/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: KEESLER, GRAYHAM C
Permit Number: 07682E
Effective:
12/01/2017-12/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG734101
Exp Date: 12/07/2019

Test	g/210L	Time
DIAG	Pass	3:29pm
AIR BLK	.00	3:30pm
ACCY CHK	.07	3:31pm
AIR BLK	.00	3:32pm
SUB TEST	.00	3:32pm
AIR BLK	.00	3:33pm
SUB TEST	.00	3:35pm
AIR BLK	.00	3:36pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

MONTGOMERY COUNTY MONTGOMERY CO JAIL 610

Serial Number: 008728 Test Record Number: 320
Test Date: 08/06/2018 Test Time: 3:37pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:38pm
FLO	Pass	3:38pm
FC	Pass	3:38pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:38pm
SRC	Pass	3:38pm
DET	Pass	3:38pm
BAR	Pass	3:38pm
BT	Pass	3:38pm

Blank Tests

Test	Status	Time
AIR	Pass	3:39pm

Printer Tests


Test	Status	Time
PRNT	Pass	3:39pm

CRC Tests

Test	Status	Time
COMP	Pass	3:39pm
CAL	Pass	3:39pm

Preventive Maintenance

Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Montgomery Co Instrument Location Montgomery Co. T.A.!
Instrument Serial No. 008863 Troy NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 6th day of August, 20 18 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]

Signature of Certifying Official

654

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MONTGOMERY COUNTY MONTGOMERY CO JAIL
610

Serial Number: 008863
Test Date: 08/06/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: KEESLER, GRAYHAM C

Permit Number: 07682E

Effective:

12/01/2017-12/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG716201

Exp Date: 06/11/2019

Test	g/210L	Time
DIAG	Pass	3:23pm
AIR BLK	.00	3:24pm
ACCY CHK	.07	3:24pm
AIR BLK	.00	3:26pm
SUB TEST	.00	3:27pm
AIR BLK	.00	3:27pm
SUB TEST	.00	3:29pm
AIR BLK	.00	3:30pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

MONTGOMERY COUNTY MONTGOMERY CO JAIL 610

Serial Number: 008863 Test Record Number: 585
Test Date: 08/06/2018 Test Time: 3:36pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:37pm
FLO	Pass	3:37pm
FC	Pass	3:37pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:37pm
SRC	Pass	3:37pm
DET	Pass	3:37pm
BAR	Pass	3:37pm
BT	Pass	3:37pm

Blank Tests

Test	Status	Time
AIR	Pass	3:38pm


Printer Tests

Test	Status	Time
PRNT	Pass	3:38pm

CRC Tests

Test	Status	Time
COMP	Pass	3:38pm
CAL	Pass	3:38pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II

County Montgomery Co. Instrument Location Montgomery Co. Jail
Instrument Serial No. 008709 TROY NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16th day of AUGUST, 20 18 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

659
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MONTGOMERY COUNTY MONTGOMERY CO. JAIL
610

Serial Number: 008709
Test Date: 08/16/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: KEESLER, GRAYHAM C
Permit Number: 07682E
Effective:
12/01/2017-12/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG734101
Exp Date: 12/07/2019

Test	g/210L	Time
DIAG	Pass	12:21pm
AIR BLK	.00	12:21pm
ACCY CHK	.07	12:22pm
AIR BLK	.00	12:23pm
SUB TEST	.00	12:23pm
AIR BLK	.00	12:24pm
SUB TEST	.00	12:26pm
AIR BLK	.00	12:27pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

MONTGOMERY COUNTY MONTGOMERY CO. JAIL 610

Serial Number: 008709 Test Record Number: 1083
Test Date: 08/16/2018 Test Time: 12:29pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:29pm
FLO	Pass	12:29pm
FC	Pass	12:29pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:30pm
SRC	Pass	12:30pm
DET	Pass	12:30pm
BAR	Pass	12:30pm
BT	Pass	12:30pm

Blank Tests

Test	Status	Time
AIR	Pass	12:30pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:30pm

CRC Tests

Test	Status	Time
COMP	Pass	12:31pm
CAL	Pass	12:31pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Montgomery Co. Instrument Location Montgomery Co. Jail

Instrument Serial No. 008657 Troy NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16th day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

654
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MONTGOMERY COUNTY MONTGOMERY CO. JAIL
610

Serial Number: 008657
Test Date: 08/16/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: KEESLER, GRAYHAM C
Permit Number: 07682E
Effective:
12/01/2017-12/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG716201
Exp Date: 06/11/2019

Test	g/210L	Time
DIAG	Pass	12:23pm
AIR BLK	.00	12:24pm
ACCY CHK	.08	12:24pm
AIR BLK	.00	12:25pm
SUB TEST	.00	12:26pm
AIR BLK	.00	12:27pm
SUB TEST	.00	12:29pm
AIR BLK	.00	12:30pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

MONTGOMERY COUNTY MONTGOMERY CO. JAIL 610

Serial Number: 008657 Test Record Number: 1582
Test Date: 08/16/2018 Test Time: 12:31pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:31pm
FLO	Pass	12:31pm
FC	Pass	12:31pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:31pm
SRC	Pass	12:31pm
DET	Pass	12:31pm
BAR	Pass	12:31pm
BT	Pass	12:31pm

Blank Tests

Test	Status	Time
AIR	Pass	12:32pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:32pm

CRC Tests

Test	Status	Time
COMP	Pass	12:32pm
CAL	Pass	12:32pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County MOORE Instrument Location SOUTHERN PINES PD
Instrument Serial No. 008720 SOUTHERN PINES, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 3 day of AUGUST, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. Barnes
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MOORE COUNTY SOUTHERN PINES PD 620

Serial Number: 008720
Test Date: 08/03/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R
Permit Number: 15671E
Effective:
07/01/2017-07/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG805802
Exp Date: 02/27/2020

Test	g/210L	Time
DIAC	Pass	1:52pm
AIR BLK	.00	1:52pm
ACCY CHK	.07	1:53pm
AIR BLK	.00	1:54pm
SUB TEST	.00	1:54pm
AIR BLK	.00	1:55pm
SUB TEST	.00	1:56pm
AIR BLK	.00	1:57pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

MOORE COUNTY SOUTHERN PINES PD 620

Serial Number: 008720 Test Record Number: 1060
Test Date: 08/03/2018 Test Time: 1:58pm EDT

System Check: Passed

Baseline Tests

Test	Status	Time
IR	Pass	1:58pm
FLO	Pass	1:58pm
FC	Pass	1:59pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:59pm
SRC	Pass	1:59pm
DET	Pass	1:59pm
BAR	Pass	1:59pm
BT	Pass	1:59pm

Blank Tests

Test	Status	Time
AIR	Pass	1:59pm


Printer Tests

Test	Status	Time
PRNT	Pass	1:59pm

CRC Tests

Test	Status	Time
COMP	Pass	1:59pm
CAL	Pass	1:59pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Moore Instrument Location Mobile BAT Unit 1
Instrument Serial No. 008788 Pinehurst PD

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 19 day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

660
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MOORE COUNTY BAT MOBILE UNIT 1 950

Serial Number: 008788
Test Date: 08/04/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: SMITH, JASON R

Permit Number: 19145E

Effective:

03/01/2018-03/01/2020

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG716201


Exp Date: 06/11/2019

Test	g/210L	Time
DIAG	Pass	10:23pm
AIR BLK	.00	10:24pm
ACCY CHK	.07	10:24pm
AIR BLK	.00	10:25pm
SUB TEST	.00	10:26pm
AIR BLK	.00	10:27pm
SUB TEST	.00	10:28pm
AIR BLK	.00	10:29pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

MOORE COUNTY BAT MOBILE UNIT 1 950

Serial Number: 008788 Test Record Number: 1362
Test Date: 08/04/2018 Test Time: 10:36pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:37pm
FLO	Pass	10:37pm
FC	Pass	10:37pm

Temperature Tests

Test	Status	Time
FC1	Pass	10:37pm
SRC	Pass	10:37pm
DET	Pass	10:37pm
BAR	Pass	10:37pm
BT	Pass	10:37pm

Blank Tests

Test	Status	Time
AIR	Pass	10:38pm

Printer Tests

Test	Status	Time
PRNT	Pass	10:38pm

CRC Tests

Test	Status	Time
COMP	Pass	10:39pm
CAL	Pass	10:39pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County NASH Instrument Location NASHVILLE PD

Instrument Serial No. 008630 501 S. BARNES ST. NASHVILLE, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 20 day of AUGUST, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

637
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

NASH COUNTY NASHVILLE PD 630

Serial Number: 008630
Test Date: 08/20/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: SMITH, BRIAN D
Permit Number: 08937E
Effective:
08/01/2017-08/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG805801
Exp Date: 02/27/2020

Test	g/210L	Time
DIAG	Pass	12:30pm
AIR BLK	.00	12:31pm
ACCY CHK	.08	12:32pm
AIR BLK	.00	12:33pm
SUB TEST	.00	12:34pm
AIR BLK	.00	12:35pm
SUB TEST	.00	12:36pm
AIR BLK	.00	12:37pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

NASH COUNTY NASHVILLE PD 630

Serial Number: 008630 Test Record Number: 4221
Test Date: 08/20/2018 Test Time: 12:38pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:38pm
FLO	Pass	12:38pm
FC	Pass	12:38pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:38pm
SRC	Pass	12:38pm
DET	Pass	12:38pm
BAR	Pass	12:38pm
BT	Pass	12:38pm

Blank Tests

Test	Status	Time
AIR	Pass	12:39pm

Printer Tests

Test	Status	Time
PRNT	Pass	12:39pm

CRC Tests

Test	Status	Time
COMP	Pass	12:39pm
CAL	Pass	12:39pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County NASH Instrument Location SAT MONITE UNIT 6

Instrument Serial No. 008776 STANDS MARK

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 31 day of AUGUST, 2010, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

667
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

NASH COUNTY BAT MOBILE UNIT 6 630

Serial Number: 008776
Test Date: 08/31/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: VARNELL, BRYON L

Permit Number: 16896E

Effective:

09/22/2017-09/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG710701

Exp Date: 04/17/2019

Test	g/210L	Time
DIAG	Pass	9:25pm
AIR BLK	.00	9:26pm
ACCY CHK	.07	9:27pm
AIR BLK	.00	9:27pm
SUB TEST	.00	9:28pm
AIR BLK	.00	9:29pm
SUB TEST	.00	9:30pm
AIR BLK	.00	9:31pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

NASH COUNTY BAT MOBILE UNIT 6 630

Serial Number: 008776 Test Record Number: 3472
Test Date: 08/31/2018 Test Time: 9:36pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	9:36pm
FLO	Pass	9:36pm
FC	Pass	9:36pm

Temperature Tests

Test	Status	Time
FC1	Pass	9:36pm
SRC	Pass	9:36pm
DET	Pass	9:36pm
BAR	Pass	9:36pm
BT	Pass	9:36pm

Blank Tests

Test	Status	Time
AIR	Pass	9:37pm

Printer Tests

Test	Status	Time
PRNT	Pass	9:37pm

CRC Tests

Test	Status	Time
COMP	Pass	9:37pm
CAL	Pass	9:37pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II


County NASH Instrument Location NAT MONIE UNIT 6

Instrument Serial No. 00Y6Y6 SHANBULL

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 31 day of August, 2014, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

667
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

NASH COUNTY BAT MOBILE UNIT 6 630

Serial Number: 008686
Test Date: 08/31/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: VARNELL, BRYON L

Permit Number: 16896E

Effective:

09/22/2017-09/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG807101

Exp Date: 03/12/2020


Test	g/210L	Time
DIAG	Pass	9:29pm
AIR BLK	.00	9:30pm
ACCY CHK	.07	9:30pm
AIR BLK	.00	9:31pm
SUB TEST	.00	9:31pm
AIR BLK	.00	9:32pm
SUB TEST	.00	9:34pm
AIR BLK	.00	9:35pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

NASH COUNTY BAT MOBILE UNIT 6 630

Serial Number: 008686 Test Record Number: 6588
Test Date: 08/31/2018 Test Time: 9:37pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	9:37pm
FLO	Pass	9:37pm
FC	Pass	9:37pm

Temperature Tests

Test	Status	Time
FC1	Pass	9:37pm
SRC	Pass	9:37pm
DET	Pass	9:37pm
BAR	Pass	9:37pm
BT	Pass	9:37pm

Blank Tests

Test	Status	Time
AIR	Pass	9:38pm


Printer Tests

Test	Status	Time
PRNT	Pass	9:38pm

CRC Tests

Test	Status	Time
COMP	Pass	9:38pm
CAL	Pass	9:38pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II


County NASH Instrument Location SAF MOBILE UNIT 6

Instrument Serial No. 008590 SHARPSHAW

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 31 day of AUGUST, 2011, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]

Signature of Certifying Official

663

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

NASH COUNTY BAT MOBILE UNIT 6 630

Serial Number: 008580
Test Date: 08/31/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: VARNELL, BRYON L
Permit Number: 16896E
Effective:
09/22/2017-09/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG710701
Exp Date: 04/17/2019

Test	g/210L	Time
DIAG	Pass	9:26pm
AIR BLK	.00	9:27pm
ACCY CHK	.07	9:28pm
AIR BLK	.00	9:28pm
SUB TEST	.00	9:29pm
AIR BLK	.00	9:30pm
SUB TEST	.00	9:31pm
AIR BLK	.00	9:32pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

NASH COUNTY BAT MOBILE UNIT 6 630

Serial Number: 008580 Test Record Number: 2455
Test Date: 08/31/2018 Test Time: 9:35pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	9:35pm
FLO	Pass	9:35pm
FC	Pass	9:36pm

Temperature Tests

Test	Status	Time
FC1	Pass	9:36pm
SRC	Pass	9:36pm
DET	Pass	9:36pm
BAR	Pass	9:36pm
BT	Pass	9:36pm

Blank Tests

Test	Status	Time
AIR	Pass	9:36pm

Printer Tests

Test	Status	Time
PRNT	Pass	9:36pm

CRC Tests

Test	Status	Time
COMP	Pass	9:37pm
CAL	Pass	9:37pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County New Hanover Instrument Location BAT Mobile Unit 1
Instrument Serial No. 008698 UNCW

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 26 day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

660
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

NEW HANOVER BAT MOBILE UNIT 1 640

Serial Number: 008698
Test Date: 08/26/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: SMITH, JASON R
Permit Number: 19145E
Effective:
03/01/2018-03/01/2020

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG814901
Exp Date: 05/29/2020

Test	g/210L	Time
DIAG	Pass	12:01am
AIR BLK	.00	12:02am
ACCY CHK	.08	12:02am
AIR BLK	.00	12:04am
SUB TEST	.00	12:04am
AIR BLK	.00	12:05am
SUB TEST	.00	12:07am
AIR BLK	.00	12:08am

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

NEW HANOVER BAT MOBILE UNIT 1 640

Serial Number: 008698 Test Record Number: 1380
Test Date: 08/26/2018 Test Time: 12:21am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:22am
FLO	Pass	12:22am
FC	Pass	12:22am

Temperature Tests

Test	Status	Time
FC1	Pass	12:22am
SRC	Pass	12:22am
DET	Pass	12:22am
BAR	Pass	12:22am
BT	Pass	12:22am

Blank Tests

Test	Status	Time
AIR	Pass	12:23am

Printer Tests

Test	Status	Time
PRNT	Pass	12:23am

CRC Tests

Test	Status	Time
COMP	Pass	12:23am
CAL	Pass	12:23am

Preventive Maintenance
Status: Pass


Analyst

Intox EC/IR-II: Subject Test

HARNETT COUNTY BAT MOBILE UNIT 1 420

Serial Number: 008600
Test Date: 08/10/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: SMITH, JASON R
Permit Number: 19145E
Effective:
03/01/2018-03/01/2020

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG716201
Exp Date: 06/11/2019

Test	g/210L	Time
DIAG	Pass	10:33pm
AIR BLK	.00	10:34pm
ACCY CHK	.07	10:34pm
AIR BLK	.00	10:35pm
SUB TEST	.00	10:36pm
AIR BLK	.00	10:37pm
SUB TEST	.00	10:38pm
AIR BLK	.00	10:39pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County New Hanover Instrument Location BAT mobile Unit 1
Instrument Serial No. 008600 UNCW

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 25 day of August, 20 18 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

660
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

NEW HANOVER BAT MOBILE UNIT 1 640

Serial Number: 008600
Test Date: 08/25/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: SMITH, JASON R

Permit Number: 19145E

Effective:

03/01/2018-03/01/2020

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG716201

Exp Date: 06/11/2019

Test	g/210L	Time
DIAG	Pass	11:42pm
AIR BLK	.00	11:43pm
ACCY CHK	.07	11:43pm
AIR BLK	.00	11:44pm
SUB TEST	.00	11:46pm
AIR BLK	.00	11:47pm
SUB TEST	.00	11:49pm
AIR BLK	.00	11:50pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007

Intox EC/IR-II: Preventive Maintenance

NEW HANOVER BAT MOBILE UNIT 1 640

Serial Number: 008600 Test Record Number: 1822
Test Date: 08/25/2018 Test Time: 11:51pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:52pm
FLO	Pass	11:52pm
FC	Pass	11:52pm

Temperature Tests

Test	Status	Time
FC1	Pass	11:52pm
SRC	Pass	11:52pm
DET	Pass	11:52pm
BAR	Pass	11:52pm
BT	Pass	11:52pm

Blank Tests

Test	Status	Time
AIR	Pass	11:52pm


Printer Tests

Test	Status	Time
PRNT	Pass	11:53pm

CRC Tests

Test	Status	Time
COMP	Pass	11:53pm
CAL	Pass	11:53pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Pasquotank Instrument Location Elizabeth City P.D.
Instrument Serial No. 008918 305 E. MAIN ST., Elizabeth City

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 30th day of AUGUST, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Timothy Keel
Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

PASQUOTANK COUNTY ELIZABETH CITY PD
690

Serial Number: 008918
Test Date: 08/30/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: KEESLER, LINDA A
Permit Number: 11646E
Effective:
08/01/2017-08/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG805801
Exp Date: 02/27/2020


Test	g/210L	Time
DIAG	Pass	11:09am
AIR BLK	.00	11:10am
ACCY CHK	.08	11:10am
AIR BLK	.00	11:11am
SUB TEST	.00	11:12am
AIR BLK	.00	11:13am
SUB TEST	.00	11:14am
AIR BLK	.00	11:15am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

PASQUOTANK COUNTY ELIZABETH CITY PD 690

Serial Number: 008918 Test Record Number: 639
Test Date: 08/30/2018 Test Time: 11:16am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:16am
FLO	Pass	11:16am
FC	Pass	11:16am

Temperature Tests

Test	Status	Time
FC1	Pass	11:16am
SRC	Pass	11:16am
DET	Pass	11:16am
BAR	Pass	11:16am
BT	Pass	11:16am

Blank Tests

Test	Status	Time
AIR	Pass	11:17am

Printer Tests

Test	Status	Time
PRNT	Pass	11:17am

CRC Tests

Test	Status	Time
COMP	Pass	11:17am
CAL	Pass	11:17am

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Pasquotank Instrument Location Pasquotank Co. Public Safety
Instrument Serial No. 008950 Bldg. 200 E. Colonial St.,
Elizabeth City N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 30th day of AUGUST, 20 18 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Linda K. Keel
Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

PASQUOTANK COUNTY PUBLIC SAFETY BLDG
690

Serial Number: 008950
Test Date: 08/30/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: KEESLER, LINDA A
Permit Number: 11646E
Effective:
08/01/2017-08/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG805801
Exp Date: 02/27/2020


Test	g/210L	Time
DIAG	Pass	10:22am
AIR BLK	.00	10:23am
ACCY CHK	.08	10:23am
AIR BLK	.00	10:24am
SUB TEST	.00	10:25am
AIR BLK	.00	10:26am
SUB TEST	.00	10:27am
AIR BLK	.00	10:28am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

PASQUOTANK COUNTY PUBLIC SAFETY BLDG 690

Serial Number: 008950 Test Record Number: 1644
Test Date: 08/30/2018 Test Time: 10:31am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:32am
FLO	Pass	10:32am
FC	Pass	10:32am

Temperature Tests

Test	Status	Time
FC1	Pass	10:32am
SRC	Pass	10:32am
DET	Pass	10:32am
BAR	Pass	10:32am
BT	Pass	10:32am

Blank Tests

Test	Status	Time
AIR	Pass	10:33am

Printer Tests

Test	Status	Time
PRNT	Pass	10:33am

CRC Tests

Test	Status	Time
COMP	Pass	10:33am
CAL	Pass	10:33am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County PERSON Instrument Location PERSON Co. LEC

Instrument Serial No. 008651 120 COURT ST. ROXBORO, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14 day of AUGUST, 20 18 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Bruce D. Smith
Signature of Certifying Official

637
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

PERSON COUNTY PERSON CO. LEC 720

Serial Number: 008651

Test Date: 08/14/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: SMITH, BRIAN D.

Permit Number: 08937E

Effective:

08/01/2017-08/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG702302

Exp Date: 01/23/2019


Test	g/210L	Time
DIAG	Pass	4:05pm
AIR BLK	.00	4:05pm
ACCY CHK	.08	4:06pm
AIR BLK	.00	4:07pm
SUB TEST	.00	4:09pm
AIR BLK	.00	4:09pm
SUB TEST	.00	4:12pm
AIR BLK	.00	4:13pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

PERSON COUNTY PERSON CO. LEC 720

Serial Number: 008651 Test Record Number: 1381
Test Date: 08/14/2018 Test Time: 4:13pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	4:14pm
FLO	Pass	4:14pm
FC	Pass	4:14pm

Temperature Tests

Test	Status	Time
FC1	Pass	4:14pm
SRC	Pass	4:14pm
DET	Pass	4:14pm
BAR	Pass	4:14pm
BT	Pass	4:14pm

Blank Tests

Test	Status	Time
AIR	Pass	4:14pm

Printer Tests

Test	Status	Time
PRNT	Pass	4:14pm

CRC Tests

Test	Status	Time
COMP	Pass	4:15pm
CAL	Pass	4:15pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II

County PERSON Instrument Location PERSON CO LEC
Instrument Serial No. 008693 120 COURT ST ROXBORO NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14 day of AUGUST, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Brian D. Smith
Signature of Certifying Official

637
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

PERSON COUNTY PERSON CO. LEC 720

Serial Number: 008693
Test Date: 08/14/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: SMITH, BRIAN D
Permit Number: 08937E
Effective:
08/01/2017-08/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG702302
Exp Date: 01/23/2019

Test	g/210L	Time
DIAG	Pass	4:04pm
AIR BLK	.00	4:04pm
ACCY CHK	.07	4:05pm
AIR BLK	.00	4:06pm
SUB TEST	.00	4:08pm
AIR BLK	.00	4:09pm
SUB TEST	.00	4:11pm
AIR BLK	.00	4:12pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

PERSON COUNTY PERSON CO. LEC 720

Serial Number: 008693 Test Record Number: 1494
Test Date: 08/14/2018 Test Time: 4:12pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	4:13pm
FLO	Pass	4:13pm
FC	Pass	4:13pm

Temperature Tests

Test	Status	Time
FC1	Pass	4:13pm
SRC	Pass	4:13pm
DET	Pass	4:13pm
BAR	Pass	4:13pm
BT	Pass	4:13pm

Blank Tests

Test	Status	Time
AIR	Pass	4:14pm


Printer Tests

Test	Status	Time
PRNT	Pass	4:14pm

CRC Tests

Test	Status	Time
COMP	Pass	4:14pm
CAL	Pass	4:14pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Pitt Instrument Location Pitt Co. Detention Center
Instrument Serial No. 0086602 124 Detention Dr., Greenville, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 27th day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Keely A. [Signature]
Signature of Certifying Official

643
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

PITT COUNTY PITT CO DETENTION 730

Serial Number: 008662
Test Date: 08/27/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: GUARD, KELLY G

Permit Number: 12955E

Effective:

06/01/2017-06/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG710701

Exp Date: 04/17/2019

Test	g/210L	Time
DIAG	Pass	11:42am
AIR BLK	.00	11:43am
ACCY CHK	.07	11:43am
AIR BLK	.00	11:44am
SUB TEST	.00	11:45am
AIR BLK	.00	11:46am
SUB TEST	.00	11:47am
AIR BLK	.00	11:48am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

PITT COUNTY PITT CO DETENTION 730

Serial Number: 008662 Test Record Number: 1074
Test Date: 08/27/2018 Test Time: 11:50am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:50am
FLO	Pass	11:50am
FC	Pass	11:50am

Temperature Tests

Test	Status	Time
FC1	Pass	11:50am
SRC	Pass	11:50am
DET	Pass	11:50am
BAR	Pass	11:50am
BT	Pass	11:50am

Blank Tests

Test	Status	Time
AIR	Pass	11:51am


Printer Tests

Test	Status	Time
PRNT	Pass	11:51am

CRC Tests

Test	Status	Time
COMP	Pass	11:51am
CAL	Pass	11:51am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Pitt Instrument Location Pitt Co. Detention Center
Instrument Serial No. 008646 124 Detention Dr, Greenville, NC.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 27th day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Kelly N. O
Signature of Certifying Official

643
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

PITT COUNTY PITT CO DETENTION 730

Serial Number: 008646
Test Date: 08/27/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: GUARD, KELLY G

Permit Number: 12955E

Effective:

06/01/2017-06/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG734101

Exp Date: 12/07/2019

Test	g/210L	Time
DIAG	Pass	11:29am
AIR BLK	.00	11:29am
ACCY CHK	.08	11:30am
AIR BLK	.00	11:31am
SUB TEST	.00	11:31am
AIR BLK	.00	11:32am
SUB TEST	.00	11:34am
AIR BLK	.00	11:35am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

PITT COUNTY PITT CO DETENTION 730

Serial Number: 008646 Test Record Number: 3693
Test Date: 08/27/2018 Test Time: 11:36am EDT

System Check: Passed

Baseline Tests

Test	Status	Time
IR	Pass	11:36am
FLO	Pass	11:36am
FC	Pass	11:36am

Temperature Tests

Test	Status	Time
FC1	Pass	11:36am
SRC	Pass	11:36am
DET	Pass	11:36am
BAR	Pass	11:36am
BT	Pass	11:36am

Blank Tests

Test	Status	Time
AIR	Pass	11:37am

Printer Tests

Test	Status	Time
PRNT	Pass	11:37am

CRC Tests

Test	Status	Time
COMP	Pass	11:37am
CAL	Pass	11:37am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Pitt Instrument Location Pitt Co Detention Center
Instrument Serial No. 008668 124 Detention Dr., Greenville, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 27th day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

643
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

PITT COUNTY PITT CO DETENTION 730

Serial Number: 008668
Test Date: 08/27/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: GUARD, KELLY G

Permit Number: 12955E

Effective:

06/01/2017-06/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG722408

Exp Date: 08/12/2019


Test	g/210L	Time
DIAG	Pass	11:15am
AIR BLK	.00	11:15am
ACCY CHK	.07	11:16am
AIR BLK	.00	11:17am
SUB TEST	.00	11:17am
AIR BLK	.00	11:18am
SUB TEST	.00	11:20am
AIR BLK	.00	11:21am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

PITT COUNTY PITT CO DETENTION 730

Serial Number: 008668 Test Record Number: 3055
Test Date: 08/27/2018 Test Time: 11:22am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:22am
FLO	Pass	11:22am
FC	Pass	11:22am

Temperature Tests

Test	Status	Time
FC1	Pass	11:22am
SRC	Pass	11:22am
DET	Pass	11:22am
BAR	Pass	11:22am
BT	Pass	11:22am

Blank Tests

Test	Status	Time
AIR	Pass	11:23am

Printer Tests

Test	Status	Time
PRNT	Pass	11:23am

CRC Tests

Test	Status	Time
COMP	Pass	11:23am
CAL	Pass	11:23am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II

County RANDOLPH

Instrument Location RANDOLPH CO JAIL

Instrument Serial No. 009860

ASHEBORO, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 20 day of AUGUST, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. B...
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

RANDOLPH COUNTY RANDOLPH CO JAIL 750

Serial Number: 008860
Test Date: 08/20/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R

Permit Number: 15671E

Effective:

07/01/2017-07/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG702401


Exp Date: 01/24/2019

Test	g/210L	Time
DIAG	Pass	1:04pm
AIR BLK	.00	1:04pm
ACCY CHK	.07	1:05pm
AIR BLK	.00	1:06pm
SUB TEST	.00	1:06pm
AIR BLK	.00	1:07pm
SUB TEST	.00	1:09pm
AIR BLK	.00	1:10pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

RANDOLPH COUNTY RANDOLPH CO JAIL 750

Serial Number: 008860 Test Record Number: 2624
Test Date: 08/20/2018 Test Time: 1:10pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:11pm
FLO	Pass	1:11pm
FC	Pass	1:11pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:11pm
SRC	Pass	1:11pm
DET	Pass	1:11pm
BAR	Pass	1:11pm
BT	Pass	1:11pm

Blank Tests

Test	Status	Time
AIR	Pass	1:12pm

Printer Tests

Test	Status	Time
PRNT	Pass	1:12pm

CRC Tests

Test	Status	Time
COMP	Pass	1:12pm
CAL	Pass	1:12pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II

County RANDOLPH Instrument Location RANDOLPH CO JAIL
Instrument Serial No. 008899 ASHEBORO, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 20 day of AUGUST, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. Boney
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

RANDOLPH COUNTY RANDOLPH CO JAIL 750

Serial Number: 008899
Test Date: 08/20/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R

Permit Number: 15671E

Effective:

07/01/2017-07/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG716201


Exp Date: 06/11/2019

Test	g/210L	Time
DIAG	Pass	1:09pm
AIR BLK	.00	1:10pm
ACCY CHK	.08	1:10pm
AIR BLK	.00	1:11pm
SUB TEST	.00	1:12pm
AIR BLK	.00	1:13pm
SUB TEST	.00	1:14pm
AIR BLK	.00	1:15pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

RANDOLPH COUNTY RANDOLPH CO JAIL 750

Serial Number: 008899 Test Record Number: 2913
Test Date: 08/20/2018 Test Time: 1:17pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:17pm
FLO	Pass	1:17pm
FC	Pass	1:17pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:17pm
SRC	Pass	1:17pm
DET	Pass	1:17pm
BAR	Pass	1:17pm
BT	Pass	1:17pm

Blank Tests

Test	Status	Time
AIR	Pass	1:18pm

Printer Tests

Test	Status	Time
PRNT	Pass	1:18pm

CRC Tests

Test	Status	Time
COMP	Pass	1:18pm
CAL	Pass	1:18pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II

County RANDOLPH Instrument Location LIBERTY POLICE DEPT
Instrument Serial No. 008863 LIBERTY, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 21 day of AUGUST, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. B...
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

RANDOLPH COUNTY LIBERTY PD 750

Serial Number: 008863
Test Date: 08/21/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R

Permit Number: 15671E

Effective:

07/01/2017-07/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG734101

Exp Date: 12/07/2019

Test	g/210L	Time
DIAG	Pass	10:27am
AIR BLK	.00	10:27am
ACCY CHK	.07	10:28am
AIR BLK	.00	10:30am
SUB TEST	.00	10:30am
AIR BLK	.00	10:31am
SUB TEST	.00	10:32am
AIR BLK	.00	10:33am

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

RANDOLPH COUNTY LIBERTY PD 750

Serial Number: 008863 Test Record Number: 589
Test Date: 08/21/2018 Test Time: 10:34am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:34am
FLO	Pass	10:34am
FC	Pass	10:35am

Temperature Tests

Test	Status	Time
FC1	Pass	10:35am
SRC	Pass	10:35am
DET	Pass	10:35am
BAR	Pass	10:35am
BT	Pass	10:35am

Blank Tests

Test	Status	Time
AIR	Pass	10:35am


Printer Tests

Test	Status	Time
PRNT	Pass	10:35am

CRC Tests

Test	Status	Time
COMP	Pass	10:36am
CAL	Pass	10:36am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County RANDOLPH Instrument Location RANDLEMAN POLICE DEPT
Instrument Serial No. 008728 RANDLEMAN, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 21 day of AUGUST, 2018 the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alvin R. Bann
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

RANDOLPH COUNTY RANDLEMAN PD 750

Serial Number: 008728
Test Date: 08/21/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R

Permit Number: 15671E

Effective:

07/01/2017-07/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG734102

Exp Date: 12/07/2019

Test	g/210L	Time
DIAG	Pass	2:43pm
AIR BLK	.00	2:44pm
ACCY CHK	.07	2:45pm
AIR BLK	.00	2:45pm
SUB TEST	.00	2:46pm
AIR BLK	.00	2:47pm
SUB TEST	.00	2:48pm
AIR BLK	.00	2:49pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

RANDOLPH COUNTY RANDLEMAN PD 750

Serial Number: 008728 Test Record Number: 327
Test Date: 08/21/2018 Test Time: 2:50pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:50pm
FLO	Pass	2:50pm
FC	Pass	2:50pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:51pm
SRC	Pass	2:51pm
DET	Pass	2:51pm
BAR	Pass	2:51pm
BT	Pass	2:51pm

Blank Tests

Test	Status	Time
AIR	Pass	2:51pm

Printer Tests

Test	Status	Time
PRNT	Pass	2:51pm

CRC Tests

Test	Status	Time
COMP	Pass	2:51pm
CAL	Pass	2:51pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II

County Randolph Instrument Location Bot mobile Unit 8
Instrument Serial No. 08775 SHP-Randolph

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 25 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Donya B Skinner 644
Signature of Certifying Official Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

RANDOLPH COUNTY BAT MOBILE UNIT 8 750

Serial Number: 008775
Test Date: 08/25/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Female

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: SKINNER, TONYA B

Permit Number: 13651E

Effective:

08/01/2017-08/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG734101


Exp Date: 12/07/2019

Test	g/210L	Time
DIAG	Pass	11:31pm
AIR BLK	.00	11:32pm
ACCY CHK	.07	11:33pm
AIR BLK	.00	11:34pm
SUB TEST	.00	11:34pm
AIR BLK	.00	11:35pm
SUB TEST	.00	11:37pm
AIR BLK	.00	11:37pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

RANDOLPH COUNTY BAT MOBILE UNIT 8 750

Serial Number: 008775 Test Record Number: 1790
Test Date: 08/25/2018 Test Time: 11:40pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:41pm
FLO	Pass	11:41pm
FC	Pass	11:41pm

Temperature Tests

Test	Status	Time
FC1	Pass	11:41pm
SRC	Pass	11:41pm
DET	Pass	11:41pm
BAR	Pass	11:41pm
BT	Pass	11:41pm

Blank Tests

Test	Status	Time
AIR	Pass	11:42pm


Printer Tests

Test	Status	Time
PRNT	Pass	11:42pm

CRC Tests

Test	Status	Time
COMP	Pass	11:42pm
CAL	Pass	11:42pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Randolph Instrument Location Bat Mobile Unit 8
Instrument Serial No. 008615 SHP - Randolph

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 25 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Danya B Skinner
Signature of Certifying Official

644
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

RANDOLPH COUNTY BAT MOBILE UNIT 8 750

Serial Number: 008615
Test Date: 08/25/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Female

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: SKINNER, TONYA B

Permit Number: 13651E

Effective:

08/01/2017-08/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG716201


Exp Date: 06/11/2019

Test	g/210L	Time
DIAG	Pass	11:29pm
AIR BLK	.00	11:30pm
ACCY CHK	.07	11:30pm
AIR BLK	.00	11:31pm
SUB TEST	.00	11:32pm
AIR BLK	.00	11:33pm
SUB TEST	.00	11:34pm
AIR BLK	.00	11:35pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

RANDOLPH COUNTY BAT MOBILE UNIT 8 750

Serial Number: 008615 Test Record Number: 5556
Test Date: 08/25/2018 Test Time: 11:37pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:37pm
FLO	Pass	11:37pm
FC	Pass	11:37pm

Temperature Tests

Test	Status	Time
FC1	Pass	11:37pm
SRC	Pass	11:37pm
DET	Pass	11:37pm
BAR	Pass	11:37pm
BT	Pass	11:37pm

Blank Tests

Test	Status	Time
AIR	Pass	11:38pm


Printer Tests

Test	Status	Time
PRNT	Pass	11:38pm

CRC Tests

Test	Status	Time
COMP	Pass	11:38pm
CAL	Pass	11:38pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Randolph Instrument Location Bat Mobile Unit 8
Instrument Serial No. 008734 SHP-Randolph

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 24 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Jonya B Skinner
Signature of Certifying Official

644
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

RANDOLPH COUNTY BAT MOBILE UNIT 8 750

Serial Number: 008736
Test Date: 08/26/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Female
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: SKINNER, TONYA B
Permit Number: 13651E
Effective:
08/01/2017-08/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG716201
Exp Date: 06/11/2019

Test	g/210L	Time
DIAG	Pass	12:21am
AIR BLK	.00	12:22am
ACCY CHK	.08	12:23am
AIR BLK	.00	12:24am
SUB TEST	.00	12:26am
AIR BLK	.00	12:27am
SUB TEST	.00	12:28am
AIR BLK	.00	12:29am

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007

Intox EC/IR-II: Preventive Maintenance

RANDOLPH COUNTY BAT MOBILE UNIT 8 750

Serial Number: 008736 Test Record Number: 916
Test Date: 08/26/2018 Test Time: 12:31am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:31am
FLO	Pass	12:31am
FC	Pass	12:31am

Temperature Tests

Test	Status	Time
FC1	Pass	12:31am
SRC	Pass	12:31am
DET	Pass	12:31am
BAR	Pass	12:31am
BT	Pass	12:31am

Blank Tests

Test	Status	Time
AIR	Pass	12:32am

Printer Tests

Test	Status	Time
PRNT	Pass	12:32am

CRC Tests

Test	Status	Time
COMP	Pass	12:32am
CAL	Pass	12:32am

Preventive Maintenance
Status: Pass

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Randolph

Instrument Location Bat mobile Unit


Instrument Serial No. 008929

SHP-Randolph

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 25 day of August, 2016, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Jana B Skinner

Signature of Certifying Official

1044

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

RANDOLPH COUNTY BAT MOBILE UNIT 8 750

Serial Number: 008929
Test Date: 08/25/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Female

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: SKINNER, TONYA B

Permit Number: 13651E

Effective:

08/01/2017-08/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG814901


Exp Date: 05/29/2020

Test	g/210L	Time
DIAG	Pass	11:38pm
AIR BLK	.00	11:39pm
ACCY CHK	.08	11:39pm
AIR BLK	.00	11:40pm
SUB TEST	.00	11:41pm
AIR BLK	.00	11:42pm
SUB TEST	.00	11:44pm
AIR BLK	.00	11:45pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

RANDOLPH COUNTY BAT MOBILE UNIT 8 750

Serial Number: 008929 Test Record Number: 1009
Test Date: 08/25/2018 Test Time: 11:46pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:47pm
FLO	Pass	11:47pm
FC	Pass	11:47pm

Temperature Tests

Test	Status	Time
FC1	Pass	11:47pm
SRC	Pass	11:47pm
DET	Pass	11:47pm
BAR	Pass	11:47pm
BT	Pass	11:47pm

Blank Tests

Test	Status	Time
AIR	Pass	11:48pm

Printer Tests

Test	Status	Time
PRNT	Pass	11:48pm

CRC Tests

Test	Status	Time
COMP	Pass	11:48pm
CAL	Pass	11:48pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Randolph Instrument Location Bat mobile unit
Instrument Serial No 008601 SHP. Randolph

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 25 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Danya B Skinn
Signature of Certifying Official

644
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

RANDOLPH COUNTY BATMOBILE UNIT 8 750

Serial Number: 008601
Test Date: 08/25/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Female

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: SKINNER, TONYA B

Permit Number: 13651E

Effective:

08/01/2017-08/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG702401

Exp Date: 01/24/2019

Test	g/210L	Time
DIAG	Pass	11:51pm
AIR BLK	.00	11:52pm
ACCY CHK	.08	11:52pm
AIR BLK	.00	11:53pm
SUB TEST	.00	11:54pm
AIR BLK	.00	11:55pm
SUB TEST	.00	11:56pm
AIR BLK	.00	11:57pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007

Intox EC/IR-II: Preventive Maintenance

RANDOLPH COUNTY BATMOBILE UNIT 8 750

Serial Number: 008601 Test Record Number: 1296
Test Date: 08/25/2018 Test Time: 11:59pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:59pm
FLO	Pass	11:59pm
FC	Pass	11:59pm

Temperature Tests

Test	Status	Time
FC1	Pass	11:59pm
SRC	Pass	11:59pm
DET	Pass	11:59pm
BAR	Pass	11:59pm
BT	Pass	11:59pm

Blank Tests

Test	Status	Time
AIR	Pass	12:00am


Printer Tests

Test	Status	Time
PRNT	Pass	12:00am

CRC Tests

Test	Status	Time
COMP	Pass	12:00am
CAL	Pass	12:00am

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Richmond Instrument Location Richmond Co. Mag. Office

Instrument Serial No. 008101 Rockingham NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 6th day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]

Signature of Certifying Official

654

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

RICHMOND COUNTY RICHMOND CO. MAG OFF
760

Serial Number: 008701
Test Date: 08/06/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: KEESLER, GRAYHAM C

Permit Number: 07682E

Effective:

12/01/2017-12/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG805802


Exp Date: 02/27/2020

Test	g/210L	Time
DIAG	Pass	1:48pm
AIR BLK	.00	1:49pm
ACCY CHK	.08	1:49pm
AIR BLK	.00	1:50pm
SUB TEST	.00	1:51pm
AIR BLK	.00	1:52pm
SUB TEST	.00	1:53pm
AIR BLK	.00	1:54pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

RICHMOND COUNTY RICHMOND CO. MAG OFF 760

Serial Number: 008701 Test Record Number: 1167
Test Date: 08/06/2018 Test Time: 1:55pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:55pm
FLO	Pass	1:55pm
FC	Pass	1:55pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:55pm
SRC	Pass	1:55pm
DET	Pass	1:55pm
BAR	Pass	1:55pm
BT	Pass	1:55pm

Blank Tests

Test	Status	Time
AIR	Pass	1:56pm


Printer Tests

Test	Status	Time
PRNT	Pass	1:56pm

CRC Tests

Test	Status	Time
COMP	Pass	1:56pm
CAL	Pass	1:56pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Robeson Co. Instrument Location Pembroke Police Dept.

Instrument Serial No. 008837 Pembroke, NC -

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15th day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Handwritten Signature]
Signature of Certifying Official

654
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

ROBESON COUNTY PEMBROKE POLICE DEPT
770

Serial Number: 008837
Test Date: 08/15/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: KEESLER, GRAYHAM C
Permit Number: 07682E
Effective:
12/01/2017-12/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG702302
Exp Date: 01/23/2019

Test	g/210L	Time
DIAG	Pass	11:37am
AIR BLK	.00	11:38am
ACCY CHK	.08	11:39am
AIR BLK	.00	11:39am
SUB TEST	.00	11:40am
AIR BLK	.00	11:41am
SUB TEST	.00	11:43am
AIR BLK	.00	11:43am

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007

Intox EC/IR-II: Preventive Maintenance

ROBESON COUNTY PEMBROKE POLICE DEPT 770

Serial Number: 008837 Test Record Number: 1000
Test Date: 08/15/2018 Test Time: 11:49am EDT

System Check: Passed

Baseline Tests

Test	Status	Time
IR	Pass	11:50am
FLO	Pass	11:50am
FC	Pass	11:50am

Temperature Tests

Test	Status	Time
FC1	Pass	11:50am
SRC	Pass	11:50am
DET	Pass	11:50am
BAR	Pass	11:50am
BT	Pass	11:50am

Blank Tests

Test	Status	Time
AIR	Pass	11:50am


Printer Tests

Test	Status	Time
PRNT	Pass	11:50am

CRC Tests

Test	Status	Time
COMP	Pass	11:51am
CAL	Pass	11:51am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Robeson Co. Instrument Location St Pauls Police Dept.

Instrument Serial No. 008814 ST PAULS, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 22nd day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

654
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

ROBESON COUNTY ST. PAULS PD. 770

Serial Number: 008814
Test Date: 08/22/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: KEESLER, GRAYHAM C

Permit Number: 07682E

Effective:

12/01/2017-12/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG702302

Exp Date: 01/23/2019

Test	g/210L	Time
DIAG	Pass	10:10am
AIR BLK	.00	10:11am
ACCY CHK	.07	10:12am
AIR BLK	.00	10:12am
SUB TEST	.00	10:13am
AIR BLK	.00	10:14am
SUB TEST	.00	10:15am
AIR BLK	.00	10:16am

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

ROBESON COUNTY ST. PAULS PD. 770

Serial Number: 008814 Test Record Number: 635
Test Date: 08/22/2018 Test Time: 10:17am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:17am
FLO	Pass	10:17am
FC	Pass	10:17am

Temperature Tests

Test	Status	Time
FC1	Pass	10:17am
SRC	Pass	10:17am
DET	Pass	10:17am
BAR	Pass	10:17am
BT	Pass	10:17am

Blank Tests

Test	Status	Time
AIR	Pass	10:18am


Printer Tests

Test	Status	Time
PRNT	Pass	10:18am

CRC Tests

Test	Status	Time
COMP	Pass	10:18am
CAL	Pass	10:18am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Forsyth Co. Instrument Location Red Springs Police Dept.

Instrument Serial No. 008857 Red Springs, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 22nd day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

654
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

ROBESON COUNTY RED SPRINGS PD 770

Serial Number: 008857
Test Date: 08/22/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: KEESLER, GRAYHAM C
Permit Number: 07682E
Effective:
12/01/2017-12/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG734101
Exp Date: 12/07/2019

Test	g/210L	Time
DIAG	Pass	12:02pm
AIR BLK	.00	12:03pm
ACCY CHK	.07	12:03pm
AIR BLK	.00	12:05pm
SUB TEST	.00	12:05pm
AIR BLK	.00	12:06pm
SUB TEST	.00	12:08pm
AIR BLK	.00	12:08pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

ROBESON COUNTY RED SPRINGS PD 770

Serial Number: 008857 Test Record Number: 534
Test Date: 08/22/2018 Test Time: 12:09pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:10pm
FLO	Pass	12:10pm
FC	Pass	12:10pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:10pm
SRC	Pass	12:10pm
DET	Pass	12:10pm
BAR	Pass	12:10pm
BT	Pass	12:10pm

Blank Tests

Test	Status	Time
AIR	Pass	12:11pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:11pm

CRC Tests

Test	Status	Time
COMP	Pass	12:11pm
CAL	Pass	12:11pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Robeson Co. Instrument Location Lumberton P.D.

Instrument Serial No. 008629 Lumberton, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 22nd day of August, 20 18 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

654
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

ROBESON COUNTY LUMBERTON PD 770

Serial Number: 008629

Test Date: 08/22/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: KEESLER, GRAYHAM C

Permit Number: 07682E

Effective:

12/01/2017-12/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG734101

Exp Date: 12/07/2019

Test	g/210L	Time
DIAG	Pass	1:03pm
AIR BLK	.00	1:04pm
ACCY CHK	.07	1:04pm
AIR BLK	.00	1:05pm
SUB TEST	.00	1:06pm
AIR BLK	.00	1:07pm
SUB TEST	.00	1:08pm
AIR BLK	.00	1:09pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

ROBESON COUNTY LUMBERTON PD 770

Serial Number: 008629 Test Record Number: 655
Test Date: 08/22/2018 Test Time: 1:11pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:11pm
FLO	Pass	1:11pm
FC	Pass	1:11pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:11pm
SRC	Pass	1:11pm
DET	Pass	1:11pm
BAR	Pass	1:11pm
BT	Pass	1:11pm

Blank Tests

Test	Status	Time
AIR	Pass	1:12pm


Printer Tests

Test	Status	Time
PRNT	Pass	1:12pm

CRC Tests

Test	Status	Time
COMP	Pass	1:12pm
CAL	Pass	1:12pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Robeson Co. Instrument Location Robeson Co. Jail

Instrument Serial No. 108805 Lumberton, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 23rd day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

654
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

ROBESON COUNTY LUMBERTON LEC 770

Serial Number: 008805
Test Date: 08/23/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: KEESLER, GRAYHAM C
Permit Number: 07682E
Effective:
12/01/2017-12/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG734101
Exp Date: 12/07/2019

Test	g/210L	Time
DIAG	Pass	12:13pm
AIR BLK	.00	12:13pm
ACCY CHK	.07	12:14pm
AIR BLK	.00	12:15pm
SUB TEST	.00	12:15pm
AIR BLK	.00	12:16pm
SUB TEST	.00	12:18pm
AIR BLK	.00	12:19pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

ROBESON COUNTY LUMBERTON LEC 770

Serial Number: 008805 Test Record Number: 4204
Test Date: 08/23/2018 Test Time: 12:20pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:20pm
FLO	Pass	12:20pm
FC	Pass	12:20pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:21pm
SRC	Pass	12:21pm
DET	Pass	12:21pm
BAR	Pass	12:21pm
BT	Pass	12:21pm

Blank Tests

Test	Status	Time
AIR	Pass	12:21pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:21pm

CRC Tests

Test	Status	Time
COMP	Pass	12:21pm
CAL	Pass	12:21pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II

County Robeson Co. Instrument Location Robeson Co. Jail

Instrument Serial No. 008836 Lumberton, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 23rd day of August, 20 18 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

654
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

ROBESON COUNTY LUMBERTON LEC 770

Serial Number: 008836
Test Date: 08/23/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: KEESLER, GRAYHAM C
Permit Number: 07682E
Effective:
12/01/2017-12/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG734101
Exp Date: 12/07/2019

Test	g/210L	Time
DIAG	Pass	12:19pm
AIR BLK	.00	12:20pm
ACCY CHK	.07	12:21pm
AIR BLK	.00	12:22pm
SUB TEST	.00	12:22pm
AIR BLK	.00	12:23pm
SUB TEST	.00	12:25pm
AIR BLK	.00	12:26pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

ROBESON COUNTY LUMBERTON LEC 770

Serial Number: 008836 Test Record Number: 4913
Test Date: 08/23/2018 Test Time: 12:26pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:27pm
FLO	Pass	12:27pm
FC	Pass	12:27pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:27pm
SRC	Pass	12:27pm
DET	Pass	12:27pm
BAR	Pass	12:27pm
BT	Pass	12:27pm

Blank Tests

Test	Status	Time
AIR	Pass	12:28pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:28pm

CRC Tests

Test	Status	Time
COMP	Pass	12:28pm
CAL	Pass	12:28pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County SAMPSON Instrument Location SAF MADE UNIT 6

Instrument Serial No. 008776

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 19 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

663
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

SAMPSON COUNTY BAT MOBILE UNIT 6 810

Serial Number: 008776

Test Date: 08/19/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: VARNELL, BRYON L

Permit Number: 16896E

Effective:

09/26/2017-01/26/2026

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG710701

Exp Date: 04/17/2019

Test	g/210L	Time
DIAG	Pass	4:38pm
AIR BLK	.00	4:39pm
ACCY CHK	.07	4:39pm
AIR BLK	.00	4:40pm
SUB TEST	.00	4:40pm
AIR BLK	.00	4:41pm
SUB TEST	.00	4:43pm
AIR BLK	.00	4:44pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

SAMPSON COUNTY BAT MOBILE UNIT 6 810

Serial Number: 008776 Test Record Number: 3464
Test Date: 08/19/2018 Test Time: 4:46pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	4:47pm
FLO	Pass	4:47pm
FC	Pass	4:47pm

Temperature Tests

Test	Status	Time
FC1	Pass	4:47pm
SRC	Pass	4:47pm
DET	Pass	4:47pm
BAR	Pass	4:47pm
BT	Pass	4:47pm

Blank Tests

Test	Status	Time
AIR	Pass	4:47pm


Printer Tests

Test	Status	Time
PRNT	Pass	4:47pm

CRC Tests

Test	Status	Time
COMP	Pass	4:48pm
CAL	Pass	4:48pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II


County Scotland Co. Instrument Location Laurinburg Police Dept

Instrument Serial No. 008834 Laurinburg, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 21th day of AUGUST, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

421
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

SCOTLAND COUNTY LAURINBURG PD. 820

Serial Number: 008834

Test Date: 08/21/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: KEESLER, GRAYHAM C

Permit Number: 07682E

Effective:

12/01/2017-12/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG734101

Exp Date: 12/07/2019

Test	g/210L	Time
DIAG	Pass	12:58pm
AIR BLK	.00	12:59pm
ACCY CHK	.07	12:59pm
AIR BLK	.00	1:00pm
SUB TEST	.00	1:01pm
AIR BLK	.00	1:02pm
SUB TEST	.00	1:03pm
AIR BLK	.00	1:04pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

SCOTLAND COUNTY LAURINBURG PD. 820

Serial Number: 008834 Test Record Number: 866
Test Date: 08/21/2018 Test Time: 1:05pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:05pm
FLO	Pass	1:05pm
FC	Pass	1:05pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:05pm
SRC	Pass	1:05pm
DET	Pass	1:05pm
BAR	Pass	1:05pm
BT	Pass	1:05pm

Blank Tests

Test	Status	Time
AIR	Pass	1:06pm


Printer Tests

Test	Status	Time
PRNT	Pass	1:06pm

CRC Tests

Test	Status	Time
COMP	Pass	1:06pm
CAL	Pass	1:06pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Scotland Co. Instrument Location Scotland Co. Jail

Instrument Serial No. 008861 LAURINBURG, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 21st day of AUGUST, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Handwritten Signature]

Signature of Certifying Official

154

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

SCOTLAND COUNTY SHERIFF'S OFFICE 820

Serial Number: 008861
Test Date: 08/21/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: KEESLER, GRAYHAM C

Permit Number: 07682E

Effective:

12/01/2017-12/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG721401

Exp Date: 08/02/2019

Test	g/210L	Time
DIAG	Pass	1:45pm
AIR BLK	.00	1:46pm
ACCY CHK	.07	1:47pm
AIR BLK	.00	1:48pm
SUB TEST	.00	1:48pm
AIR BLK	.00	1:49pm
SUB TEST	.00	1:51pm
AIR BLK	.00	1:52pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

SCOTLAND COUNTY SHERIFF'S OFFICE 820

Serial Number: 008861 Test Record Number: 1437
Test Date: 08/21/2018 Test Time: 1:53pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:53pm
FLO	Pass	1:53pm
FC	Pass	1:54pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:54pm
SRC	Pass	1:54pm
DET	Pass	1:54pm
BAR	Pass	1:54pm
BT	Pass	1:54pm

Blank Tests

Test	Status	Time
AIR	Pass	1:54pm

Printer Tests

Test	Status	Time
PRNT	Pass	1:54pm

CRC Tests

Test	Status	Time
COMP	Pass	1:54pm
CAL	Pass	1:54pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Stokes Instrument Location Stokes County Jail
Instrument Serial No. 008596 Danbury, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

657
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

STOKES COUNTY STOKES COUNTY JAIL 840

Serial Number: 008596
Test Date: 08/15/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name:
BENFIELD II, KENNETH R
Permit Number: 22067E
Effective:
06/01/2018-06/01/2020

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG702401
Exp Date: 01/24/2019

Test	g/210L	Time
DIAG	Pass	11:00am
AIR BLK	.00	11:00am
ACCY CHK	.08	11:01am
AIR BLK	.00	11:02am
SUB TEST	.00	11:03am
AIR BLK	.00	11:04am
SUB TEST	.00	11:05am
AIR BLK	.00	11:06am

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

STOKES COUNTY STOKES COUNTY JAIL 840

Serial Number: 008596 Test Record Number: 1022
Test Date: 08/15/2018 Test Time: 11:07am EDT

System Check: Passed

Baseline Tests

Test	Status	Time
IR	Pass	11:07am
FLO	Pass	11:07am
FC	Pass	11:07am

Temperature Tests

Test	Status	Time
FC1	Pass	11:07am
SRC	Pass	11:07am
DET	Pass	11:07am
BAR	Pass	11:07am
BT	Pass	11:07am

Blank Tests

Test	Status	Time
AIR	Pass	11:08am


Printer Tests

Test	Status	Time
PRNT	Pass	11:08am

CRC Tests

Test	Status	Time
COMP	Pass	11:08am
CAL	Pass	11:08am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Stokes Instrument Location King Police
Instrument Serial No. 008610 Department

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

657
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

STOKES COUNTY KING PD 840

Serial Number: 008610
Test Date: 08/13/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name:

BENFIELD II, KENNETH R

Permit Number: 22067E

Effective:

06/01/2018-06/01/2020

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG702401


Exp Date: 01/24/2019

Test	g/210L	Time
DIAG	Pass	10:35am
AIR BLK	.00	10:36am
ACCY CHK	.07	10:37am
AIR BLK	.00	10:38am
SUB TEST	.00	10:38am
AIR BLK	.00	10:39am
SUB TEST	.00	10:41am
AIR BLK	.00	10:42am

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

STOKES COUNTY KING PD 840

Serial Number: 008610 Test Record Number: 1962
Test Date: 08/13/2018 Test Time: 10:42am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:43am
FLO	Pass	10:43am
FC	Pass	10:43am

Temperature Tests

Test	Status	Time
FC1	Pass	10:43am
SRC	Pass	10:43am
DET	Pass	10:43am
BAR	Pass	10:43am
BT	Pass	10:43am

Blank Tests

Test	Status	Time
AIR	Pass	10:43am


Printer Tests

Test	Status	Time
PRNT	Pass	10:44am

CRC Tests

Test	Status	Time
COMP	Pass	10:44am
CAL	Pass	10:44am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Surry Instrument Location Elkin Police
Instrument Serial No. 008926 Department

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 9 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

657
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

SURRY COUNTY ELKIN PD 850

Serial Number: 008926
Test Date: 08/09/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name:

BENFIELD II, KENNETH R

Permit Number: 22067E

Effective:

06/01/2018-06/01/2020

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG734102

Exp Date: 12/07/2019


Test	g/210L	Time
DIAG	Pass	2:09pm
AIR BLK	.00	2:10pm
ACCY CHK	.08	2:11pm
AIR BLK	.00	2:12pm
SUB TEST	.00	2:12pm
AIR BLK	.00	2:13pm
SUB TEST	.00	2:15pm
AIR BLK	.00	2:16pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

SURRY COUNTY ELKIN PD 850

Serial Number: 008926 Test Record Number: 812
Test Date: 08/09/2018 Test Time: 2:17pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:17pm
FLO	Pass	2:17pm
FC	Pass	2:17pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:17pm
SRC	Pass	2:17pm
DET	Pass	2:17pm
BAR	Pass	2:17pm
BT	Pass	2:17pm

Blank Tests

Test	Status	Time
AIR	Pass	2:18pm


Printer Tests

Test	Status	Time
PRNT	Pass	2:18pm

CRC Tests

Test	Status	Time
COMP	Pass	2:18pm
CAL	Pass	2:18pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II


County SWAN Instrument Location Bad Mobile Unit 2

Instrument Serial No. 008973 NCHP

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 4 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Cheryl Joy
Signature of Certifying Official

658
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Preventive Maintenance

SWAIN BAT MOBILE UNIT 02 860

Serial Number: 008973 Test Record Number: 526
Test Date: 08/04/2018 Test Time: 7:26pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	7:26pm
FLO	Pass	7:26pm
FC	Pass	7:27pm

Temperature Tests

Test	Status	Time
FC1	Pass	7:27pm
SRC	Pass	7:27pm
DET	Pass	7:27pm
BAR	Pass	7:27pm
BT	Pass	7:27pm

Blank Tests

Test	Status	Time
AIR	Pass	7:27pm


Printer Tests

Test	Status	Time
PRNT	Pass	7:27pm

CRC Tests

Test	Status	Time
COMP	Pass	7:27pm
CAL	Pass	7:27pm

Preventive Maintenance
Status: Pass



Analyst

Intox EC/IR-II: Subject Test

SWAIN BAT MOBILE UNIT 02 860

Serial Number: 008973
Test Date: 08/04/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: TOWERY, CHAD V
Permit Number: 26632E
Effective:
06/01/2017-06/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG807101
Exp Date: 03/12/2020


Test	g/210L	Time
DIAG	Pass	7:19pm
AIR BLK	.00	7:20pm
ACCY CHK	.08	7:20pm
AIR BLK	.00	7:21pm
SUB TEST	.00	7:22pm
AIR BLK	.00	7:23pm
SUB TEST	.00	7:24pm
AIR BLK	.00	7:25pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Transylvania Instrument Location Transylvania Co. Jail
Instrument Serial No. 008606 Brevard, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 22 day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Carol R. Cuth

Signature of Certifying Official

635

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

TRANSYLVANIA COUNTY TRANSYLVANIA CO
JAIL 870

Serial Number: 008606
Test Date: 08/22/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: CUTLER, DANIEL R

Permit Number: 08457E

Effective:

09/01/2017-09/01/2019

Officer's Name: NONE,

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG734102

Exp Date: 12/07/2019

Test	g/210L	Time
DIAG	Pass	12:17pm
AIR BLK	.00	12:18pm
ACCY CHK	.08	12:19pm
AIR BLK	.00	12:20pm
SUB TEST	.00	12:21pm
AIR BLK	.00	12:22pm
SUB TEST	.00	12:23pm
AIR BLK	.00	12:24pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

TRANSYLVANIA COUNTY TRANSYLVANIA CO JAIL 870

Serial Number: 008606 Test Record Number: 323
Test Date: 08/22/2018 Test Time: 12:25pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:25pm
FLO	Pass	12:25pm
FC	Pass	12:25pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:25pm
SRC	Pass	12:25pm
DET	Pass	12:25pm
BAR	Pass	12:25pm
BT	Pass	12:25pm

Blank Tests

Test	Status	Time
AIR	Pass	12:26pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:26pm

CRC Tests

Test	Status	Time
COMP	Pass	12:26pm
CAL	Pass	12:26pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Transylvania Instrument Location Transylvania Co. Jail
Instrument Serial No. 008820 Brevard, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 22 day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Chris R. Cuthbert
Signature of Certifying Official

635
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

TRANSYLVANIA COUNTY TRANSYLVANIA CO
JAIL 870

Serial Number: 008820
Test Date: 08/22/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: CUTLER, DANIEL R
Permit Number: 08457E
Effective:
09/01/2017-09/01/2019

Officer's Name: NONE,
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG734102
Exp Date: 12/07/2019

Test	g/210L	Time
DIAG	Pass	12:00pm
AIR BLK	.00	12:01pm
ACCY CHK	.07	12:02pm
AIR BLK	.00	12:03pm
SUB TEST	.00	12:03pm
AIR BLK	.00	12:04pm
SUB TEST	.00	12:06pm
AIR BLK	.00	12:06pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

TRANSYLVANIA COUNTY TRANSYLVANIA CO JAIL 870

Serial Number: 008820 Test Record Number: 1184
Test Date: 08/22/2018 Test Time: 12:12pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:12pm
FLO	Pass	12:12pm
FC	Pass	12:13pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:13pm
SRC	Pass	12:13pm
DET	Pass	12:13pm
BAR	Pass	12:13pm
BT	Pass	12:13pm

Blank Tests

Test	Status	Time
AIR	Pass	12:13pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:13pm

CRC Tests

Test	Status	Time
COMP	Pass	12:14pm
CAL	Pass	12:14pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Vance Instrument Location Bat mobile Unit
Instrument Serial No 008775 Henderson PD

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 10 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Donna B Skinner
Signature of Certifying Official

644
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

VANCE COUNTY BAT MOBILE UNIT 8 900

Serial Number: 008775
Test Date: 08/10/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Female
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: SKINNER, TONYA B
Permit Number: 13651E
Effective:
08/01/2017-08/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG734101
Exp Date: 12/07/2019

Test	g/210L	Time
DIAG	Pass	9:55pm
AIR BLK	.00	9:56pm
ACCY CHK	.08	9:57pm
AIR BLK	.00	9:58pm
SUB TEST	.00	9:58pm
AIR BLK	.00	9:59pm
SUB TEST	.00	10:01pm
AIR BLK	.00	10:02pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

VANCE COUNTY BAT MOBILE UNIT 8 900

Serial Number: 008775 Test Record Number: 1776
Test Date: 08/10/2018 Test Time: 10:04pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:04pm
FLO	Pass	10:04pm
FC	Pass	10:04pm

Temperature Tests

Test	Status	Time
FC1	Pass	10:05pm
SRC	Pass	10:05pm
DET	Pass	10:05pm
BAR	Pass	10:05pm
BT	Pass	10:05pm

Blank Tests

Test	Status	Time
AIR	Pass	10:05pm

Printer Tests

Test	Status	Time
PRNT	Pass	10:05pm

CRC Tests

Test	Status	Time
COMP	Pass	10:05pm
CAL	Pass	10:05pm

Preventive Maintenance
Status: Pass


Donya B Skinner
Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County VANCE Instrument Location Pat Mobile Unit
Instrument Serial No. 008816 Henderson PD

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 10 day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Danya B Skumin
Signature of Certifying Official

644
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

VANCE COUNTY BAT MOBILE UNIT 8 900

Serial Number: 008816
Test Date: 08/10/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: SKINNER, TONYA B
Permit Number: 13651E
Effective:
08/01/2017-08/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG805801
Exp Date: 02/27/2020

Test	g/210L	Time
DIAG	Pass	10:02pm
AIR BLK	.00	10:03pm
ACCY CHK	.07	10:04pm
AIR BLK	.00	10:05pm
SUB TEST	.00	10:05pm
AIR BLK	.00	10:06pm
SUB TEST	.00	10:08pm
AIR BLK	.00	10:09pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

VANCE COUNTY BAT MOBILE UNIT 8 900

Serial Number: 008816 Test Record Number: 7425
Test Date: 08/10/2018 Test Time: 10:13pm EDT

System Check: Passed

Baseline Tests

Test	Status	Time
IR	Pass	10:14pm
FLO	Pass	10:14pm
FC	Pass	10:14pm

Temperature Tests

Test	Status	Time
FC1	Pass	10:14pm
SRC	Pass	10:14pm
DET	Pass	10:14pm
BAR	Pass	10:14pm
BT	Pass	10:14pm

Blank Tests

Test	Status	Time
AIR	Pass	10:14pm

Printer Tests

Test	Status	Time
PRNT	Pass	10:14pm

CRC Tests

Test	Status	Time
COMP	Pass	10:15pm
CAL	Pass	10:15pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County VANCE Instrument Location Kat Mobile Unit 8

Instrument Serial No. 008736 HENDERSON PD

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 10 day of AUGUST, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Donna B Skum
Signature of Certifying Official

644
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

VANCE COUNTY BAT MOBILE UNIT 8 900

Serial Number: 008736
Test Date: 08/10/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: SKINNER, TONYA B
Permit Number: 13651E
Effective:
08/01/2017-08/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG716201
Exp Date: 06/11/2019

Test	g/210L	Time
DIAG	Pass	10:23pm
AIR BLK	.00	10:24pm
ACCY CHK	.08	10:24pm
AIR BLK	.00	10:25pm
SUB TEST	.00	10:26pm
AIR BLK	.00	10:27pm
SUB TEST	.00	10:28pm
AIR BLK	.00	10:29pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

VANCE COUNTY BAT MOBILE UNIT 8 900

Serial Number: 008736 Test Record Number: 908
Test Date: 08/10/2018 Test Time: 10:32pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:33pm
FLO	Pass	10:33pm
FC	Pass	10:33pm

Temperature Tests

Test	Status	Time
FC1	Pass	10:33pm
SRC	Pass	10:33pm
DET	Pass	10:33pm
BAR	Pass	10:33pm
BT	Pass	10:33pm

Blank Tests

Test	Status	Time
AIR	Pass	10:33pm

Printer Tests

Test	Status	Time
PRNT	Pass	10:33pm

CRC Tests

Test	Status	Time
COMP	Pass	10:34pm
CAL	Pass	10:34pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II

County Vance Instrument Location Bat Mobile Unit 8
Instrument Serial No. 008601 Henderson PD

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 10 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Donya B Skinner
Signature of Certifying Official

644
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

VANCE COUNTY BATMOBILE UNIT 8 900

Serial Number: 008601
Test Date: 08/10/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Female

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: SKINNER, TONYA B

Permit Number: 13651E

Effective:

08/01/2017-08/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG702401

Exp Date: 01/24/2019

Test	g/210L	Time
DIAG	Pass	10:15pm
AIR BLK	.00	10:16pm
ACCY CHK	.08	10:17pm
AIR BLK	.00	10:17pm
SUB TEST	.00	10:19pm
AIR BLK	.00	10:20pm
SUB TEST	.00	10:22pm
AIR BLK	.00	10:23pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

VANCE COUNTY BATMOBILE UNIT 8 900

Serial Number: 008601 Test Record Number: 1284
Test Date: 08/10/2018 Test Time: 10:24pm EDT

System Check: Passed

Baseline Tests

Test	Status	Time
IR	Pass	10:24pm
FLO	Pass	10:24pm
FC	Pass	10:24pm

Temperature Tests

Test	Status	Time
FC1	Pass	10:24pm
SRC	Pass	10:24pm
DET	Pass	10:24pm
BAR	Pass	10:24pm
BT	Pass	10:24pm

Blank Tests

Test	Status	Time
AIR	Pass	10:25pm

Printer Tests

Test	Status	Time
PRNT	Pass	10:25pm

CRC Tests

Test	Status	Time
COMP	Pass	10:25pm
CAL	Pass	10:25pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County VANCE Instrument Location VANCE CO SHERIFF'S OFFICE
Instrument Serial No. 008870 156 Church St Henderson, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 28 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

662
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

VANCE COUNTY SHERIFF'S DEPARTMENT 900

Serial Number: 008870
Test Date: 08/28/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: BARNES, STOKES
Permit Number: 11434E
Effective:
05/01/2017-05/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG805801
Exp Date: 02/27/2020

Test	g/210L	Time
DIAG	Pass	1:22pm
AIR BLK	.00	1:23pm
ACCY CHK	.08	1:24pm
AIR BLK	.00	1:25pm
SUB TEST	.00	1:27pm
AIR BLK	.00	1:28pm
SUB TEST	.00	1:29pm
AIR BLK	.00	1:30pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

VANCE COUNTY SHERIFF'S DEPARTMENT 900

Serial Number: 008870 Test Record Number: 2368
Test Date: 08/28/2018 Test Time: 1:31pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:31pm
FLO	Pass	1:31pm
FC	Pass	1:31pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:31pm
SRC	Pass	1:31pm
DET	Pass	1:31pm
BAR	Pass	1:31pm
BT	Pass	1:31pm

Blank Tests

Test	Status	Time
AIR	Pass	1:32pm

Printer Tests

Test	Status	Time
PRNT	Pass	1:32pm

CRC Tests

Test	Status	Time
COMP	Pass	1:32pm
CAL	Pass	1:32pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County VANCE

Instrument Location Vance Co Sheriff's Office


Instrument Serial No. 008937

156 Church St Henderson, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 28 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

462
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

VANCE COUNTY SHERIFF'S DEPARTMENT 900

Serial Number: 008937
Test Date: 08/28/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: BARNES, STOKES
Permit Number: 11434E
Effective:
05/01/2017-05/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG702402
Exp Date: 01/24/2019


Test	g/210L	Time
DIAG	Pass	1:23pm
AIR BLK	.00	1:24pm
ACCY CHK	.08	1:25pm
AIR BLK	.00	1:26pm
SUB TEST	.00	1:26pm
AIR BLK	.00	1:27pm
SUB TEST	.00	1:29pm
AIR BLK	.00	1:30pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

VANCE COUNTY SHERIFF'S DEPARTMENT 900

Serial Number: 008937 Test Record Number: 2609
Test Date: 08/28/2018 Test Time: 1:30pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:30pm
FLO	Pass	1:30pm
FC	Pass	1:31pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:31pm
SRC	Pass	1:31pm
DET	Pass	1:31pm
BAR	Pass	1:31pm
BT	Pass	1:31pm

Blank Tests

Test	Status	Time
AIR	Pass	1:31pm

Printer Tests

Test	Status	Time
PRNT	Pass	1:31pm

CRC Tests

Test	Status	Time
COMP	Pass	1:32pm
CAL	Pass	1:32pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Wake Instrument Location Bar Mobile Unit 8
Instrument Serial No. 008812 Raleigh PD

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16 day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Donna B. Skinner
Signature of Certifying Official

644
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAKE COUNTY BAT MOBILE UNIT 8 910

Serial Number: 008816
Test Date: 08/16/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Female

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: SKINNER, TONYA B

Permit Number: 13651E

Effective:

08/01/2017-08/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG805801

Exp Date: 02/27/2020

Test	g/210L	Time
DIAG	Pass	8:59pm
AIR BLK	.00	9:00pm
ACCY CHK	.07	9:00pm
AIR BLK	.00	9:01pm
SUB TEST	.00	9:02pm
AIR BLK	.00	9:03pm
SUB TEST	.00	9:04pm
AIR BLK	.00	9:05pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY BAT MOBILE UNIT 8 910

Serial Number: 008816 Test Record Number: 7434
Test Date: 08/16/2018 Test Time: 9:06pm EDT

System Check: Passed

Baseline Tests

Test	Status	Time
IR	Pass	9:06pm
FLO	Pass	9:06pm
FC	Pass	9:07pm

Temperature Tests

Test	Status	Time
FC1	Pass	9:07pm
SRC	Pass	9:07pm
DET	Pass	9:07pm
BAR	Pass	9:07pm
BT	Pass	9:07pm

Blank Tests

Test	Status	Time
AIR	Pass	9:07pm

Printer Tests

Test	Status	Time
PRNT	Pass	9:07pm

CRC Tests

Test	Status	Time
COMP	Pass	9:07pm
CAL	Pass	9:07pm

Preventive Maintenance
Status: Pass

Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Wake Instrument Location Bat mobile Unit 8
Instrument Serial No. 008775 Raleigh PD

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16 day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Donya B Skinner
Signature of Certifying Official

644
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAKE COUNTY BAT MOBILE UNIT 8 910

Serial Number: 008775
Test Date: 08/16/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Female

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: SKINNER, TONYA B

Permit Number: 13651E

Effective:

08/01/2017-08/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG734101


Exp Date: 12/07/2019

Test	g/210L	Time
DIAG	Pass	9:03pm
AIR BLK	.00	9:04pm
ACCY CHK	.07	9:05pm
AIR BLK	.00	9:06pm
SUB TEST	.00	9:06pm
AIR BLK	.00	9:07pm
SUB TEST	.00	9:09pm
AIR BLK	.00	9:10pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY BAT MOBILE UNIT 8 910

Serial Number: 008775 Test Record Number: 1783
Test Date: 08/16/2018 Test Time: 9:11pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	9:11pm
FLO	Pass	9:11pm
FC	Pass	9:11pm

Temperature Tests

Test	Status	Time
FC1	Pass	9:11pm
SRC	Pass	9:11pm
DET	Pass	9:11pm
BAR	Pass	9:11pm
BT	Pass	9:11pm

Blank Tests

Test	Status	Time
AIR	Pass	9:12pm


Printer Tests

Test	Status	Time
PRNT	Pass	9:12pm

CRC Tests

Test	Status	Time
COMP	Pass	9:12pm
CAL	Pass	9:12pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II

County Wake

Instrument Location Bot mobile Unit 8


Instrument Serial No. 008601

Raleigh PD

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16 day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Danya B Skinner
Signature of Certifying Official

644
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAKE COUNTY BATMOBILE UNIT 8 910

Serial Number: 008601
Test Date: 08/16/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Female

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: SKINNER, TONYA B

Permit Number: 13651E

Effective:

08/01/2017-08/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG702401

Exp Date: 01/24/2019

Test	g/210L	Time
DIAG	Pass	9:14pm
AIR BLK	.00	9:15pm
ACCY CHK	.08	9:16pm
AIR BLK	.00	9:17pm
SUB TEST	.00	9:18pm
AIR BLK	.00	9:19pm
SUB TEST	.00	9:20pm
AIR BLK	.00	9:21pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY BATMOBILE UNIT 8 910

Serial Number: 008601 Test Record Number: 1291
Test Date: 08/16/2018 Test Time: 9:22pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	9:22pm
FLO	Pass	9:22pm
FC	Pass	9:23pm

Temperature Tests

Test	Status	Time
FC1	Pass	9:23pm
SRC	Pass	9:23pm
DET	Pass	9:23pm
BAR	Pass	9:23pm
BT	Pass	9:23pm

Blank Tests

Test	Status	Time
AIR	Pass	9:23pm


Printer Tests

Test	Status	Time
PRNT	Pass	9:23pm

CRC Tests

Test	Status	Time
COMP	Pass	9:23pm
CAL	Pass	9:23pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County WAKE Instrument Location RALEIGH PD NORTHEAST DISTRICT

Instrument Serial No. DU 8623 5228 GREEN'S DAIRY RD RALEIGH, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 20 day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Russell Smith
Signature of Certifying Official

637
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAKE COUNTY NORTH EAST DISTRICT 910

Serial Number: 008623

Test Date: 08/20/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: SMITH, BRIAN D

Permit Number: 08937E

Effective:

08/01/2017-08/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG716202

Exp Date: 06/11/2019


Test	g/210L	Time
DIAG	Pass	9:52am
AIR BLK	.00	9:53am
ACCY CHK	.08	9:53am
AIR BLK	.00	9:54am
SUB TEST	.00	9:55am
AIR BLK	.00	9:56am
SUB TEST	.00	9:57am
AIR BLK	.00	9:58am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

This form is used when performing Preventive Maintenance procedures

Forensic Tests for Alcohol Branch

Department of Health and Human Services

Rev. 12/2007

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY NORTH EAST DISTRICT 910
Serial Number: 008623 Test Record Number: 3690
Test Date: 08/20/2018 Test Time: 9:59am EDT
System Check: Passed

Baseline Tests

Test	Status	Time
IR	Pass	9:59am
FLO	Pass	9:59am
FC	Pass	10:00am

Temperature Tests

Test	Status	Time
FC1	Pass	10:00am
SRC	Pass	10:00am
DET	Pass	10:00am
BAR	Pass	10:00am
BT	Pass	10:00am

Blank Tests

Test	Status	Time
AIR	Pass	10:01am


Printer Tests

Test	Status	Time
PRNT	Pass	10:01am

CRC Tests

Test	Status	Time
COMP	Pass	10:01am
CAL	Pass	10:01am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County WAKE Instrument Location WAKE CO DETENTION CTR

Instrument Serial No. 008612 3301 HAMMOND RD RALEIGH, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 27 day of AUGUST, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Bru. D. Smith
Signature of Certifying Official

637
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAKE COUNTY DETENTION CENTER 910

Serial Number: 008612
Test Date: 08/27/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: SMITH, BRIAN D
Permit Number: 08937E
Effective:
08/01/2017-08/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG807102
Exp Date: 03/12/2020

Test	g/210L	Time
DIAG	Pass	2:47pm
AIR BLK	.00	2:48pm
ACCY CHK	.07	2:48pm
AIR BLK	.00	2:49pm
SUB TEST	.00	2:50pm
AIR BLK	.00	2:51pm
SUB TEST	.00	2:54pm
AIR BLK	.00	2:55pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY DETENTION CENTER 910

Serial Number: 008612 Test Record Number: 4013
Test Date: 08/27/2018 Test Time: 3:00pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:00pm
FLO	Pass	3:00pm
FC	Pass	3:00pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:01pm
SRC	Pass	3:01pm
DET	Pass	3:01pm
BAR	Pass	3:01pm
BT	Pass	3:01pm

Blank Tests

Test	Status	Time
AIR	Pass	3:01pm

Printer Tests

Test	Status	Time
PRNT	Pass	3:01pm

CRC Tests

Test	Status	Time
COMP	Pass	3:01pm
CAL	Pass	3:01pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County WAKE Instrument Location WARE CO DETENTION STR

Instrument Serial No. 008577 3301 HAMMOND RD RALEIGH, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 27 day of August, 20 18 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Bruce D. Smith
Signature of Certifying Official

637
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAKE COUNTY DETENTION CENTER 910

Serial Number: 008577
Test Date: 08/27/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: SMITH, BRIAN D
Permit Number: 08937E
Effective:
08/01/2017-08/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG807102
Exp Date: 03/12/2020


Test	g/210L	Time
DIAG	Pass	2:45pm
AIR BLK	.00	2:46pm
ACCY CHK	.07	2:47pm
AIR BLK	.00	2:48pm
SUB TEST	.00	2:49pm
AIR BLK	.00	2:50pm
SUB TEST	.00	2:51pm
AIR BLK	.00	2:52pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY DETENTION CENTER 910

Serial Number: 008577 Test Record Number: 3970
Test Date: 08/27/2018 Test Time: 2:53pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:53pm
FLO	Pass	2:53pm
FC	Pass	2:54pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:54pm
SRC	Pass	2:54pm
DET	Pass	2:54pm
BAR	Pass	2:54pm
BT	Pass	2:54pm

Blank Tests

Test	Status	Time
AIR	Pass	2:54pm

Printer Tests

Test	Status	Time
PRNT	Pass	2:54pm

CRC Tests

Test	Status	Time
COMP	Pass	2:54pm
CAL	Pass	2:54pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County WAKE Instrument Location WAKE CO DETENTION CTR

Instrument Serial No. 008778 3301 HAMMOND RD RALEIGH, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 27 day of August, 20 18 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Bruce D. Smith
Signature of Certifying Official

637
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAKE COUNTY DETENTION CENTER 910

Serial Number: 008778
Test Date: 08/27/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: SMITH, BRIAN D
Permit Number: 08937E
Effective:
08/01/2017-08/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG807102
Exp Date: 03/12/2020


Test	g/210L	Time
DIAG	Pass	2:13pm
AIR BLK	.00	2:13pm
ACCY CHK	.07	2:14pm
AIR BLK	.00	2:15pm
SUB TEST	.00	2:16pm
AIR BLK	.00	2:17pm
SUB TEST	.00	2:18pm
AIR BLK	.00	2:19pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY DETENTION CENTER 910

Serial Number: 008778 Test Record Number: 3360
Test Date: 08/27/2018 Test Time: 2:22pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:22pm
FLO	Pass	2:22pm
FC	Pass	2:22pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:22pm
SRC	Pass	2:22pm
DET	Pass	2:22pm
BAR	Pass	2:22pm
BT	Pass	2:22pm

Blank Tests

Test	Status	Time
AIR	Pass	2:23pm

Printer Tests

Test	Status	Time
PRNT	Pass	2:23pm

CRC Tests

Test	Status	Time
COMP	Pass	2:23pm
CAL	Pass	2:23pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County WAKE Instrument Location WAKE CO. DETENTION CTR

Instrument Serial No. 008760 3301 HAMMOND RD RALEIGH, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 27 day of AUGUST, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Bruce D. Smith
Signature of Certifying Official

637
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAKE COUNTY DETENTION CENTER 910

Serial Number: 008760
Test Date: 08/27/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: SMITH, BRIAN D

Permit Number: 08937E

Effective:

08/01/2017-08/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG807102

Exp Date: 03/12/2020


Test	g/210L	Time
DIAG	Pass	2:10pm
AIR BLK	.00	2:11pm
ACCY CHK	.08	2:11pm
AIR BLK	.00	2:12pm
SUB TEST	.00	2:14pm
AIR BLK	.00	2:15pm
SUB TEST	.00	2:17pm
AIR BLK	.00	2:18pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY DETENTION CENTER 910

Serial Number: 008760 Test Record Number: 3078
Test Date: 08/27/2018 Test Time: 2:21pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:21pm
FLO	Pass	2:21pm
FC	Pass	2:22pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:22pm
SRC	Pass	2:22pm
DET	Pass	2:22pm
BAR	Pass	2:22pm
BT	Pass	2:22pm

Blank Tests

Test	Status	Time
AIR	Pass	2:22pm

Printer Tests

Test	Status	Time
PRNT	Pass	2:22pm

CRC Tests

Test	Status	Time
COMP	Pass	2:23pm
CAL	Pass	2:23pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County WAKE Instrument Location CARY PD

Instrument Serial No. 008587 102 Wilkinson Ave Cary, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 17 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

662
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAKE COUNTY CARY PD 910

Serial Number: 008587

Test Date: 08/17/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, STOKES

Permit Number: 11434E

Effective:

05/01/2017-05/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG734101

Exp Date: 12/07/2019


Test	g/210L	Time
DIAG	Pass	2:06pm
AIR BLK	.00	2:06pm
ACCY CHK	.07	2:07pm
AIR BLK	.00	2:08pm
SUB TEST	.00	2:09pm
AIR BLK	.00	2:10pm
SUB TEST	.00	2:11pm
AIR BLK	.00	2:12pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY CARY PD 910

Serial Number: 008587 Test Record Number: 3849
Test Date: 08/17/2018 Test Time: 2:15pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:16pm
FLO	Pass	2:16pm
FC	Pass	2:16pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:16pm
SRC	Pass	2:16pm
DET	Pass	2:16pm
BAR	Pass	2:16pm
BT	Pass	2:16pm

Blank Tests

Test	Status	Time
AIR	Pass	2:17pm


Printer Tests

Test	Status	Time
PRNT	Pass	2:17pm

CRC Tests

Test	Status	Time
COMP	Pass	2:17pm
CAL	Pass	2:17pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Wake Instrument Location Apex PD STATION 41
Instrument Serial No. 008621 1615 E. Williams St. Apex, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 17 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

642
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAKE COUNTY APEX PD

Serial Number: 008621

Test Date: 08/17/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, STOKES

Permit Number: 11434E

Effective:

05/01/2017-05/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG734101

Exp Date: 12/07/2019

Test	g/210L	Time
DIAG	Pass	3:19pm
AIR BLK	.00	3:20pm
ACCY CHK	.07	3:20pm
AIR BLK	.00	3:22pm
SUB TEST	.00	3:22pm
AIR BLK	.00	3:23pm
SUB TEST	.00	3:24pm
AIR BLK	.00	3:25pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY APEX PD

Serial Number: 008621 Test Record Number: 2492

Test Date: 08/17/2018 Test Time: 3:26pm EDT

System Check: Passed

Baseline Tests

Test	Status	Time
IR	Pass	3:26pm
FLO	Pass	3:26pm
FC	Pass	3:26pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:26pm
SRC	Pass	3:26pm
DET	Pass	3:26pm
BAR	Pass	3:26pm
BT	Pass	3:26pm

Blank Tests

Test	Status	Time
AIR	Pass	3:27pm


Printer Tests

Test	Status	Time
PRNT	Pass	3:27pm

CRC Tests

Test	Status	Time
COMP	Pass	3:27pm
CAL	Pass	3:27pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County WAKE Instrument Location KNIGHTDALE P.S.

Instrument Serial No. 008838 979 STEADLE SQUARE CT
KNIGHTDALE, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 27 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

662
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAKE COUNTY KNIGHTDALE PS 910

Serial Number: 008838
Test Date: 08/27/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, STOKES

Permit Number: 11434E

Effective:

05/01/2017-05/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG807102

Exp Date: 03/12/2020


Test	g/210L	Time
DIAG	Pass	9:57am
AIR BLK	.00	9:58am
ACCY CHK	.07	9:59am
AIR BLK	.00	9:59am
SUB TEST	.00	10:00am
AIR BLK	.00	10:01am
SUB TEST	.00	10:02am
AIR BLK	.00	10:03am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY KNIGHTDALE PS 910

Serial Number: 008838 Test Record Number: 1742
Test Date: 08/27/2018 Test Time: 10:04am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:04am
FLO	Pass	10:04am
FC	Pass	10:04am

Temperature Tests

Test	Status	Time
FC1	Pass	10:04am
SRC	Pass	10:04am
DET	Pass	10:04am
BAR	Pass	10:04am
BT	Pass	10:04am

Blank Tests

Test	Status	Time
AIR	Pass	10:05am

Printer Tests

Test	Status	Time
PRNT	Pass	10:05am

CRC Tests

Test	Status	Time
COMP	Pass	10:05am
CAL	Pass	10:05am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Wake Instrument Location Bat mobile Unit 8

Instrument Serial No. 008615 Garner PD

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 30 day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Donna B. Skinner
Signature of Certifying Official

444
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAKE COUNTY BAT MOBILE UNIT 8 910

Serial Number: 008615
Test Date: 08/30/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Female
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: SKINNER, TONYA B
Permit Number: 13651E
Effective:
08/01/2017-08/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG716201
Exp Date: 06/11/2019

Test	g/210L	Time
DIAG	Pass	11:01pm
AIR BLK	.00	11:02pm
ACCY CHK	.07	11:02pm
AIR BLK	.00	11:03pm
SUB TEST	.00	11:04pm
AIR BLK	.00	11:05pm
SUB TEST	.00	11:06pm
AIR BLK	.00	11:07pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY BAT MOBILE UNIT 8 910

Serial Number: 008615 Test Record Number: 5566
Test Date: 08/30/2018 Test Time: 11:10pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:10pm
FLO	Pass	11:10pm
FC	Pass	11:10pm

Temperature Tests

Test	Status	Time
FC1	Pass	11:10pm
SRC	Pass	11:10pm
DET	Pass	11:10pm
BAR	Pass	11:10pm
BT	Pass	11:10pm

Blank Tests

Test	Status	Time
AIR	Pass	11:11pm


Printer Tests

Test	Status	Time
PRNT	Pass	11:11pm

CRC Tests

Test	Status	Time
COMP	Pass	11:11pm
CAL	Pass	11:11pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Wake Instrument Location Bot Mosik Unit 8
Instrument Serial No 008929 Garner PD

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 30 day of August, 20 18 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Donya B Skinnin
Signature of Certifying Official

644
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAKE COUNTY BAT MOBILE UNIT 8 910

Serial Number: 008929
Test Date: 08/30/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Female

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: SKINNER, TONYA B

Permit Number: 13651E

Effective:

08/01/2017-08/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG814901


Exp Date: 05/29/2020

Test	g/210L	Time
DIAG	Pass	11:04pm
AIR BLK	.00	11:05pm
ACCY CHK	.08	11:06pm
AIR BLK	.00	11:07pm
SUB TEST	.00	11:08pm
AIR BLK	.00	11:09pm
SUB TEST	.00	11:10pm
AIR BLK	.00	11:11pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY BAT MOBILE UNIT 8 910

Serial Number: 008929 Test Record Number: 1014
Test Date: 08/30/2018 Test Time: 11:14pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:15pm
FLO	Pass	11:15pm
FC	Pass	11:15pm

Temperature Tests

Test	Status	Time
FC1	Pass	11:15pm
SRC	Pass	11:15pm
DET	Pass	11:15pm
BAR	Pass	11:15pm
BT	Pass	11:15pm

Blank Tests

Test	Status	Time
AIR	Pass	11:16pm


Printer Tests

Test	Status	Time
PRNT	Pass	11:16pm

CRC Tests

Test	Status	Time
COMP	Pass	11:16pm
CAL	Pass	11:16pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Wayne Instrument Location Wayne Co. Detention Ctr.
Instrument Serial No. 008847 207E, CHESTNUT ST., GOLDSBORO, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 6th day of AUGUST, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Lincoln Reese
Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAYNE COUNTY WAYNE CO DETENTION 950

Serial Number: 008847
Test Date: 08/06/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: KEESLER, LINDA A
Permit Number: 11646
Effective:
08/01/2017-08/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG710701
Exp Date: 04/17/2019


Test	g/210L	Time
DIAG	Pass	3:35pm
AIR BLK	.00	3:36pm
ACCY CHK	.07	3:37pm
AIR BLK	.00	3:38pm
SUB TEST	.00	3:39pm
AIR BLK	.00	3:40pm
SUB TEST	.00	3:41pm
AIR BLK	.00	3:42pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

WAYNE COUNTY WAYNE CO DETENTION 950

Serial Number: 008847 Test Record Number: 643
Test Date: 08/06/2018 Test Time: 3:43pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:44pm
FLO	Pass	3:44pm
FC	Pass	3:44pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:44pm
SRC	Pass	3:44pm
DET	Pass	3:44pm
BAR	Pass	3:44pm
BT	Pass	3:44pm

Blank Tests

Test	Status	Time
AIR	Pass	3:45pm


Printer Tests

Test	Status	Time
PRNT	Pass	3:45pm

CRC Tests

Test	Status	Time
COMP	Pass	3:45pm
CAL	Pass	3:45pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Wayne Instrument Location Wayne Co. Detention CTR,
Instrument Serial No. 008671 207 E. CHESTNUT ST., Goldsboro, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 20th day of AUGUST, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAYNE COUNTY WAYNE CO DETENTION 950

Serial Number: 008671
Test Date: 08/20/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: KEESLER, LINDA A
Permit Number: 11646
Effective:
08/01/2017-08/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG710701
Exp Date: 04/17/2019


Test	g/210L	Time
DIAG	Pass	12:13pm
AIR BLK	.00	12:14pm
ACCY CHK	.07	12:15pm
AIR BLK	.00	12:16pm
SUB TEST	.00	12:17pm
AIR BLK	.00	12:18pm
SUB TEST	.00	12:19pm
AIR BLK	.00	12:20pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

WAYNE COUNTY WAYNE CO DETENTION 950

Serial Number: 008671 Test Record Number: 4630
Test Date: 08/20/2018 Test Time: 12:21pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:22pm
FLO	Pass	12:22pm
FC	Pass	12:22pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:22pm
SRC	Pass	12:22pm
DET	Pass	12:22pm
BAR	Pass	12:22pm
BT	Pass	12:22pm

Blank Tests

Test	Status	Time
AIR	Pass	12:22pm

Printer Tests

Test	Status	Time
PRNT	Pass	12:22pm

CRC Tests

Test	Status	Time
COMP	Pass	12:23pm
CAL	Pass	12:23pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Wayne Instrument Location Wayne Co. Retention CTR.

Instrument Serial No. 008649 207 E. CHESTNUT ST., GOLDSBORO, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 20th day of AUGUST, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Linda K. Keene
Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAYNE COUNTY WAYNE CO DETENTION 950

Serial Number: 008649
Test Date: 08/20/2018

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: KEESLER, LINDA A

Permit Number: 11646

Effective:

08/01/2017-08/01/2019

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG710701

Exp Date: 04/17/2019

Test	g/210L	Time
DIAG	Pass	12:12pm
AIR BLK	.00	12:13pm
ACCY CHK	.08	12:13pm
AIR BLK	.00	12:14pm
SUB TEST	.00	12:15pm
AIR BLK	.00	12:16pm
SUB TEST	.00	12:17pm
AIR BLK	.00	12:18pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

WAYNE COUNTY WAYNE CO DETENTION 950

Serial Number: 008649 Test Record Number: 3575
Test Date: 08/20/2018 Test Time: 12:20pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:20pm
FLO	Pass	12:20pm
FC	Pass	12:20pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:20pm
SRC	Pass	12:20pm
DET	Pass	12:20pm
BAR	Pass	12:20pm
BT	Pass	12:20pm

Blank Tests

Test	Status	Time
AIR	Pass	12:21pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:21pm

CRC Tests

Test	Status	Time
COMP	Pass	12:21pm
CAL	Pass	12:21pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Wayne Instrument Location Wayne Co. Detention CTR,
Instrument Serial No. 008649 207 E. CHESTNUT ST., GOLDSBORO, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 24th day of AUGUST, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Loke A. Reese
Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAYNE COUNTY WAYNE CO DETENTION 950

Serial Number: 008649
Test Date: 08/24/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: KEESLER, LINDA A
Permit Number: 11646
Effective:
08/01/2017-08/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG710701
Exp Date: 04/17/2019

Test	g/210L	Time
DIAG	Pass	11:19am
AIR BLK	.00	11:20am
ACCY CHK	.08	11:21am
AIR BLK	.00	11:21am
SUB TEST	.00	11:22am
AIR BLK	.00	11:23am
SUB TEST	.00	11:26am
AIR BLK	.00	11:27am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

WAYNE COUNTY WAYNE CO DETENTION 950

Serial Number: 008649 Test Record Number: 3580
Test Date: 08/24/2018 Test Time: 11:28am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:28am
FLO	Pass	11:28am
FC	Pass	11:28am

Temperature Tests

Test	Status	Time
FC1	Pass	11:29am
SRC	Pass	11:29am
DET	Pass	11:29am
BAR	Pass	11:29am
BT	Pass	11:29am

Blank Tests

Test	Status	Time
AIR	Pass	11:29am


Printer Tests

Test	Status	Time
PRNT	Pass	11:29am

CRC Tests

Test	Status	Time
COMP	Pass	11:29am
CAL	Pass	11:29am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II

County Wayne Instrument Location Wayne CO. Detention Ctr.
Instrument Serial No. 008671 207 E. CHESTNUT ST., Goldsboro, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 24th day of AUGUST, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Lucas A. Keene
Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAYNE COUNTY WAYNE CO DETENTION 950

Serial Number: 008671
Test Date: 08/24/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: KEESLER, LINDA A
Permit Number: 11646
Effective:
08/01/2017-08/01/2019

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG710701
Exp Date: 04/17/2019


Test	g/210L	Time
DIAG	Pass	11:18am
AIR BLK	.00	11:19am
ACCY CHK	.07	11:20am
AIR BLK	.00	11:21am
SUB TEST	.00	11:22am
AIR BLK	.00	11:23am
SUB TEST	.00	11:25am
AIR BLK	.00	11:25am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

WAYNE COUNTY WAYNE CO DETENTION 950

Serial Number: 008671 Test Record Number: 4638
Test Date: 08/24/2018 Test Time: 11:28am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:29am
FLO	Pass	11:29am
FC	Pass	11:29am

Temperature Tests

Test	Status	Time
FC1	Pass	11:29am
SRC	Pass	11:29am
DET	Pass	11:29am
BAR	Pass	11:29am
BT	Pass	11:29am

Blank Tests

Test	Status	Time
AIR	Pass	11:30am


Printer Tests

Test	Status	Time
PRNT	Pass	11:30am

CRC Tests

Test	Status	Time
COMP	Pass	11:30am
CAL	Pass	11:30am

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Watauga Instrument Location Boone PD
Instrument Serial No. 008716 Boone, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 1 day of August, 2018 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

649
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WATAUGA COUNTY BOONE P D 940

Serial Number: 008716
Test Date: 08/01/2018

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BURNETTE, ANTHONY J

Permit Number: 11304E

Effective:

05/01/2017-05/01/2019

Officer's Name: NONE,

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG807101

Exp Date: 03/12/2020

Test	g/210L	Time
DIAG	Pass	5:03pm
AIR BLK	.00	5:04pm
ACCY CHK	.08	5:05pm
AIR BLK	.00	5:05pm
SUB TEST	.00	5:06pm
AIR BLK	.00	5:07pm
SUB TEST	.00	5:09pm
AIR BLK	.00	5:09pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

WATAUGA COUNTY BOONE P D 940

Serial Number: 008716 Test Record Number: 2328
Test Date: 08/01/2018 Test Time: 5:10pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	5:10pm
FLO	Pass	5:10pm
FC	Pass	5:10pm

Temperature Tests

Test	Status	Time
FC1	Pass	5:10pm
SRC	Pass	5:10pm
DET	Pass	5:10pm
BAR	Pass	5:10pm
BT	Pass	5:10pm

Blank Tests

Test	Status	Time
AIR	Pass	5:11pm

Printer Tests

Test	Status	Time
PRNT	Pass	5:11pm

CRC Tests

Test	Status	Time
COMP	Pass	5:11pm
CAL	Pass	5:11pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Wilkes Instrument Location Wilkes County Detention
Instrument Serial No. 008865 Wilkesboro, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

657
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WILKES COUNTY WILKES CO DETENTION 960

Serial Number: 008865
Test Date: 08/14/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name:
BENFIELD II, KENNETH R
Permit Number: 22067E
Effective:
06/01/2018-06/01/2020

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG805801
Exp Date: 02/27/2020


Test	g/210L	Time
DIAG	Pass	10:53am
AIR BLK	.00	10:54am
ACCY CHK	.08	10:54am
AIR BLK	.00	10:55am
SUB TEST	.00	10:57am
AIR BLK	.00	10:58am
SUB TEST	.00	10:59am
AIR BLK	.00	11:00am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

WILKES COUNTY WILKES CO DETENTION 960

Serial Number: 008865 Test Record Number: 637
Test Date: 08/14/2018 Test Time: 11:01am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:02am
FLO	Pass	11:02am
FC	Pass	11:02am

Temperature Tests

Test	Status	Time
FC1	Pass	11:02am
SRC	Pass	11:02am
DET	Pass	11:02am
BAR	Pass	11:02am
BT	Pass	11:02am

Blank Tests

Test	Status	Time
AIR	Pass	11:03am


Printer Tests

Test	Status	Time
PRNT	Pass	11:03am

CRC Tests

Test	Status	Time
COMP	Pass	11:03am
CAL	Pass	11:03am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX/EC/IR II**

County Wilkes Instrument Location Wilkes County Detention
Instrument Serial No. 008843 Wilkesboro, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

657
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WILKES COUNTY WILKES CO DETENTION 960

Serial Number: 008843
Test Date: 08/14/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name:
BENFIELD II, KENNETH R
Permit Number: 22067E
Effective:
06/01/2018-06/01/2020

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG805801
Exp Date: 02/27/2020


Test	g/210L	Time
DIAG	Pass	11:05am
AIR BLK	.00	11:06am
ACCY CHK	.08	11:07am
AIR BLK	.00	11:08am
SUB TEST	.00	11:08am
AIR BLK	.00	11:09am
SUB TEST	.00	11:11am
AIR BLK	.00	11:11am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

WILKES COUNTY WILKES CO DETENTION 960

Serial Number: 008843 Test Record Number: 2279
Test Date: 08/14/2018 Test Time: 11:12am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:13am
FLO	Pass	11:13am
FC	Pass	11:13am

Temperature Tests

Test	Status	Time
FC1	Pass	11:13am
SRC	Pass	11:13am
DET	Pass	11:13am
BAR	Pass	11:13am
BT	Pass	11:13am

Blank Tests

Test	Status	Time
AIR	Pass	11:13am


Printer Tests

Test	Status	Time
PRNT	Pass	11:14am

CRC Tests

Test	Status	Time
COMP	Pass	11:14am
CAL	Pass	11:14am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Yadkin Instrument Location Yadkin County Jail
Instrument Serial No. 008944 Yadkinville, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 9 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

657
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

YADKIN COUNTY YADKIN CO JAIL 980

Serial Number: 008944
Test Date: 08/09/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name:
BENFIELD II, KENNETH R
Permit Number: 22067E
Effective:
06/01/2018-06/01/2020

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG702302
Exp Date: 01/23/2019


Test	g/210L	Time
DIAG	Pass	1:07pm
AIR BLK	.00	1:08pm
ACCY CHK	.07	1:08pm
AIR BLK	.00	1:09pm
SUB TEST	.00	1:10pm
AIR BLK	.00	1:11pm
SUB TEST	.00	1:14pm
AIR BLK	.00	1:14pm

Reported AC: 00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

YADKIN COUNTY YADKIN CO JAIL 980

Serial Number: 008944 Test Record Number: 1533
Test Date: 08/09/2018 Test Time: 1:15pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:16pm
FLO	Pass	1:16pm
FC	Pass	1:16pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:16pm
SRC	Pass	1:16pm
DET	Pass	1:16pm
BAR	Pass	1:16pm
BT	Pass	1:16pm

Blank Tests

Test	Status	Time
AIR	Pass	1:17pm


Printer Tests

Test	Status	Time
PRNT	Pass	1:17pm

CRC Tests

Test	Status	Time
COMP	Pass	1:17pm
CAL	Pass	1:17pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Yadkin Instrument Location Yadkin County Jail
Instrument Serial No. 008854 Yadkinville, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 9 day of August, 2018, the foregoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

657
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

YADKIN COUNTY YADKIN CO JAIL 980

Serial Number: 008854
Test Date: 08/09/2018

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name:
BENFIELD II, KENNETH R
Permit Number: 22067E
Effective:
06/01/2018-06/01/2020

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG702302
Exp Date: 01/23/2019


Test	g/210L	Time
DIAG	Pass	1:05pm
AIR BLK	.00	1:06pm
ACCY CHK	.08	1:06pm
AIR BLK	.00	1:07pm
SUB TEST	.00	1:08pm
AIR BLK	.00	1:09pm
SUB TEST	.00	1:11pm
AIR BLK	.00	1:11pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

YADKIN COUNTY YADKIN CO JAIL 980

Serial Number: 008854 Test Record Number: 515
Test Date: 08/09/2018 Test Time: 1:13pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:14pm
FLO	Pass	1:14pm
FC	Pass	1:14pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:14pm
SRC	Pass	1:14pm
DET	Pass	1:14pm
BAR	Pass	1:14pm
BT	Pass	1:14pm

Blank Tests

Test	Status	Time
AIR	Pass	1:15pm


Printer Tests

Test	Status	Time
PRNT	Pass	1:15pm

CRC Tests

Test	Status	Time
COMP	Pass	1:15pm
CAL	Pass	1:15pm

Preventive Maintenance
Status: Pass



Analyst