

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County New Hanover Instrument Location BAT Mobile Unit 6

Instrument Serial No. 008898 Wilmington

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 30 day of OCT, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



K. C. Rhoads

Signature of Certifying Official

601

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Preventive Maintenance

NEW HANOVER COUNTY BAT MOBILE UNIT 6 640

Serial Number: 008898 Test Record Number: 332
Test Date: 10/30/2009 Test Time: 10:50pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:51pm
FLO	Pass	10:51pm
FC	Pass	10:51pm

Temperature Tests

Test	Status	Time
FC1	Pass	10:51pm
SRC	Pass	10:51pm
DET	Pass	10:51pm
BAR	Pass	10:51pm
BT	Pass	10:51pm

Blank Tests

Test	Status	Time
AIR	Pass	10:52pm

Printer Tests

Test	Status	Time
PRNT	Pass	10:52pm

CRC Tests

Test	Status	Time
COMP	Pass	10:52pm
CAL	Pass	10:52pm

Preventive Maintenance
Status: Pass



Analyst

Intox EC/IR-II: Subject Test

NEW HANOVER COUNTY BAT MOBILE UNIT 6
640

Serial Number: 008898
Test Date: 10/30/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: RHODES, KENNETH C
Permit Number: 5329E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG814002
Exp Date: 05/19/2010

Test	g/210L	Time
DIAG	Pass	10:43pm
AIR BLK	.00	10:44pm
ACCY CHK	.07	10:45pm
AIR BLK	.00	10:46pm
SUB TEST	.00	10:46pm
AIR BLK	.00	10:47pm
SUB TEST	.00	10:49pm
AIR BLK	.00	10:50pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County New Hanover Instrument Location BAT Mobile Unit 6
Instrument Serial No. 008939 Wilmington

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 30 day of OCT, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



K. C. [Signature]

Signature of Certifying Official

601

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Preventive Maintenance

NEW HANOVER COUNTY BAT MOBILE UNIT 6 640

Serial Number: 008939 Test Record Number: 305
Test Date: 10/30/2009 Test Time: 11:02pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:03pm
FLO	Pass	11:03pm
FC	Pass	11:03pm

Temperature Tests

Test	Status	Time
FC1	Pass	11:03pm
SRC	Pass	11:03pm
DET	Pass	11:03pm
BAR	Pass	11:03pm
BT	Pass	11:03pm

Blank Tests

Test	Status	Time
AIR	Pass	11:04pm

Printer Tests

Test	Status	Time
PRNT	Pass	11:04pm

CRC Tests

Test	Status	Time
COMP	Pass	11:04pm
CAL	Pass	11:04pm

Preventive Maintenance
Status: Pass



Analyst

Intox EC/IR-II: Subject Test

NEW HANOVER COUNTY BAT MOBILE UNIT 6
640

Serial Number: 008939
Test Date: 10/30/2009

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: RHODES, KENNETH C

Permit Number: 5329E

Effective:

10/01/2009-10/01/2011

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG814101

Exp Date: 05/20/2010

Test	g/210L	Time
DIAG	Pass	10:55pm
AIR BLK	.00	10:56pm
ACCY CHK	.08	10:57pm
AIR BLK	.00	10:58pm
SUB TEST	.00	10:58pm
AIR BLK	.00	10:59pm
SUB TEST	.00	11:00pm
AIR BLK	.00	11:01pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County New Hanover Instrument Location BAT Mobile Unit
Instrument Serial No. 008869 Wilmington

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 30 day of OCT, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature] 601
Signature of Certifying Official Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Preventive Maintenance

NEW HANOVER COUNTY BAT MOBILE UNIT 6 640

Serial Number: 008869 Test Record Number: 205
Test Date: 10/30/2009 Test Time: 11:58pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:58pm
FLO	Pass	11:58pm
FC	Pass	11:58pm

Temperature Tests

Test	Status	Time
FC1	Pass	11:58pm
SRC	Pass	11:58pm
DET	Pass	11:58pm
BAR	Pass	11:58pm
BT	Pass	11:58pm

Blank Tests

Test	Status	Time
AIR	Pass	11:59pm


Printer Tests

Test	Status	Time
PRNT	Pass	11:59pm

CRC Tests

Test	Status	Time
COMP	Pass	11:59pm
CAL	Pass	11:59pm

Preventive Maintenance
Status: Pass



Analyst

Intox EC/IR-II: Subject Test

NEW HANOVER COUNTY BAT MOBILE UNIT 6
640

Serial Number: 008869
Test Date: 10/30/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: RHODES, KENNETH C

Permit Number: 5329E

Effective:

10/01/2009-10/01/2011

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG814002

Exp Date: 05/19/2010

Test	g/210L	Time
DIAG	Pass	11:50pm
AIR BLK	.00	11:51pm
ACCY CHK	.07	11:52pm
AIR BLK	.00	11:53pm
SUB TEST	.00	11:53pm
AIR BLK	.00	11:54pm
SUB TEST	.00	11:56pm
AIR BLK	.00	11:57pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Cabarrus Instrument Location Cabarrus County SD

Instrument Serial No. 008625 30 Corbett Ave SE, Concord
704 - 920 - 3000

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 26th day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Joseph E. Hutchison
Signature of Certifying Official

650
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CABARRUS COUNTY CABARRUS COUNTY SD 120

Serial Number: 008625

Test Date: 10/26/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: HUTCHINSON, JOSEPH E

Permit Number: 19951E

Effective:

10/01/2009-10/01/2011

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG920401

Exp Date: 07/23/2011


Test	g/210L	Time
DIAG	Pass	1:25pm
AIR BLK	.00	1:26pm
ACCY CHK	.08	1:27pm
AIR BLK	.00	1:28pm
SUB TEST	.00	1:28pm
AIR BLK	.00	1:29pm
SUB TEST	.00	1:31pm
AIR BLK	.00	1:32pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR.



Analyst

Intox EC/IR-II: Preventive Maintenance

CABARRUS COUNTY CABARRUS COUNTY SD 120

Serial Number: 008625 Test Record Number: 1567
Test Date: 10/26/2009 Test Time: 1:33pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:34pm
FLO	Pass	1:34pm
FC	Pass	1:34pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:34pm
SRC	Pass	1:34pm
DET	Pass	1:34pm
BAR	Pass	1:34pm
BT	Pass	1:34pm

Blank Tests

Test	Status	Time
AIR	Pass	1:34pm


Printer Tests

Test	Status	Time
PRNT	Pass	1:34pm

CRC Tests

Test	Status	Time
COMP	Pass	1:35pm
CAL	Pass	1:35pm

Preventive Maintenance
Status: Pass


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Gaston Instrument Location Gaston County SD
Instrument Serial No. 008643 425 N. Marietta Street, Gastonia
704-869-6800

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 26th day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Joseph E. Hutchins
Signature of Certifying Official

650
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

GASTON COUNTY GASTON COUNTY SD 350

Serial Number: 008643
Test Date: 10/26/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: HUTCHINSON, JOSEPH E

Permit Number: 19951E

Effective:

10/01/2009-10/01/2011

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG920401

Exp Date: 07/23/2011


Test	g/210L	Time
DIAG	Pass	11:17am
AIR BLK	.00	11:18am
ACCY CHK	.08	11:18am
AIR BLK	.00	11:19am
SUB TEST	.00	11:20am
AIR BLK	.00	11:21am
SUB TEST	.00	11:22am
AIR BLK	.00	11:23am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

GASTON COUNTY GASTON COUNTY SD 350

Serial Number: 008643 Test Record Number: 707
Test Date: 10/26/2009 Test Time: 11:12am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:13am
FLO	Pass	11:13am
FC	Pass	11:13am

Temperature Tests

Test	Status	Time
FC1	Pass	11:13am
SRC	Pass	11:13am
DET	Pass	11:13am
BAR	Pass	11:13am
BT	Pass	11:13am

Blank Tests

Test	Status	Time
AIR	Pass	11:14am


Printer Tests

Test	Status	Time
PRNT	Pass	11:14am

CRC Tests

Test	Status	Time
COMP	Pass	11:14am
CAL	Pass	11:14am

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County HARNETT Instrument Location DUNN Police

Instrument Serial No. 003244 Dept. Dunn, NC.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 26 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Paul T. [Signature]
Signature of Certifying Official

528
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

HARNETT COUNTY DUNN POLICE DEPT. 420

Serial Number: 008644

Test Date: 10/26/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: SIMMONS, PAUL T

Permit Number: 08619E

Effective:

12/01/2007-12/01/2009

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG814002

Exp Date: 05/19/2010

Test	g/210L	Time
DIAG	Pass	12:29pm
AIR BLK	.00	12:29pm
ACCY CHK	.08	12:30pm
AIR BLK	.00	12:31pm
SUB TEST	.00	12:31pm
AIR BLK	.00	12:32pm
SUB TEST	.00	12:34pm
AIR BLK	.00	12:35pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007

Intox EC/IR-II: Preventive Maintenance

HARNETT COUNTY DUNN POLICE DEPT. 420

Serial Number: 008644 Test Record Number: 670
Test Date: 10/26/2009 Test Time: 12:36pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:36pm
FLO	Pass	12:36pm
FC	Pass	12:37pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:37pm
SRC	Pass	12:37pm
DET	Pass	12:37pm
BAR	Pass	12:37pm
BT	Pass	12:37pm

Blank Tests

Test	Status	Time
AIR	Pass	12:37pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:37pm

CRC Tests

Test	Status	Time
COMP	Pass	12:37pm
CAL	Pass	12:37pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County MECKLENBURG Instrument Location BAT MOBILE UNIT 3
Instrument Serial No. 008647 CHARLOTTE, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 30 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. Bams
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MECKLENBURG COUNTY BAT MOBILE UNIT 3
590

Serial Number: 008647
Test Date: 10/30/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R
Permit Number: 15671E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG904903
Exp Date: 02/18/2011

Test	g/210L	Time
DIAG	Pass	11:38pm
AIR BLK	.00	11:39pm
ACCY CHK	.08	11:39pm
AIR BLK	.00	11:40pm
SUB TEST	.00	11:41pm
AIR BLK	.00	11:42pm
SUB TEST	.00	11:43pm
AIR BLK	.00	11:44pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007

Intox EC/IR-II: Preventive Maintenance

MECKLENBURG COUNTY BAT MOBILE UNIT 3 590

Serial Number: 008647 Test Record Number: 644
Test Date: 10/30/2009 Test Time: 11:45pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:45pm
FLO	Pass	11:45pm
FC	Pass	11:45pm

Temperature Tests

Test	Status	Time
FC1	Pass	11:45pm
SRC	Pass	11:45pm
DET	Pass	11:45pm
BAR	Pass	11:45pm
BT	Pass	11:45pm

Blank Tests

Test	Status	Time
AIR	Pass	11:46pm

Printer Tests

Test	Status	Time
PRNT	Pass	11:46pm

CRC Tests

Test	Status	Time
COMP	Pass	11:46pm
CAL	Pass	11:46pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County MECKLENBURG

Instrument Location BATMOBILE UNIT 3


Instrument Serial No. 008616

CHARLOTTE, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 30 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alvin R. Benson
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MECKLENBURG COUNTY BAT MOBILE UNIT 3
590

Serial Number: 008616
Test Date: 10/30/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R
Permit Number: 15671E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG904903
Exp Date: 02/18/2011

Test	g/210L	Time
DIAG	Pass	11:34pm
AIR BLK	.00	11:35pm
ACCY CHK	.08	11:35pm
AIR BLK	.00	11:36pm
SUB TEST	.00	11:36pm
AIR BLK	.00	11:37pm
SUB TEST	.00	11:39pm
AIR BLK	.00	11:40pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

MECKLENBURG COUNTY BAT MOBILE UNIT 3 590

Serial Number: 008616 Test Record Number: 662
Test Date: 10/30/2009 Test Time: 11:41pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:42pm
FLO	Pass	11:42pm
FC	Pass	11:42pm

Temperature Tests

Test	Status	Time
FC1	Pass	11:42pm
SRC	Pass	11:42pm
DET	Pass	11:42pm
BAR	Pass	11:42pm
BT	Pass	11:42pm

Blank Tests

Test	Status	Time
AIR	Pass	11:42pm

Printer Tests

Test	Status	Time
PRNT	Pass	11:42pm

CRC Tests

Test	Status	Time
COMP	Pass	11:43pm
CAL	Pass	11:43pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County MECKLENBURG Instrument Location BAT MOBILE UNIT 3

Instrument Serial No. 008707 CHARLOTTE, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 30 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. Baus

Signature of Certifying Official

648

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MECKLENBURG COUNTY BAT MOBILE UNIT 3
590

Serial Number: 008707
Test Date: 10/30/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R
Permit Number: 15671E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG902001
Exp Date: 01/20/2011

Test	g/210L	Time
DIAG	Pass	11:41pm
AIR BLK	.00	11:42pm
ACCY CHK	.08	11:43pm
AIR BLK	.00	11:43pm
SUB TEST	.00	11:44pm
AIR BLK	.00	11:45pm
SUB TEST	.00	11:47pm
AIR BLK	.00	11:47pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007

Intox EC/IR-II: Preventive Maintenance

MECKLENBURG COUNTY BAT MOBILE UNIT 3 590

Serial Number: 008707 Test Record Number: 457
Test Date: 10/30/2009 Test Time: 11:49pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:50pm
FLO	Pass	11:50pm
FC	Pass	11:50pm

Temperature Tests

Test	Status	Time
FC1	Pass	11:50pm
SRC	Pass	11:50pm
DET	Pass	11:50pm
BAR	Pass	11:50pm
BT	Pass	11:50pm

Blank Tests

Test	Status	Time
AIR	Pass	11:50pm


Printer Tests

Test	Status	Time
PRNT	Pass	11:51pm

CRC Tests

Test	Status	Time
COMP	Pass	11:51pm
CAL	Pass	11:51pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County CABARRUS Instrument Location BAT MOBILE UNIT 3

Instrument Serial No. 008707 CONCORD, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 17 day of OCTOBER, 20 09 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan Rg Burns

Signature of Certifying Official

648

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CABARRUS COUNTY BAT MOBILE UNIT 3 120

Serial Number: 008707

Test Date: 10/17/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R

Permit Number: 15671E

Effective:

10/01/2009-10/01/2011

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG902001


Exp Date: 01/20/2011

Test	g/210L	Time
DIAG	Pass	4:14pm
AIR BLK	.00	4:15pm
ACCY CHK	.08	4:15pm
AIR BLK	.00	4:16pm
SUB TEST	.00	4:17pm
AIR BLK	.00	4:18pm
SUB TEST	.00	4:19pm
AIR BLK	.00	4:20pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

CABARRUS COUNTY BAT MOBILE UNIT 3 120

Serial Number: 008707 Test Record Number: 445
Test Date: 10/17/2009 Test Time: 4:20pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	4:21pm
FLO	Pass	4:21pm
FC	Pass	4:21pm

Temperature Tests

Test	Status	Time
FC1	Pass	4:21pm
SRC	Pass	4:21pm
DET	Pass	4:21pm
BAR	Pass	4:21pm
BT	Pass	4:21pm

Blank Tests

Test	Status	Time
AIR	Pass	4:22pm


Printer Tests

Test	Status	Time
PRNT	Pass	4:22pm

CRC Tests

Test	Status	Time
COMP	Pass	4:22pm
CAL	Pass	4:22pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County CABARRUS Instrument Location BAT MOBILE UNIT 3
Instrument Serial No. 008647 CONCORD, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 17 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan Rg Bann
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CABARRUS COUNTY BAT MOBILE UNIT 3 120

Serial Number: 008647

Test Date: 10/17/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R

Permit Number: 15671E

Effective:

10/01/2009-10/01/2011

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG904903


Exp Date: 02/18/2011

Test	g/210L	Time
DIAG	Pass	3:53pm
AIR BLK	.00	3:54pm
ACCY CHK	.08	3:54pm
AIR BLK	.00	3:55pm
SUB TEST	.00	3:56pm
AIR BLK	.00	3:57pm
SUB TEST	.00	3:58pm
AIR BLK	.00	3:59pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

CABARRUS COUNTY BAT MOBILE UNIT 3 120

Serial Number: 008647 Test Record Number: 632
Test Date: 10/17/2009 Test Time: 4:00pm EDT

System Check: Passed

Baseline Tests

Test	Status	Time
IR	Pass	4:00pm
FLO	Pass	4:00pm
FC	Pass	4:00pm

Temperature Tests

Test	Status	Time
FC1	Pass	4:00pm
SRC	Pass	4:00pm
DET	Pass	4:00pm
BAR	Pass	4:00pm
BT	Pass	4:00pm

Blank Tests

Test	Status	Time
AIR	Pass	4:01pm


Printer Tests

Test	Status	Time
PRNT	Pass	4:01pm

CRC Tests

Test	Status	Time
COMP	Pass	4:01pm
CAL	Pass	4:01pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County CABARRUS Instrument Location BAT MOBILE UNIT 3
Instrument Serial No. 008616 CONCORD, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16 day of OCTOBER, 20 09 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alvin R. B...
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CABARRUS COUNTY BAT MOBILE UNIT 3 120

Serial Number: 008616
Test Date: 10/16/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R
Permit Number: 15671E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG904903
Exp Date: 02/18/2011

Test	g/210L	Time
DIAG	Pass	10:31pm
AIR BLK	.00	10:32pm
ACCY CHK	.08	10:33pm
AIR BLK	.00	10:33pm
SUB TEST	.00	10:34pm
AIR BLK	.00	10:35pm
SUB TEST	.00	10:36pm
AIR BLK	.00	10:37pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

CABARRUS COUNTY BAT MOBILE UNIT 3 120

Serial Number: 008616 Test Record Number: 651
Test Date: 10/16/2009 Test Time: 10:38pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:38pm
FLO	Pass	10:38pm
FC	Pass	10:38pm

Temperature Tests

Test	Status	Time
FC1	Pass	10:38pm
SRC	Pass	10:38pm
DET	Pass	10:38pm
BAR	Pass	10:38pm
BT	Pass	10:38pm

Blank Tests

Test	Status	Time
AIR	Pass	10:39pm


Printer Tests

Test	Status	Time
PRNT	Pass	10:39pm

CRC Tests

Test	Status	Time
COMP	Pass	10:39pm
CAL	Pass	10:39pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II

County RANDOLPH Instrument Location BAT MOBILE UNIT 3
Instrument Serial No. 008707 TRINITY, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 24 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan Rg Bunn
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

RANDOLPH COUNTY BAT MOBILE UNIT 3 750

Serial Number: 008707
Test Date: 10/24/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R

Permit Number: 15671E

Effective:

10/01/2009-10/01/2011

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG902001


Exp Date: 01/20/2011

Test	g/210L	Time
DIAG	Pass	11:35pm
AIR BLK	.00	11:36pm
ACCY CHK	.08	11:36pm
AIR BLK	.00	11:37pm
SUB TEST	.00	11:38pm
AIR BLK	.00	11:39pm
SUB TEST	.00	11:40pm
AIR BLK	.00	11:41pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

RANDOLPH COUNTY BAT MOBILE UNIT 3 750

Serial Number: 008707 Test Record Number: 450
Test Date: 10/24/2009 Test Time: 11:42pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:42pm
FLO	Pass	11:42pm
FC	Pass	11:42pm

Temperature Tests

Test	Status	Time
FC1	Pass	11:42pm
SRC	Pass	11:42pm
DET	Pass	11:42pm
BAR	Pass	11:42pm
BT	Pass	11:42pm

Blank Tests

Test	Status	Time
AIR	Pass	11:43pm


Printer Tests

Test	Status	Time
PRNT	Pass	11:43pm

CRC Tests

Test	Status	Time
COMP	Pass	11:43pm
CAL	Pass	11:43pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County RANDOLPH Instrument Location BAT MOBILE UNIT 3
Instrument Serial No. 008616 TRINITY, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 24 day of OCTOBER, 20 09 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alvin R. Benson
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

RANDOLPH COUNTY BAT MOBILE UNIT 3 750

Serial Number: 008616
Test Date: 10/24/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R
Permit Number: 15671E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG904903
Exp Date: 02/18/2011

Test	g/210L	Time
DIAG	Pass	10:15pm
AIR BLK	.00	10:16pm
ACCY CHK	.08	10:16pm
AIR BLK	.00	10:17pm
SUB TEST	.00	10:18pm
AIR BLK	.00	10:18pm
SUB TEST	.00	10:20pm
AIR BLK	.00	10:21pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

RANDOLPH COUNTY BAT MOBILE UNIT 3 750

Serial Number: 008616 Test Record Number: 656
Test Date: 10/24/2009 Test Time: 10:27pm EDT

System Check: Passed

Baseline Tests

Test	Status	Time
IR	Pass	10:28pm
FLO	Pass	10:28pm
FC	Pass	10:28pm

Temperature Tests

Test	Status	Time
FC1	Pass	10:28pm
SRC	Pass	10:28pm
DET	Pass	10:28pm
BAR	Pass	10:28pm
BT	Pass	10:28pm

Blank Tests

Test	Status	Time
AIR	Pass	10:29pm


Printer Tests

Test	Status	Time
PRNT	Pass	10:29pm

CRC Tests

Test	Status	Time
COMP	Pass	10:29pm
CAL	Pass	10:29pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County RANDOLPH Instrument Location BAT MOBILE UNIT 3
Instrument Serial No. 008647 TRINITY, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 24 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. B...
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

RANDOLPH COUNTY BAT MOBILE UNIT 3 750

Serial Number: 008647
Test Date: 10/24/2009

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R

Permit Number: 15671E

Effective:

10/01/2009-10/01/2011

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG904903

Exp Date: 02/18/2011

Test	g/210L	Time
DIAG	Pass	10:17pm
AIR BLK	.00	10:18pm
ACCY CHK	.08	10:18pm
AIR BLK	.00	10:19pm
SUB TEST	.00	10:19pm
AIR BLK	.00	10:20pm
SUB TEST	.00	10:22pm
AIR BLK	.00	10:23pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

RANDOLPH COUNTY BAT MOBILE UNIT 3 750

Serial Number: 008647 Test Record Number: 636
Test Date: 10/24/2009 Test Time: 10:27pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:28pm
FLO	Pass	10:28pm
FC	Pass	10:28pm

Temperature Tests

Test	Status	Time
FC1	Pass	10:28pm
SRC	Pass	10:28pm
DET	Pass	10:28pm
BAR	Pass	10:28pm
BT	Pass	10:28pm

Blank Tests

Test	Status	Time
AIR	Pass	10:29pm


Printer Tests

Test	Status	Time
PRNT	Pass	10:29pm

CRC Tests

Test	Status	Time
COMP	Pass	10:29pm
CAL	Pass	10:29pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Guilford Instrument Location Greensboro Jail

Instrument Serial No. 008790

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 29 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Kevin Dean
Signature of Certifying Official

642
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

GUILFORD COUNTY GREENSBORO JAIL 400

Serial Number: 008790

Test Date: 10/29/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: DEAN, LARRY K

Permit Number: 11598E

Effective:

10/01/2009-10/01/2011

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG920303

Exp Date: 07/22/2011

Test	g/210L	Time
DIAG	Pass	12:24pm
AIR BLK	.00	12:24pm
ACCY CHK	.08	12:25pm
AIR BLK	.00	12:26pm
SUB TEST	.00	12:26pm
AIR BLK	.00	12:27pm
SUB TEST	.00	12:29pm
AIR BLK	.00	12:30pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR.


Analyst

Intox EC/IR-II: Preventive Maintenance

GUILFORD COUNTY GREENSBORO JAIL 400

Serial Number: 008790 Test Record Number: 1286
Test Date: 10/29/2009 Test Time: 12:30pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:31pm
FLO	Pass	12:31pm
FC	Pass	12:31pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:31pm
SRC	Pass	12:31pm
DET	Pass	12:31pm
BAR	Pass	12:31pm
BT	Pass	12:31pm

Blank Tests

Test	Status	Time
AIR	Pass	12:31pm

Printer Tests

Test	Status	Time
PRNT	Pass	12:31pm

CRC Tests

Test	Status	Time
COMP	Pass	12:32pm
CAL	Pass	12:32pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Guilford Instrument Location Greensboro Jail

Instrument Serial No. 008794

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 29 day of October, 20 09 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

642
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

GUILFORD COUNTY GREENSBORO JAIL 400

Serial Number: 008794
Test Date: 10/29/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: DEAN, LARRY K
Permit Number: 11598E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG904902
Exp Date: 02/18/2011

Test	g/210L	Time
DIAG	Pass	12:52pm
AIR BLK	.00	12:52pm
ACCY CHK	.08	12:53pm
AIR BLK	.00	12:54pm
SUB TEST	.00	12:54pm
AIR BLK	.00	12:55pm
SUB TEST	.00	12:57pm
AIR BLK	.00	12:58pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

GUILFORD COUNTY GREENSBORO JAIL 400

Serial Number: 008794 Test Record Number: 833
Test Date: 10/29/2009 Test Time: 12:58pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:58pm
FLO	Pass	12:58pm
FC	Pass	12:59pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:59pm
SRC	Pass	12:59pm
DET	Pass	12:59pm
BAR	Pass	12:59pm
BT	Pass	12:59pm

Blank Tests

Test	Status	Time
AIR	Pass	12:59pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:59pm

CRC Tests

Test	Status	Time
COMP	Pass	12:59pm
CAL	Pass	12:59pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II


County Wilson Instrument Location BATMOBILE UNIT #5

Instrument Serial No. 008788 Wilson

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 29th day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Steph G. Thomas
Signature of Certifying Official

636
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Preventive Maintenance

WILSON COUNTY BAT MOBILE UNIT 5 970

Serial Number: 008788 Test Record Number: 282
Test Date: 10/29/2009 Test Time: 9:50pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	9:50pm
FLO	Pass	9:50pm
FC	Pass	9:50pm

Temperature Tests

Test	Status	Time
FC1	Pass	9:50pm
SRC	Pass	9:50pm
DET	Pass	9:50pm
BAR	Pass	9:50pm
BT	Pass	9:50pm

Blank Tests

Test	Status	Time
AIR	Pass	9:51pm


Printer Tests

Test	Status	Time
PRNT	Pass	9:51pm

CRC Tests

Test	Status	Time
COMP	Pass	9:51pm
CAL	Pass	9:51pm

Preventive Maintenance
Status: Pass


Analyst

Intox EC/IR-II: Subject Test.

WILSON COUNTY BAT MOBILE UNIT 5 970

Serial Number: 008788
Test Date: 10/29/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: MORGART, STEPHEN G
Permit Number: 09372E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG904903
Exp Date: 02/18/2011

Test	g/210L	Time
DIAG	Pass	9:41pm
AIR BLK	.00	9:42pm
ACCY CHK	.08	9:42pm
AIR BLK	.00	9:43pm
SUB TEST	.00	9:44pm
AIR BLK	.00	9:45pm
SUB TEST	.00	9:47pm
AIR BLK	.00	9:47pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Wilson Instrument Location BAT MOBILE Unit #5
Instrument Serial No. 005698 Wilson

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 29th day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

636
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Preventive Maintenance

WILSON COUNTY BAT MOBILE UNIT 5 970

Serial Number: 008698 Test Record Number: 411
Test Date: 10/29/2009 Test Time: 9:51pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	9:51pm
FLO	Pass	9:51pm
FC	Pass	9:51pm

Temperature Tests

Test	Status	Time
FC1	Pass	9:51pm
SRC	Pass	9:51pm
DET	Pass	9:51pm
BAR	Pass	9:51pm
BT	Pass	9:51pm

Blank Tests

Test	Status	Time
AIR	Pass	9:52pm


Printer Tests

Test	Status	Time
PRNT	Pass	9:52pm

CRC Tests

Test	Status	Time
COMP	Pass	9:52pm
CAL	Pass	9:52pm

Preventive Maintenance
Status: Pass



Analyst

Intox EC/IR-II: Subject Test

WILSON COUNTY BAT MOBILE UNIT 5 970

Serial Number: 008698
Test Date: 10/29/2009

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: MORGART, STEPHEN G

Permit Number: 09372E

Effective:

12/01/2007-12/01/2009

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG920302


Exp Date: 07/22/2011

Test	g/210L	Time
DIAG	Pass	9:42pm
AIR BLK	.00	9:43pm
ACCY CHK	.08	9:44pm
AIR BLK	.00	9:45pm
SUB TEST	.00	9:45pm
AIR BLK	.00	9:46pm
SUB TEST	.00	9:48pm
AIR BLK	.00	9:48pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County WAYNE Instrument Location BAT MOBILE UNIT #5

Instrument Serial No. 0081000 GOLDSBORO

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 30th day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Steph C. Tillman

Signature of Certifying Official

636

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Preventive Maintenance

WAYNE COUNTY BAT MOBILE UNIT 5 950

Serial Number: 008600 Test Record Number: 549
Test Date: 10/30/2009 Test Time: 11:43pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:43pm
FLO	Pass	11:43pm
FC	Pass	11:43pm

Temperature Tests

Test	Status	Time
FC1	Pass	11:43pm
SRC	Pass	11:43pm
DET	Pass	11:43pm
BAR	Pass	11:43pm
BT	Pass	11:43pm

Blank Tests

Test	Status	Time
AIR	Pass	11:44pm


Printer Tests

Test	Status	Time
PRNT	Pass	11:44pm

CRC Tests

Test	Status	Time
COMP	Pass	11:44pm
CAL	Pass	11:44pm

Preventive Maintenance
Status: Pass



Analyst

Intox EC/IR-II: Subject Test

WAYNE COUNTY BAT MOBILE UNIT 5 950

Serial Number: 008600
Test Date: 10/30/2009

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: MORGART, STEPHEN G

Permit Number: 09372E

Effective:

12/01/2007-12/01/2009

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG920302

Exp Date: 07/22/2011


Test	g/210L	Time
DIAG	Pass	11:32pm
AIR BLK	.00	11:33pm
ACCY CHK	.08	11:33pm
AIR BLK	.00	11:34pm
SUB TEST	.00	11:35pm
AIR BLK	.00	11:36pm
SUB TEST	.00	11:37pm
AIR BLK	.00	11:38pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II

County WAYNE Instrument Location DET MOBILE UNIT #5
Instrument Serial No. 005698 GLDS BORD

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 30th day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

636
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Preventive Maintenance

WAYNE COUNTY BAT MOBILE UNIT 5 950

Serial Number: 008698 Test Record Number: 414
Test Date: 10/30/2009 Test Time: 11:29pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:30pm
FLO	Pass	11:30pm
FC	Pass	11:30pm

Temperature Tests

Test	Status	Time
FC1	Pass	11:30pm
SRC	Pass	11:30pm
DET	Pass	11:30pm
BAR	Pass	11:30pm
BT	Pass	11:30pm

Blank Tests

Test	Status	Time
AIR	Pass	11:31pm


Printer Tests

Test	Status	Time
PRNT	Pass	11:31pm

CRC Tests

Test	Status	Time
COMP	Pass	11:31pm
CAL	Pass	11:31pm

Preventive Maintenance
Status: Pass



Analyst

Intox EC/IR-II: Subject Test

WAYNE COUNTY BAT MOBILE UNIT 5 950

Serial Number: 008698
Test Date: 10/30/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: MORGART, STEPHEN G
Permit Number: 09372E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG920302
Exp Date: 07/22/2011

Test	g/210L	Time
DIAG	Pass	11:13pm
AIR BLK	.00	11:14pm
ACCY CHK	.08	11:15pm
AIR BLK	.00	11:15pm
SUB TEST	.00	11:16pm
AIR BLK	.00	11:17pm
SUB TEST	.00	11:19pm
AIR BLK	.00	11:19pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County WALNUT

Instrument Location But Mobile Unit #5


Instrument Serial No. 005788

GOLDSPRING

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 30TH day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Steph G. Thomas
Signature of Certifying Official

656
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Preventive Maintenance

WAYNE COUNTY BAT MOBILE UNIT 5 950

Serial Number: 008788 Test Record Number: 286
Test Date: 10/30/2009 Test Time: 11:22pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:22pm
FLO	Pass	11:22pm
FC	Pass	11:22pm

Temperature Tests

Test	Status	Time
FC1	Pass	11:22pm
SRC	Pass	11:22pm
DET	Pass	11:22pm
BAR	Pass	11:22pm
BT	Pass	11:22pm

Blank Tests

Test	Status	Time
AIR	Pass	11:23pm


Printer Tests

Test	Status	Time
PRNT	Pass	11:23pm

CRC Tests

Test	Status	Time
COMP	Pass	11:23pm
CAL	Pass	11:23pm

Preventive Maintenance
Status: Pass



Analyst

Intox EC/IR-II: Subject Test

WAYNE COUNTY BAT MOBILE UNIT 5 950

Serial Number: 008788

Test Date: 10/30/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: MORGART, STEPHEN G

Permit Number: 09372E

Effective:

12/01/2007-12/01/2009

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG904903

Exp Date: 02/18/2011


Test	g/210L	Time
DIAG	Pass	11:12pm
AIR BLK	.00	11:13pm
ACCY CHK	.08	11:13pm
AIR BLK	.00	11:14pm
SUB TEST	.00	11:15pm
AIR BLK	.00	11:16pm
SUB TEST	.00	11:17pm
AIR BLK	.00	11:18pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Pitt Instrument Location BAT Mobile Unit #5

Instrument Serial No. 208788 Greenville

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 31st day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Steph B. Thomas
Signature of Certifying Official

636
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Preventive Maintenance

PITT COUNTY BAT MOBILE UNIT 5 730

Serial Number: 008788 Test Record Number: 292
Test Date: 10/31/2009 Test Time: 10:11pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:12pm
FLO	Pass	10:12pm
FC	Pass	10:12pm

Temperature Tests

Test	Status	Time
FC1	Pass	10:12pm
SRC	Pass	10:12pm
DET	Pass	10:12pm
BAR	Pass	10:12pm
BT	Pass	10:12pm

Blank Tests

Test	Status	Time
AIR	Pass	10:13pm

Printer Tests

Test	Status	Time
PRNT	Pass	10:13pm

CRC Tests

Test	Status	Time
COMP	Pass	10:13pm
CAL	Pass	10:13pm

Preventive Maintenance
Status: Pass



Analyst

Intox EC/IR-II: Subject Test

PITT COUNTY BAT MOBILE UNIT 5 730

Serial Number: 008788
Test Date: 10/31/2009

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: MORGART, STEPHEN G

Permit Number: 09372E

Effective:

12/01/2007-12/01/2009

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG904903

Exp Date: 02/18/2011

Test	g/210L	Time
DIAG	Pass	9:57pm
AIR BLK	.00	9:58pm
ACCY CHK	.08	9:58pm
AIR BLK	.00	9:59pm
SUB TEST	.00	10:00pm
AIR BLK	.00	10:01pm
SUB TEST	.00	10:02pm
AIR BLK	.00	10:03pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Pitt Instrument Location BAT Mobile Unit

Instrument Serial No. 008698 Greenville

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 31st day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Stephen C. Thompson
Signature of Certifying Official

6236
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Preventive Maintenance

PITT COUNTY BAT MOBILE UNIT 5 730

Serial Number: 008698 Test Record Number: 417
Test Date: 10/31/2009 Test Time: 10:13pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:13pm
FLO	Pass	10:13pm
FC	Pass	10:14pm

Temperature Tests

Test	Status	Time
FC1	Pass	10:14pm
SRC	Pass	10:14pm
DET	Pass	10:14pm
BAR	Pass	10:14pm
BT	Pass	10:14pm

Blank Tests

Test	Status	Time
AIR	Pass	10:14pm


Printer Tests

Test	Status	Time
PRNT	Pass	10:14pm

CRC Tests

Test	Status	Time
COMP	Pass	10:15pm
CAL	Pass	10:15pm

Preventive Maintenance
Status: Pass


Analyst

Intox EC/IR-II: Subject Test

PITT COUNTY BAT MOBILE UNIT 5 730

Serial Number: 008698
Test Date: 10/31/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: MORGART, STEPHEN G
Permit Number: 09372E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG920302
Exp Date: 07/22/2011


Test	g/210L	Time
DIAG	Pass	9:59pm
AIR BLK	.00	10:00pm
ACCY CHK	.08	10:01pm
AIR BLK	.00	10:02pm
SUB TEST	.00	10:02pm
AIR BLK	.00	10:03pm
SUB TEST	.00	10:06pm
AIR BLK	.00	10:07pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Pitt Instrument Location BAT Mobile Unit #5

Instrument Serial No. 008600 Greenville

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 31st day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Steph G. Thompson
Signature of Certifying Official

636
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Preventive Maintenance

PITT COUNTY BAT MOBILE UNIT 5 730

Serial Number: 008600 Test Record Number: 551
Test Date: 10/31/2009 Test Time: 10:28pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:29pm
FLO	Pass	10:29pm
FC	Pass	10:29pm

Temperature Tests

Test	Status	Time
FC1	Pass	10:29pm
SRC	Pass	10:29pm
DET	Pass	10:29pm
BAR	Pass	10:29pm
BT	Pass	10:29pm

Blank Tests

Test	Status	Time
AIR	Pass	10:30pm


Printer Tests

Test	Status	Time
PRNT	Pass	10:30pm

CRC Tests

Test	Status	Time
COMP	Pass	10:30pm
CAL	Pass	10:30pm

Preventive Maintenance
Status: Pass



Analyst

Intox EC/IR-II: Subject Test

PITT COUNTY BAT MOBILE UNIT 5 730

Serial Number: 008600
Test Date: 10/31/2009

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: MORGART, STEPHEN G

Permit Number: 09372E

Effective:

12/01/2007-12/01/2009

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG920302

Exp Date: 07/22/2011


Test	g/210L	Time
DIAG	Pass	10:21pm
AIR BLK	.00	10:22pm
ACCY CHK	.08	10:22pm
AIR BLK	.00	10:23pm
SUB TEST	.00	10:24pm
AIR BLK	.00	10:25pm
SUB TEST	.00	10:26pm
AIR BLK	.00	10:27pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Johnston Instrument Location Benson,

Instrument Serial No. 008885 Police Dept, Benson, NC.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 20 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Paul T. Summers
Signature of Certifying Official

578
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

JOHNSTON COUNTY BENSON POLICE DEPT.
500

Serial Number: 008885
Test Date: 10/20/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: SIMMONS, PAUL T
Permit Number: 08619E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG814002
Exp Date: 05/19/2010


Test	g/210L	Time
DIAG	Pass	2:07pm
AIR BLK	.00	2:08pm
ACCY CHK	.07	2:08pm
AIR BLK	.00	2:09pm
SUB TEST	.00	2:09pm
AIR BLK	.00	2:10pm
SUB TEST	.00	2:12pm
AIR BLK	.00	2:13pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

JOHNSTON COUNTY BENSON POLICE DEPT. 500

Serial Number: 008885 Test Record Number: 123
Test Date: 10/20/2009 Test Time: 2:16pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:16pm
FLO	Pass	2:16pm
FC	Pass	2:16pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:16pm
SRC	Pass	2:16pm
DET	Pass	2:16pm
BAR	Pass	2:16pm
BT	Pass	2:16pm

Blank Tests

Test	Status	Time
AIR	Pass	2:17pm

Printer Tests

Test	Status	Time
PRNT	Pass	2:17pm

CRC Tests

Test	Status	Time
COMP	Pass	2:17pm
CAL	Pass	2:17pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County SCOTLAND Instrument Location SCOTLAND
Instrument Serial No. 008861 County Sheriff's Dept

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 19 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Paul T. Gumm
Signature of Certifying Official

578
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

SCOTLAND COUNTY SHERIFFS DEPT. 820

Serial Number: 008861
Test Date: 10/19/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: SIMMONS, PAUL T
Permit Number: 08619E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG904903
Exp Date: 02/18/2011

Test	g/210L	Time
DIAG	Pass	2:33pm
AIR BLK	.00	2:34pm
ACCY CHK	.08	2:35pm
AIR BLK	.00	2:36pm
SUB TEST	.00	2:36pm
AIR BLK	.00	2:37pm
SUB TEST	.00	2:39pm
AIR BLK	.00	2:40pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

SCOTLAND COUNTY SHERIFFS DEPT. 820

Serial Number: 008861 Test Record Number: 195

Test Date: 10/19/2009 Test Time: 2:44pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:44pm
FLO	Pass	2:44pm
FC	Pass	2:45pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:45pm
SRC	Pass	2:45pm
DET	Pass	2:45pm
BAR	Pass	2:45pm
BT	Pass	2:45pm

Blank Tests

Test	Status	Time
AIR	Pass	2:45pm

Printer Tests


Test	Status	Time
PRNT	Pass	2:45pm

CRC Tests

Test	Status	Time
COMP	Pass	2:46pm
CAL	Pass	2:46pm

Preventive Maintenance

Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Cumberland Instrument Location FORT BRAGG,
Instrument Serial No. 208903 PMO

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 20 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Paul T. [Signature]

Signature of Certifying Official

578

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CUMBERLAND COUNTY FORT BRAGG LEC. 250

Serial Number: 008903
Test Date: 10/20/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: SIMMONS, PAUL T
Permit Number: 08619E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG809301
Exp Date: 04/02/2010

Test	g/210L	Time
DIAG	Pass	12:44pm
AIR BLK	.00	12:45pm
ACCY CHK	.07	12:45pm
AIR BLK	.00	12:46pm
SUB TEST	.00	12:47pm
AIR BLK	.00	12:48pm
SUB TEST	.00	12:50pm
AIR BLK	.00	12:51pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

CUMBERLAND COUNTY FORT BRAGG LEC. 250

Serial Number: 008903 Test Record Number: 232
Test Date: 10/20/2009 Test Time: 12:51pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:52pm
FLO	Pass	12:52pm
FC	Pass	12:52pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:52pm
SRC	Pass	12:52pm
DET	Pass	12:52pm
BAR	Pass	12:52pm
BT	Pass	12:52pm

Blank Tests

Test	Status	Time
AIR	Pass	12:53pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:53pm

CRC Tests

Test	Status	Time
COMP	Pass	12:53pm
CAL	Pass	12:53pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County CUMBERLAND Instrument Location FORT BRAGG,
Instrument Serial No. 008908 PMO.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 20 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Paul T. Jamison
Signature of Certifying Official

578
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CUMBERLAND COUNTY FORT BRAGG, LEC. 250

Serial Number: 008908
Test Date: 10/20/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: SIMMONS, PAUL T

Permit Number: 08619E

Effective:

12/01/2007-12/01/2009

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG901901


Exp Date: 01/19/2011

Test	g/210L	Time
DIAG	Pass	12:35pm
AIR BLK	.00	12:36pm
ACCY CHK	.08	12:36pm
AIR BLK	.00	12:37pm
SUB TEST	.00	12:38pm
AIR BLK	.00	12:39pm
SUB TEST	.00	12:41pm
AIR BLK	.00	12:42pm

Reported AC: ~~.00~~ g/210L


Signature of Chemical Analyst

Court CVR


Analyst

This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007

Intox EC/IR-II: Preventive Maintenance

CUMBERLAND COUNTY FORT BRAGG, LEC. 250

Serial Number: 008908 Test Record Number: 522
Test Date: 10/20/2009 Test Time: 12:45pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:45pm
FLO	Pass	12:45pm
FC	Pass	12:45pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:45pm
SRC	Pass	12:45pm
DET	Pass	12:45pm
BAR	Pass	12:45pm
BT	Pass	12:45pm

Blank Tests

Test	Status	Time
AIR	Pass	12:46pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:46pm

CRC Tests

Test	Status	Time
COMP	Pass	12:46pm
CAL	Pass	12:46pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Wilkes Instrument Location North Wilkesboro P.D.

Instrument Serial No. 008862

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 20 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

632
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WILKES COUNTY NORTH WILKESBORO PD 960

Serial Number: 008862
Test Date: 10/20/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: WEAVER, GEORGE A
Permit Number: 09442E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG816303
Exp Date: 06/11/2010

Test	g/210L	Time
DIAG	Pass	12:23pm
AIR BLK	.00	12:24pm
ACCY CHK	.08	12:24pm
AIR BLK	.00	12:25pm
SUB TEST	.00	12:26pm
AIR BLK	.00	12:27pm
SUB TEST	.00	12:28pm
AIR BLK	.00	12:29pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

WILKES COUNTY NORTH WILKESBORO PD 960

Serial Number: 008862 Test Record Number: 123
Test Date: 10/20/2009 Test Time: 12:31pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:31pm
FLO	Pass	12:31pm
FC	Pass	12:31pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:31pm
SRC	Pass	12:31pm
DET	Pass	12:31pm
BAR	Pass	12:31pm
BT	Pass	12:31pm

Blank Tests

Test	Status	Time
AIR	Pass	12:32pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:32pm

CRC Tests

Test	Status	Time
COMP	Pass	12:32pm
CAL	Pass	12:32pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Stokes Instrument Location Stokes Co Jail

Instrument Serial No. 008596

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 21 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

632
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

STOKES COUNTY STOKES COUNTY JAIL 840

Serial Number: 008596
Test Date: 10/21/2009

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: WEAVER, GEORGE A.

Permit Number: 09442E

Effective:

10/01/2009-10/01/2011

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG916701

Exp Date: 06/16/2011

Test	g/210L	Time
DIAG	Pass	11:47am
AIR BLK	.00	11:48am
ACCY CHK	.08	11:49am
AIR BLK	.00	11:50am
SUB TEST	.00	11:50am
AIR BLK	.00	11:51am
SUB TEST	.00	11:53am
AIR BLK	.00	11:54am

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR.


Analyst

This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007

Intox EC/IR-II: Preventive Maintenance

STOKES COUNTY STOKES COUNTY JAIL 840

Serial Number: 008596 Test Record Number: 373
Test Date: 10/21/2009 Test Time: 11:54am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:55am
FLO	Pass	11:55am
FC	Pass	11:55am

Temperature Tests

Test	Status	Time
FC1	Pass	11:55am
SRC	Pass	11:55am
DET	Pass	11:55am
BAR	Pass	11:55am
BT	Pass	11:55am

Blank Tests

Test	Status	Time
AIR	Pass	11:56am


Printer Tests

Test	Status	Time
PRNT	Pass	11:56am

CRC Tests

Test	Status	Time
COMP	Pass	11:56am
CAL	Pass	11:56am

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Stokes Instrument Location King P D

Instrument Serial No. 008610

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 21 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

632
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

STOKES COUNTY KING PD 840

Serial Number: 008610
Test Date: 10/21/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: *WEAVER, GEORGE A*
Permit Number: 09442E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG902001
Exp Date: 01/20/2011

Test	g/210L	Time
DIAG	Pass	12:36pm
AIR BLK	.00	12:37pm
ACCY CHK	.08	12:37pm
AIR BLK	.00	12:38pm
SUB TEST	.00	12:39pm
AIR BLK	.00	12:40pm
SUB TEST	.00	12:41pm
AIR BLK	.00	12:42pm

Reported AC: 00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007

Intox EC/IR-II: Preventive Maintenance

STOKES COUNTY KING PD 840

Serial Number: 008610 Test Record Number: 629
Test Date: 10/21/2009 Test Time: 12:43pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:43pm
FLO	Pass	12:43pm
FC	Pass	12:44pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:44pm
SRC	Pass	12:44pm
DET	Pass	12:44pm
BAR	Pass	12:44pm
BT	Pass	12:44pm

Blank Tests

Test	Status	Time
AIR	Pass	12:44pm

Printer Tests

Test	Status	Time
PRNT	Pass	12:44pm

CRC Tests

Test	Status	Time
COMP	Pass	12:45pm
CAL	Pass	12:45pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Yadkin Instrument Location Yadkin Co Jail

Instrument Serial No. 008944

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 22 day of October, 2007 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

632
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

YADKIN COUNTY YADKIN CO JAIL 980

Serial Number: 008944
Test Date: 10/22/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: WEAVER, GEORGE A
Permit Number: 09442E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG902901
Exp Date: 01/29/2011

Test	g/210L	Time
DIAG	Pass	10:09am
AIR BLK	.00	10:10am
ACCY CHK	.08	10:11am
AIR BLK	.00	10:12am
SUB TEST	.00	10:12am
AIR BLK	.00	10:13am
SUB TEST	.00	10:15am
AIR BLK	.00	10:16am

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007

Intox EC/IR-II: Preventive Maintenance

YADKIN COUNTY YADKIN CO JAIL 980

Serial Number: 008944 Test Record Number: 359
Test Date: 10/22/2009 Test Time: 10:16am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:16am
FLO	Pass	10:16am
FC	Pass	10:17am

Temperature Tests

Test	Status	Time
FC1	Pass	10:17am
SRC	Pass	10:17am
DET	Pass	10:17am
BAR	Pass	10:17am
BT	Pass	10:17am

Blank Tests

Test	Status	Time
AIR	Pass	10:17am


Printer Tests

Test	Status	Time
PRNT	Pass	10:17am

CRC Tests

Test	Status	Time
COMP	Pass	10:18am
CAL	Pass	10:18am

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Yadkin Instrument Location Yadkinville P. D.

Instrument Serial No. 008925

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 22 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

632
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

YADKIN COUNTY YADKINVILLE PD 980

Serial Number: 008925
Test Date: 10/22/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: WEAVER, GEORGE A
Permit Number: 09442E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG902901
Exp Date: 01/29/2011

Test	g/210L	Time
DIAG	Pass	10:33am
AIR BLK	.00	10:34am
ACCY CHK	.08	10:35am
AIR BLK	.00	10:36am
SUB TEST	.00	10:36am
AIR BLK	.00	10:37am
SUB TEST	.00	10:39am
AIR BLK	.00	10:40am

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

YADKIN COUNTY YADKINVILLE PD 980

Serial Number: 008925 Test Record Number: 145
Test Date: 10/22/2009 Test Time: 10:40am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:41am
FLO	Pass	10:41am
FC	Pass	10:41am

Temperature Tests

Test	Status	Time
FC1	Pass	10:41am
SRC	Pass	10:41am
DET	Pass	10:41am
BAR	Pass	10:41am
BT	Pass	10:41am

Blank Tests

Test	Status	Time
AIR	Pass	10:42am


Printer Tests

Test	Status	Time
PRNT	Pass	10:42am

CRC Tests

Test	Status	Time
COMP	Pass	10:42am
CAL	Pass	10:42am

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Forsyth Instrument Location Kennettville R.D.

Instrument Serial No. 009650

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 28 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

682
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

FORSYTH COUNTY KERNERSVILLE PD 330

Serial Number: 008650

Test Date: 10/28/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: WEAVER, GEORGE A

Permit Number: 09442E

Effective:

10/01/2009-10/01/2011

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG902901

Exp Date: 01/29/2011

Test	g/210L	Time
DIAG	Pass	11:10am
AIR BLK	.00	11:11am
ACCY CHK	.07	11:12am
AIR BLK	.00	11:13am
SUB TEST	.00	11:13am
AIR BLK	.00	11:14am
SUB TEST	.00	11:16am
AIR BLK	.00	11:17am

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

FORSYTH COUNTY KERNERSVILLE PD 330
Serial Number: 008650 Test Record Number: 448
Test Date: 10/28/2009 Test Time: 11:18am EDT
System Check: Passed

Baseline Tests

Test	Status	Time
IR	Pass	11:18am
FLO	Pass	11:18am
FC	Pass	11:18am

Temperature Tests

Test	Status	Time
FC1	Pass	11:18am
SRC	Pass	11:18am
DET	Pass	11:18am
BAR	Pass	11:18am
BT	Pass	11:18am

Blank Tests

Test	Status	Time
AIR	Pass	11:19am

Printer Tests

Test	Status	Time
PRNT	Pass	11:19am

CRC Tests

Test	Status	Time
COMP	Pass	11:19am
CAL	Pass	11:19am

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Forsyth Instrument Location Forsyth Co Detention

Instrument Serial No. 008583

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 28 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

632
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

FORSYTH COUNTY FORSYTH CO DETENTION

330

Serial Number: 008583

Test Date: 10/28/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: WEAVER, GEORGE A

Permit Number: 09442E

Effective:

10/01/2009-10/01/2011

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG916701


Exp Date: 06/11/2011

Test	g/210L	Time
DIAG	Pass	1:39pm
AIR BLK	.00	1:40pm
ACCY CHK	.08	1:41pm
AIR BLK	.00	1:42pm
SUB TEST	.00	1:42pm
AIR BLK	.00	1:43pm
SUB TEST	.00	1:45pm
AIR BLK	.00	1:46pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

FORSYTH COUNTY FORSYTH CO DETENTION 330

Serial Number: 008583 Test Record Number: 1767
Test Date: 10/28/2009 Test Time: 1:47pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:47pm
FLO	Pass	1:47pm
FC	Pass	1:47pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:47pm
SRC	Pass	1:47pm
DET	Pass	1:47pm
BAR	Pass	1:47pm
BT	Pass	1:47pm

Blank Tests

Test	Status	Time
AIR	Pass	1:48pm

Printer Tests

Test	Status	Time
PRNT	Pass	1:48pm

CRC Tests

Test	Status	Time
COMP	Pass	1:48pm
CAL	Pass	1:48pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Forsyth


Instrument Location Forsyth Co Detention

Instrument Serial No. 008660

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 28 day of OCTOBER, 2007 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

632
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

FORSYTH COUNTY FORSYTH CO DETENTION

330

Serial Number: 008660

Test Date: 10/28/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: WEAVER, GEORGE A

Permit Number: 09442E

Effective:

10/01/2009-10/01/2011

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG916701

Exp Date: 06/16/2011

Test	g/210L	Time
DIAG	Pass	1:30pm
AIR BLK	.00	1:31pm
ACCY CHK	.08	1:32pm
AIR BLK	.00	1:33pm
SUB TEST	.00	1:33pm
AIR BLK	.00	1:34pm
SUB TEST	.00	1:36pm
AIR BLK	.00	1:37pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007

Intox EC/IR-II: Preventive Maintenance

FORSYTH COUNTY FORSYTH CO DETENTION 330

Serial Number: 008660 Test Record Number: 916
Test Date: 10/28/2009 Test Time: 1:39pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:39pm
FLO	Pass	1:39pm
FC	Pass	1:39pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:40pm
SRC	Pass	1:40pm
DET	Pass	1:40pm
BAR	Pass	1:40pm
BT	Pass	1:40pm

Blank Tests

Test	Status	Time
AIR	Pass	1:40pm


Printer Tests

Test	Status	Time
PRNT	Pass	1:40pm

CRC Tests

Test	Status	Time
COMP	Pass	1:40pm
CAL	Pass	1:40pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Forsyth Instrument Location Forsyth Co Detention

Instrument Serial No. 008239 Center

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 28 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

632
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

FORSYTH COUNTY FORSYTH CO DETENTION
330

Serial Number: 008659
Test Date: 10/28/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: WEAVER, GEORGE A
Permit Number: 09442E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG902001
Exp Date: 01/20/2011

Test	g/210L	Time
DIAG	Pass	1:23pm
AIR BLK	.00	1:24pm
ACCY CHK	.08	1:25pm
AIR BLK	.00	1:26pm
SUB TEST	.00	1:26pm
AIR BLK	.00	1:27pm
SUB TEST	.00	1:30pm
AIR BLK	.00	1:31pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007

Intox EC/IR-II: Preventive Maintenance

FORSYTH COUNTY FORSYTH CO DETENTION 330

Serial Number: 008659 Test Record Number: 896
Test Date: 10/28/2009 Test Time: 1:32pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:32pm
FLO	Pass	1:32pm
FC	Pass	1:32pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:32pm
SRC	Pass	1:32pm
DET	Pass	1:32pm
BAR	Pass	1:32pm
BT	Pass	1:32pm

Blank Tests

Test	Status	Time
AIR	Pass	1:33pm


Printer Tests

Test	Status	Time
PRNT	Pass	1:33pm

CRC Tests

Test	Status	Time
COMP	Pass	1:33pm
CAL	Pass	1:33pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County SURRY Instrument Location ELKIN P.D.

Instrument Serial No. 008926

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 29 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

632
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

SURRY COUNTY ELKIN PD 850

Serial Number: 008926

Test Date: 10/29/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: WEAVER, GEORGE A

Permit Number: 09442E

Effective:

10/01/2009-10/01/2011

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG902901

Exp Date: 01/29/2011

Test	g/210L	Time
DIAG	Pass	10:34am
AIR BLK	.00	10:35am
ACCY CHK	.08	10:36am
AIR BLK	.00	10:37am
SUB TEST	.00	10:37am
AIR BLK	.00	10:38am
SUB TEST	.00	10:40am
AIR BLK	.00	10:41am

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

SURRY COUNTY ELKIN PD 850

Serial Number: 008926 Test Record Number: 273
Test Date: 10/29/2009 Test Time: 10:42am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:42am
FLO	Pass	10:42am
FC	Pass	10:42am

Temperature Tests

Test	Status	Time
FC1	Pass	10:42am
SRC	Pass	10:42am
DET	Pass	10:42am
BAR	Pass	10:42am
BT	Pass	10:42am

Blank Tests

Test	Status	Time
AIR	Pass	10:43am


Printer Tests

Test	Status	Time
PRNT	Pass	10:43am

CRC Tests

Test	Status	Time
COMP	Pass	10:43am
CAL	Pass	10:43am

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Beaufort Instrument Location Belhaven Police Dept.

Instrument Serial No. 008928 Belhaven, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 29th day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Trish A. Keas
Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

BEAUFORT COUNTY BELHAVEN PD 060

Serial Number: 008928
Test Date: 10/29/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: KEESLER, LINDA A
Permit Number: 11646E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG816302
Exp Date: 06/11/2010

Test	g/210L	Time
DIAG	Pass	1:06pm
AIR BLK	.00	1:07pm
ACCY CHK	.07	1:08pm
AIR BLK	.00	1:08pm
SUB TEST	.00	1:09pm
AIR BLK	.00	1:10pm
SUB TEST	.00	1:11pm
AIR BLK	.00	1:12pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

BEAUFORT COUNTY BELHAVEN PD 060

Serial Number: 008928 Test Record Number: 84
Test Date: 10/29/2009 Test Time: 1:14pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:15pm
FLO	Pass	1:15pm
FC	Pass	1:15pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:15pm
SRC	Pass	1:15pm
DET	Pass	1:15pm
BAR	Pass	1:15pm
BT	Pass	1:15pm

Blank Tests

Test	Status	Time
AIR	Pass	1:15pm

Printer Tests

Test	Status	Time
PRNT	Pass	1:15pm

CRC Tests

Test	Status	Time
COMP	Pass	1:16pm
CAL	Pass	1:16pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Hyde Instrument Location Hyde Co. S.O., DLRAALAKE
Instrument Serial No. 008797 NC 12, DLRAALAKE, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 27th day of OCTOBER, 20 09 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Laura A. Kiser
Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

HYDE COUNTY HYDE CO SO OCRACOKE 470

Serial Number: 008797
Test Date: 10/27/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: KEESLER, LINDA A
Permit Number: 11646E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG910601
Exp Date: 04/16/2011

Test	g/210L	Time
DIAG	Pass	1:33pm
AIR BLK	.00	1:34pm
ACCY CHK	.08	1:35pm
AIR BLK	.00	1:36pm
SUB TEST	.00	1:36pm
AIR BLK	.00	1:37pm
SUB TEST	.00	1:39pm
AIR BLK	.00	1:40pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

HYDE COUNTY HYDE CO SO OCRACOKE 470

Serial Number: 008797 Test Record Number: 172
Test Date: 10/27/2009 Test Time: 1:41pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:42pm
FLO	Pass	1:42pm
FC	Pass	1:42pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:42pm
SRC	Pass	1:42pm
DET	Pass	1:42pm
BAR	Pass	1:42pm
BT	Pass	1:42pm

Blank Tests

Test	Status	Time
AIR	Pass	1:43pm

Printer Tests

Test	Status	Time
PRNT	Pass	1:43pm

CRC Tests

Test	Status	Time
COMP	Pass	1:43pm
CAL	Pass	1:43pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County DARE Instrument Location DARE Co. S.D., HATTERAS

Instrument Serial No. 004407 50346 NC HWY 12, Frisco, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 27th day of OCTOBER, 20 09 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

447
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

DARE COUNTY DARE CO SO HATTERAS 270

Serial Number: 008807

Test Date: 10/27/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: KEESLER, LINDA A

Permit Number: 11646E

Effective:

12/01/2007-12/01/2009

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG910601

Exp Date: 04/16/2011


Test	g/210L	Time
DIAG	Pass	11:22am
AIR BLK	.00	11:23am
ACCY CHK	.07	11:24am
AIR BLK	.00	11:25am
SUB TEST	.00	11:25am
AIR BLK	.00	11:26am
SUB TEST	.00	11:28am
AIR BLK	.00	11:29am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

DARE COUNTY DARE CO SO HATTERAS 270

Serial Number: 008807 Test Record Number: 211
Test Date: 10/27/2009 Test Time: 11:32am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:32am
FLO	Pass	11:32am
FC	Pass	11:32am

Temperature Tests

Test	Status	Time
FC1	Pass	11:32am
SRC	Pass	11:32am
DET	Pass	11:32am
BAR	Pass	11:32am
BT	Pass	11:32am

Blank Tests

Test	Status	Time
AIR	Pass	11:33am


Printer Tests

Test	Status	Time
PRNT	Pass	11:33am

CRC Tests

Test	Status	Time
COMP	Pass	11:33am
CAL	Pass	11:33am

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Edgecombe Instrument Location Edgecombe Co. Magistrates Office
Instrument Serial No. 008463 300 S. ANACONDA RD., TARBORO, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 22nd day of December, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

EDGECOMBE COUNTY EDGECOMBE CO MAGISTR
320

Serial Number: 008663
Test Date: 10/22/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: KEESLER, LINDA
Permit Number: 11646E
Effective:
09/01/2009-09/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG916602
Exp Date: 06/15/2011

Test	g/210L	Time
DIAG	Pass	4:13pm
AIR BLK	.00	4:14pm
ACCY CHK	.08	4:14pm
AIR BLK	.00	4:15pm
SUB TEST	.00	4:16pm
AIR BLK	.00	4:17pm
SUB TEST	.00	4:18pm
AIR BLK	.00	4:19pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

EDGECOMBE COUNTY EDGECOMBE CO MAGISTR 320

Serial Number: 008663 Test Record Number: 1064
Test Date: 10/22/2009 Test Time: 4:20pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	4:20pm
FLO	Pass	4:20pm
FC	Pass	4:20pm

Temperature Tests

Test	Status	Time
FC1	Pass	4:20pm
SRC	Pass	4:20pm
DET	Pass	4:20pm
BAR	Pass	4:20pm
BT	Pass	4:20pm

Blank Tests

Test	Status	Time
AIR	Pass	4:21pm

Printer Tests

Test	Status	Time
PRNT	Pass	4:21pm

CRC Tests

Test	Status	Time
COMP	Pass	4:21pm
CAL	Pass	4:21pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County PASQUOTA Instrument Location PASQUOTA CO. PUBLIC SAFETY BLDG.)
Instrument Serial No. 008941 200 E. COLONIAL AVE.) ELIZABETH CITY, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 19th day of OCTOBER, 2004 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

PASQUOTANK COUNTY PUBLIC SAFETY BLDG
690

Serial Number: 008941
Test Date: 10/19/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: KEESLER, LINDA A
Permit Number: 11646E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG910601
Exp Date: 04/16/2011

Test	g/210L	Time
DIAG	Pass	1:11pm
AIR BLK	.00	1:12pm
ACCY CHK	.08	1:13pm
AIR BLK	.00	1:13pm
SUB TEST	.00	1:14pm
AIR BLK	.00	1:15pm
SUB TEST	.00	1:16pm
AIR BLK	.00	1:17pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

PASQUOTANK COUNTY PUBLIC SAFETY BLDG 690

Serial Number: 008941 Test Record Number: 247
Test Date: 10/19/2009 Test Time: 1:19pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:19pm
FLO	Pass	1:19pm
FC	Pass	1:19pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:20pm
SRC	Pass	1:20pm
DET	Pass	1:20pm
BAR	Pass	1:20pm
BT	Pass	1:20pm

Blank Tests

Test	Status	Time
AIR	Pass	1:20pm

Printer Tests

Test	Status	Time
PRNT	Pass	1:20pm

CRC Tests

Test	Status	Time
COMP	Pass	1:20pm
CAL	Pass	1:20pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County PASQUOTANK Instrument Location PASQUOTANK CO. Public Safety Bldg.
Instrument Serial No. DD4950 200 E. Colonial Ave., Elizabeth City, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 19th day of DECEMBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

PASQUOTANK COUNTY PUBLIC SAFETY BLDG
690

Serial Number: 008950
Test Date: 10/19/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: KEESLER, LINDA A
Permit Number: 11646E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG910601
Exp Date: 04/16/2011

Test	g/210L	Time
DIAG	Pass	1:08pm
AIR BLK	.00	1:09pm
ACCY CHK	.08	1:10pm
AIR BLK	.00	1:10pm
SUB TEST	.00	1:11pm
AIR BLK	.00	1:12pm
SUB TEST	.00	1:14pm
AIR BLK	.00	1:15pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

PASQUOTANK COUNTY PUBLIC SAFETY BLDG 690

Serial Number: 008950 Test Record Number: 307
Test Date: 10/19/2009 Test Time: 1:19pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:19pm
FLO	Pass	1:19pm
FC	Pass	1:20pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:20pm
SRC	Pass	1:20pm
DET	Pass	1:20pm
BAR	Pass	1:20pm
BT	Pass	1:20pm

Blank Tests

Test	Status	Time
AIR	Pass	1:20pm

Printer Tests

Test	Status	Time
PRNT	Pass	1:20pm

CRC Tests

Test	Status	Time
COMP	Pass	1:21pm
CAL	Pass	1:21pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County HERTFORD Instrument Location MURFREESBORO Police Dept.
Instrument Serial No. 004906 115 E. Broad St., Murfreesboro, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16th day of NOVEMBER, 20 09 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

HERTFORD COUNTY MURFREESBORO PD 450

Serial Number: 008906
Test Date: 10/16/2009

Citation Number: M0000000-0
Subject's Name: PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: KEESLER, LINDA A
Permit Number: 11646E
Effective: 12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG809301
Exp Date: 04/02/2010

Test	g/210L	Time
DIAG	Pass	3:06pm
AIR BLK	.00	3:07pm
ACCY CHK	.07	3:08pm
AIR BLK	.00	3:09pm
SUB TEST	.00	3:09pm
AIR BLK	.00	3:10pm
SUB TEST	.00	3:12pm
AIR BLK	.00	3:13pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

HERTFORD COUNTY MURFREESBORO PD 450

Serial Number: 008906 Test Record Number: 168
Test Date: 10/16/2009 Test Time: 3:14pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:14pm
FLO	Pass	3:14pm
FC	Pass	3:14pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:14pm
SRC	Pass	3:14pm
DET	Pass	3:14pm
BAR	Pass	3:14pm
BT	Pass	3:14pm

Blank Tests

Test	Status	Time
AIR	Pass	3:15pm


Printer Tests

Test	Status	Time
PRNT	Pass	3:15pm

CRC Tests

Test	Status	Time
COMP	Pass	3:15pm
CAL	Pass	3:15pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County GATES Instrument Location GATES Co. S.O.

Instrument Serial No. 008484 202 Court St., Grakesville, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16th day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

697
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

GATES COUNTY GATES CO SO 360

Serial Number: 008884

Test Date: 10/16/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: KEESLER, LINDA A

Permit Number: 11646E

Effective:

12/01/2007-12/01/2009

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG807702

Exp Date: 03/17/2010

Test	g/210L	Time
DIAG	Pass	2:14pm
AIR BLK	.00	2:15pm
ACCY CHK	.07	2:15pm
AIR BLK	.00	2:16pm
SUB TEST	.00	2:17pm
AIR BLK	.00	2:17pm
SUB TEST	.00	2:19pm
AIR BLK	.00	2:20pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

This form is used when performing Preventive Maintenance procedures

Forensic Tests for Alcohol Branch

Department of Health and Human Services

Rev. 12/2007

Intox EC/IR-II: Preventive Maintenance

GATES COUNTY GATES CO SO 360

Serial Number: 008884 Test Record Number: 184
Test Date: 10/16/2009 Test Time: 2:22pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:22pm
FLO	Pass	2:22pm
FC	Pass	2:22pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:22pm
SRC	Pass	2:22pm
DET	Pass	2:22pm
BAR	Pass	2:22pm
BT	Pass	2:22pm

Blank Tests

Test	Status	Time
AIR	Pass	2:23pm

Printer Tests

Test	Status	Time
PRNT	Pass	2:23pm

CRC Tests

Test	Status	Time
COMP	Pass	2:23pm
CAL	Pass	2:23pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Hertford Instrument Location Albion Police Dept.
Instrument Serial No. 008848 705 W. MAIN ST., ALBION, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14th day of DECEMBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

HERTFORD COUNTY AHOSKIE PD 450

Serial Number: 008848
Test Date: 10/14/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: KEESLER, LINDA A
Permit Number: 11646E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG809301
Exp Date: 04/02/2010


Test	g/210L	Time
DIAG	Pass	11:14am
AIR BLK	.00	11:15am
ACCY CHK	.08	11:15am
AIR BLK	.00	11:16am
SUB TEST	.00	11:17am
AIR BLK	.00	11:17am
SUB TEST	.00	11:19am
AIR BLK	.00	11:20am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

HERTFORD COUNTY AHOSKIE PD 450

Serial Number: 008848 Test Record Number: 298
Test Date: 10/14/2009 Test Time: 11:23am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:23am
FLO	Pass	11:23am
FC	Pass	11:23am

Temperature Tests

Test	Status	Time
FC1	Pass	11:23am
SRC	Pass	11:23am
DET	Pass	11:23am
BAR	Pass	11:23am
BT	Pass	11:23am

Blank Tests

Test	Status	Time
AIR	Pass	11:24am


Printer Tests

Test	Status	Time
PRNT	Pass	11:24am

CRC Tests

Test	Status	Time
COMP	Pass	11:24am
CAL	Pass	11:24am

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Edgecombe Instrument Location Edgecombe Co. Magistrate's Office
Instrument Serial No. 008663 300 S. Adalonda Rd., Tarboro, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16th day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Linda A. Kessel
Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

EDGECOMBE COUNTY EDGECOMBE CO MAGISTR
320

Serial Number: 008663
Test Date: 10/16/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: KEESLER, LINDA A
Permit Number: 11646E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG916602
Exp Date: 06/15/2011


Test	g/210L	Time
DIAG	Pass	11:45am
AIR BLK	.00	11:46am
ACCY CHK	.08	11:46am
AIR BLK	.00	11:47am
SUB TEST	.00	11:48am
AIR BLK	.00	11:49am
SUB TEST	.00	11:51am
AIR BLK	.00	11:52am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

EDGECOMBE COUNTY EDGECOMBE CO MAGISTR 320

Serial Number: 008663 Test Record Number: 1055
Test Date: 10/16/2009 Test Time: 12:00pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:00pm
FLO	Pass	12:00pm
FC	Pass	12:00pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:00pm
SRC	Pass	12:00pm
DET	Pass	12:00pm
BAR	Pass	12:00pm
BT	Pass	12:00pm

Blank Tests

Test	Status	Time
AIR	Pass	12:01pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:01pm

CRC Tests

Test	Status	Time
COMP	Pass	12:01pm
CAL	Pass	12:01pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Edgecombe Instrument Location Edgecombe Co. Mavis notes office
Instrument Serial No. 008603 300 S. ANACONDA RD., TAREPTO, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16th day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Linda A. Reese
Signature of Certifying Official

647
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

EDGECOMBE COUNTY EDGECOMBE CO MAGISTR
320

Serial Number: 008603
Test Date: 10/16/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: KEESLER, LINDA A
Permit Number: 11646E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG916602
Exp Date: 06/15/2011

Test	g/210L	Time
DIAG	Pass	11:46am
AIR BLK	.00	11:47am
ACCY CHK	.08	11:48am
AIR BLK	.00	11:49am
SUB TEST	.00	11:49am
AIR BLK	.00	11:50am
SUB TEST	.00	11:52am
AIR BLK	.00	11:53am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

EDGECOMBE COUNTY EDGECOMBE CO MAGISTR 320

Serial Number: 008603 Test Record Number: 833
Test Date: 10/16/2009 Test Time: 12:01pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:01pm
FLO	Pass	12:01pm
FC	Pass	12:01pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:01pm
SRC	Pass	12:01pm
DET	Pass	12:01pm
BAR	Pass	12:01pm
BT	Pass	12:01pm

Blank Tests

Test	Status	Time
AIR	Pass	12:02pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:02pm

CRC Tests

Test	Status	Time
COMP	Pass	12:02pm
CAL	Pass	12:02pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Greene Instrument Location Greene Co. S.O.

Instrument Serial No. D08670 301 N. Greene St., Snow Hill, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 23rd day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

643
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

GREENE COUNTY GREENE CO SO 390

Serial Number: 008670
Test Date: 10/23/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: GUARD, KELLY G
Permit Number: 12955E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG910601
Exp Date: 04/16/2011

Test	g/210L	Time
DIAG	Pass	11:06am
AIR BLK	.00	11:07am
ACCY CHK	.08	11:08am
AIR BLK	.00	11:09am
SUB TEST	.00	11:09am
AIR BLK	.00	11:10am
SUB TEST	.00	11:12am
AIR BLK	.00	11:13am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

GREENE COUNTY GREENE CO SO 390

Serial Number: 008670 Test Record Number: 841
Test Date: 10/23/2009 Test Time: 11:16am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:16am
FLO	Pass	11:16am
FC	Pass	11:16am

Temperature Tests

Test	Status	Time
FC1	Pass	11:16am
SRC	Pass	11:16am
DET	Pass	11:16am
BAR	Pass	11:16am
BT	Pass	11:16am

Blank Tests

Test	Status	Time
AIR	Pass	11:17am

Printer Tests

Test	Status	Time
PRNT	Pass	11:17am

CRC Tests

Test	Status	Time
COMP	Pass	11:17am
CAL	Pass	11:17am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Currituck Instrument Location Currituck Co. S.O. - Corolla

Instrument Serial No. 008949 1123 Ocean Trail, Corolla, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 22nd day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Kelly M. [Signature]
Signature of Certifying Official

643
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CURRITUCK COUNTY SO-COROLLA 260

Serial Number: 008949
Test Date: 10/22/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: *GUARD, KELLY G*
Permit Number: 12955E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG902603
Exp Date: 01/26/2011

Test	g/210L	Time
DIAG	Pass	11:42am
AIR BLK	.00	11:43am
ACCY CHK	.08	11:43am
AIR BLK	.00	11:44am
SUB TEST	.00	11:45am
AIR BLK	.00	11:46am
SUB TEST	.00	11:48am
AIR BLK	.00	11:49am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

CURRITUCK COUNTY SO-COROLLA 260

Serial Number: 008949 Test Record Number: 103
Test Date: 10/22/2009 Test Time: 11:50am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:50am
FLO	Pass	11:50am
FC	Pass	11:50am

Temperature Tests

Test	Status	Time
FC1	Pass	11:50am
SRC	Pass	11:50am
DET	Pass	11:50am
BAR	Pass	11:50am
BT	Pass	11:50am

Blank Tests

Test	Status	Time
AIR	Pass	11:51am

Printer Tests

Test	Status	Time
PRNT	Pass	11:51am

CRC Tests

Test	Status	Time
COMP	Pass	11:51am
CAL	Pass	11:51am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Lenoir Instrument Location Kinston P.D.

Instrument Serial No. 008624 205 E. King St., Kinston, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 20th day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Kelly M.
Signature of Certifying Official

643
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

LENOIR COUNTY KINSTON PD 530

Serial Number: 008624
Test Date: 10/20/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: GUARD, KELLY G
Permit Number: 12955E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG916602
Exp Date: 06/15/2011

Test	g/210L	Time
DIAG	Pass	2:27pm
AIR BLK	.00	2:28pm
ACCY CHK	.08	2:28pm
AIR BLK	.00	2:29pm
SUB TEST	.00	2:30pm
AIR BLK	.00	2:31pm
SUB TEST	.00	2:32pm
AIR BLK	.00	2:33pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

LENOIR COUNTY KINSTON PD 530

Serial Number: 008624 Test Record Number: 576
Test Date: 10/20/2009 Test Time: 2:34pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:35pm
FLO	Pass	2:35pm
FC	Pass	2:35pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:35pm
SRC	Pass	2:35pm
DET	Pass	2:35pm
BAR	Pass	2:35pm
BT	Pass	2:35pm

Blank Tests

Test	Status	Time
AIR	Pass	2:36pm


Printer Tests

Test	Status	Time
PRNT	Pass	2:36pm

CRC Tests

Test	Status	Time
COMP	Pass	2:36pm
CAL	Pass	2:36pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Lenoir Instrument Location Lenoir Co. S.O.

Instrument Serial No. 008639 130 Queen St, Kinston, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 20th day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]

Signature of Certifying Official

643

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

LENOIR COUNTY LENOIR CO SO 530

Serial Number: 008639
Test Date: 10/20/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: GUARD, KELLY G
Permit Number: 12955E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG916602
Exp Date: 06/15/2011

Test	g/210L	Time
DIAG	Pass	1:53pm
AIR BLK	.00	1:54pm
ACCY CHK	.07	1:54pm
AIR BLK	.00	1:55pm
SUB TEST	.00	1:56pm
AIR BLK	.00	1:57pm
SUB TEST	.00	1:58pm
AIR BLK	.00	1:59pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

LENOIR COUNTY LENOIR CO SO 530

Serial Number: 008639 Test Record Number: 838
Test Date: 10/20/2009 Test Time: 2:00pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:01pm
FLO	Pass	2:01pm
FC	Pass	2:01pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:01pm
SRC	Pass	2:01pm
DET	Pass	2:01pm
BAR	Pass	2:01pm
BT	Pass	2:01pm

Blank Tests

Test	Status	Time
AIR	Pass	2:02pm

Printer Tests

Test	Status	Time
PRNT	Pass	2:02pm

CRC Tests

Test	Status	Time
COMP	Pass	2:02pm
CAL	Pass	2:02pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Pitt Instrument Location Pitt Co. Detention Center

Instrument Serial No. 008918 124 Detention Dr., Greenville, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 19th day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Kelly M. D.
Signature of Certifying Official

643
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

PITT COUNTY PITT CO DETENTION 730

Serial Number: 008918
Test Date: 10/19/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: GUARD, KELLY G
Permit Number: 12955E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG825401
Exp Date: 09/10/2010

Test	g/210L	Time
DIAG	Pass	2:20pm
AIR BLK	.00	2:21pm
ACCY CHK	.08	2:22pm
AIR BLK	.00	2:22pm
SUB TEST	.00	2:23pm
AIR BLK	.00	2:24pm
SUB TEST	.00	2:25pm
AIR BLK	.00	2:26pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

PITT COUNTY PITT CO DETENTION 730

Serial Number: 008918 Test Record Number: 92
Test Date: 10/19/2009 Test Time: 2:28pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:28pm
FLO	Pass	2:28pm
FC	Pass	2:28pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:28pm
SRC	Pass	2:28pm
DET	Pass	2:28pm
BAR	Pass	2:28pm
BT	Pass	2:28pm

Blank Tests

Test	Status	Time
AIR	Pass	2:29pm


Printer Tests

Test	Status	Time
PRNT	Pass	2:29pm

CRC Tests

Test	Status	Time
COMP	Pass	2:29pm
CAL	Pass	2:29pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Durham Instrument Location BAT Mobile Unit 4

Instrument Serial No. 008871

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 30th day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Daniel T. Treadwell
Signature of Certifying Official

657
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Preventive Maintenance

DURHAM COUNTY BAT MOBILE UNIT 4 310

Serial Number: 008871 Test Record Number: 200
Test Date: 10/30/2009 Test Time: 9:23pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	9:23pm
FLO	Pass	9:23pm
FC	Pass	9:24pm

Temperature Tests

Test	Status	Time
FC1	Pass	9:24pm
SRC	Pass	9:24pm
DET	Pass	9:24pm
BAR	Pass	9:24pm
BT	Pass	9:24pm

Blank Tests

Test	Status	Time
AIR	Pass	9:24pm


Printer Tests

Test	Status	Time
PRNT	Pass	9:24pm

CRC Tests

Test	Status	Time
COMP	Pass	9:25pm
CAL	Pass	9:25pm

Preventive Maintenance
Status: Pass



Analyst

Intox EC/IR-II: Subject Test

DURHAM COUNTY BAT MOBILE UNIT 4 310

Serial Number: 008871

Test Date: 10/30/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: TRUDELL, SR., DANIEL T

Permit Number: 21535E

Effective:

10/01/2009-10/01/2011

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG816303


Exp Date: 06/11/2010

Test	g/210L	Time
DIAG	Pass	9:15pm
AIR BLK	.00	9:16pm
ACCY CHK	.07	9:17pm
AIR BLK	.00	9:17pm
SUB TEST	.00	9:18pm
AIR BLK	.00	9:19pm
SUB TEST	.00	9:20pm
AIR BLK	.00	9:21pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County D.H. Instrument Location BAT Mobile Unit 9

Instrument Serial No. 008717

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 31st day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Daniel O. Treva Sr
Signature of Certifying Official

651
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Preventive Maintenance

PITT COUNTY BAT MOBILE UNIT 4 730

Serial Number: 008717 Test Record Number: 199
Test Date: 10/31/2009 Test Time: 9:57pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	9:57pm
FLO	Pass	9:57pm
FC	Pass	9:57pm

Temperature Tests

Test	Status	Time
FC1	Pass	9:57pm
SRC	Pass	9:57pm
DET	Pass	9:57pm
BAR	Pass	9:57pm
BT	Pass	9:57pm

Blank Tests

Test	Status	Time
AIR	Pass	9:58pm


Printer Tests

Test	Status	Time
PRNT	Pass	9:58pm

CRC Tests

Test	Status	Time
COMP	Pass	9:58pm
CAL	Pass	9:58pm

Preventive Maintenance
Status: Pass


Analyst

. Intex EC/IR-II: Subject Test

PITT COUNTY BAT MOBILE UNIT 4 730

Serial Number: 008717

Test Date: 10/31/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: TRUDELL, SR., DANIEL T

Permit Number: 21535E

Effective:

10/01/2009-10/01/2011

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG920302


Exp Date: 07/22/2011

Test	g/210L	Time
DIAG	Pass	9:50pm
AIR BLK	.00	9:51pm
ACCY CHK	.08	9:51pm
AIR BLK	.00	9:52pm
SUB TEST	.00	9:52pm
AIR BLK	.00	9:53pm
SUB TEST	.00	9:55pm
AIR BLK	.00	9:56pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County P.H.


Instrument Location BAT mobile unit 4

Instrument Serial No. 008734

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 31st day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Daniel T. Trumble
Signature of Certifying Official

651
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Preventive Maintenance

PITT COUNTY BAT MOBILE UNIT 4 730

Serial Number: 008734 Test Record Number: 308
Test Date: 10/31/2009 Test Time: 8:53pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	8:53pm
FLO	Pass	8:53pm
FC	Pass	8:53pm

Temperature Tests

Test	Status	Time
FC1	Pass	8:53pm
SRC	Pass	8:53pm
DET	Pass	8:53pm
BAR	Pass	8:53pm
BT	Pass	8:53pm

Blank Tests

Test	Status	Time
AIR	Pass	8:54pm


Printer Tests

Test	Status	Time
PRNT	Pass	8:54pm

CRC Tests

Test	Status	Time
COMP	Pass	8:54pm
CAL	Pass	8:54pm

Preventive Maintenance
Status: Pass


Analyst

Intox EC/IR-II: Subject Test

PITT COUNTY BAT MOBILE UNIT 4 730

Serial Number: 008734
Test Date: 10/31/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: TRUDELL, SR., DANIEL T
Permit Number: 21535E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG920302
Exp Date: 07/22/2011

Test	g/210L	Time
DIAG	Pass	8:45pm
AIR BLK	.00	8:46pm
ACCY CHK	.08	8:47pm
AIR BLK	.00	8:48pm
SUB TEST	.00	8:48pm
AIR BLK	.00	8:49pm
SUB TEST	.00	8:51pm
AIR BLK	.00	8:52pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County D. H Instrument Location BAT Mobile Unit 4

Instrument Serial No. 008871

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 31st day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Daniel O. Tressler
Signature of Certifying Official

651
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Preventive Maintenance

PITT COUNTY BAT MOBILE UNIT 4 730

Serial Number: 008871 Test Record Number: 205
Test Date: 10/31/2009 Test Time: 8:51pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	8:51pm
FLO	Pass	8:51pm
FC	Pass	8:51pm

Temperature Tests

Test	Status	Time
FC1	Pass	8:51pm
SRC	Pass	8:51pm
DET	Pass	8:51pm
BAR	Pass	8:51pm
BT	Pass	8:51pm

Blank Tests

Test	Status	Time
AIR	Pass	8:52pm


Printer Tests

Test	Status	Time
PRNT	Pass	8:52pm

CRC Tests

Test	Status	Time
COMP	Pass	8:52pm
CAL	Pass	8:52pm

Preventive Maintenance
Status: Pass


Analyst

Intox EC/IR-II: Subject Test

PITT COUNTY BAT MOBILE UNIT 4 730

Serial Number: 008871
Test Date: 10/31/2009

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: TRUDELL, SR., DANIEL T

Permit Number: 21535E

Effective:

10/01/2009-10/01/2011

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG816303


Exp Date: 06/11/2010

Test	g/210L	Time
DIAG	Pass	8:44pm
AIR BLK	.00	8:45pm
ACCY CHK	.07	8:45pm
AIR BLK	.00	8:46pm
SUB TEST	.00	8:46pm
AIR BLK	.00	8:47pm
SUB TEST	.00	8:49pm
AIR BLK	.00	8:50pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County BLADEN Instrument Location Bladen County
Instrument Serial No. 8613 Sherrills Dept

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 29 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Anthony Rivera 634
Signature of Certifying Official Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

BLADEN COUNTY BLADEN CO SD 080

Serial Number: 008613
Test Date: 10/29/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: RIVERA, ANTHONY
Permit Number: 08259E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG910601
Exp Date: 04/16/2011


Test	g/210L	Time
DIAG	Pass	12:12pm
AIR BLK	.00	12:13pm
ACCY CHK	.08	12:14pm
AIR BLK	.00	12:14pm
SUB TEST	.00	12:15pm
AIR BLK	.00	12:16pm
SUB TEST	.00	12:17pm
AIR BLK	.00	12:18pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

BLADEN COUNTY BLADEN CO SD 080

Serial Number: 008613 Test Record Number: 521
Test Date: 10/29/2009 Test Time: 12:19pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:20pm
FLO	Pass	12:20pm
FC	Pass	12:20pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:20pm
SRC	Pass	12:20pm
DET	Pass	12:20pm
BAR	Pass	12:20pm
BT	Pass	12:20pm

Blank Tests

Test	Status	Time
AIR	Pass	12:20pm

Printer Tests

Test	Status	Time
PRNT	Pass	12:20pm

CRC Tests

Test	Status	Time
COMP	Pass	12:21pm
CAL	Pass	12:21pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County NEW Hanover Instrument Location NEW Hanover County
Instrument Serial No. 8901 Sheriff's Dept

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15 day of OCTOBER, 20 09 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Anthony R. Rocco
Signature of Certifying Official

634
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

NEW HANOVER COUNTY NEW HANOVER CO SD
640

Serial Number: 008901
Test Date: 10/15/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: RIVERA, ANTHONY
Permit Number: 08259E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG825401
Exp Date: 09/10/2010

Test	g/210L	Time
DIAG	Pass	3:54pm
AIR BLK	.00	3:55pm
ACCY CHK	.07	3:56pm
AIR BLK	.00	3:57pm
SUB TEST	.00	3:57pm
AIR BLK	.00	3:58pm
SUB TEST	.00	4:00pm
AIR BLK	.00	4:01pm

Reported AC: .00 g/210L

Anthony Rivera
Signature of Chemical Analyst

Court CVR

Anthony Rivera
Analyst

Intox EC/IR-II: Preventive Maintenance

NEW HANOVER COUNTY NEW HANOVER CO SD 640

Serial Number: 008901 Test Record Number: 132
Test Date: 10/15/2009 Test Time: 4:02pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	4:02pm
FLO	Pass	4:02pm
FC	Pass	4:02pm

Temperature Tests

Test	Status	Time
FC1	Pass	4:02pm
SRC	Pass	4:02pm
DET	Pass	4:02pm
BAR	Pass	4:02pm
BT	Pass	4:02pm

Blank Tests

Test	Status	Time
AIR	Pass	4:03pm


Printer Tests

Test	Status	Time
PRNT	Pass	4:03pm

CRC Tests

Test	Status	Time
COMP	Pass	4:03pm
CAL	Pass	4:03pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County DURHAM Instrument Location DURHAM CO. JAIL

Instrument Serial No. 008859 217 S. HANCOCK ST DURHAM, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

652
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

DURHAM COUNTY DURHAM COUNTY JAIL 310

Serial Number: 008859
Test Date: 10/13/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name:
QUARANTELLA, NICHOLAS J
Permit Number: 21536E
Effective:
01/01/2008-01/01/2010

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG920303
Exp Date: 07/22/2011


Test	g/210L	Time
DIAG	Pass	12:26pm
AIR BLK	.00	12:27pm
ACCY CHK	.07	12:27pm
AIR BLK	.00	12:28pm
SUB TEST	.00	12:29pm
AIR BLK	.00	12:30pm
SUB TEST	.00	12:32pm
AIR BLK	.00	12:33pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

DURHAM COUNTY DURHAM COUNTY JAIL 310

Serial Number: 008859 Test Record Number: 369
Test Date: 10/13/2009 Test Time: 12:35pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:35pm
FLO	Pass	12:35pm
FC	Pass	12:35pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:35pm
SRC	Pass	12:35pm
DET	Pass	12:35pm
BAR	Pass	12:35pm
BT	Pass	12:35pm

Blank Tests

Test	Status	Time
AIR	Pass	12:36pm

Printer Tests

Test	Status	Time
PRNT	Pass	12:36pm

CRC Tests

Test	Status	Time
COMP	Pass	12:36pm
CAL	Pass	12:36pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County DURHAM Instrument Location DURHAM CO. JAIL

Instrument Serial No. 008878 217 S. HANCOCK ST. DURHAM, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

652
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

DURHAM COUNTY DURHAM COUNTY JAIL 310

Serial Number: 008878
Test Date: 10/13/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name:
QUARANTELLA, NICHOLAS J
Permit Number: 21536E
Effective:
01/01/2008-01/01/2010

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG916701
Exp Date: 06/16/2011

Test	g/210L	Time
DIAG	Pass	12:45pm
AIR BLK	.00	12:46pm
ACCY CHK	.08	12:46pm
AIR BLK	.00	12:47pm
SUB TEST	.00	12:48pm
AIR BLK	.00	12:49pm
SUB TEST	.00	12:50pm
AIR BLK	.00	12:51pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

DURHAM COUNTY DURHAM COUNTY JAIL 310

Serial Number: 008878 Test Record Number: 560
Test Date: 10/13/2009 Test Time: 12:54pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:54pm
FLO	Pass	12:54pm
FC	Pass	12:54pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:54pm
SRC	Pass	12:54pm
DET	Pass	12:54pm
BAR	Pass	12:54pm
BT	Pass	12:54pm

Blank Tests

Test	Status	Time
AIR	Pass	12:55pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:55pm

CRC Tests

Test	Status	Time
COMP	Pass	12:55pm
CAL	Pass	12:55pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County DURHAM Instrument Location DURHAM CO. JAIL

Instrument Serial No. 008891 217 S. HANCOCK ST. DURHAM, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

652
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

DURHAM COUNTY DURHAM COUNTY JAIL 310

Serial Number: 008891
Test Date: 10/13/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name:
QUARANTELLA, NICHOLAS J
Permit Number: 21536E
Effective:
01/01/2008-01/01/2010

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG814002
Exp Date: 05/19/2010

Test	g/210L	Time
DIAG	Pass	12:50pm
AIR BLK	.00	12:51pm
ACCY CHK	.07	12:52pm
AIR BLK	.00	12:53pm
SUB TEST	.00	12:53pm
AIR BLK	.00	12:54pm
SUB TEST	.00	12:56pm
AIR BLK	.00	12:57pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

DURHAM COUNTY DURHAM COUNTY JAIL 310

Serial Number: 008891 Test Record Number: 421
Test Date: 10/13/2009 Test Time: 12:59pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:00pm
FLO	Pass	1:00pm
FC	Pass	1:00pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:00pm
SRC	Pass	1:00pm
DET	Pass	1:00pm
BAR	Pass	1:00pm
BT	Pass	1:00pm

Blank Tests

Test	Status	Time
AIR	Pass	1:01pm


Printer Tests

Test	Status	Time
PRNT	Pass	1:01pm

CRC Tests

Test	Status	Time
COMP	Pass	1:01pm
CAL	Pass	1:01pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County GRANVILLE Instrument Location OXFORD PD

Instrument Serial No. 008923 204 E McCLANAHAN ST OXFORD, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16 day of OCTOBER, 20 09 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

652
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

GRANVILLE COUNTY OXFORD PD 380

Serial Number: 008923
Test Date: 10/16/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name:
QUARANTELLA, NICHOLAS J
Permit Number: 21536E
Effective:
01/01/2008-01/01/2010

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG902603
Exp Date: 01/26/2011


Test	g/210L	Time
DIAG	Pass	10:21am
AIR BLK	.00	10:22am
ACCY CHK	.08	10:23am
AIR BLK	.00	10:24am
SUB TEST	.00	10:24am
AIR BLK	.00	10:25am
SUB TEST	.00	10:26am
AIR BLK	.00	10:27am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

GRANVILLE COUNTY OXFORD PD 380

Serial Number: 008923 Test Record Number: 109
Test Date: 10/16/2009 Test Time: 10:28am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:29am
FLO	Pass	10:29am
FC	Pass	10:29am

Temperature Tests

Test	Status	Time
FC1	Pass	10:29am
SRC	Pass	10:29am
DET	Pass	10:29am
BAR	Pass	10:29am
BT	Pass	10:29am

Blank Tests

Test	Status	Time
AIR	Pass	10:29am


Printer Tests

Test	Status	Time
PRNT	Pass	10:29am

CRC Tests

Test	Status	Time
COMP	Pass	10:30am
CAL	Pass	10:30am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County ALAMANCE Instrument Location BURLINGTON PA

Instrument Serial No. 008907 267 W. FRONT ST BURLINGTON, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 19 day of OCTOBER, 20 09 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

652
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

ALAMANCE COUNTY BURLINGTON PD 000

Serial Number: 008907
Test Date: 10/19/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name:
QUARANTELLA, NICHOLAS J
Permit Number: 21536E
Effective:
01/01/2008-01/01/2010

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG814002
Exp Date: 05/19/2010


Test	g/210L	Time
DIAG	Pass	10:13am
AIR BLK	.00	10:14am
ACCY CHK	.07	10:15am
AIR BLK	.00	10:15am
SUB TEST	.00	10:16am
AIR BLK	.00	10:17am
SUB TEST	.00	10:18am
AIR BLK	.00	10:19am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

ALAMANCE COUNTY BURLINGTON PD 000

Serial Number: 008907 Test Record Number: 247
Test Date: 10/19/2009 Test Time: 10:21am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:21am
FLO	Pass	10:21am
FC	Pass	10:21am

Temperature Tests

Test	Status	Time
FC1	Pass	10:21am
SRC	Pass	10:21am
DET	Pass	10:21am
BAR	Pass	10:21am
BT	Pass	10:21am

Blank Tests

Test	Status	Time
AIR	Pass	10:22am


Printer Tests

Test	Status	Time
PRNT	Pass	10:22am

CRC Tests

Test	Status	Time
COMP	Pass	10:22am
CAL	Pass	10:22am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County ALAMANCE

Instrument Location BURLINGTON P.D.


Instrument Serial No. 008812

267 W. FRONT ST BURLINGTON, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 19 day of OCTOBER, 20 09 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

652
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

ALAMANCE COUNTY BURLINGTON PD 000

Serial Number: 008812
Test Date: 10/19/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name:
QUARANTELLA, NICHOLAS J
Permit Number: 21536E
Effective:
01/01/2008-01/01/2010

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG814002
Exp Date: 05/19/2010


Test	g/210L	Time
DIAG	Pass	10:41am
AIR BLK	.00	10:42am
ACCY CHK	.07	10:43am
AIR BLK	.00	10:44am
SUB TEST	.00	10:44am
AIR BLK	.00	10:45am
SUB TEST	.00	10:47am
AIR BLK	.00	10:48am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

ALAMANCE COUNTY BURLINGTON PD 000

Serial Number: 008812 Test Record Number: 426
Test Date: 10/19/2009 Test Time: 10:49am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:50am
FLO	Pass	10:50am
FC	Pass	10:50am

Temperature Tests

Test	Status	Time
FC1	Pass	10:50am
SRC	Pass	10:50am
DET	Pass	10:50am
BAR	Pass	10:50am
BT	Pass	10:50am

Blank Tests

Test	Status	Time
AIR	Pass	10:51am


Printer Tests

Test	Status	Time
PRNT	Pass	10:51am

CRC Tests

Test	Status	Time
COMP	Pass	10:51am
CAL	Pass	10:51am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County WAKE Instrument Location WAKE FOREST P.D.

Instrument Serial No. 008700 401 OWEN ST. WAKE FOREST, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 20 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

652
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAKE COUNTY WAKE FOREST PD 910

Serial Number: 008700
Test Date: 10/20/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name:
QUARANTELLA, NICHOLAS J
Permit Number: 21536E
Effective:
01/01/2008-01/01/2010

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG916701
Exp Date: 06/16/2011

Test	g/210L	Time
DIAG	Pass	12:58pm
AIR BLK	.00	12:59pm
ACCY CHK	.08	1:00pm
AIR BLK	.00	1:01pm
SUB TEST	.00	1:01pm
AIR BLK	.00	1:02pm
SUB TEST	.00	1:03pm
AIR BLK	.00	1:04pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY WAKE FOREST PD 910

Serial Number: 008700 Test Record Number: 304
Test Date: 10/20/2009 Test Time: 1:06pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:06pm
FLO	Pass	1:06pm
FC	Pass	1:06pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:06pm
SRC	Pass	1:06pm
DET	Pass	1:06pm
BAR	Pass	1:06pm
BT	Pass	1:06pm

Blank Tests

Test	Status	Time
AIR	Pass	1:07pm

Printer Tests

Test	Status	Time
PRNT	Pass	1:07pm

CRC Tests

Test	Status	Time
COMP	Pass	1:07pm
CAL	Pass	1:07pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County PERSON Instrument Location PERSON CO. LEC

Instrument Serial No. 008693 120 CART ST. ROXBORO, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 21 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

652
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

PERSON COUNTY PERSON CO. LEC 720

Serial Number: 008693
Test Date: 10/21/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name:
QUARANTELLA, NICHOLAS J
Permit Number: 21536E
Effective:
01/01/2008-01/01/2010

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG814002
Exp Date: 05/19/2010


Test	g/210L	Time
DIAG	Pass	11:15am
AIR BLK	.00	11:16am
ACCY CHK	.07	11:16am
AIR BLK	.00	11:17am
SUB TEST	.00	11:18am
AIR BLK	.00	11:19am
SUB TEST	.00	11:20am
AIR BLK	.00	11:21am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

PERSON COUNTY PERSON CO. LEC 720

Serial Number: 008693 Test Record Number: 439
Test Date: 10/21/2009 Test Time: 11:22am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:23am
FLO	Pass	11:23am
FC	Pass	11:23am

Temperature Tests

Test	Status	Time
FC1	Pass	11:23am
SRC	Pass	11:23am
DET	Pass	11:23am
BAR	Pass	11:23am
BT	Pass	11:23am

Blank Tests

Test	Status	Time
AIR	Pass	11:24am

Printer Tests

Test	Status	Time
PRNT	Pass	11:24am

CRC Tests

Test	Status	Time
COMP	Pass	11:24am
CAL	Pass	11:24am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County PERSON Instrument Location PERSON Co. LEC

Instrument Serial No. 608880 120 COURT ST ROXBORO, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 21 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

652
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

PERSON COUNTY PERSON CO. LEC 720

Serial Number: 008880
Test Date: 10/21/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name:
QUARANTELLA, NICHOLAS J
Permit Number: 21536E
Effective:
01/01/2008-01/01/2010

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG814101
Exp Date: 05/20/2010


Test	g/210L	Time
DIAG	Pass	11:16am
AIR BLK	.00	11:17am
ACCY CHK	.08	11:18am
AIR BLK	.00	11:19am
SUB TEST	.00	11:19am
AIR BLK	.00	11:20am
SUB TEST	.00	11:22am
AIR BLK	.00	11:22am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

PERSON COUNTY PERSON CO. LEC 720

Serial Number: 008880 Test Record Number: 186
Test Date: 10/21/2009 Test Time: 11:24am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:24am
FLO	Pass	11:24am
FC	Pass	11:24am

Temperature Tests

Test	Status	Time
FC1	Pass	11:24am
SRC	Pass	11:24am
DET	Pass	11:24am
BAR	Pass	11:24am
BT	Pass	11:24am

Blank Tests

Test	Status	Time
AIR	Pass	11:25am

Printer Tests

Test	Status	Time
PRNT	Pass	11:25am

CRC Tests

Test	Status	Time
COMP	Pass	11:25am
CAL	Pass	11:25am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County WAKE Instrument Location CCBI

Instrument Serial No. 008686 330 S. SAUSBOY ST RALEIGH N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 22 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

652
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAKE COUNTY CCBI 910

Serial Number: 008686
Test Date: 10/22/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name:
QUARANTELLA, NICHOLAS J
Permit Number: 21536E
Effective:
01/01/2008-01/01/2010

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG904903
Exp Date: 02/18/2011


Test	g/210L	Time
DIAG	Pass	11:58am
AIR BLK	.00	11:59am
ACCY CHK	.08	12:00pm
AIR BLK	.00	12:01pm
SUB TEST	.00	12:02pm
AIR BLK	.00	12:03pm
SUB TEST	.00	12:04pm
AIR BLK	.00	12:05pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY CCBI 910

Serial Number: 008686 Test Record Number: 1530
Test Date: 10/22/2009 Test Time: 12:07pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:08pm
FLO	Pass	12:08pm
FC	Pass	12:08pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:08pm
SRC	Pass	12:08pm
DET	Pass	12:08pm
BAR	Pass	12:08pm
BT	Pass	12:08pm

Blank Tests

Test	Status	Time
AIR	Pass	12:08pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:08pm

CRC Tests

Test	Status	Time
COMP	Pass	12:09pm
CAL	Pass	12:09pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County WAKE Instrument Location CCBI

Instrument Serial No. 008816 330 S. SALISBURY ST. RALEIGH NC.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 22 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

652
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAKE COUNTY CCBI 910

Serial Number: 008816
Test Date: 10/22/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name:

QUARANTELLA, NICHOLAS J

Permit Number: 21536E

Effective:

01/01/2008-01/01/2010

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG920302

Exp Date: 07/22/2011


Test	g/210L	Time
DIAG	Pass	12:02pm
AIR BLK	.00	12:03pm
ACCY CHK	.08	12:03pm
AIR BLK	.00	12:04pm
SUB TEST	.00	12:04pm
AIR BLK	.00	12:05pm
SUB TEST	.00	12:07pm
AIR BLK	.00	12:08pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY CCBI 910

Serial Number: 008816 Test Record Number: 2060
Test Date: 10/22/2009 Test Time: 12:09pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:10pm
FLO	Pass	12:10pm
FC	Pass	12:10pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:10pm
SRC	Pass	12:10pm
DET	Pass	12:10pm
BAR	Pass	12:10pm
BT	Pass	12:10pm

Blank Tests

Test	Status	Time
AIR	Pass	12:11pm

Printer Tests

Test	Status	Time
PRNT	Pass	12:11pm

CRC Tests

Test	Status	Time
COMP	Pass	12:11pm
CAL	Pass	12:11pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County WAKE Instrument Location CCBI

Instrument Serial No. 008826 330 SALISBURY ST. RALEIGH NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 27 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

652
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAKE COUNTY CCBI 910

Serial Number: 008826
Test Date: 10/22/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name:

QUARANTELLA, NICHOLAS J

Permit Number: 21536E

Effective:

01/01/2008-01/01/2010

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG920302

Exp Date: 07/22/2011


Test	g/210L	Time
DIAG	Pass	12:26pm
AIR BLK	.00	12:27pm
ACCY CHK	.08	12:28pm
AIR BLK	.00	12:29pm
SUB TEST	.00	12:30pm
AIR BLK	.00	12:30pm
SUB TEST	.00	12:32pm
AIR BLK	.00	12:33pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY CCBI 910

Serial Number: 008826 Test Record Number: 2028
Test Date: 10/22/2009 Test Time: 12:36pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:36pm
FLO	Pass	12:36pm
FC	Pass	12:36pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:36pm
SRC	Pass	12:36pm
DET	Pass	12:36pm
BAR	Pass	12:36pm
BT	Pass	12:36pm

Blank Tests

Test	Status	Time
AIR	Pass	12:37pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:37pm

CRC Tests

Test	Status	Time
COMP	Pass	12:37pm
CAL	Pass	12:37pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County WAKE Instrument Location CCBI

Instrument Serial No. 008615 330 S. SAUBURY ST RALEIGH, N.C

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 22 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

652
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAKE COUNTY CCBI 910

Serial Number: 008615
Test Date: 10/22/2009

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name:

QUARANTELLA, NICHOLAS J

Permit Number: 21536E

Effective:

01/01/2008-01/01/2010

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG910601

Exp Date: 04/16/2011


Test	g/210L	Time
DIAG	Pass	12:32pm
AIR BLK	.00	12:33pm
ACCY CHK	.08	12:33pm
AIR BLK	.00	12:34pm
SUB TEST	.00	12:35pm
AIR BLK	.00	12:36pm
SUB TEST	.00	12:37pm
AIR BLK	.00	12:38pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY CCBI 910

Serial Number: 008615 Test Record Number: 1366
Test Date: 10/22/2009 Test Time: 12:41pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:42pm
FLO	Pass	12:42pm
FC	Pass	12:42pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:42pm
SRC	Pass	12:42pm
DET	Pass	12:42pm
BAR	Pass	12:42pm
BT	Pass	12:42pm

Blank Tests

Test	Status	Time
AIR	Pass	12:42pm

Printer Tests

Test	Status	Time
PRNT	Pass	12:42pm

CRC Tests

Test	Status	Time
COMP	Pass	12:43pm
CAL	Pass	12:43pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Wake Instrument Location BAI Mobile Unit #5

Instrument Serial No. 008600 Carry

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 23rd day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Steph O. Thomas
Signature of Certifying Official

636
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY BAT MOBILE UNIT 5 910

Serial Number: 008600 Test Record Number: 546
Test Date: 10/23/2009 Test Time: 11:23pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:23pm
FLO	Pass	11:23pm
FC	Pass	11:23pm

Temperature Tests

Test	Status	Time
FC1	Pass	11:23pm
SRC	Pass	11:23pm
DET	Pass	11:23pm
BAR	Pass	11:23pm
BT	Pass	11:23pm

Blank Tests

Test	Status	Time
AIR	Pass	11:24pm


Printer Tests

Test	Status	Time
PRNT	Pass	11:24pm

CRC Tests

Test	Status	Time
COMP	Pass	11:24pm
CAL	Pass	11:24pm

Preventive Maintenance
Status: Pass



Analyst

Intox EC/IR-II: Subject Test

WAKE COUNTY BAT MOBILE UNIT 5 910

Serial Number: 008600
Test Date: 10/23/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: MORGART, STEPHEN G
Permit Number: 09372E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG920302
Exp Date: 07/22/2011


Test	g/210L	Time
DIAG	Pass	11:14pm
AIR BLK	.00	11:15pm
ACCY CHK	.08	11:15pm
AIR BLK	.00	11:16pm
SUB TEST	.00	11:17pm
AIR BLK	.00	11:18pm
SUB TEST	.00	11:19pm
AIR BLK	.00	11:20pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Wake Instrument Location BAT MOBILE UNIT #5

Instrument Serial No. 008698 Camy

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 23rd day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Steph [Signature]
Signature of Certifying Official

656
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY BAT MOBILE UNIT 5 910

Serial Number: 008698 Test Record Number: 409
Test Date: 10/23/2009 Test Time: 11:19pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:19pm
FLO	Pass	11:19pm
FC	Pass	11:19pm

Temperature Tests

Test	Status	Time
FC1	Pass	11:20pm
SRC	Pass	11:20pm
DET	Pass	11:20pm
BAR	Pass	11:20pm
BT	Pass	11:20pm

Blank Tests

Test	Status	Time
AIR	Pass	11:20pm

Printer Tests

Test	Status	Time
PRNT	Pass	11:20pm

CRC Tests

Test	Status	Time
COMP	Pass	11:20pm
CAL	Pass	11:20pm

Preventive Maintenance
Status: Pass



Analyst

Intox EC/IR-II: Subject Test

WAKE COUNTY BAT MOBILE UNIT 5 910

Serial Number: 008698
Test Date: 10/23/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: MORGART, STEPHEN G

Permit Number: 09372E

Effective:

12/01/2007-12/01/2009

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG920302

Exp Date: 07/22/2011

Test	g/210L	Time
DIAG	Pass	11:10pm
AIR BLK	.00	11:11pm
ACCY CHK	.08	11:12pm
AIR BLK	.00	11:12pm
SUB TEST	.00	11:13pm
AIR BLK	.00	11:14pm
SUB TEST	.00	11:16pm
AIR BLK	.00	11:17pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Wake Instrument Location BAT MOBILE UNIT #5

Instrument Serial No. 008788 CAN

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 23rd day of OCTOBER, 2029 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

036
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY BAT MOBILE UNIT 5 910

Serial Number: 008788 Test Record Number: 279
Test Date: 10/23/2009 Test Time: 11:16pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:16pm
FLO	Pass	11:16pm
FC	Pass	11:17pm

Temperature Tests

Test	Status	Time
FC1	Pass	11:17pm
SRC	Pass	11:17pm
DET	Pass	11:17pm
BAR	Pass	11:17pm
BT	Pass	11:17pm

Blank Tests

Test	Status	Time
AIR	Pass	11:17pm


Printer Tests

Test	Status	Time
PRNT	Pass	11:17pm

CRC Tests

Test	Status	Time
COMP	Pass	11:17pm
CAL	Pass	11:17pm

Preventive Maintenance
Status: Pass



Analyst

Intox EC/IR-II: Subject Test

WAKE COUNTY BAT MOBILE UNIT 5 910

Serial Number: 008788
Test Date: 10/23/2009

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: MORGART, STEPHEN G
Permit Number: 09372E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG904903
Exp Date: 02/18/2011

Test	g/210L	Time
DIAG	Pass	11:06pm
AIR BLK	.00	11:07pm
ACCY CHK	.08	11:07pm
AIR BLK	.00	11:08pm
SUB TEST	.00	11:09pm
AIR BLK	.00	11:10pm
SUB TEST	.00	11:12pm
AIR BLK	.00	11:13pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II


County JOHNSTON Instrument Location JOHNSTON Co. JAIL

Instrument Serial No. 008810 SMITHFIELD NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Reginald Russell
Signature of Certifying Official

371
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

JOHNSTON COUNTY JOHNSTON CO. JAIL 500

Serial Number: 008810
Test Date: 10/15/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: RUSSELL, LARRY H
Permit Number: 06108E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG920301
Exp Date: 07/11/2011


Test	g/210L	Time
DIAG	Pass	1:51pm
AIR BLK	.00	1:52pm
ACCY CHK	.07	1:52pm
AIR BLK	.00	1:53pm
SUB TEST	.00	1:54pm
AIR BLK	.00	1:55pm
SUB TEST	.00	1:56pm
AIR BLK	.00	1:57pm

Reported Ag: .00 g/210L



Signature of Chemical Analyst

Court CVR.



Analyst

Intox EC/IR-II: Preventive Maintenance

JOHNSTON COUNTY JOHNSTON CO. JAIL 500

Serial Number: 008810 Test Record Number: 491
Test Date: 10/15/2009 Test Time: 2:03pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:04pm
FLO	Pass	2:04pm
FC	Pass	2:04pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:04pm
SRC	Pass	2:04pm
DET	Pass	2:04pm
BAR	Pass	2:04pm
BT	Pass	2:04pm

Blank Tests

Test	Status	Time
AIR	Pass	2:05pm


Printer Tests

Test	Status	Time
PRNT	Pass	2:05pm

CRC Tests

Test	Status	Time
COMP	Pass	2:05pm
CAL	Pass	2:05pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County JOHNSTON Instrument Location CLAYTON POLICE DEPT.
Instrument Serial No. 008658 CLAYTON NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15 day of OCTOBER, 20 09 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

371
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

JOHNSTON COUNTY CLAYTON PD. 500

Serial Number: 008658
Test Date: 10/15/2009

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: RUSSELL, LARRY H

Permit Number: 06108E

Effective:

12/01/2007-12/01/2009

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG910601


Exp Date: 04/16/2011

Test	g/210L	Time
DIAG	Pass	12:19pm
AIR BLK	.00	12:19pm
ACCY CHK	.08	12:20pm
AIR BLK	.00	12:21pm
SUB TEST	.00	12:22pm
AIR BLK	.00	12:23pm
SUB TEST	.00	12:24pm
AIR BLK	.00	12:25pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

JOHNSTON COUNTY CLAYTON PD. 500

Serial Number: 008658 Test Record Number: 367
Test Date: 10/15/2009 Test Time: 12:27pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:27pm
FLO	Pass	12:27pm
FC	Pass	12:27pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:27pm
SRC	Pass	12:27pm
DET	Pass	12:27pm
BAR	Pass	12:27pm
BT	Pass	12:27pm

Blank Tests

Test	Status	Time
AIR	Pass	12:28pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:28pm

CRC Tests

Test	Status	Time
COMP	Pass	12:28pm
CAL	Pass	12:28pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II


County JOHNSTON Instrument Location JOHNSTON Co. JAIL

Instrument Serial No. 008846 SMITHFIELD, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Paul Russell
Signature of Certifying Official

371
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

JOHNSTON COUNTY JOHNSTON CO. JAIL 500

Serial Number: 008846

Test Date: 10/15/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: RUSSELL, LARRY H

Permit Number: 06108E

Effective:

12/01/2007-12/01/2009

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG920301

Exp Date: 07/11/2011

Test	g/210L	Time
DIAG	Pass	1:47pm
AIR BLK	.00	1:48pm
ACCY CHK	.07	1:48pm
AIR BLK	.00	1:49pm
SUB TEST	.00	1:50pm
AIR BLK	.00	1:51pm
SUB TEST	.00	1:53pm
AIR BLK	.00	1:54pm

Reported ~~AC~~: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

JOHNSTON COUNTY JOHNSTON CO. JAIL 500
Serial Number: 008846 Test Record Number: 849
Test Date: 10/15/2009 Test Time: 1:57pm EDT
System Check: Passed

Baseline Tests

Test	Status	Time
IR	Pass	1:57pm
FLO	Pass	1:57pm
FC	Pass	1:57pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:57pm
SRC	Pass	1:57pm
DET	Pass	1:57pm
BAR	Pass	1:57pm
BT	Pass	1:57pm

Blank Tests

Test	Status	Time
AIR	Pass	1:58pm


Printer Tests

Test	Status	Time
PRNT	Pass	1:58pm

CRC Tests

Test	Status	Time
COMP	Pass	1:58pm
CAL	Pass	1:58pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County MONTGOMERY Instrument Location MONTGOMERY Co. JAIL

Instrument Serial No. 008721 TROY NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

371
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MONTGOMERY COUNTY MONTGOMERY CO. JAIL
610

Serial Number: 008721
Test Date: 10/16/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: RUSSELL, LARRY H
Permit Number: 06108E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG916701
Exp Date: 06/16/2011


Test	g/210L	Time
DIAG	Pass	12:12pm
AIR BLK	.00	12:13pm
ACCY CHK	.08	12:14pm
AIR BLK	.00	12:15pm
SUB TEST	.00	12:15pm
AIR BLK	.00	12:16pm
SUB TEST	.00	12:18pm
AIR BLK	.00	12:19pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

MONTGOMERY COUNTY MONTGOMERY CO. JAIL 610

Serial Number: 008721 Test Record Number: 268
Test Date: 10/16/2009 Test Time: 12:21pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:21pm
FLO	Pass	12:21pm
FC	Pass	12:21pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:21pm
SRC	Pass	12:21pm
DET	Pass	12:21pm
BAR	Pass	12:21pm
BT	Pass	12:21pm

Blank Tests

Test	Status	Time
AIR	Pass	12:22pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:22pm

CRC Tests

Test	Status	Time
COMP	Pass	12:22pm
CAL	Pass	12:22pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County MONTGOMERY Instrument Location MONTGOMERY Co. JAIL
Instrument Serial No. 008709 TROY NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 16 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

371
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MONTGOMERY COUNTY MONTGOMERY CO. JAIL
610

Serial Number: 008709
Test Date: 10/16/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: RUSSELL, LARRY H
Permit Number: 06108E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG916701
Exp Date: 06/16/2011


Test	g/210L	Time
DIAG	Pass	12:47pm
AIR BLK	.00	12:47pm
ACCY CHK	.08	12:48pm
AIR BLK	.00	12:49pm
SUB TEST	.00	12:49pm
AIR BLK	.00	12:50pm
SUB TEST	.00	12:52pm
AIR BLK	.00	12:52pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

MONTGOMERY COUNTY MONTGOMERY CO. JAIL 610

Serial Number: 008709 Test Record Number: 370
Test Date: 10/16/2009 Test Time: 12:55pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:55pm
FLO	Pass	12:55pm
FC	Pass	12:55pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:56pm
SRC	Pass	12:56pm
DET	Pass	12:56pm
BAR	Pass	12:56pm
BT	Pass	12:56pm

Blank Tests

Test	Status	Time
AIR	Pass	12:56pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:56pm

CRC Tests

Test	Status	Time
COMP	Pass	12:56pm
CAL	Pass	12:56pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County MOORE Instrument Location Southern Pines
Instrument Serial No. 008720 Police Dept.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Paul T. [Signature]
Signature of Certifying Official

578
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

• Intox EC/IR-II: Subject Test

MOORE SOUTHERN PINES PD. 620

Serial Number: 008720

Test Date: 10/13/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: SIMMONS, PAUL T

Permit Number: 08619E

Effective:

12/01/2007-12/01/2009

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG904903

Exp Date: 02/18/2011


Test	g/210L	Time
DIAG	Pass	3:34pm
AIR BLK	.00	3:35pm
ACCY CHK	.08	3:35pm
AIR BLK	.00	3:36pm
SUB TEST	.00	3:37pm
AIR BLK	.00	3:38pm
SUB TEST	.00	3:39pm
AIR BLK	.00	3:40pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

MOORE SOUTHERN PINES PD. 620

Serial Number: 008720 Test Record Number: 315
Test Date: 10/13/2009 Test Time: 3:41pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	3:41pm
FLO	Pass	3:41pm
FC	Pass	3:41pm

Temperature Tests

Test	Status	Time
FC1	Pass	3:42pm
SRC	Pass	3:42pm
DET	Pass	3:42pm
BAR	Pass	3:42pm
BT	Pass	3:42pm

Blank Tests

Test	Status	Time
AIR	Pass	3:42pm

Printer Tests

Test	Status	Time
PRNT	Pass	3:42pm

CRC Tests

Test	Status	Time
COMP	Pass	3:42pm
CAL	Pass	3:42pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County MOORE Instrument Location PINEHURST
Instrument Serial No. 008710 POLICE DEPT.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Paul T. Sumner
Signature of Certifying Official

578
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MOORE PINEHURST PD. 620

Serial Number: 008710
Test Date: 10/13/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: SIMMONS, PAUL T

Permit Number: 08619E

Effective:

12/01/2007-12/01/2009

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG904903


Exp Date: 02/18/2011

Test	g/210L	Time
DIAG	Pass	2:43pm
AIR BLK	.00	2:44pm
ACCY CHK	.08	2:45pm
AIR BLK	.00	2:45pm
SUB TEST	.00	2:46pm
AIR BLK	.00	2:47pm
SUB TEST	.00	2:49pm
AIR BLK	.00	2:50pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

MOORE PINEHURST PD. 620

Serial Number: 008710 Test Record Number: 346
Test Date: 10/13/2009 Test Time: 2:52pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:53pm
FLO	Pass	2:53pm
FC	Pass	2:53pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:53pm
SRC	Pass	2:53pm
DET	Pass	2:53pm
BAR	Pass	2:53pm
BT	Pass	2:53pm

Blank Tests

Test	Status	Time
AIR	Pass	2:53pm


Printer Tests

Test	Status	Time
PRNT	Pass	2:53pm

CRC Tests

Test	Status	Time
COMP	Pass	2:54pm
CAL	Pass	2:54pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Onslow Instrument Location Onslow County

Instrument Serial No. 008931 Sheriff's Office

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 5 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Randy E. Hall

Signature of Certifying Official

354

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

ONslow COUNTY ONSLOW COUNTY SD 660

Serial Number: 008931
Test Date: 10/05/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: HALL, RANDY E
Permit Number: 03462E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG920302
Exp Date: 07/22/2011


Test	g/210L	Time
DIAG	Pass	11:45am
AIR BLK	.00	11:46am
ACCY CHK	.08	11:46am
AIR BLK	.00	11:47am
SUB TEST	.00	11:48am
AIR BLK	.00	11:49am
SUB TEST	.00	11:50am
AIR BLK	.00	11:51am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

ONSLOW COUNTY ONSLOW COUNTY SD 660

Serial Number: 008931 Test Record Number: 895
Test Date: 10/05/2009 Test Time: 11:52am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:53am
FLO	Pass	11:53am
FC	Pass	11:53am

Temperature Tests

Test	Status	Time
FC1	Pass	11:53am
SRC	Pass	11:53am
DET	Pass	11:53am
BAR	Pass	11:53am
BT	Pass	11:53am

Blank Tests

Test	Status	Time
AIR	Pass	11:53am

Printer Tests

Test	Status	Time
PRNT	Pass	11:53am

CRC Tests

Test	Status	Time
COMP	Pass	11:54am
CAL	Pass	11:54am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Onslow Instrument Location Onslow County

Instrument Serial No. 008932 Sheriff's Office

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 5 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Randy E. Hall
Signature of Certifying Official

354
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

ONSLOW COUNTY ONSLOW COUNTY SD 660

Serial Number: 008932
Test Date: 10/05/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: HALL, RANDY E
Permit Number: 03462E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG816302
Exp Date: 06/11/2010

Test	g/210L	Time
DIAG	Pass	11:50am
AIR BLK	.00	11:51am
ACCY CHK	.08	11:52am
AIR BLK	.00	11:52am
SUB TEST	.00	11:53am
AIR BLK	.00	11:54am
SUB TEST	.00	11:56am
AIR BLK	.00	11:57am

Reported AC: .00 g/210L

R E Hall

Signature of Chemical Analyst

Court CVR

Randy E Hall

Analyst

Intox EC/IR-II: Preventive Maintenance

ONslow COUNTY ONslow COUNTY SD 660

Serial Number: 008932 Test Record Number: 362
Test Date: 10/05/2009 Test Time: 11:57am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:57am
FLO	Pass	11:57am
FC	Pass	11:58am

Temperature Tests

Test	Status	Time
FC1	Pass	11:58am
SRC	Pass	11:58am
DET	Pass	11:58am
BAR	Pass	11:58am
BT	Pass	11:58am

Blank Tests

Test	Status	Time
AIR	Pass	11:58am


Printer Tests

Test	Status	Time
PRNT	Pass	11:58am

CRC Tests

Test	Status	Time
COMP	Pass	11:59am
CAL	Pass	11:59am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Carteret


Instrument Location Morehead City P.A.

Instrument Serial No. 008731

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 7 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Randy E. Hall

Signature of Certifying Official

354

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CARTERET COUNTY MOREHEAD CITY PD 150

Serial Number: 008731
Test Date: 10/07/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: HALL, RANDY E
Permit Number: 03462E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG91.0501
Exp Date: 04/15/2011


Test	g/210L	Time
DIAG	Pass	12:03pm
AIR BLK	.00	12:03pm
ACCY CHK	.08	12:04pm
AIR BLK	.00	12:05pm
SUB TEST	.00	12:05pm
AIR BLK	.00	12:06pm
SUB TEST	.00	12:08pm
AIR BLK	.00	12:08pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR.



Analyst

Intox EC/IR-II: Preventive Maintenance

CARTERET COUNTY MOREHEAD CITY PD 150

Serial Number: 008731 Test Record Number: 533
Test Date: 10/07/2009 Test Time: 12:09pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:09pm
FLO	Pass	12:09pm
FC	Pass	12:09pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:10pm
SRC	Pass	12:10pm
DET	Pass	12:10pm
BAR	Pass	12:10pm
BT	Pass	12:10pm

Blank Tests

Test	Status	Time
AIR	Pass	12:10pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:10pm

CRC Tests

Test	Status	Time
COMP	Pass	12:10pm
CAL	Pass	12:10pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Carteret Instrument Location Carteret County
Instrument Serial No. 008605 Sheriff's Office

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 7 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Randy E. Hall

Signature of Certifying Official

354

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CARTERET COUNTY CARTERET COUNTY SD 150

Serial Number: 008605
Test Date: 10/07/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: HALL, RANDY E
Permit Number: 03462E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG902901
Exp Date: 01/29/2011

Test	g/210L	Time
DIAG	Pass	12:44pm
AIR BLK	.00	12:44pm
ACCY CHK	.08	12:45pm
AIR BLK	.00	12:46pm
SUB TEST	.00	12:47pm
AIR BLK	.00	12:47pm
SUB TEST	.00	12:49pm
AIR BLK	.00	12:50pm

Reported AC: .00 g/210L

RE Hall

Signature of Chemical Analyst

Court CVR

Randy E Hall

Analyst

Intox EC/IR-II: Preventive Maintenance

CARTERET COUNTY CARTERET COUNTY SD 150

Serial Number: 008605 Test Record Number: 1322
Test Date: 10/07/2009 Test Time: 12:50pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:51pm
FLO	Pass	12:51pm
FC	Pass	12:51pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:51pm
SRC	Pass	12:51pm
DET	Pass	12:51pm
BAR	Pass	12:51pm
BT	Pass	12:51pm

Blank Tests

Test	Status	Time
AIR	Pass	12:51pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:51pm

CRC Tests

Test	Status	Time
COMP	Pass	12:52pm
CAL	Pass	12:52pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Carteret Instrument Location ATLANTIC BEACH P.D.

Instrument Serial No. 008785

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 9 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Raney E. Hall
Signature of Certifying Official

354
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CARTERET COUNTY ATLANTIC BEACH PD 150

Serial Number: 008785
Test Date: 10/09/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: HALL, RANDY E
Permit Number: 03462E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG910501
Exp Date: 04/15/2011

Test	g/210L	Time
DIAG	Pass	11:12am
AIR BLK	.00	11:12am
ACCY CHK	.08	11:13am
AIR BLK	.00	11:14am
SUB TEST	.00	11:14am
AIR BLK	.00	11:15am
SUB TEST	.00	11:17am
AIR BLK	.00	11:18am

Reported AC: .00 g/210L

R E Hall

Signature of Chemical Analyst

Court CVR.

Randy E Hall

Analyst

Intox EC/IR-II: Preventive Maintenance

CARTERET COUNTY ATLANTIC BEACH PD 150

Serial Number: 008785 Test Record Number: 273
Test Date: 10/09/2009 Test Time: 11:18am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:18am
FLO	Pass	11:18am
FC	Pass	11:18am

Temperature Tests

Test	Status	Time
FC1	Pass	11:19am
SRC	Pass	11:19am
DET	Pass	11:19am
BAR	Pass	11:19am
BT	Pass	11:19am

Blank Tests

Test	Status	Time
AIR	Pass	11:19am

Printer Tests

Test	Status	Time
PRNT	Pass	11:19am

CRC Tests

Test	Status	Time
COMP	Pass	11:19am
CAL	Pass	11:19am

Preventive Maintenance
Status: Pass

Randy E. Hall

Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County CARTERET


Instrument Location EMERALD ISLE P.D.

Instrument Serial No. 008620

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 9 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Randy E. Hall

Signature of Certifying Official

354

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CARTERET COUNTY EMERALD ISLE PD 150

Serial Number: 008620
Test Date: 10/09/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: HALL, RANDY E
Permit Number: 03462E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG910501
Exp Date: 04/15/2011

Test	g/210L	Time
DIAG	Pass	12:02pm
AIR BLK	.00	12:03pm
ACCY CHK	.08	12:03pm
AIR BLK	.00	12:04pm
SUB TEST	.00	12:05pm
AIR BLK	.00	12:06pm
SUB TEST	.00	12:07pm
AIR BLK	.00	12:08pm

Reported AC: .00 g/210L

R E Hall

Signature of Chemical Analyst

Court CVR.

Randy E Hall

Analyst

Intox EC/IR-II: Preventive Maintenance

CARTERET COUNTY EMERALD ISLE PD 150

Serial Number: 008620 Test Record Number: 840
Test Date: 10/09/2009 Test Time: 12:09pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:09pm
FLO	Pass	12:09pm
FC	Pass	12:09pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:09pm
SRC	Pass	12:09pm
DET	Pass	12:09pm
BAR	Pass	12:09pm
BT	Pass	12:09pm

Blank Tests

Test	Status	Time
AIR	Pass	12:10pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:10pm

CRC Tests

Test	Status	Time
COMP	Pass	12:10pm
CAL	Pass	12:10pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County CRAVEN Instrument Location CRAVEN County

Instrument Serial No. 008732 SHERIFF'S OFFICE

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Randy E. Hall

Signature of Certifying Official

354

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CRAVEN COUNTY CRAVEN COUNTY SD 240

Serial Number: 008732
Test Date: 10/15/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: HALL, RANDY E
Permit Number: 03462E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG910501
Exp Date: 04/15/2011

Test	g/210L	Time
DIAG	Pass	12:04pm
AIR BLK	.00	12:05pm
ACCY CHK	.08	12:05pm
AIR BLK	.00	12:06pm
SUB TEST	.00	12:06pm
AIR BLK	.00	12:07pm
SUB TEST	.00	12:09pm
AIR BLK	.00	12:10pm

Reported AC: .00 g/210L

RE Hall

Signature of Chemical Analyst

Court CVR.

Randy E Hall

Analyst

Intox EC/IR-II: Preventive Maintenance

CRAVEN COUNTY CRAVEN COUNTY SD 240

Serial Number: 008732 Test Record Number: 466
Test Date: 10/15/2009 Test Time: 12:10pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:11pm
FLO	Pass	12:11pm
FC	Pass	12:11pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:11pm
SRC	Pass	12:11pm
DET	Pass	12:11pm
BAR	Pass	12:11pm
BT	Pass	12:11pm

Blank Tests

Test	Status	Time
AIR	Pass	12:11pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:11pm

CRC Tests

Test	Status	Time
COMP	Pass	12:11pm
CAL	Pass	12:11pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County CRAVEN Instrument Location New Bern P.D.

Instrument Serial No. 008817

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Raney E. Hall
Signature of Certifying Official

354
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CRAVEN COUNTY NEW BERN PD 240

Serial Number: 008817
Test Date: 10/15/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: HALL, RANDY E
Permit Number: 03462E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG904902
Exp Date: 02/18/2011


Test	g/210L	Time
DIAG	Pass	12:38pm
AIR BLK	.00	12:39pm
ACCY CHK	.08	12:40pm
AIR BLK	.00	12:41pm
SUB TEST	.00	12:41pm
AIR BLK	.00	12:42pm
SUB TEST	.00	12:43pm
AIR BLK	.00	12:44pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

CRAVEN COUNTY NEW BERN PD 240

Serial Number: 008817 Test Record Number: 196
Test Date: 10/15/2009 Test Time: 12:45pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:45pm
FLO	Pass	12:45pm
FC	Pass	12:45pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:45pm
SRC	Pass	12:45pm
DET	Pass	12:45pm
BAR	Pass	12:45pm
BT	Pass	12:45pm

Blank Tests

Test	Status	Time
AIR	Pass	12:46pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:46pm

CRC Tests

Test	Status	Time
COMP	Pass	12:46pm
CAL	Pass	12:46pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Jones Instrument Location Jones County

Instrument Serial No. 008765 Sheriff's Office

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 19 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Randy E. Hall
Signature of Certifying Official

354
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

JONES COUNTY JONES COUNTY SD 510

Serial Number: 008705
Test Date: 10/19/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: HALL, RANDY E
Permit Number: 03462E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG910501
Exp Date: 04/15/2011

Test	g/210L	Time
DIAG	Pass	10:51am
AIR BLK	.00	10:52am
ACCY CHK	.08	10:53am
AIR BLK	.00	10:54am
SUB TEST	.00	10:54am
AIR BLK	.00	10:55am
SUB TEST	.00	10:56am
AIR BLK	.00	10:57am

Reported AC: .00 g/210L

RE Hall

Signature of Chemical Analyst

Court CVR

Randy E Hall

Analyst

Intox EC/IR-II: Preventive Maintenance

JONES COUNTY JONES COUNTY SD 510

Serial Number: 008705 Test Record Number: 493
Test Date: 10/19/2009 Test Time: 10:58am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:58am
FLO	Pass	10:58am
FC	Pass	10:58am

Temperature Tests

Test	Status	Time
FC1	Pass	10:58am
SRC	Pass	10:58am
DET	Pass	10:58am
BAR	Pass	10:58am
BT	Pass	10:58am

Blank Tests

Test	Status	Time
AIR	Pass	10:59am


Printer Tests

Test	Status	Time
PRNT	Pass	10:59am

CRC Tests

Test	Status	Time
COMP	Pass	10:59am
CAL	Pass	10:59am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Pamlico Instrument Location Pamlico County

Instrument Serial No. 008640 Sheriff's Office

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 19 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Randy E. Hall
Signature of Certifying Official

354
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

PAMLICO COUNTY PAMLICO COUNTY SD 680

Serial Number: 008640
Test Date: 10/19/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: HALL, RANDY E
Permit Number: 03462E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG910501
Exp Date: 04/15/2011


Test	g/210L	Time
DIAG	Pass	12:01pm
AIR BLK	.00	12:01pm
ACCY CHK	.08	12:02pm
AIR BLK	.00	12:03pm
SUB TEST	.00	12:03pm
AIR BLK	.00	12:04pm
SUB TEST	.00	12:06pm
AIR BLK	.00	12:07pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

PAMLICO COUNTY PAMLICO COUNTY SD 680

Serial Number: 008640 Test Record Number: 653
Test Date: 10/19/2009 Test Time: 12:07pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:07pm
FLO	Pass	12:07pm
FC	Pass	12:08pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:08pm
SRC	Pass	12:08pm
DET	Pass	12:08pm
BAR	Pass	12:08pm
BT	Pass	12:08pm

Blank Tests

Test	Status	Time
AIR	Pass	12:08pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:08pm

CRC Tests

Test	Status	Time
COMP	Pass	12:09pm
CAL	Pass	12:09pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Onslow Instrument Location Camp Lejeune PMO

Instrument Serial No. 008920

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 20 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Randy E. Hill

Signature of Certifying Official

354

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

ONslow COUNTY CAMP LEJEUNE PMO 660

Serial Number: 008920
Test Date: 10/20/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: HALL, RANDY E
Permit Number: 03462E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG910501
Exp Date: 04/15/2011

Test	g/210L	Time
DIAG	Pass	11:59am
AIR BLK	.00	11:59am
ACCY CHK	.08	12:00pm
AIR BLK	.00	12:01pm
SUB TEST	.00	12:01pm
AIR BLK	.00	12:02pm
SUB TEST	.00	12:03pm
AIR BLK	.00	12:04pm

Reported AC: .00 g/210L

R E Hall

Signature of Chemical Analyst

Court CVR

Randy E Hall

Analyst

Intox EC/IR-II: Preventive Maintenance

ONslow COUNTY CAMP LEJEUNE PMO 660

Serial Number: 008920 Test Record Number: 342
Test Date: 10/20/2009 Test Time: 12:05pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:05pm
FLO	Pass	12:05pm
FC	Pass	12:05pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:05pm
SRC	Pass	12:05pm
DET	Pass	12:05pm
BAR	Pass	12:05pm
BT	Pass	12:05pm

Blank Tests

Test	Status	Time
AIR	Pass	12:06pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:06pm

CRC Tests

Test	Status	Time
COMP	Pass	12:06pm
CAL	Pass	12:06pm

Preventive Maintenance
Status: *Pass*



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County ONslow Instrument Location MCA5 New River P110

Instrument Serial No. 008922

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 20 day of October, 20 09 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Raney E. Hall

Signature of Certifying Official

354

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

ONSLOW COUNTY MCAS NEW RIVER 660

Serial Number: 008922
Test Date: 10/20/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: HALL, RANDY E
Permit Number: 03462E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG904902
Exp Date: 02/18/2011

Test	g/210L	Time
DIAG	Pass	1:44pm
AIR BLK	.00	1:44pm
ACCY CHK	.08	1:45pm
AIR BLK	.00	1:46pm
SUB TEST	.00	1:46pm
AIR BLK	.00	1:47pm
SUB TEST	.00	1:48pm
AIR BLK	.00	1:49pm

Reported AC: .00 g/210L

RE Hall

Signature of Chemical Analyst

Court CVR

Randy E Hall

Analyst

Intox EC/IR-II: Preventive Maintenance

ONSLOW COUNTY MCAS NEW RIVER 660

Serial Number: 008922 Test Record Number: 130
Test Date: 10/20/2009 Test Time: 1:50pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:50pm
FLO	Pass	1:50pm
FC	Pass	1:50pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:50pm
SRC	Pass	1:50pm
DET	Pass	1:50pm
BAR	Pass	1:50pm
BT	Pass	1:50pm

Blank Tests

Test	Status	Time
AIR	Pass	1:51pm


Printer Tests

Test	Status	Time
PRNT	Pass	1:51pm

CRC Tests

Test	Status	Time
COMP	Pass	1:51pm
CAL	Pass	1:51pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County CRAVEN


Instrument Location MCHS CHERRY POINT PAIC

Instrument Serial No. 010819

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 21 day of October, 20 09 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Randy E. Hall

Signature of Certifying Official

354

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CRAVEN COUNTY MCAS CHERRY POINT 240

Serial Number: 010819
Test Date: 10/21/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: HALL, RANDY E
Permit Number: 03462E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG902603
Exp Date: 01/26/2011

Test	g/210L	Time
DIAG	Pass	11:01am
AIR BLK	.00	11:01am
ACCY CHK	.08	11:02am
AIR BLK	.00	11:03am
SUB TEST	.00	11:03am
AIR BLK	.00	11:04am
SUB TEST	.00	11:06am
AIR BLK	.00	11:07am

Reported AC: .00 g/210L

RE Hall

Signature of Chemical Analyst

Court CVR

Randy E Hall

Analyst

Intox EC/IR-II: Preventive Maintenance

CRAVEN COUNTY MCAS CHERRY POINT 240

Serial Number: 010819 Test Record Number: 79
Test Date: 10/21/2009 Test Time: 11:07am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:08am
FLO	Pass	11:08am
FC	Pass	11:08am

Temperature Tests

Test	Status	Time
FC1	Pass	11:08am
SRC	Pass	11:08am
DET	Pass	11:08am
BAR	Pass	11:08am
BT	Pass	11:08am

Blank Tests

Test	Status	Time
AIR	Pass	11:08am


Printer Tests

Test	Status	Time
PRNT	Pass	11:08am

CRC Tests

Test	Status	Time
COMP	Pass	11:09am
CAL	Pass	11:09am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County CRAVEN Instrument Location HAVELOCK A.D.

Instrument Serial No. 008819

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 21 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Randy E. Hall

Signature of Certifying Official

354

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CRAVEN COUNTY HAVELOCK PD 240

Serial Number: 008819
Test Date: 10/21/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: HALL, RANDY E
Permit Number: 03462E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG904902
Exp Date: 02/18/2011

Test	g/210L	Time
DIAG	Pass	11:58am
AIR BLK	.00	11:59am
ACCY CHK	.08	11:59am
AIR BLK	.00	12:00pm
SUB TEST	.00	12:01pm
AIR BLK	.00	12:02pm
SUB TEST	.00	12:03pm
AIR BLK	.00	12:04pm

Reported AC: .00 g/210L

RE Hall

Signature of Chemical Analyst

Court CVR

Randy E Hall

Analyst

Intox EC/IR-II: Preventive Maintenance

CRAVEN COUNTY HAVELOCK PD 240

Serial Number: 008819 Test Record Number: 104
Test Date: 10/21/2009 Test Time: 12:04pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:05pm
FLO	Pass	12:05pm
FC	Pass	12:05pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:05pm
SRC	Pass	12:05pm
DET	Pass	12:05pm
BAR	Pass	12:05pm
BT	Pass	12:05pm

Blank Tests

Test	Status	Time
AIR	Pass	12:06pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:06pm

CRC Tests

Test	Status	Time
COMP	Pass	12:06pm
CAL	Pass	12:06pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Halifax Instrument Location BATIMOBILE UNIT #5
Instrument Serial No. 008788 WALDON

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 17th day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Steph C. Thomas
Signature of Certifying Official

636
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Preventive Maintenance

HALIFAX COUNTY BAT MOBILE UNIT 5 410

Serial Number: 008788 Test Record Number: 275
Test Date: 10/17/2009 Test Time: 9:25pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	9:25pm
FLO	Pass	9:25pm
FC	Pass	9:26pm

Temperature Tests

Test	Status	Time
FC1	Pass	9:26pm
SRC	Pass	9:26pm
DET	Pass	9:26pm
BAR	Pass	9:26pm
BT	Pass	9:26pm

Blank Tests

Test	Status	Time
AIR	Pass	9:26pm


Printer Tests

Test	Status	Time
PRNT	Pass	9:26pm

CRC Tests

Test	Status	Time
COMP	Pass	9:27pm
CAL	Pass	9:27pm

Preventive Maintenance
Status: Pass



Analyst

Intox EC/IR-II: Subject Test

HALIFAX COUNTY BAT MOBILE UNIT 5 410

Serial Number: 008788
Test Date: 10/17/2009

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: MORGART, STEPHEN G
Permit Number: 09372E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG904903
Exp Date: 02/18/2011

Test	g/210L	Time
DIAG	Pass	9:14pm
AIR BLK	.00	9:15pm
ACCY CHK	.08	9:16pm
AIR BLK	.00	9:17pm
SUB TEST	.00	9:18pm
AIR BLK	.00	9:19pm
SUB TEST	.00	9:22pm
AIR BLK	.00	9:23pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Camden Instrument Location Camden Co. S.O.

Instrument Serial No. 008940 113 Hwy 343, Camden, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15th day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Kelly [Signature]
Signature of Certifying Official

643
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CAMDEN COUNTY CAMDEN CO SO 140

Serial Number: 008940
Test Date: 10/15/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: GUARD, KELLY G
Permit Number: 12955E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG916602
Exp Date: 06/15/2011

Test	g/210L	Time
DIAG	Pass	12:21pm
AIR BLK	.00	12:22pm
ACCY CHK	.08	12:23pm
AIR BLK	.00	12:24pm
SUB TEST	.00	12:24pm
AIR BLK	.00	12:25pm
SUB TEST	.00	12:27pm
AIR BLK	.00	12:27pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

CAMDEN COUNTY CAMDEN CO SO 140

Serial Number: 008940 Test Record Number: 161
Test Date: 10/15/2009 Test Time: 12:29pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:29pm
FLO	Pass	12:29pm
FC	Pass	12:29pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:29pm
SRC	Pass	12:29pm
DET	Pass	12:29pm
BAR	Pass	12:29pm
BT	Pass	12:29pm

Blank Tests

Test	Status	Time
AIR	Pass	12:30pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:30pm

CRC Tests

Test	Status	Time
COMP	Pass	12:30pm
CAL	Pass	12:30pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Currituck Instrument Location Currituck Co. S.O.

Instrument Serial No. 008947 407-A Maple Rd., Maple, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15th day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Kelly M. P.

Signature of Certifying Official

643

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CURRITUCK COUNTY CURRITUCK SO-MAPLE
260

Serial Number: 008947
Test Date: 10/15/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: GUARD, KELLY G
Permit Number: 12955E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG916602
Exp Date: 06/15/2011

Test	g/210L	Time
DIAG	Pass	11:44am
AIR BLK	.00	11:45am
ACCY CHK	.08	11:45am
AIR BLK	.00	11:46am
SUB TEST	.00	11:47am
AIR BLK	.00	11:48am
SUB TEST	.00	11:50am
AIR BLK	.00	11:50am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007

Intox EC/IR-II: Preventive Maintenance

CURRITUCK COUNTY CURRITUCK SO-MAPLE 260

Serial Number: 008947 Test Record Number: 365
Test Date: 10/15/2009 Test Time: 11:52am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:52am
FLO	Pass	11:52am
FC	Pass	11:52am

Temperature Tests

Test	Status	Time
FC1	Pass	11:52am
SRC	Pass	11:52am
DET	Pass	11:52am
BAR	Pass	11:52am
BT	Pass	11:52am

Blank Tests

Test	Status	Time
AIR	Pass	11:53am

Printer Tests

Test	Status	Time
PRNT	Pass	11:53am

CRC Tests

Test	Status	Time
COMP	Pass	11:53am
CAL	Pass	11:53am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County P.H. Instrument Location Ayden Police Dept.
Instrument Serial No. 008666 4144 West Ave., Ayden, NC 28513

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13th day of October, 20 09 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Kelly SA
Signature of Certifying Official

643
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

PITT AYDEN PD 730

Serial Number: 008666
Test Date: 10/13/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: *Male*
Driver's License State: *XX*
Driver's License Number: *NONE*

Analyst's Name: *GUARD, KELLY G*
Permit Number: *12955E*
Effective:
12/01/2007-12/01/2009

Officer's Name: *NONE, NONE*
Type of Agency: *FTA*
Agency: *DHHS*
Test Type: *Breath Test*

Lot Number: AG910601
Exp Date: 04/16/2011

Test	g/210L	Time
DIAG	Pass	2:50pm
AIR BLK	.00	2:51pm
ACCY CHK	.08	2:52pm
AIR BLK	.00	2:53pm
SUB TEST	.00	2:53pm
AIR BLK	.00	2:54pm
SUB TEST	.00	2:56pm
AIR BLK	.00	2:56pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

PITT AYDEN PD 730

Serial Number: 008666 Test Record Number: 345
Test Date: 10/13/2009 Test Time: 2:58pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:58pm
FLO	Pass	2:58pm
FC	Pass	2:58pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:58pm
SRC	Pass	2:58pm
DET	Pass	2:58pm
BAR	Pass	2:58pm
BT	Pass	2:58pm

Blank Tests

Test	Status	Time
AIR	Pass	2:59pm


Printer Tests

Test	Status	Time
PRNT	Pass	2:59pm

CRC Tests

Test	Status	Time
COMP	Pass	2:59pm
CAL	Pass	2:59pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Moore Instrument Location BAT Mobile Unit 4

Instrument Serial No. 008871

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 17th day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Daniel T. Inoué
Signature of Certifying Official

651
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Preventive Maintenance

MOORE COUNTY BAT MOBILE UNIT 4 620

Serial Number: 008871 Test Record Number: 196
Test Date: 10/17/2009 Test Time: 8:18pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	8:18pm
FLO	Pass	8:18pm
FC	Pass	8:18pm

Temperature Tests

Test	Status	Time
FC1	Pass	8:18pm
SRC	Pass	8:18pm
DET	Pass	8:18pm
BAR	Pass	8:18pm
BT	Pass	8:18pm

Blank Tests

Test	Status	Time
AIR	Pass	8:19pm


Printer Tests

Test	Status	Time
PRNT	Pass	8:19pm

CRC Tests

Test	Status	Time
COMP	Pass	8:19pm
CAL	Pass	8:19pm

Preventive Maintenance
Status: Pass


Analyst

Intox EC/IR-II: Subject Test

MOORE COUNTY BAT MOBILE UNIT 4 620

Serial Number: 008871
Test Date: 10/17/2009

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: TRUDELL, SR., DANIEL T
Permit Number: 21535E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG816303
Exp Date: 06/11/2010

Test	g/210L	Time
DIAG	Pass	8:09pm
AIR BLK	.00	8:10pm
ACCY CHK	.07	8:11pm
AIR BLK	.00	8:11pm
SUB TEST	.00	8:12pm
AIR BLK	.00	8:13pm
SUB TEST	.00	8:14pm
AIR BLK	.00	8:15pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County MOORE Instrument Location ROBBINS POLICE DEPT.

Instrument Serial No. 008728 Robbins NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 14 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

371
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MOORE ROBBINS PD 620

Serial Number: 008728
Test Date: 10/14/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: RUSSELL, LARRY H
Permit Number: 06108E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG910601
Exp Date: 04/16/2011


Test	g/210L	Time
DIAG	Pass	2:15pm
AIR BLK	.00	2:16pm
ACCY CHK	.08	2:16pm
AIR BLK	.00	2:17pm
SUB TEST	.00	2:18pm
AIR BLK	.00	2:19pm
SUB TEST	.00	2:20pm
AIR BLK	.00	2:21pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR.



Analyst

Intox EC/IR-II: Preventive Maintenance

MOORE ROBBINS PD 620

Serial Number: 008728 Test Record Number: 124
Test Date: 10/14/2009 Test Time: 2:23pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:23pm
FLO	Pass	2:23pm
FC	Pass	2:24pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:24pm
SRC	Pass	2:24pm
DET	Pass	2:24pm
BAR	Pass	2:24pm
BT	Pass	2:24pm

Blank Tests

Test	Status	Time
AIR	Pass	2:24pm


Printer Tests

Test	Status	Time
PRNT	Pass	2:24pm

CRC Tests

Test	Status	Time
COMP	Pass	2:25pm
CAL	Pass	2:25pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County MOORE Instrument Location MOORE CO. JAIL

Instrument Serial No. 008735 CARRHAGE, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



R. H. Russell
Signature of Certifying Official

371
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MOORE COUNTY MOORE COUNTY JAIL 620

Serial Number: 008735
Test Date: 10/13/2009

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: RUSSELL, LARRY H

Permit Number: 06108E

Effective:

12/01/2007-12/01/2009

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG902603

Exp Date: 01/26/2011


Test	g/210L	Time
DIAG	Pass	12:46pm
AIR BLK	.00	12:46pm
ACCY CHK	.08	12:47pm
AIR BLK	.00	12:48pm
SUB TEST	.00	12:48pm
AIR BLK	.00	12:49pm
SUB TEST	.00	12:51pm
AIR BLK	.00	12:51pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

MOORE COUNTY MOORE COUNTY JAIL 620

Serial Number: 008735 Test Record Number: 474
Test Date: 10/13/2009 Test Time: 12:52pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:53pm
FLO	Pass	12:53pm
FC	Pass	12:53pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:53pm
SRC	Pass	12:53pm
DET	Pass	12:53pm
BAR	Pass	12:53pm
BT	Pass	12:53pm

Blank Tests

Test	Status	Time
AIR	Pass	12:54pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:54pm

CRC Tests

Test	Status	Time
COMP	Pass	12:54pm
CAL	Pass	12:54pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Marion Instrument Location Marion Co. S.O.

Instrument Serial No. 008912 305 E. Main St, Williamston, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 12th day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Kelle M. D.
Signature of Certifying Official

643
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MARTIN COUNTY SHERIFF'S OFFICE 570

Serial Number: 008912
Test Date: 10/12/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: GUARD, KELLY G
Permit Number: 12955E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG809301
Exp Date: 04/02/2010

Test	g/210L	Time
DIAG	Pass	10:58am
AIR BLK	.00	10:59am
ACCY CHK	.07	11:00am
AIR BLK	.00	11:01am
SUB TEST	.00	11:01am
AIR BLK	.00	11:02am
SUB TEST	.00	11:04am
AIR BLK	.00	11:04am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

MARTIN COUNTY SHERIFF'S OFFICE 570

Serial Number: 008912 Test Record Number: 224
Test Date: 10/12/2009 Test Time: 11:06am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:06am
FLO	Pass	11:06am
FC	Pass	11:06am

Temperature Tests

Test	Status	Time
FC1	Pass	11:06am
SRC	Pass	11:06am
DET	Pass	11:06am
BAR	Pass	11:06am
BT	Pass	11:06am

Blank Tests

Test	Status	Time
AIR	Pass	11:07am


Printer Tests

Test	Status	Time
PRNT	Pass	11:07am

CRC Tests

Test	Status	Time
COMP	Pass	11:07am
CAL	Pass	11:07am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Martin Instrument Location Martin Co S.D.

Instrument Serial No. 008879 305 E. Main St., Williamston, N.C.

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 12th day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Kelly M. O.
Signature of Certifying Official

643
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MARTIN COUNTY SHERIFF'S OFFICE 570

Serial Number: 008879
Test Date: 10/12/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: GUARD, KELLY G
Permit Number: 12955E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG809301
Exp Date: 04/02/2010


Test	g/210L	Time
DIAG	Pass	10:42am
AIR BLK	.00	10:43am
ACCY CHK	.07	10:43am
AIR BLK	.00	10:44am
SUB TEST	.00	10:45am
AIR BLK	.00	10:45am
SUB TEST	.00	10:47am
AIR BLK	.00	10:48am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

MARTIN COUNTY SHERIFF'S OFFICE 570

Serial Number: 008879 Test Record Number: 136
Test Date: 10/12/2009 Test Time: 10:49am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:50am
FLO	Pass	10:50am
FC	Pass	10:50am

Temperature Tests

Test	Status	Time
FC1	Pass	10:50am
SRC	Pass	10:50am
DET	Pass	10:50am
BAR	Pass	10:50am
BT	Pass	10:50am

Blank Tests

Test	Status	Time
AIR	Pass	10:50am


Printer Tests

Test	Status	Time
PRNT	Pass	10:51am

CRC Tests

Test	Status	Time
COMP	Pass	10:51am
CAL	Pass	10:51am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Surry Instrument Location Police Museum P.O.

Instrument Serial No. 8938

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 2 day of October, 2007 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

632
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

SURRY COUNTY PILOT MOUNTAIN PD 850

Serial Number: 008938

Test Date: 10/02/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: WEAVER, GEORGE A

Permit Number: 09442E

Effective:

12/01/2007-12/01/2009

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG904902


Exp Date: 02/18/2011

Test	g/210L	Time
DIAG	Pass	4:30pm
AIR BLK	.00	4:31pm
ACCY CHK	.08	4:32pm
AIR BLK	.00	4:32pm
SUB TEST	.00	4:33pm
AIR BLK	.00	4:34pm
SUB TEST	.00	4:36pm
AIR BLK	.00	4:36pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

SURRY COUNTY PILOT MOUNTAIN PD 850

Serial Number: 008938 Test Record Number: 166
Test Date: 10/02/2009 Test Time: 4:44pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	4:45pm
FLO	Pass	4:45pm
FC	Pass	4:45pm

Temperature Tests

Test	Status	Time
FC1	Pass	4:45pm
SRC	Pass	4:45pm
DET	Pass	4:45pm
BAR	Pass	4:45pm
BT	Pass	4:45pm

Blank Tests

Test	Status	Time
AIR	Pass	4:46pm


Printer Tests

Test	Status	Time
PRNT	Pass	4:46pm

CRC Tests

Test	Status	Time
COMP	Pass	4:46pm
CAL	Pass	4:46pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Rockingham Instrument Location Madison A.D.

Instrument Serial No. 008812

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 9 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

632
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

ROCKINGHAM COUNTY MADISON PD 780

Serial Number: 008802
Test Date: 10/09/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: WEAVER, GEORGE A
Permit Number: 09442E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG904902
Exp Date: 02/18/2011

Test	g/210L	Time
DIAG	Pass	11:24am
AIR BLK	.00	11:25am
ACCY CHK	.07	11:26am
AIR BLK	.00	11:27am
SUB TEST	.00	11:27am
AIR BLK	.00	11:28am
SUB TEST	.00	11:30am
AIR BLK	.00	11:31am

Reported AC: .00/ g/210L


Signature of Chemical Analyst

Court CVR


Analyst

This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007

Intox EC/IR-II: Preventive Maintenance

ROCKINGHAM COUNTY MADISON PD 780

Serial Number: 008802 Test Record Number: 224
Test Date: 10/09/2009 Test Time: 11:32am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:32am
FLO	Pass	11:32am
FC	Pass	11:32am

Temperature Tests

Test	Status	Time
FC1	Pass	11:32am
SRC	Pass	11:32am
DET	Pass	11:32am
BAR	Pass	11:32am
BT	Pass	11:32am

Blank Tests

Test	Status	Time
AIR	Pass	11:33am

Printer Tests

Test	Status	Time
PRNT	Pass	11:33am

CRC Tests

Test	Status	Time
COMP	Pass	11:33am
CAL	Pass	11:33am

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Surry Instrument Location Surry Co Jail

Instrument Serial No. 008934

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 2 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

632
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

SURRY COUNTY SURRY CO JAIL 850

Serial Number: 008934
Test Date: 10/02/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: *WEAVER, GEORGE A*
Permit Number: 09442E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG904902
Exp Date: 02/18/2011

Test	g/210L	Time
DIAG	Pass	6:11pm
AIR BLK	.00	6:12pm
ACCY CHK	.08	6:13pm
AIR BLK	.00	6:14pm
SUB TEST	.00	6:14pm
AIR BLK	.00	6:15pm
SUB TEST	.00	6:17pm
AIR BLK	.00	6:18pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

SURRY COUNTY SURRY CO JAIL 850

Serial Number: 008934 Test Record Number: 400
Test Date: 10/02/2009 Test Time: 6:18pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	6:19pm
FLO	Pass	6:19pm
FC	Pass	6:19pm

Temperature Tests

Test	Status	Time
FC1	Pass	6:19pm
SRC	Pass	6:19pm
DET	Pass	6:19pm
BAR	Pass	6:19pm
BT	Pass	6:19pm

Blank Tests

Test	Status	Time
AIR	Pass	6:20pm

Printer Tests

Test	Status	Time
PRNT	Pass	6:20pm

CRC Tests

Test	Status	Time
COMP	Pass	6:20pm
CAL	Pass	6:20pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County SURRY


Instrument Location MOORE AINLEY P.D.

Instrument Serial No. 008943

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 2 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

632
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

SURRY COUNTY MOUNT AIRY PD 850

Serial Number: 008943
Test Date: 10/02/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: *WEAVER, GEORGE A*
Permit Number: 09442E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: *Breath Test*

Lot Number: AG825401
Exp Date: 09/10/2010

Test	g/210L	Time
DIAG	Pass	5:14pm
AIR BLK	.00	5:15pm
ACCY CHK	.08	5:16pm
AIR BLK	.00	5:16pm
SUB TEST	.00	5:17pm
AIR BLK	.00	5:19pm
SUB TEST	.00	5:19pm
AIR BLK	.00	5:20pm

Reported AC *.00* g/210L


Signature of Chemical Analyst

Court CVR


Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

SURRY COUNTY MOUNT AIRY PD 850

Serial Number: 008943 Test Record Number: 475
Test Date: 10/02/2009 Test Time: 5:22pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	5:22pm
FLO	Pass	5:22pm
FC	Pass	5:22pm

Temperature Tests

Test	Status	Time
FC1	Pass	5:22pm
SRC	Pass	5:22pm
DET	Pass	5:22pm
BAR	Pass	5:22pm
BT	Pass	5:22pm

Blank Tests

Test	Status	Time
AIR	Pass	5:23pm


Printer Tests

Test	Status	Time
PRNT	Pass	5:23pm

CRC Tests

Test	Status	Time
COMP	Pass	5:23pm
CAL	Pass	5:23pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County NASH Instrument Location NASH CO. JAIL

Instrument Serial No. 008630 NASHVILLE, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 7 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

652
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

NASH COUNTY NASH COUNTY JAIL 630

Serial Number: 008630

Test Date: 10/07/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name:

QUARANTELLA, NICHOLAS J

Permit Number: 21536E

Effective:

01/01/2008-01/01/2010

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG901901


Exp Date: 01/19/2011

Test	g/210L	Time
DIAG	Pass	12:54pm
AIR BLK	.00	12:55pm
ACCY CHK	.08	12:55pm
AIR BLK	.00	12:56pm
SUB TEST	.00	12:57pm
AIR BLK	.00	12:58pm
SUB TEST	.00	12:59pm
AIR BLK	.00	1:00pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

NASH COUNTY NASH COUNTY JAIL 630

Serial Number: 008630 Test Record Number: 1235
Test Date: 10/07/2009 Test Time: 1:01pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:01pm
FLO	Pass	1:01pm
FC	Pass	1:01pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:01pm
SRC	Pass	1:01pm
DET	Pass	1:01pm
BAR	Pass	1:01pm
BT	Pass	1:01pm

Blank Tests

Test	Status	Time
AIR	Pass	1:02pm


Printer Tests

Test	Status	Time
PRNT	Pass	1:02pm

CRC Tests

Test	Status	Time
COMP	Pass	1:02pm
CAL	Pass	1:02pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Wake Instrument Location SHP BAT Unit

Instrument Serial No. 008910

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 7TH day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Steph B. Thomas
Signature of Certifying Official

636
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Preventive Maintenance

SHP BAT MOBILE UNIT WAKE COUNTY 910

Serial Number: 008910 Test Record Number: 83
Test Date: 10/07/2009 Test Time: 2:04pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:05pm
FLO	Pass	2:05pm
FC	Pass	2:05pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:05pm
SRC	Pass	2:05pm
DET	Pass	2:05pm
BAR	Pass	2:05pm
BT	Pass	2:05pm

Blank Tests

Test	Status	Time
AIR	Pass	2:06pm


Printer Tests

Test	Status	Time
PRNT	Pass	2:06pm

CRC Tests

Test	Status	Time
COMP	Pass	2:06pm
CAL	Pass	2:06pm

Preventive Maintenance
Status: Pass



Analyst

Intox EC/IR-II: Subject Test

SHP BAT MOBILE UNIT WAKE COUNTY 910

Serial Number: 008910
Test Date: 10/07/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: *MORGART, STEPHEN G*
Permit Number: 09372E
Effective:
12/01/2007-12/01/2009

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG825401
Exp Date: 09/10/2010

Test	g/210L	Time
DIAG	Pass	1:46pm
AIR BLK	.00	1:47pm
ACCY CHK	.07	1:48pm
AIR BLK	.00	1:48pm
SUB TEST	.00	1:49pm
AIR BLK	.00	1:50pm
SUB TEST	.00	1:52pm
AIR BLK	.00	1:53pm

Reported AC: .00 g/210L

Steph G. Morgart
Signature of Chemical Analyst

Court CVR

Steph G. Morgart
Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County GUILFORD Instrument Location BAT MOBILE UNIT 3
Instrument Serial No. 008647 GREENSBORO, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 02 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alvin R. Benson
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

GUILFORD COUNTY BAT MOBILE UNIT 3 400

Serial Number: 008647
Test Date: 10/02/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R

Permit Number: 15671E

Effective:

10/01/2009-10/01/2011

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG904903


Exp Date: 02/18/2011

Test	g/210L	Time
DIAG	Pass	11:30pm
AIR BLK	.00	11:31pm
ACCY CHK	.08	11:31pm
AIR BLK	.00	11:32pm
SUB TEST	.00	11:33pm
AIR BLK	.00	11:34pm
SUB TEST	.00	11:35pm
AIR BLK	.00	11:36pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

GUILFORD COUNTY BAT MOBILE UNIT 3 400

Serial Number: 008647 Test Record Number: 626
Test Date: 10/02/2009 Test Time: 11:36pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:37pm
FLO	Pass	11:37pm
FC	Pass	11:37pm

Temperature Tests

Test	Status	Time
FC1	Pass	11:37pm
SRC	Pass	11:37pm
DET	Pass	11:37pm
BAR	Pass	11:37pm
BT	Pass	11:37pm

Blank Tests

Test	Status	Time
AIR	Pass	11:37pm


Printer Tests

Test	Status	Time
PRNT	Pass	11:38pm

CRC Tests

Test	Status	Time
COMP	Pass	11:38pm
CAL	Pass	11:38pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II


County GUILFORD Instrument Location BAT MOBILE UNIT 3

Instrument Serial No. 008707 GREENSBORO, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 07 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alvin R. Bandy
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

GUILFORD COUNTY BAT MOBILE UNIT 3 400

Serial Number: 008707

Test Date: 10/02/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R

Permit Number: 15671E

Effective:

10/01/2009-10/01/2011

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG902001

Exp Date: 01/20/2011

Test	g/210L	Time
DIAG	Pass	11:36pm
AIR BLK	.00	11:37pm
ACCY CHK	.08	11:37pm
AIR BLK	.00	11:38pm
SUB TEST	.00	11:38pm
AIR BLK	.00	11:39pm
SUB TEST	.00	11:41pm
AIR BLK	.00	11:42pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

GUILFORD COUNTY BAT MOBILE UNIT 3 400

Serial Number: 008707 Test Record Number: 441
Test Date: 10/02/2009 Test Time: 11:42pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:42pm
FLO	Pass	11:42pm
FC	Pass	11:43pm

Temperature Tests

Test	Status	Time
FC1	Pass	11:43pm
SRC	Pass	11:43pm
DET	Pass	11:43pm
BAR	Pass	11:43pm
BT	Pass	11:43pm

Blank Tests

Test	Status	Time
AIR	Pass	11:43pm


Printer Tests

Test	Status	Time
PRNT	Pass	11:43pm

CRC Tests

Test	Status	Time
COMP	Pass	11:43pm
CAL	Pass	11:43pm

Preventive Maintenance
Status: *Pass*



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County GUILFORD Instrument Location BAT MOBILE UNIT 3

Instrument Serial No. 008616 GREENSBORO, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 02 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Alan R. Bann
Signature of Certifying Official

648
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

GUILFORD COUNTY BAT MOBILE UNIT 3 400

Serial Number: 008616
Test Date: 10/02/2009

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: BARNES, ALVIN R

Permit Number: 15671E

Effective:

10/01/2009-10/01/2011

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG904903


Exp Date: 02/18/2011

Test	g/210L	Time
DIAG	Pass	10:04pm
AIR BLK	.00	10:05pm
ACCY CHK	.08	10:06pm
AIR BLK	.00	10:07pm
SUB TEST	.00	10:07pm
AIR BLK	.00	10:08pm
SUB TEST	.00	10:10pm
AIR BLK	.00	10:11pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007

Intox EC/IR-II: Preventive Maintenance

GUILFORD COUNTY BAT MOBILE UNIT 3 400

Serial Number: 008616 Test Record Number: 646
Test Date: 10/02/2009 Test Time: 10:15pm EDT

System Check: Passed

Baseline Tests

Test	Status	Time
IR	Pass	10:16pm
FLO	Pass	10:16pm
FC	Pass	10:16pm

Temperature Tests

Test	Status	Time
FC1	Pass	10:16pm
SRC	Pass	10:16pm
DET	Pass	10:16pm
BAR	Pass	10:16pm
BT	Pass	10:16pm

Blank Tests

Test	Status	Time
AIR	Pass	10:17pm


Printer Tests

Test	Status	Time
PRNT	Pass	10:17pm

CRC Tests

Test	Status	Time
COMP	Pass	10:17pm
CAL	Pass	10:17pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Wake Instrument Location SHP BAT Unit

Instrument Serial No. 208929

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 7TH day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

686
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY SHP BAT UNIT 910

Serial Number: 008929 Test Record Number: 183
Test Date: 10/07/2009 Test Time: 2:39pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	2:39pm
FLO	Pass	2:39pm
FC	Pass	2:39pm

Temperature Tests

Test	Status	Time
FC1	Pass	2:40pm
SRC	Pass	2:40pm
DET	Pass	2:40pm
BAR	Pass	2:40pm
BT	Pass	2:40pm

Blank Tests

Test	Status	Time
AIR	Pass	2:40pm


Printer Tests

Test	Status	Time
PRNT	Pass	2:40pm

CRC Tests

Test	Status	Time
COMP	Pass	2:40pm
CAL	Pass	2:40pm

Preventive Maintenance
Status: Pass



Analyst

Intox EC/IR-II: Subject Test

WAKE COUNTY SHP BAT UNIT 910

Serial Number: 008929
Test Date: 10/07/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: MORGART, STEPHEN G

Permit Number: 09372E

Effective:

12/01/2007-12/01/2009

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG904903

Exp Date: 02/18/2011


Test	g/210L	Time
DIAG	Pass	1:45pm
AIR BLK	.00	1:46pm
ACCY CHK	.08	1:46pm
AIR BLK	.00	1:47pm
SUB TEST	.00	1:48pm
AIR BLK	.00	1:49pm
SUB TEST	.00	1:50pm
AIR BLK	.00	1:51pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II

County WAKE Instrument Location BAT MOBILE UNIT #5
Instrument Serial No. 008600 MORRISVILLE

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 2nd day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature] 636
Signature of Certifying Official Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY BAT MOBILE UNIT 5 910

Serial Number: 008600 Test Record Number: 541
Test Date: 10/02/2009 Test Time: 9:14pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	9:14pm
FLO	Pass	9:14pm
FC	Pass	9:14pm

Temperature Tests

Test	Status	Time
FC1	Pass	9:14pm
SRC	Pass	9:14pm
DET	Pass	9:14pm
BAR	Pass	9:14pm
BT	Pass	9:14pm

Blank Tests

Test	Status	Time
AIR	Pass	9:15pm


Printer Tests

Test	Status	Time
PRNT	Pass	9:15pm

CRC Tests

Test	Status	Time
COMP	Pass	9:15pm
CAL	Pass	9:15pm

Preventive Maintenance
Status: Pass



Analyst

Intox EC/IR-II: Subject Test

WAKE COUNTY BAT MOBILE UNIT 5 910

Serial Number: 008600

Test Date: 10/02/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: MORGART, STEPHEN G

Permit Number: 09372E

Effective:

12/01/2007-12/01/2009

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG920302


Exp Date: 07/22/2011

Test	g/210L	Time
DIAG	Pass	9:04pm
AIR BLK	.00	9:05pm
ACCY CHK	.08	9:06pm
AIR BLK	.00	9:06pm
SUB TEST	.00	9:07pm
AIR BLK	.00	9:08pm
SUB TEST	.00	9:10pm
AIR BLK	.00	9:11pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH


**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Wake Instrument Location BAA Mobile Unit #15
Morrisville
Instrument Serial No. 008788

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 2nd day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official 636
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY BAT MOBILE UNIT 5 910

Serial Number: 008788 Test Record Number: 271
Test Date: 10/02/2009 Test Time: 9:11pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	9:11pm
FLO	Pass	9:11pm
FC	Pass	9:11pm

Temperature Tests

Test	Status	Time
FC1	Pass	9:12pm
SRC	Pass	9:12pm
DET	Pass	9:12pm
BAR	Pass	9:12pm
BT	Pass	9:12pm

Blank Tests

Test	Status	Time
AIR	Pass	9:12pm


Printer Tests

Test	Status	Time
PRNT	Pass	9:12pm

CRC Tests

Test	Status	Time
COMP	Pass	9:12pm
CAL	Pass	9:12pm

Preventive Maintenance
Status: Pass



Analyst

Intox EC/IR-II: Subject Test

WAKE COUNTY BAT MOBILE UNIT 5 910

Serial Number: 008788
Test Date: 10/02/2009

Citation Number: M0000000-0
Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: MORGART, STEPHEN G

Permit Number: 09372E

Effective:

12/01/2007-12/01/2009

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG904903


Exp Date: 02/18/2011

Test	g/210L	Time
DIAG	Pass	9:02pm
AIR BLK	.00	9:03pm
ACCY CHK	.08	9:03pm
AIR BLK	.00	9:04pm
SUB TEST	.00	9:05pm
AIR BLK	.00	9:06pm
SUB TEST	.00	9:07pm
AIR BLK	.00	9:08pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County VANCE Instrument Location VANCE CO. SHERIFF'S DEPT

Instrument Serial No. 008937 156 CHURCH ST. HENDERSON, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 05 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Bruce D. Smith
Signature of Certifying Official

637
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

VANCE COUNTY SHERIFF'S DEPARTMENT 900

Serial Number: 008937
Test Date: 10/05/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: SMITH, BRIAN D
Permit Number: 08937E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG901901
Exp Date: 01/19/2011

Test	g/210L	Time
DIAG	Pass	9:22am
AIR BLK	.00	9:23am
ACCY CHK	.08	9:23am
AIR BLK	.00	9:24am
SUB TEST	.00	9:25am
AIR BLK	.00	9:26am
SUB TEST	.00	9:27am
AIR BLK	.00	9:28am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

VANCE COUNTY SHERIFF'S DEPARTMENT 900

Serial Number: 008937 Test Record Number: 480
Test Date: 10/05/2009 Test Time: 9:29am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	9:29am
FLO	Pass	9:29am
FC	Pass	9:29am

Temperature Tests

Test	Status	Time
FC1	Pass	9:29am
SRC	Pass	9:29am
DET	Pass	9:29am
BAR	Pass	9:29am
BT	Pass	9:29am

Blank Tests

Test	Status	Time
AIR	Pass	9:30am

Printer Tests

Test	Status	Time
PRNT	Pass	9:30am

CRC Tests

Test	Status	Time
COMP	Pass	9:30am
CAL	Pass	9:30am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County VANCE Instrument Location VANCE CO. SHERIFF'S DEPT

Instrument Serial No. 008870 156 CHURCH ST. HENDERSON, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 05 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Brian D. Smith
Signature of Certifying Official

637
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

VANCE COUNTY SHERIFF'S DEPARTMENT 900

Serial Number: 008870
Test Date: 10/05/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: SMITH, BRIAN D
Permit Number: 08937E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG902603
Exp Date: 01/26/2011


Test	g/210L	Time
DIAG	Pass	9:23am
AIR BLK	.00	9:24am
ACCY CHK	.08	9:24am
AIR BLK	.00	9:25am
SUB TEST	.00	9:26am
AIR BLK	.00	9:27am
SUB TEST	.00	9:28am
AIR BLK	.00	9:29am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR.



Analyst

Intox EC/IR-II: Preventive Maintenance

VANCE COUNTY SHERIFF'S DEPARTMENT 900

Serial Number: 008870 Test Record Number: 150
Test Date: 10/05/2009 Test Time: 9:31am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	9:31am
FLO	Pass	9:31am
FC	Pass	9:31am

Temperature Tests

Test	Status	Time
FC1	Pass	9:31am
SRC	Pass	9:31am
DET	Pass	9:31am
BAR	Pass	9:31am
BT	Pass	9:31am

Blank Tests

Test	Status	Time
AIR	Pass	9:32am


Printer Tests

Test	Status	Time
PRNT	Pass	9:32am

CRC Tests

Test	Status	Time
COMP	Pass	9:32am
CAL	Pass	9:32am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County Craven


Instrument Location BAT mobile unit

Instrument Serial No. 008898

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 2 day of OCT, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



K.C. [Signature]
Signature of Certifying Official

601
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Preventive Maintenance

CRAVEN COUNTY BAT MOBILE UNIT 6 240

Serial Number: 008898 Test Record Number: 329
Test Date: 10/02/2009 Test Time: 11:41pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:42pm
FLO	Pass	11:42pm
FC	Pass	11:42pm

Temperature Tests

Test	Status	Time
FC1	Pass	11:42pm
SRC	Pass	11:42pm
DET	Pass	11:42pm
BAR	Pass	11:42pm
BT	Pass	11:42pm

Blank Tests

Test	Status	Time
AIR	Pass	11:43pm

Printer Tests

Test	Status	Time
PRNT	Pass	11:43pm

CRC Tests

Test	Status	Time
COMP	Pass	11:43pm
CAL	Pass	11:43pm

Preventive Maintenance
Status: Pass



Analyst

Intox EC/IR-II: Subject Test

CRAVEN COUNTY BAT MOBILE UNIT 6 240

Serial Number: 008898
Test Date: 10/02/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: RHODES, KENNETH C
Permit Number: 5329E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG814002
Exp Date: 05/19/2010

Test	g/210L	Time
DIAG	Pass	11:31pm
AIR BLK	.00	11:32pm
ACCY CHK	.07	11:32pm
AIR BLK	.00	11:33pm
SUB TEST	.00	11:34pm
AIR BLK	.00	11:34pm
SUB TEST	.00	11:36pm
AIR BLK	.00	11:37pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR.



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Craven Instrument Location BAT Mobile Unit 6

Instrument Serial No. 008869

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 3 day of OCT, 20 09 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



K.C. Moore
Signature of Certifying Official

601
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Preventive Maintenance

CRAVEN COUNTY BAT MOBILE UNIT 6 240

Serial Number: 008869 Test Record Number: 202
Test Date: 10/03/2009 Test Time: 12:22am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:22am
FLO	Pass	12:22am
FC	Pass	12:22am

Temperature Tests

Test	Status	Time
FC1	Pass	12:23am
SRC	Pass	12:23am
DET	Pass	12:23am
BAR	Pass	12:23am
BT	Pass	12:23am

Blank Tests

Test	Status	Time
AIR	Pass	12:23am

Printer Tests

Test	Status	Time
PRNT	Pass	12:23am

CRC Tests

Test	Status	Time
COMP	Pass	12:23am
CAL	Pass	12:23am

Preventive Maintenance
Status: Pass



Analyst

Intox EC/IR-II: Subject Test

CRAVEN COUNTY BAT MOBILE UNIT 6 240

Serial Number: 008869
Test Date: 10/03/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: RHODES, KENNETH C
Permit Number: 5329E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG814002
Exp Date: 05/19/2010

Test	g/210L	Time
DIAG	Pass	12:15am
AIR BLK	.00	12:16am
ACCY CHK	.07	12:16am
AIR BLK	.00	12:17am
SUB TEST	.00	12:18am
AIR BLK	.00	12:19am
SUB TEST	.00	12:20am
AIR BLK	.00	12:21am

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Onslow Instrument Location BAT mobile unit #

Instrument Serial No. 008939 Holly Ridge

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 3 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



K. C. Phode
Signature of Certifying Official

601
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Preventive Maintenance

ONslow COUNTY BAT MOBILE UNIT 6 660

Serial Number: 008939 Test Record Number: 302
Test Date: 10/03/2009 Test Time: 12:36pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:36pm
FLO	Pass	12:36pm
FC	Pass	12:36pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:36pm
SRC	Pass	12:36pm
DET	Pass	12:36pm
BAR	Pass	12:36pm
BT	Pass	12:36pm

Blank Tests

Test	Status	Time
AIR	Pass	12:37pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:37pm

CRC Tests

Test	Status	Time
COMP	Pass	12:37pm
CAL	Pass	12:37pm

Preventive Maintenance
Status: Pass


Analyst

Intox EC/IR-II: Subject Test

ONslow COUNTY BAT MOBILE UNIT 6 66C

Serial Number: 008939
Test Date: 10/03/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: RHODES, KENNETH C

Permit Number: 5329E

Effective:

10/01/2009-10/01/2011

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG814101

Exp Date: 05/20/2010

Test	g/210L	Time
DIAG	Pass	12:27pm
AIR BLK	.00	12:28pm
ACCY CHK	.08	12:29pm
AIR BLK	.00	12:29pm
SUB TEST	.00	12:30pm
AIR BLK	.00	12:31pm
SUB TEST	.00	12:32pm
AIR BLK	.00	12:33pm

Reported AC: .00/g/210L



Signature of Chemical Analyst

Court CVR



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County FRANKLIN

Instrument Location FRANKLIN Police Dept


Instrument Serial No. 008815

#7 W. MASON ST, FRANKLIN, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 2 day of OCTOBER, 20 09 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

652
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

FRANKLIN COUNTY FRANKLINTON PD 340

Serial Number: 008815

Test Date: 10/02/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name:

QUARANTELLA, NICHOLAS J

Permit Number: 21536E

Effective:

01/01/2008-01/01/2010

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG904903

Exp Date: 02/18/2011

Test	g/210L	Time
DIAG	Pass	11:40am
AIR BLK	.00	11:41am
ACCY CHK	.08	11:41am
AIR BLK	.00	11:42am
SUB TEST	.00	11:43am
AIR BLK	.00	11:44am
SUB TEST	.00	11:46am
AIR BLK	.00	11:47am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

FRANKLIN COUNTY FRANKLINTON PD 340

Serial Number: 008815 Test Record Number: 261
Test Date: 10/02/2009 Test Time: 11:48am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:49am
FLO	Pass	11:49am
FC	Pass	11:49am

Temperature Tests

Test	Status	Time
FC1	Pass	11:49am
SRC	Pass	11:49am
DET	Pass	11:49am
BAR	Pass	11:49am
BT	Pass	11:49am

Blank Tests

Test	Status	Time
AIR	Pass	11:49am


Printer Tests

Test	Status	Time
PRNT	Pass	11:49am

CRC Tests

Test	Status	Time
COMP	Pass	11:50am
CAL	Pass	11:50am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County FRANKLIN Instrument Location FRANKLIN Co. JAIL

Instrument Serial No. 008933 285 T KEMP RD LOUISBURG, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 2 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

652
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

FRANKLIN COUNTY FRANKLIN CO, JAIL 340

Serial Number: 008933
Test Date: 10/02/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name:
QUARANTELLA, NICHOLAS J
Permit Number: 21536E
Effective:
01/01/2008-01/01/2010

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG904903
Exp Date: 02/18/2011

Test	g/210L	Time
DIAG	Pass	11:08am
AIR BLK	.00	11:09am
ACCY CHK	.08	11:10am
AIR BLK	.00	11:11am
SUB TEST	.00	11:11am
AIR BLK	.00	11:12am
SUB TEST	.00	11:14am
AIR BLK	.00	11:15am

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

FRANKLIN COUNTY FRANKLIN CO. JAIL 340

Serial Number: 008933 Test Record Number: 280
Test Date: 10/02/2009 Test Time: 11:16am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:16am
FLO	Pass	11:16am
FC	Pass	11:16am

Temperature Tests

Test	Status	Time
FC1	Pass	11:16am
SRC	Pass	11:16am
DET	Pass	11:16am
BAR	Pass	11:16am
BT	Pass	11:16am

Blank Tests

Test	Status	Time
AIR	Pass	11:17am

Printer Tests

Test	Status	Time
PRNT	Pass	11:17am

CRC Tests

Test	Status	Time
COMP	Pass	11:17am
CAL	Pass	11:17am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County FRANKLIN Instrument Location FRANKLIN Co. JAIL

Instrument Serial No. 208942 285 T KEMP RD LOUISBURG, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 2 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

652
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

FRANKLIN COUNTY FRANKLIN CO. JAIL 340

Serial Number: 008942
Test Date: 10/02/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name:
QUARANTELLA, NICHOLAS J
Permit Number: 21536E
Effective:
01/01/2008-01/01/2010

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG904903
Exp Date: 02/18/2011


Test	g/210L	Time
DIAG	Pass	10:57am
AIR BLK	.00	10:58am
ACCY CHK	.08	10:59am
AIR BLK	.00	11:00am
SUB TEST	.00	11:00am
AIR BLK	.00	11:01am
SUB TEST	.00	11:03am
AIR BLK	.00	11:04am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

FRANKLIN COUNTY FRANKLIN CO. JAIL 340

Serial Number: 008942 Test Record Number: 176
Test Date: 10/02/2009 Test Time: 11:06am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:06am
FLO	Pass	11:06am
FC	Pass	11:06am

Temperature Tests

Test	Status	Time
FC1	Pass	11:06am
SRC	Pass	11:06am
DET	Pass	11:06am
BAR	Pass	11:06am
BT	Pass	11:06am

Blank Tests

Test	Status	Time
AIR	Pass	11:07am


Printer Tests

Test	Status	Time
PRNT	Pass	11:07am

CRC Tests

Test	Status	Time
COMP	Pass	11:07am
CAL	Pass	11:07am

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County WAS Instrument Location TROOP C HEADQUARTERS

Instrument Serial No. 008621 RIVE RIDGE RD RALEIGH, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 1 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

652
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAKE COUNTY TROOP C HEADQUARTERS 910

Serial Number: 008621
Test Date: 10/01/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name:
QUARANTELLA, NICHOLAS J
Permit Number: 21536E
Effective:
01/01/2008-01/01/2010

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG816302
Exp Date: 06/11/2010

Test	g/210L	Time
DIAG	Pass	1:00pm
AIR BLK	.00	1:01pm
ACCY CHK	.07	1:02pm
AIR BLK	.00	1:03pm
SUB TEST	.00	1:03pm
AIR BLK	.00	1:04pm
SUB TEST	.00	1:06pm
AIR BLK	.00	1:06pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY TROOP C HEADQUARTERS 910

Serial Number: 008621 Test Record Number: 535
Test Date: 10/01/2009 Test Time: 1:08pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:08pm
FLO	Pass	1:08pm
FC	Pass	1:09pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:09pm
SRC	Pass	1:09pm
DET	Pass	1:09pm
BAR	Pass	1:09pm
BT	Pass	1:09pm

Blank Tests

Test	Status	Time
AIR	Pass	1:09pm

Printer Tests

Test	Status	Time
PRNT	Pass	1:09pm

CRC Tests

Test	Status	Time
COMP	Pass	1:10pm
CAL	Pass	1:10pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County WAKE Instrument Location TROOP C HEADQUARTERS

Instrument Serial No. 008851 BLUE RIDGE RD RALEIGH, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 1 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

652
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAKE COUNTY TROOP C HEADQUARTERS 910

Serial Number: 008851
Test Date: 10/01/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name:

QUARANTELLA, NICHOLAS J

Permit Number: 21536E

Effective:

01/01/2008-01/01/2010

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS


Test Type: Breath Test

Lot Number: AG920301

Exp Date: 07/22/2011

Test	g/210L	Time
DIAG	Pass	12:54pm
AIR BLK	.00	12:55pm
ACCY CHK	.08	12:55pm
AIR BLK	.00	12:56pm
SUB TEST	.00	12:57pm
AIR BLK	.00	12:58pm
SUB TEST	.00	12:59pm
AIR BLK	.00	1:00pm

Reported AC: .00 g/210L


Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY TROOP C HEADQUARTERS 910

Serial Number: 008851 Test Record Number: 269
Test Date: 10/01/2009 Test Time: 1:01pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:02pm
FLO	Pass	1:02pm
FC	Pass	1:02pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:02pm
SRC	Pass	1:02pm
DET	Pass	1:02pm
BAR	Pass	1:02pm
BT	Pass	1:02pm

Blank Tests

Test	Status	Time
AIR	Pass	1:03pm


Printer Tests

Test	Status	Time
PRNT	Pass	1:03pm

CRC Tests

Test	Status	Time
COMP	Pass	1:03pm
CAL	Pass	1:03pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County WAKE Instrument Location TROOP C HEADQUARTERS

Instrument Serial No. 008598 Blue Ridge Rd, RALEIGH NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 1 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

652
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

WAKE COUNTY TROOP C HEADQUARTERS 910

Serial Number: 008598
Test Date: 10/01/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name:
QUARANTELLA, NICHOLAS J
Permit Number: 21536E
Effective:
01/01/2008-01/01/2010

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG920301
Exp Date: 07/22/2011


Test	g/210L	Time
DIAG	Pass	12:32:15
AIR BLK	.00	12:32:54
ACCY CHK	.08	12:33:29
AIR BLK	.00	12:34:27
SUB TEST	.00	12:35:11
AIR BLK	.00	12:36:07
SUB TEST	.00	12:37:44
AIR BLK	.00	12:38:38

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

WAKE COUNTY TROOP C HEADQUARTERS 910

Serial Number: 008598 Test Record Number: 276
Test Date: 10/01/2009 Test Time: 12:39:56

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:40:17
FLO	Pass	12:40:17
FC	Pass	12:40:23

Temperature Tests

Test	Status	Time
FC1	Pass	12:40:30
SRC	Pass	12:40:30
DET	Pass	12:40:30
BAR	Pass	12:40:30
BT	Pass	12:40:30

Blank Tests

Test	Status	Time
AIR	Pass	12:41:12


Printer Tests

Test	Status	Time
PRNT	Pass	12:41:16

CRC Tests

Test	Status	Time
COMP	Pass	12:41:24
CAL	Pass	12:41:24

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Buncombe Instrument Location Buncombe Co. Jail

Instrument Serial No. 008631 Asheville, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 28 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Daniel R. Guth
Signature of Certifying Official

635
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

BUNCOMBE COUNTY BUNCOMBE COUNTY JAIL
100

Serial Number: 008631
Test Date: 10/28/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: CUTLER, DANIEL R
Permit Number: 08457E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE,
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test


Lot Number: AG920401
Exp Date: 07/23/2011

Test	g/210L	Time
DIAG	Pass	11:13am
AIR BLK	.00	11:14am
ACCY CHK	.08	11:14am
AIR BLK	.00	11:15am
SUB TEST	.00	11:16am
AIR BLK	.00	11:17am
SUB TEST	.00	11:18am
AIR BLK	.00	11:19am

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

BUNCOMBE COUNTY BUNCOMBE COUNTY JAIL 100

Serial Number: 008631 Test Record Number: 1079
Test Date: 10/28/2009 Test Time: 11:20am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:20am
FLO	Pass	11:20am
FC	Pass	11:20am

Temperature Tests

Test	Status	Time
FC1	Pass	11:20am
SRC	Pass	11:20am
DET	Pass	11:20am
BAR	Pass	11:20am
BT	Pass	11:20am

Blank Tests

Test	Status	Time
AIR	Pass	11:21am


Printer Tests

Test	Status	Time
PRNT	Pass	11:21am

CRC Tests

Test	Status	Time
COMP	Pass	11:21am
CAL	Pass	11:21am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Clay Instrument Location Clay Co. Jail

Instrument Serial No. 008608 Hayesville, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 27 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



David R. Cuth

Signature of Certifying Official

635

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CLAY COUNTY CLAY COUNTY JAIL 210

Serial Number: 008608
Test Date: 10/27/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name: CUTLER, DANIEL R
Permit Number: 08457E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE,
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG910501
Exp Date: 04/15/2011


Test	g/210L	Time
DIAG	Pass	12:02pm
AIR BLK	.00	12:02pm
ACCY CHK	.08	12:03pm
AIR BLK	.00	12:04pm
SUB TEST	.00	12:04pm
AIR BLK	.00	12:05pm
SUB TEST	.00	12:07pm
AIR BLK	.00	12:08pm

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

CLAY COUNTY CLAY COUNTY JAIL 210

Serial Number: 008608 Test Record Number: 641
Test Date: 10/27/2009 Test Time: 12:09pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:09pm
FLO	Pass	12:09pm
FC	Pass	12:09pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:09pm
SRC	Pass	12:09pm
DET	Pass	12:09pm
BAR	Pass	12:09pm
BT	Pass	12:09pm

Blank Tests

Test	Status	Time
AIR	Pass	12:10pm

Printer Tests

Test	Status	Time
PRNT	Pass	12:10pm

CRC Tests

Test	Status	Time
COMP	Pass	12:10pm
CAL	Pass	12:10pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Swain Instrument Location Cherokee P.D.

Instrument Serial No. 008782 Cherokee, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 27 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



David R. Arthur
Signature of Certifying Official

635
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

SWAIN COUNTY CHEROKEE INDIAN PD 860

Serial Number: 008782

Test Date: 10/27/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: CUTLER, DANIEL R

Permit Number: 08457E

Effective:

10/01/2009-10/01/2011

Officer's Name: NONE,

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG910501

Exp Date: 04/15/2011

Test	g/210L	Time
DIAG	Pass	9:55am
AIR BLK	.00	9:56am
ACCY CHK	.08	9:57am
AIR BLK	.00	9:58am
SUB TEST	.00	9:58am
AIR BLK	.00	9:59am
SUB TEST	.00	10:00am
AIR BLK	.00	10:01am

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007

Intox EC/IR-II: Preventive Maintenance

SWAIN COUNTY CHEROKEE INDIAN PD 860

Serial Number: 008782 Test Record Number: 293
Test Date: 10/27/2009 Test Time: 10:03am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:03am
FLO	Pass	10:03am
FC	Pass	10:03am

Temperature Tests

Test	Status	Time
FC1	Pass	10:03am
SRC	Pass	10:03am
DET	Pass	10:03am
BAR	Pass	10:03am
BT	Pass	10:03am

Blank Tests

Test	Status	Time
AIR	Pass	10:04am

Printer Tests

Test	Status	Time
PRNT	Pass	10:04am

CRC Tests

Test	Status	Time
COMP	Pass	10:04am
CAL	Pass	10:04am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Graham Instrument Location Graham Co. S.D.

Instrument Serial No. 008683 Robbinsville, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 15 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Orvil R. Cuth
Signature of Certifying Official

635
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

GRAHAM COUNTY GRAHAM COUNTY SD 370

Serial Number: 008683

Test Date: 10/15/2009

Citation Number: M0000000-0

Subject's Name:

PREVENTIVE, MAINTENANCE

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name: CUTLER, DANIEL R

Permit Number: 08457E

Effective:

10/01/2009-10/01/2011

Officer's Name: NONE,

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG910501

Exp Date: 04/15/2011

Test	g/210L	Time
DIAG	Pass	11:44am
AIR BLK	.00	11:44am
ACCY CHK	.07	11:45am
AIR BLK	.00	11:46am
SUB TEST	.00	11:46am
AIR BLK	.00	11:47am
SUB TEST	.00	11:49am
AIR BLK	.00	11:50am

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

**This form is used when performing Preventive Maintenance procedures
Forensic Tests for Alcohol Branch
Department of Health and Human Services
Rev. 12/2007**

Intox EC/IR-II: Preventive Maintenance

GRAHAM COUNTY GRAHAM COUNTY SD 370

Serial Number: 008683 Test Record Number: 529
Test Date: 10/15/2009 Test Time: 11:50am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:50am
FLO	Pass	11:50am
FC	Pass	11:51am

Temperature Tests

Test	Status	Time
FC1	Pass	11:51am
SRC	Pass	11:51am
DET	Pass	11:51am
BAR	Pass	11:51am
BT	Pass	11:51am

Blank Tests

Test	Status	Time
AIR	Pass	11:51am


Printer Tests

Test	Status	Time
PRNT	Pass	11:51am

CRC Tests

Test	Status	Time
COMP	Pass	11:51am
CAL	Pass	11:51am

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Haywood Instrument Location Haywood Co. Jail

Instrument Serial No. 008714 Waynesville, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of October, 20 09 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



David R. Guth
Signature of Certifying Official

635
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

HAYWOOD COUNTY HAYWOOD COUNTY JAIL 430

Serial Number: 008714
Test Date: 10/13/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: CUTLER, DANIEL R
Permit Number: 08457E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE,
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG902001
Exp Date: 01/20/2011

Test	g/210L	Time
DIAG	Pass	12:12pm
AIR BLK	.00	12:12pm
ACCY CHK	.08	12:13pm
AIR BLK	.00	12:14pm
SUB TEST	.00	12:14pm
AIR BLK	.00	12:16pm
SUB TEST	.00	12:17pm
AIR BLK	.00	12:18pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR



Analyst

Intox EC/IR-II: Preventive Maintenance

HAYWOOD COUNTY HAYWOOD COUNTY JAIL 430

Serial Number: 008714 Test Record Number: 352
Test Date: 10/13/2009 Test Time: 12:18pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:19pm
FLO	Pass	12:19pm
FC	Pass	12:19pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:19pm
SRC	Pass	12:19pm
DET	Pass	12:19pm
BAR	Pass	12:19pm
BT	Pass	12:19pm

Blank Tests

Test	Status	Time
AIR	Pass	12:20pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:20pm

CRC Tests

Test	Status	Time
COMP	Pass	12:20pm
CAL	Pass	12:20pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Haywood Instrument Location Haywood Co. Jail

Instrument Serial No. 008712 Waynesville, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Earl R. Cuth
Signature of Certifying Official

635
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

HAYWOOD COUNTY HAYWOOD COUNTY JAIL 430

Serial Number: 008712
Test Date: 10/13/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: *CUTLER, DANIEL R*
Permit Number: 08457E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE,
Type of Agency: FTA
Agency: DHHS
Test Type: *Breath Test*

Lot Number: AG902001
Exp Date: 01/20/2011

Test	g/210L	Time
DIAG	Pass	11:53am
AIR BLK	.00	11:54am
ACCY CHK	.08	11:54am
AIR BLK	.00	11:55am
SUB TEST	.00	11:56am
AIR BLK	.00	11:57am
SUB TEST	.00	11:58am
AIR BLK	.00	11:59am

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR.



Analyst

Intox EC/IR-II: Preventive Maintenance

HAYWOOD COUNTY HAYWOOD COUNTY JAIL 430

Serial Number: 008712 Test Record Number: 666
Test Date: 10/13/2009 Test Time: 12:00pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	12:00pm
FLO	Pass	12:00pm
FC	Pass	12:00pm

Temperature Tests

Test	Status	Time
FC1	Pass	12:00pm
SRC	Pass	12:00pm
DET	Pass	12:00pm
BAR	Pass	12:00pm
BT	Pass	12:00pm

Blank Tests

Test	Status	Time
AIR	Pass	12:01pm


Printer Tests

Test	Status	Time
PRNT	Pass	12:01pm

CRC Tests

Test	Status	Time
COMP	Pass	12:01pm
CAL	Pass	12:01pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Rutherford Instrument Location Rutherford Co. S.D.

Instrument Serial No. 008914 400 N. Washington St, Rutherfordton
828-627-6247

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 29 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Bobby D. Willis
Signature of Certifying Official

557
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

RUTHERFORD COUNTY RUTHERFORD COUNTY SD
800

Serial Number: 008914
Test Date: 10/29/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: WILLIS, BOBBY D
Permit Number: 08010E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG816303
Exp Date: 06/11/2010

Test	g/210L	Time
DIAG	Pass	1:22pm
AIR BLK	.00	1:23pm
ACCY CHK	.07	1:24pm
AIR BLK	.00	1:25pm
SUB TEST	.00	1:25pm
AIR BLK	.00	1:26pm
SUB TEST	.00	1:27pm
AIR BLK	.00	1:28pm

Reported AC: .00 g/210L

Bobby D. Willis
Signature of Chemical Analyst

Court CVR

Bobby D. Willis
Analyst

Intox EC/IR-II: Preventive Maintenance

RUTHERFORD COUNTY RUTHERFORD COUNTY SD 800

Serial Number: 008914 Test Record Number: 331
Test Date: 10/29/2009 Test Time: 1:29pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:30pm
FLO	Pass	1:30pm
FC	Pass	1:30pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:30pm
SRC	Pass	1:30pm
DET	Pass	1:30pm
BAR	Pass	1:30pm
BT	Pass	1:30pm

Blank Tests

Test	Status	Time
AIR	Pass	1:31pm


Printer Tests

Test	Status	Time
PRNT	Pass	1:31pm

CRC Tests

Test	Status	Time
COMP	Pass	1:31pm
CAL	Pass	1:31pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Cleveland Instrument Location Cleveland County S. D.

Instrument Serial No. 008887 100 Justice Pl., Shelby
704-484-4888

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 27 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Bobby D. Willis
Signature of Certifying Official

557
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CLEVELAND COUNTY CLEVELAND COUNTY SD
220

Serial Number: 008887
Test Date: 10/27/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: WILLIS, BOBBY D
Permit Number: 08010E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG816303
Exp Date: 06/11/2010

Test	g/210L	Time
DIAG	Pass	1:21pm
AIR BLK	.00	1:22pm
ACCY CHK	.07	1:23pm
AIR BLK	.00	1:24pm
SUB TEST	.00	1:24pm
AIR BLK	.00	1:25pm
SUB TEST	.00	1:27pm
AIR BLK	.00	1:28pm

Reported AC: .00 g/210L

Bobby D. Willis
Signature of Chemical Analyst

Court CVR

Bobby D. Willis
Analyst

Intox EC/IR-II: Preventive Maintenance

CLEVELAND COUNTY CLEVELAND COUNTY SD 220

Serial Number: 008887 Test Record Number: 396
Test Date: 10/27/2009 Test Time: 1:29pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:30pm
FLO	Pass	1:30pm
FC	Pass	1:30pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:30pm
SRC	Pass	1:30pm
DET	Pass	1:30pm
BAR	Pass	1:30pm
BT	Pass	1:30pm

Blank Tests

Test	Status	Time
AIR	Pass	1:30pm

Printer Tests

Test	Status	Time
PRNT	Pass	1:30pm

CRC Tests

Test	Status	Time
COMP	Pass	1:31pm
CAL	Pass	1:31pm

Preventive Maintenance
Status: Pass

Bobby D. Willis
Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Cleveland Instrument Location Cleveland Co. S.D.

Instrument Serial No. 008893 100 Justice Pl., Shelby
704-484-4888

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 19 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Bobby D. Willis
Signature of Certifying Official

557
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

CLEVELAND COUNTY CLEVELAND COUNTY SD
220

Serial Number: 008893
Test Date: 10/19/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: WILLIS, BOBBY D
Permit Number: 08010E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG901901
Exp Date: 01/19/2011

Test	g/210L	Time
DIAG	Pass	1:43pm
AIR BLK	.00	1:44pm
ACCY CHK	.08	1:45pm
AIR BLK	.00	1:46pm
SUB TEST	.00	1:47pm
AIR BLK	.00	1:47pm
SUB TEST	.00	1:49pm
AIR BLK	.00	1:50pm

Reported AC: .00 g/210L

Bobby D. Willis
Signature of Chemical Analyst

Court CVR

Bobby D. Willis
Analyst

Intox EC/IR-II: Preventive Maintenance

CLEVELAND COUNTY CLEVELAND COUNTY SD 220

Serial Number: 008893 Test Record Number: 382
Test Date: 10/19/2009 Test Time: 1:52pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:52pm
FLO	Pass	1:52pm
FC	Pass	1:52pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:52pm
SRC	Pass	1:52pm
DET	Pass	1:52pm
BAR	Pass	1:52pm
BT	Pass	1:52pm

Blank Tests

Test	Status	Time
AIR	Pass	1:53pm


Printer Tests

Test	Status	Time
PRNT	Pass	1:53pm

CRC Tests

Test	Status	Time
COMP	Pass	1:53pm
CAL	Pass	1:53pm

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Rutherford Instrument Location Forest City P.D.

Instrument Serial No. 008889 187 S. Church St. Forest City
828-245-5555

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 19 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



Bobby L. Willis
Signature of Certifying Official

557
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

RUTHERFORD COUNTY FOREST CITY PD 800

Serial Number: 008889
Test Date: 10/19/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: WILLIS, BOBBY D
Permit Number: 08010E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG816303
Exp Date: 06/11/2010

Test	g/210L	Time
DIAG	Pass	10:08am
AIR BLK	.00	10:09am
ACCY CHK	.07	10:10am
AIR BLK	.00	10:10am
SUB TEST	.00	10:11am
AIR BLK	.00	10:12am
SUB TEST	.00	10:14am
AIR BLK	.00	10:14am

Reported AC: .00 g/210L

Bobby D. Willis
Signature of Chemical Analyst

Court CVR.

Bobby D. Willis
Analyst

Intox EC/IR-II: Preventive Maintenance

RUTHERFORD COUNTY FOREST CITY PD 800

Serial Number: 008889 Test Record Number: 235
Test Date: 10/19/2009 Test Time: 10:16am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	10:16am
FLO	Pass	10:16am
FC	Pass	10:16am

Temperature Tests

Test	Status	Time
FC1	Pass	10:16am
SRC	Pass	10:16am
DET	Pass	10:16am
BAR	Pass	10:16am
BT	Pass	10:16am

Blank Tests

Test	Status	Time
AIR	Pass	10:17am

Printer Tests

Test	Status	Time
PRNT	Pass	10:17am

CRC Tests

Test	Status	Time
COMP	Pass	10:17am
CAL	Pass	10:17am

Preventive Maintenance
Status: Pass

Bolley D. Willis
Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Madison Instrument Location Mars Hill PD

Instrument Serial No. 008599 Mars Hill, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MADISON COUNTY MARS HILL PD 560

Serial Number: 008599
Test Date: 10/13/2009

Citation Number: M0000000-0
Subject's Name:
PREVENTIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BURNETTE, ANTHONY J
Permit Number: 11304E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE,
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG920401
Exp Date: 07/23/2011

Test	g/210L	Time
DIAG	Pass	1:05pm
AIR BLK	.00	1:06pm
ACCY CHK	.08	1:07pm
AIR BLK	.00	1:08pm
SUB TEST	.00	1:08pm
AIR BLK	.00	1:09pm
SUB TEST	.00	1:11pm
AIR BLK	.00	1:12pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

MADISON COUNTY MARS HILL PD 560

Serial Number: 008599 Test Record Number: 317
Test Date: 10/13/2009 Test Time: 1:14pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:15pm
FLO	Pass	1:15pm
FC	Pass	1:15pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:15pm
SRC	Pass	1:15pm
DET	Pass	1:15pm
BAR	Pass	1:15pm
BT	Pass	1:15pm

Blank Tests

Test	Status	Time
AIR	Pass	1:15pm

Printer Tests

Test	Status	Time
PRNT	Pass	1:15pm

CRC Tests

Test	Status	Time
COMP	Pass	1:16pm
CAL	Pass	1:16pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**


County Madison Instrument Location Mars Hill RD

Instrument Serial No. 008582 Mars Hill, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 13 day of October, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

649
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Intox EC/IR-II: Subject Test

MADISON COUNTY MARS HILL PD 560

Serial Number: 008582
Test Date: 10/13/2009

Citation Number: M0000000-0
Subject's Name:
PREVENITIVE, MAINTENANCE
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE

Analyst's Name: BURNETTE, ANTHONY J
Permit Number: 11304E
Effective:
10/01/2009-10/01/2011

Officer's Name: NONE,
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG920401
Exp Date: 07/23/2011

Test	g/210L	Time
DIAG	Pass	1:04pm
AIR BLK	.00	1:05pm
ACCY CHK	.08	1:06pm
AIR BLK	.00	1:07pm
SUB TEST	.00	1:08pm
AIR BLK	.00	1:09pm
SUB TEST	.00	1:10pm
AIR BLK	.00	1:11pm

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR


Analyst

Intox EC/IR-II: Preventive Maintenance

MADISON COUNTY MARS HILL PD 560

Serial Number: 008582 Test Record Number: 602
Test Date: 10/13/2009 Test Time: 1:12pm EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	1:12pm
FLO	Pass	1:12pm
FC	Pass	1:12pm

Temperature Tests

Test	Status	Time
FC1	Pass	1:12pm
SRC	Pass	1:12pm
DET	Pass	1:12pm
BAR	Pass	1:12pm
BT	Pass	1:12pm

Blank Tests

Test	Status	Time
AIR	Pass	1:13pm

Printer Tests

Test	Status	Time
PRNT	Pass	1:13pm

CRC Tests

Test	Status	Time
COMP	Pass	1:13pm
CAL	Pass	1:13pm

Preventive Maintenance
Status: Pass


Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County NASH Instrument Location ROCKY MOUNT P.D.

Instrument Serial No. 008740 #7 GOVERNMENT PLAZA ROCKY MOUNT, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 7 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

672
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

NASH COUNTY ROCKY MOUNT PD 630

Serial Number: 008740

Test Date: 10/07/2009

Citation Number: M0000000-0

Subject's Name: INSPECTION, TEST

Subject's Date of Birth: 11/11/1911

Subject's Sex: Male

Driver's License State: XX

Driver's License Number: NONE

Analyst's Name:

QUARANTELLA, NICHOLAS J

Permit Number: 21536E

Effective:

01/01/2008-01/01/2010

Officer's Name: NONE, NONE

Type of Agency: FTA

Agency: DHHS

Test Type: Breath Test

Lot Number: AG916701

Exp Date: 06/16/2011

Test	g/210L	Time
DIAG	Pass	11:20am
AIR BLK	.00	11:21am
ACCY CHK	.08	11:22am
AIR BLK	.00	11:23am
SUB TEST	.00	11:23am
AIR BLK	.00	11:24am
SUB TEST	.00	11:26am
AIR BLK	.00	11:27am

Reported AC: .00 g/210L

Signature of Chemical Analyst

Court CVR

Analyst

This form is used when performing Preventive Maintenance procedures

Forensic Tests for Alcohol Branch

Department of Health and Human Services

Rev. 12/2007

Intox EC/IR-II: Preventive Maintenance

NASH COUNTY ROCKY MOUNT PD 630

Serial Number: 008740 Test Record Number: 243
Test Date: 10/07/2009 Test Time: 11:34am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:34am
FLO	Pass	11:34am
FC	Pass	11:34am

Temperature Tests

Test	Status	Time
FC1	Pass	11:34am
SRC	Pass	11:34am
DET	Pass	11:34am
BAR	Pass	11:34am
BT	Pass	11:34am

Blank Tests

Test	Status	Time
AIR	Pass	11:35am


Printer Tests

Test	Status	Time
PRNT	Pass	11:35am

CRC Tests

Test	Status	Time
COMP	Pass	11:35am
CAL	Pass	11:35am

Preventive Maintenance
Status: Pass



Analyst

DEPARTMENT OF HEALTH AND HUMAN SERVICES
FORENSIC TESTS FOR ALCOHOL BRANCH

**PREVENTIVE MAINTENANCE RECORD
INTOXIMETERS, MODEL INTOX EC/IR II**

County NASH Instrument Location Rocky Mount P.D.

Instrument Serial No. 008741 #7 GOVERNMENT PLAZA ROCKY MOUNT, NC

The preventive maintenance procedures for the Intoximeters, Model Intox EC/IR II to be followed at least once every four months are:

1. Verify the ethanol gas canister displays pressure, or the alcoholic breath simulator thermometer shows 34 degrees, plus or minus .2 degree centigrade;
2. Verify instrument displays time and date;
3. Initiate breath test sequence;
4. Enter information as prompted;
5. Verify instrument accuracy;
6. When "PLEASE BLOW" appears, collect breath sample;
7. When "PLEASE BLOW" appears, collect breath sample;
8. Print test record;
9. Verify Diagnostic Program; and
10. Verify that the ethanol gas canister is being changed before expiration date, or the alcoholic breath simulator solution is being changed every four months or after 125 Alcoholic Breath Simulator tests, whichever occurs first.

I certify that on the 7 day of OCTOBER, 2009 the forgoing preventive maintenance procedures were performed on the instrument indicated above, in accordance with current regulations of the N.C. Department of Health and Human Services, and the instrument is functioning properly.



[Signature]
Signature of Certifying Official

652
Certificate Number

A signed original of the preventive maintenance record shall be kept on file for at least three years.

Serial Number: 008741
Test Date: 10/07/2009

Citation Number: M0000000-0
Subject's Name: INSPECTION, TEST
Subject's Date of Birth: 11/11/1911
Subject's Sex: Male
Driver's License State: XX
Driver's License Number: NONE


Analyst's Name:
QUARANTELLA, NICHOLAS J
Permit Number: 21536E
Effective:
01/01/2008-01/01/2010

Officer's Name: NONE, NONE
Type of Agency: FTA
Agency: DHHS
Test Type: Breath Test

Lot Number: AG916701
Exp Date: 06/16/2011

Test	g/210L	Time
DIAG	Pass	11:26am
AIR BLK	.00	11:27am
ACCY CHK	.08	11:27am
AIR BLK	.00	11:28am
SUB TEST	.00	11:29am
AIR BLK	.00	11:30am
SUB TEST	.00	11:31am
AIR BLK	.00	11:32am

Reported AC: .00 g/210L



Signature of Chemical Analyst

Court CVR



Analyst

Serial Number: 008741 Test Record Number: 321
Test Date: 10/07/2009 Test Time: 11:38am EDT

System Check: *Passed*

Baseline Tests

Test	Status	Time
IR	Pass	11:39am
FLO	Pass	11:39am
FC	Pass	11:39am

Temperature Tests

Test	Status	Time
FC1	Pass	11:39am
SRC	Pass	11:39am
DET	Pass	11:39am
BAR	Pass	11:39am
BT	Pass	11:39am

Blank Tests

Test	Status	Time
AIR	Pass	11:40am


Printer Tests

Test	Status	Time
PRNT	Pass	11:40am

CRC Tests

Test	Status	Time
COMP	Pass	11:40am
CAL	Pass	11:40am

Preventive Maintenance
Status: Pass



Analyst